

Black Square



CARAVAN PROFESSIONAL

OPERATIONS MANUAL

For Microsoft Flight Simulator

Published By:

Just Flight[™]



“Virtual Aircraft. Real Engineering.”

Caravan Professional User Guide

Please note that Microsoft Flight Simulator must be correctly installed on your PC prior to the installation and use of this Caravan aircraft simulation.

Contents

Introduction	9
What's new since the Analog Caravan?	10
Feature Overview	10
Checklists	11
Sounds	11
Flight Dynamics	11
Paint Schemes	11
Aircraft Specifications	12
Aircraft Performance (Without Cargo Pod)	13
Aircraft Performance (Cargo Pod Installed)	13
Aircraft Performance (Cargomaster)	14
Aircraft Performance (Amphibian)	14
V-Speeds	15
Engine Limitations	15
Starter Limitations	15
Instrumentation/Equipment List	16
Main Panel	16
Avionics	16
Electrical/Miscellaneous	16
Installation, Updates & Support	17
Installation	17
Installing the PMS GTN 750/650	17
Installing The Working Title GNS 530/430	18
TDS GTNxi 750/650 Integration	18
Installing The Falcon71 KLN-90B	19
Accessing the Aircraft	19
Uninstalling	19
Updates and Technical Support	19
Regular News	20

Liveries & Custom Dynamic Tail Numbers	20
Cockpit & System Guide	22
Main Panel	22
Annunciator Panel	22
True Airspeed Indicator	23
Bendix/King KI 256 Vacuum Artificial Horizon	24
Bendix/King KEA 130A Altimeter	25
Bendix/King KI 229 Radio Magnetic Indicator (RMI)	26
Bendix/King KI 525A Horizontal Situation Indicator (HSI)	27
Vertical Speed Indicator	28
Bendix/King KI 206 Localizer	29
Mid-Continent Turn Coordinator	30
Bendix/King KRA-10 Radar Altimeter	31
Engine Instrumentation	32
Fuel Instrumentation & Imbalance	32
Duplicate Copilot Instrumentation	33
Avionics	34
Garmin GMA 340 Audio Panel	34
Garmin GTN 750/650 (Com1/Com2)	35
Garmin GNS 530/430 (Com1/Com2)	36
Bendix/King KLN-90B	37
Mid-Continent MD41-328 GPS Annunciator Control Unit	37
Bendix/King KX-155B (Com1/Com2)	38
Bendix/King KNS-80 RNAV Navigation System	38
Bendix/King KR 87 ADF	38
Bendix/King KDI 572R DME	39
Bendix/King KAP 140 Autopilot	40
Bendix RDR 1150XL Color Weather Radar	41
Garmin GTX 327 Transponder	44
Electrical/Miscellaneous	45
Circuit Breakers	45
Multi-Function Volt/Amp Meter	45
Bendix/King KA 51B Remote Compass Synchroscope	46
Propeller Amps Indicator	47
Vacuum Indicator	47
Oxygen Pressure Gauge	48
Quartz Analog Chronometer	48
Hobbs Timer	49
Lighting Controls	50
Cockpit Lighting	50
Panel Lighting	50
Courtesy Lighting	51

Individual Reading Lights	51
Map Lights	52
Voltage-Based Light Dimming	52
State Saving	53
Environmental Simulation & Controls	54
Cabin Temperature Monitoring	54
Cabin Environmental Controls	55
Air Conditioning Temperature Effects	58
Oxygen Duration Table (Hours)	59
Turboprop Engine Operation	60
Inertial Separator	60
Turbine Engine Ignition	61
Turbine Engine Fuel Control Failures	61
Propeller Governor	61
Residual Heat & Dry Motoring	62
P2.5 Bleed Air Valves	62
External Power	63
Engine Power Settings (Without Cargo Pod)	64
Take-Off Power - Standard Day (ISA) No Wind	64
Maximum Cruise Power - Standard Day (ISA)	64
Normal Cruise Power - Standard Day (ISA)	64
Long Range Cruise Power - Standard Day (ISA)	65
Climb Performance 115 KTS - Standard Day (ISA)	65
Descent Performance 140 KTS -800 FPM - Standard Day (ISA)	65
Engine Power Settings (Cargo Pod & Cargomaster)	66
Take-Off Power - Standard Day (ISA) No Wind	66
Maximum Cruise Power - Standard Day (ISA)	66
Normal Cruise Power - Standard Day (ISA)	66
Long Range Cruise Power - Standard Day (ISA)	67
Climb Performance 115 KTS - Standard Day (ISA)	67
Descent Performance 140 KTS -800 FPM - Standard Day (ISA)	67
Engine Power Settings (Amphibian)	68
Take-Off Power - Standard Day (ISA) No Wind (Land/Water)	68
Maximum Cruise Power - Standard Day (ISA)	68
Normal Cruise Power - Standard Day (ISA)	68
Long Range Cruise Power - Standard Day (ISA)	69
Climb Performance 115 KTS - Standard Day (ISA)	69
Descent Performance 140 KTS -800 FPM - Standard Day (ISA)	69
Gyroscope Physics Simulation	70
Gyroscope Physics	70
Pneumatic Gyroscopes	70
Electric Gyroscopes	71

Tips on Operation within MSFS	72
Turboprop Engine Simulation	72
Engine Limits and Failures	72
Beta Range	72
Electrical Systems	73
Third Party Navigation and GPS Systems	73
Deicing and Anti-Icing Systems	73
Foreign Object Debris Damage	74
Control Locks	75
Realistic Strobe Light Bounce	76
Headphone Isolation	77
Magnetic Compass Effects	77
Tablet Interface	78
Options Page	79
Payload Page	81
Engine Visualizer Page	83
Cold Engine	83
Starting Engine	87
Running Engine	90
Live Schematic Page	93
Cabin Climate Visualizer Page	96
Heating Cabin	96
Cooling Cabin	99
Failures Page	102
MTBF Failures	102
Scheduled Failures	105
Failure System HTML Interface	108
List of Possible Failures	109
Major System Failures	109
Electrical Bus Failures	109
Breaker Protected Failures	109
Miscellaneous Systems	110
Audible Warning Tones	110
Amphibious Gear Advisory System	111
VOR & ADF Signal Degradation	111
Overview Electrical Schematic	111
Using the KNS-80 RNAV Navigation System	113
The Concept	113
How it Works	113
“Moving” a VOR	113
Data Entry	114
Data Storage Bins	114

Distance Measuring Equipment	114
Modes of Operation	115
Other Possible Uses	115
Flying an RNAV Course with the Autopilot	115
Recommended Skills	116
Direct Flight to Airport Tutorial	116
Normal Checklists	120
Before Starting Engine	120
Engine Start (Battery)	120
Engine Start (External Power)	120
Taxi	120
Before Takeoff (Runup)	121
Takeoff	121
Max Performance Climb	121
Enroute Climb	121
Cruise	121
Descent	121
Before Landing	121
Landing	122
Balked Landing	122
After Landing	122
Shutdown & Securing	122
Instrument Markings & Colors	122
Abnormal & Emergency Checklists	123
Engine Fire (Ground)	123
Engine Failure (Takeoff)	123
Engine Failure (In Flight)	123
Engine Fire (In Flight)	123
Starter Does Not Disengage	123
Hot or Hung Start	123
Engine Clearing	123
Engine Surges	123
CHIP DETECTOR Illuminated	123
Fuel Control Unit Failure	123
Fuel Imbalance	123
Prop Governor Failure	123
Battery Overheat (AMBER Annun.)	124
Battery Hot (RED Annun.)	124
Generator Failure	124
Electrical Fire	124
Severe Icing Encounter	124
Air Start with Starter (Preferred)	124

Air Start Windmilling	124
Flap Failure	125
*Landing Gear Manual Extension	125
*Landing Gear Up after Manual Extension	125
Remote Compass Misalignment	125
Autopilot Failure or Trim Runaway	125
Cabin Door Open	125
Emergency Descent	125
Maximum Glide	125
More Information on Operation	126
Hardware Inputs & Outputs	127
Inputs	127
Exterior & Cabin Element Variables	127
Primary Control Variables	128
Lighting Control Events & Variables	129
Environmental Control Variables	130
Instrument Variables	131
Primary Control Events Events	131
Instrument Events	131
Avionics Variables & Events	133
PMS50 GTN	133
TDS GTNxi	133
Working Title GNS 530	134
KLN90B	135
KNS80	136
KX155B	136
KR87 ADF	137
GTX 327 Transponder	138
Weather Radar	138
Outputs	140
Aircraft & Engine Variables	140
Radio Navigation Variables	140
Annunciator Lights	141
Frequently Asked Questions	142
How do I open/close or move the tablet interface?	142
How do I change which avionics/radios are installed?	142
How do I choose between the TDS and PMS GTN 750?	142
Why does the aircraft crash if I open the cockpit door?	142
Is beta range simulated?	142
Do I have to use the tablet interface to set fuel & payload?	142
Why is the autopilot behaving strangely, not changing modes, showing HDG/NAV simultaneously, or not capturing altitudes?	143

Why do my engines always fail or lose health?	143
Why does it take so much power to get the aircraft moving?	143
Why is the GTN 750 GPS or KLN-90B GPS screen black?	143
Why do some switches not work, or avionics logic seem broken?	144
Can the autopilot track KNS-80 RNAV waypoints?	144
Why is the state of my aircraft and radios not saved/recalled?	144
Why does the engine not fail when limits are clearly exceeded?	144
Why do screens flicker at night when adjusting lighting intensity?	144
Why does pitch control seem overly sensitive in MSFS 2024?	144
Why does the HUD airspeed not match the cockpit instrument?	145
Why is it hard to slow the aircraft down after landing on unimproved surfaces or water?	145
Change Log	146
v1.0 - Initial Release (after public preview build)	146
Credits	147
Dedication	147
Copyright	147

Introduction

The 208B Caravan is one of the most capable, multifunction, utility aircraft in the skies, available in configurations for executive transport, passenger airline service, cargo operations, and even amphibious options. The Caravan's high ground clearance and robust fixed gear makes it ideal for flight into unimproved airports, and a great asset to developing parts of the world. One of the most popular single engine turboprop aircraft on the market, the Caravan has enjoyed many upgrades and expansions over the years.

Black Square's Caravan Professional brings you one of the most technically advanced aircraft simulations for Microsoft Flight Simulator, with 100+ possible failures, 12 hot-swappable radio configurations, Black Square's turbine engine simulation with beta range implementation, and the most advanced cabin temperature simulations in MSFS. Black Square's new tablet interface lets you configure all options, manage payload, control failures, and monitor engines, electrical schematics, and environmental control systems, all from within the simulator. The failure system allows for persistent wear, MTBF, and scheduled failures for nearly every component in the aircraft. The 3D gauges are affected by physics, and can even become stuck without engine vibration, requiring a tap on the glass to free them. Radionavigation systems are available from several eras of the C208's history. Fly without GPS via a Bendix KNS-80 RNAV system, or with the convenience of a Garmin GTN 750/650 (PMS50 or TDS). Other radio equipment includes KX-155 radios, KLN-90B, GNS 530/430, KFC 150 Autopilot, and an RDR1150XL Weather Radar. A 145+ page manual provides instruction on all equipment, and 42 in-game checklists with control highlighting are included for normal and emergency procedures. **These two products include four airframes:** The passenger Grand Caravan with and without cargopod, the Caravan Amphibian with floats and retractable landing gear, and the Super Cargomaster, all with a 675 shaft-horsepower PT6A-114A engine, and an improved de-icing system.

Analog Caravan Owners: While the panel of the Caravan Professional might look familiar, almost all other aspects of the aircraft have been rebuilt with Black Square's current technology and high standards of quality. The major additions include a **custom exterior model**, **custom sound package** from Boris Audio Works, **higher quality materials** with modifications for each model of aircraft, **fine tuned performance tables**, **tablet visualizers** with all the systems required to drive them, **more avionics options**, and the turbine **engine simulation that debuted with the Turbine Duke and TBM 850**, and has been improving ever since. This expansion of the Analog Caravan represents 1,000+ hours of dedication, and roughly a doubling of the aircraft's code complexity. Once you experience Black Square's latest technology in your favorite C208, the difference will be clear!

Primarily analog instrumentation augmented with modern avionics is still the most common aircraft panel configuration in the world. Challenge your piloting skills by flying IFR to minimums with a fully analog panel, and no GPS. You'll be amazed at the level of skill and proficiency you can achieve to conquer such adversity, and how it will translate to all your other flying.

For more information on this product's capabilities and a list of all included avionics and equipment, see the extensive operating manual at www.JustFlight.com.

What's new since the Analog Caravan?

Every feature listed below with **NEW** or **IMPROVED** has been added or significantly improved since the Analog Caravan was released, but there is even more to discover!

Feature Overview

- **IMPROVED 145+ page manual** with your complete guide to flying the Black Square Caravan Professional, including systems guide, tutorials, operating limitations, performance tables, and electrical schematics
- **NEW Tablet Interface** for configuring options, payload settings, failure management, and real time visualizers for engines, electrical schematics, and environmental systems.
- **NEW 12 hot-swappable radios**, configurable via tablet interface. Incl. PMS & TDS
- **IMPROVED 100+ Random, scheduled, or performance triggered failures**, settable via the tablet, including engine damage, compatible with 3rd party UI's and instructor stations.
- **IMPROVED Fully simulated environmental control** for heating, air conditioning, ventilation, and ram air cooling. Cool things off by opening a door, or watch the airplane heat up in the sun. Monitor via the new tablet interface.
- **Completely simulated electrical system**, with 80+ circuit breakers and failures.
- **IMPROVED turboprop dynamics**, including (ITT, TRQ, Ng, FF, FP), hot starts, residual heat, and exhaust back pressure, P2.5 HP & LP valve simulation, and fuel-oil heat exchanger.
- **NEW Turbine engine failures**, such as compressor stall and surging, fuel control failure, fuel filter clogs, propeller governors, and fire detection system.
- **NEW FOD damage based on surface type**. Use the inertial separator to avoid engine damage. Tablet interface displays the type and intensity of FOD.
- **NEW Physics-driven propeller governor and feathering simulation** and beta range from the Black Square Duke & Starship
- **NEW KLN-90B vintage GPS**. Download from <https://github.com/falcon71/kln90b/releases>
- **IMPROVED KNS-80 RNAV now supports autopilot coupling** with No-GPS configuration.
- **NEW Gyroscope physics simulation** for electric and pneumatic gyroscopes with precession, and partial failures, based on a coupled quadrature oscillator.
- **NEW Magnetic compass effects**, including fields from onboard circuits.
- **NEW Functional exterior elements (Interactive in MSFS2024) & control locks**: chocks, pitot covers, engine covers, rudder lock, and ground power cart. Pitot flags blow in the wind.
- **NEW Performance tables** reflect fine tuned aerodynamic and engine cruise performance.

- **NEW Fuel imbalance** and inadvertent crossfeeding based on terrain and acceleration.
- **NEW Voltage-based light dimming**, an immediately recognizable effect to nighttime pilots.
- **NEW Strobe light system** causes realistic distracting flashes in clouds.
- **Mathematically accurate VOR & ADF signal attenuation and noise degradation.**
- **Physics based instrument needles** bounce and respond to aerodynamic forces.
- Improper engine management will slowly **damage engines to failure.**
- State saving for fuel, radio selection, radio frequency memory, cabin aesthetics, etc.
- Crew/Passenger oxygen depletes according to pressure altitude, passenger occupancy.
- Ultra-custom dynamic registration number system for livery creators.

Checklists

Over 430 checklist items are provided for 42+ Normal, Abnormal, and Emergency procedures in textual form in the manual, and in-game, using the MSFS native checklist system with control and instrument highlighting. If it's in the checklist, it's settable in the aircraft!

Sounds

Black Square's Caravan Professional features a custom soundset created by Boris Audio Works, and recorded from the real aircraft. High quality engine and cockpit sounds will immerse you in the simulation. Sounds like engine starting are not mere recordings, but instead many layered sounds, constructed based on the underlying simulation.

Flight Dynamics

The Caravan Professional features a flight model with performance to match the real world aircraft based on real Caravan pilot feedback and in-flight data. Engine and aerodynamic performance should be within 2% of POH values, though no two engines are ever the same. The flight model uses the most up to date features available in MSFS 2020 & 2024, such as the new voxel CFD aerodynamics, CFD propeller, adverse yaw & stall parameters, and flexible tire physics. Engine damage produces a rough running engine and decreased performance.

Paint Schemes

The Black Square Caravan Professional comes with twelve paint schemes across all variants. The Caravan Professional also comes with five interior upholstery packages. This product makes use of Black Square's highly customizable dynamic tail number system, which can be configured by livery makers. See the "Custom Dynamic Tail Numbers" section of this manual for more information.

Aircraft Specifications

Length Overall	41'7" (Gear) 42'4" (Floats)
Height	15'6" (Gear) 17'9" (Floats)
Wheel Base	13'4" (Gear) 15'5" (Floats)
Track Width	11'8" (Gear) 10'8" (Floats)
Wingspan	52'1"
Wing Area	279.4 sqft.
Flight Load Factors	+3.8/-1.52 G's (+2.4 G's with Flaps Down)
Design Load Factor	150%
Cabin W/L/H	64" x 21'4" x 54"
Oil Capacity	14 U.S. Quarts
Seating	10-14
Wing Loading	31.3 lbs/sqft
Power Loading	13.0 lbs/shp
Engine	675 SHP (496 kW) Pratt & Whitney PT6A-114A
Propeller	3-Blade McCauley, Constant Speed, Full-Feathering, Reversible, Aluminum, Hydraulically Actuated, 106 inch propeller. Feathered blade angle of 88°, Low pitch blade angle of 15.6°, and maximum reverse blade angle of -15°.
Approved Fuel Grades	JET A (ASTM-D1666) JET A-1 (ASTM-D1666) JET B (ASTM-D1666) JP-1 (MIL-L-5616) JP-4 (MIL-T-5624) JP-5 (MIL-T-5624) JP-8 (MIL-T-83133 A)
Fuel Capacity	Total Capacity: 335.6 U.S. Gallons Total Capacity Each Tank: 167.8 U.S. Gallons Total Usable: 332.0 U.S. Gallons
Electrical System	
Voltage:	28 VDC
Battery:	24V, 42 amp-hour, sealed lead acid battery
Starter-Generator:	28V, 200 amp
Standby Alternator:	28V, 75 amp, automatic operation when engaged

Aircraft Performance (Without Cargo Pod)

Maximum Cruising Speed	184 ktas
Normal Cruising Speed	182 ktas
Economy Cruising Speed	155 ktas
Takeoff Distance	2,420 ft
Takeoff Ground Roll	1,365 ft
Landing Distance	1,795 ft
Landing Ground Roll	950 ft
Normal Range	907 nm
Maximum Range	1,182 nm
Rate of Climb	975 ft/min
Service Ceiling	23,700 ft
Empty Weight	4,071 lbs
Max Ramp Weight	8,785 lbs
Max Takeoff Weight	8,750 lbs
Max Landing Weight	8,500 lbs
Useful Load	4,714 lbs
Usable Fuel Weight	2,224 lbs
Full Fuel Payload	2,490 lbs
Maximum Operating Temp.	+53°C
Minimum Operating Temp.	-54°C

Aircraft Performance (Cargo Pod Installed)

Maximum Cruising Speed	174 ktas
Normal Cruising Speed	172 ktas
Economy Cruising Speed	149 ktas
Takeoff Distance	2,500 ft
Takeoff Ground Roll	1,405 ft
Landing Distance	1,740 ft
Landing Ground Roll	915 ft
Normal Range	862 nm
Maximum Range	1,081 nm
Rate of Climb	925 ft/min
Service Ceiling	22,800 ft
Empty Weight	4,237 lbs
Max Ramp Weight	8,785 lbs
Max Takeoff Weight	8,750 lbs
Max Landing Weight	8,500 lbs
Useful Load	4,548 lbs
Usable Fuel Weight	2,224 lbs
Full Fuel Payload	2,324 lbs
Maximum Operating Temp.	+53°C
Minimum Operating Temp.	-54°C

Aircraft Performance (Cargomaster)

Maximum Cruising Speed	174 ktas
Normal Cruising Speed	172 ktas
Economy Cruising Speed	149 ktas
Takeoff Distance	2,500 ft
Takeoff Ground Roll	1,405 ft
Landing Distance	1,740 ft
Landing Ground Roll	915 ft
Normal Range	862 nm
Maximum Range	1,081 nm
Rate of Climb	925 ft/min
Service Ceiling	22,800 ft
Empty Weight	3,925 lbs
Max Ramp Weight	8,785 lbs
Max Takeoff Weight	8,750 lbs
Max Landing Weight	8,500 lbs
Useful Load	4,860 lbs
Usable Fuel Weight	2,224 lbs
Full Fuel Payload	2,636 lbs
Maximum Operating Temp.	+53°C
Minimum Operating Temp.	-54°C

Aircraft Performance (Amphibian)

Maximum Cruising Speed	164 ktas
Normal Cruising Speed	162 ktas
Economy Cruising Speed	138 ktas
Takeoff Distance	3,027 ft (Land) 4,082 ft (Water)
Takeoff Ground Roll	1,810 ft (Land) 1,982 ft (Water)
Landing Distance	1,426 ft (Land) 1,208 ft (Water)
Landing Ground Roll	777 ft (Land) 598 ft (Water)
Normal Range	732 nm
Maximum Range	1,001 nm
Rate of Climb	751 ft/min
Service Ceiling	20,000 ft
Empty Weight	5,379 lbs
Max Ramp Weight	9,062 lbs
Max Takeoff Weight	9,062 lbs
Max Landing Weight	9,062 lbs
Useful Load	3,683 lbs
Usable Fuel Weight	2,224 lbs
Full Fuel Payload	1,459 lbs
Maximum Operating Temp.	+53°C
Minimum Operating Temp.	-54°C

V-Speeds

Vr	65 kts	(Rotation Speed)
Vs	63 kts	(Clean Stalling Speed)
Vso	50 kts	(Dirty Stalling Speed)
Vx	72 kts	(Best Angle of Climb Speed)
Vy	104 kts	(Best Rate of Climb Speed)
Va	148 kts	(Maneuvering Speed)
Vg	97 kts	(Best Glide Speed)
Vfo	125 kts	(Maximum Flap Operating Speed)
Vne	175 kts	(Do Not Exceed Speed)

Engine Limitations

Maximum ITT:	805°C (T/O) 765°C (Climb) 740°C (Cruise) 1090°C (Starting)
Maximum Torque:	1,865 ft-lbs (T/O) 1,970 ft-lbs (Climb) 2,400 ft-lbs (Transient)
Maximum Gas Gen RPM:	101.6% (Continuous) 102.6% (Transient)
Maximum Propeller RPM:	1,900 (Continuous) 1,825 (Reverse) 2,090 (Transient)
Oil Pressure:	85-105 PSI (Continuous) 40 PSI min. (Idle)
Oil Temperature:	0-99°C (Continuous) -40-99°C (Idle) 104°C (Transient)

- For every 10°C below -30°C ambient temperature, reduce maximum allowable Ng by 2.2%.
- Reverse thrust operation limited to durations of one minute.
- Normal oil pressure is 85-105 PSI above 72% Ng with oil temperature 60-70°C.
- Oil pressures below 85 PSI are undesirable, and should only be tolerated to complete a flight, preferably at reduced power settings.
- When ITT exceeds 765°C, time at this power setting should be limited to 5 minutes.

Starter Limitations

Using Airplane Battery:

30 seconds ON - 60 seconds OFF
30 seconds ON - 60 seconds OFF
30 seconds ON - 30 **minutes** OFF

Using External Power:

20 seconds ON - 120 seconds OFF
20 seconds ON - 120 seconds OFF
20 seconds ON - 60 **minutes** OFF

Instrumentation/Equipment List

Main Panel

- Annunciator Panel
- True Airspeed Indicator
- Bendix/King KI 256 Vacuum Artificial Horizon
- Bendix/King KEA 130A Altimeter
- Bendix/King KI 229 Radio Magnetic Indicator (RMI)
- Bendix/King KI 525A Horizontal Situation Indicator (HSI)
- Vertical Speed Indicator
- Bendix/King KI 206 Localizer
- Mid-Continent Turn Coordinator
- Bendix/King KRA-10A Radar Altimeter
- Engine Instrumentation
- Duplicate Copilot Instrumentation

Avionics

- Garmin GMA 340 Audio Panel
- Garmin GTN 750/650 (Com1/Com2)
- Garmin GNS 530/430 (Com1/Com2)
- Bendix/King KLN-90B
- Mid-Continent MD41-328 GPS Annunciator Control Unit
- Bendix/King KX-155B (Com1/Com2)
- Bendix/King KNS-80 RNAV Navigation System (incl. Nav3)
- Bendix/King KR 87 (ADF)
- Bendix/King KDI 572 (DME)
- Bendix/King KAP 140 Autopilot
- Bendix RDR1150XL Color Weather Radar
- Garmin GTX 327 Transponder

Electrical/Miscellaneous

- 80+ Circuit Breakers
- Multi-Function Volt/Amp Meter
- Bendix/King KA 51B Remote Compass Synchroscope
- Propeller Amps Indicator
- Vacuum Indicator
- Oxygen Pressure Gauge
- Quartz Analog Chronometer
- Hobbs Timer

Installation, Updates & Support

Installation

You can install this aircraft as often as you like on the same computer system:

1. Click on the 'Account' tab on the Just Flight website.
2. Log in to your account.
3. Select the 'Your Orders' button.
4. A list of your purchases will appear and you can then download the software you require.
5. Run the downloaded installation application and follow the on-screen instructions

If you already have an earlier version of this software installed, the installation application will detect this and update your existing software to the new version without you needing to uninstall it first.

NOTE: THE FOLLOWING DOWNLOADS ARE OPTIONAL, and not required to enjoy the base functionality of this Black Square aircraft; however, they are highly recommended for the most immersive experience possible.

Installing the PMS GTN 750/650

NOTE: No additional packages should be required from PMS to enable all WTT-Mode features in this aircraft. WTT-Mode is included natively in this aircraft. Only the basic download described below is required, assuming you do not already have it installed.

1. Go to the following link, and click download for the **FREE GTN 750 Mod**.
<https://pms50.com/msfs/downloads/gtn750-basic/>
2. Move the "pms50-instrument-gtn750" archive (zipped folder) from your browser's download location (downloads folder by default) to your desktop, and extract (unzip) the archive by right clicking, and selecting "Extract All".
3. Drag the resulting "pms50-instrument-gtn750" folder into your Microsoft Flight Simulator Community Folder.

If you don't know how to locate your MSFS Community Folder, you should be able to find it in one of the following locations, based on the service you used to purchase the simulator.

For the Windows Store install:

`C:\Users\[YourUserName]\AppData\Local\Packages\Microsoft.FlightSimulator_8wek
yb3d8bbwe\LocalCache\Packages\`

For the Steam install:

C:\Users\[YourUserName]\AppData\Local\Packages\Microsoft.FlightDashboard_8wekyb3d8bbwe\LocalCache\Packages\

Important: Windows 10 by default hides the “AppData” folder, so you will have to go to “View” in the menu of File Explorer, and select “Hidden items” so as to see it.

For the Custom install:

If you used a custom location for your Flight Simulator installation, then proceed there.

For example, you may have set:

E:\Steam\steamapps\common\MicrosoftFlightSimulator\Community

Installing The Working Title GNS 530/430

No additional downloads are required for the Working Title GNS 530/430 and all previous modifications should be removed from your community folder. Some older aircraft may still require a “link” to the new GPS, which can be downloaded from the in-game marketplace for free. This package is not required for the Black Square Caravan Professional, or any subsequently updated Black Square aircraft.

TDS GTNxi 750/650 Integration

To switch between PMS and TDS products, toggle the PMS/TDS switch in the avionics selection section of the tablet interface’s options page. For more information on radio hot-swapping and selecting an avionics package, see the “Options Page” section of this manual. If a new TDS installation is detected, the TDS will be automatically selected next time you load the aircraft for your convenience. Your avionics selection, including your preferred GTN 750 product, will be saved for your next flight.

The TDS GTNxi is available from: <https://www.tdssim.com/tdsgtnxi>

LIMITATIONS:

MSFS native GPS units and native flight planners will not cross-fill from the GTNxi. This could also be seen as an advantage, allowing simultaneous flight plan loading.

NOTE: These are limitations of MSFS and not this aircraft, nor the TDS GTNxi. If and when these issues are resolved, a coordinated effort from the developers of these products will be launched to remove these limitations as soon as possible.

Installing The Falcon71 KLN-90B

1. Go to the following link, and click download for the **FREE KLN-90B Mod**.
<https://github.com/falcon71/kl90b/releases>
2. Move the “falcon71-kl90b-vX.XX” archive (zipped folder) from your browser’s download location (downloads folder by default) to your desktop, and extract (unzip) the archive by right clicking, and selecting “Extract All”.
3. Drag the resulting “falcon71-kl90b” folder into your Microsoft Flight Simulator Community Folder.

If you don’t know how to locate your MSFS Community Folder, follow the instructions in the “Installing the PMS GTN 750/650” section of this manual, above.

Accessing the Aircraft

To access the aircraft:

1. Click on ‘World Map’.
2. Open the aircraft selection menu by clicking on the aircraft thumbnail in the top left.
3. Use the search feature or scroll through the available aircraft to find the ‘Caravan Professional’ series by Black Square.
4. After selecting the aircraft, use the ‘Liveries’ menu to choose your livery.

Uninstalling

To uninstall this product from your system, use one of the Windows App management features:

Control Panel -> Programs and Features

or

Settings -> Apps -> Apps & features

Select the product you want to uninstall, choose ‘Uninstall’ and follow the on-screen instructions.

Uninstalling or deleting this product in any other way may cause problems when using this product in the future or with your Windows set-up.

Updates and Technical Support

For technical support (in English) please visit the Support pages on the Just Flight website. As a Just Flight customer, you can get free technical support for any Just Flight product.

If an update becomes available for this aircraft, we will post details on the Support page and we will also send a notification email about the update to all buyers who are currently subscribed to Just Flight emails.

Regular News

To get all the latest news about Just Flight products, special offers and projects in development, subscribe to our regular emails.

We can assure you that none of your details will ever be sold or passed on to any third party and you can, of course, unsubscribe from this service at any time.

You can also keep up to date with Just Flight via Facebook and Twitter.

Liveries & Custom Dynamic Tail Numbers

This aircraft features Black Square's highly customizable dynamic registration number system. This system allows livery creators to adjust many features of how registration numbers are displayed on the aircraft. The following image shows all the areas on the aircraft where a tail number can be positioned (in blue).



For those interested in creating custom liveries, a custom PANEL.CFG file should be included in the livery package, and referenced via the livery's AIRCRAFT.CFG. In this PANEL.CFG, the [VPainting01] section, specifically the "painting00" can be edited to alter the appearance of the tail number. The parameters between the '?' and the ',' separated by '&', control the tail number. Below is an example tail number configuration, followed by an explanation of all the parameters.

```
font_color=red&stroke_size=30&stroke_color=black&sv=1&sx=18&sy=41&sr=0&sk=20&ss=250  
&tv=1&tx=16&ty=8&tr=0&tk=20&ts=225&wv=1&wx=32&wy=20&wr=9&wk=30&ws=150
```

Each position ("s" = side, "t" = tail, and "w" = winglets) has the following associated variables:

"v" = whether to show the tail number in that position (0=false, 1=true)

"x" = the nose-tail position of the tail number

"y" = the top-bottom position of the tail number

"r" = the rotation of the tail number (will accept decimals)

"k" = shears the tail number, positive values shear top towards tail

"s" = the font size of the tail number

Example "tk=30": t = tail, k = skew. This will shear the registration on the tail towards the tail of the aircraft by 30 degrees.

These values can be edited live using the Coherent GT Debugger from the MSFS SDK.

Tail Number Positioning:

Side +X -> Forward, -Y -> Up

Tail -X -> Forward, -Y -> Up

Wing -X -> Forward, -Y -> Up

Unlike the default dynamic tail number system, these tail numbers will not automatically resize, so make sure there is room for a full six character registration.

New fonts can be added in livery packages, and any font/outline/shadow color may be selected from the standard JavaScript colors by name, or by Hex Code.

The resolution of the tail numbers can be adjusted with the resolution values at the end of the painting00 entry, and the "size_mm" entry above. Large resolutions may affect performance.

Cockpit & System Guide

Main Panel

Annunciator Panel

The Caravan's annunciator panel can be tested by two buttons adjacent and to the left of the panel, labeled "Fire Detect Test", and "Lamp Test". Press and hold the buttons to confirm all 24 colored annunciators illuminate in the panel. Also adjacent to the annunciator panel is the night dimming switch, which dims the annunciator panel. It also dims several other groups of annunciators within the main instrument panel.



Below the engine instrumentation and to the right of the altimeter is also an autopilot specific annunciator panel, which indicates active autopilot modes in a different format than on the KAP 140 autopilot itself, which is sometimes preferential for quick reference. This panel includes a red back-course indicator, and a red out-of-trim indicator, which illuminates when the aircraft's pitch is more than ten degrees away from the autopilot command pitch.



True Airspeed Indicator

The Caravan's airspeed indicator displays both knots (outer scale), and miles per hour (inner scale), as well as reference speeds with colored arcs. The red marking corresponds to the never-exceed speed. The lower end of the green arc corresponds to the clean configuration stalling speed. The upper end of the white arc corresponds to the maximum flap operating speed, and the lower end of the white arc corresponds to the full flap stalling speed. The airspeed indicator also includes a true airspeed calculating ring, which can be positioned for pressure altitude and air temperature, much like an E6B flight computer, and produce a rough true airspeed indicator at the airspeed needle.



NOTE: This is the first Black Square aircraft to implement an accurate calculation of calibrated airspeed (CAS). In other aircraft, MSFS assumes the airspeed to be “ideal”, suffering no effects from the airflow around the airframe, or the design of the pitot system. For most aircraft, this effect is negligible, but for the Caravan, it can produce an apparent difference of up to 15 knots. For this reason, the airspeed indicator in the cockpit may not always match the airspeed displayed in the simulator's HUD. For more information, and an expanded discussion of CAS, see the “Why does the HUD airspeed not match the cockpit instrument?” question of the FAQ at the end of this manual.

Bendix/King KI 256 Vacuum Artificial Horizon

A vacuum powered artificial horizon with illuminated decision height indicator, and adjustable attitude bars resides at the center of the panel. Attitude bars can be adjusted with the small screw adjustment on the bottom right of the unit's face. Note that while the KI256 is capable of displaying flight director command bars, the KAP 140 autopilot is not capable of driving them.



NOTE: This attitude indicator is equipped with Black Square's highly accurate gyroscope dynamics simulation. Users can experience the multitude of gyroscope dynamics and failures inherent to the operation of these instruments. The partial or complete failure of gyroscopic instruments can surprise pilots and result in catastrophic loss of spatial awareness. For more information on Black Square's gyroscope simulation, see the "Gyroscope Physics Simulation" section of this manual.

Bendix/King KEA 130A Altimeter

The KEA 130A is a three pointer, precision, encoding altimeter, certified for flight up to 25,000 feet pressure altitude. The Kollsman setting is adjusted via the knob in the bottom left corner of the unit. Currently set barometric pressure is displayed in the Kollsman window on the right of the unit in inHg, and in the Kollsman window on the left of the unit in Millibars.



Bendix/King KI 229 Radio Magnetic Indicator (RMI)

This RMI has an automatically rotating compass card that is driven via the aircraft's remote compass, and therefore, has no adjustment knob like an ADF. The solid yellow needle of the RMI is permanently driven by the NAV1 VOR navigation source, the same as the HSI source. The hollow green needle of the RMI is permanently driven by the KR 87 ADF receiver. Both needles will point directly to the tuned radio ground station whenever signal strength is sufficient. Since there are no flags on this unit to indicate reception, it is necessary to properly identify the station via its morse code identifier before using the RMI indications as a source of navigation. The needles will both point towards the 3 o'clock position when the unit is not receiving power, or the unit is not receiving signal from the remote compass.



Bendix/King KI 525A Horizontal Situation Indicator (HSI)

The KI 525A HSI has an automatically controlled compass card, as opposed to most directional gyroscopic compass units, which can be automatically slaved to magnetic heading, or manually controlled via the remote compass controller. The HSI has two knobs for controlling the heading bug for visual reference, and for autopilot heading lateral navigation mode, and a knob for adjusting the course indicated with the yellow needle in the center of the display. The split yellow needle acts as a course deviation indicator, where the deviation scale depends on the navigation source, and operational mode, such as enroute GPS, or ILS antenna signal. On either side of the unit are normally hidden, yellow, glideslope indicator needles, which come into view when the glideslope signal is valid. Under the yellow course indicating needle, two windows with white indicators show the traditional to/from VOR indication when a VOR radio source is selected. When no navigation source has a valid signal, a red “NAV” flag appears at the top of the display. When no valid signal is received from the remote compass, a red “HDG” flag appears at the top of the display. When the unit is not receiving power, both flags are visible. The HSI in this aircraft can be controlled by either the NAV1 source, or the RNAV source, by selecting with the switch located above the localizer.

NOTE: The autopilot will only use the KNS-80 as a navigation source when the no-GPS avionics configuration is selected from the tablet interface. Press the navigation source button to illuminate its “RNAV” annunciator. Use the toggle switch above the localizer to select “RNAV” as the HSI source.



Vertical Speed Indicator

A vertical speed indicator displaying a maximum of +/- 4,000 feet per minute. This instrument will display slipstreaming effects from the turbulent propeller wash passing over the static ports on the rear of the aircraft.



Bendix/King KI 206 Localizer

The KI 206 Localizer acts as a secondary radionavigation source in this aircraft, being permanently driven by the NAV2 VOR radio source. The KI 206 includes both lateral and vertical guidance needles, which can be driven from either a VOR/ILS receiver, or via the GNS 430W or GTN 650. The unit incorporates both vertical “GS”, and horizontal “NAV” red flags to indicate when the unit has power, and when the respective navigation source is being received. Two windows with white indicators show the traditional to/from VOR indication when a VOR radio source is selected. This unit is not connected to the remote compass, and therefore, must be manually adjusted for the desired course with the omni-bearing-selector (OBS) knob on the unit’s face.



Mid-Continent Turn Coordinator

A DC electric turn coordinator with indicator markings for a standard rate 2-minute turn, a traditional slip indicator, and a red power flag to indicate when the unit is not receiving power.



Bendix/King KRA-10 Radar Altimeter

The KRA-10 Radar Altimeter displays the height of the belly-mounted radar transducer with respect to the terrain below the aircraft. The yellow indicating needle rests in a vertical “OFF” position when the unit is not receiving power, a valid signal, or when the indicated altitude is below 10 feet. An orange decision height bug can be positioned from 0 to 2,500 feet on the indicating scale with the adjustment knob. When passing the decision height in a descent, the integrated, yellow, decision height indicator will illuminate, as well as the connected indicator on the KI 256 attitude indicator. Be aware that the indicating scale is non-linear.



Engine Instrumentation

A row of eight round-dial engine instruments resides at the top of the main instrument panel for monitoring the health of the powerplant. From left to right, the gauges are Propeller Torque (TRQ), Propeller RPM (RPM), Interstage Turbine Temperature (ITT), Gas Generator RPM (Ng), Oil Pressure (PSI), Oil Temperature (°C), Fuel Flow (FF), Left Fuel Tank Quantity (L QTY), and Right Fuel Tank Quantity (R QTY). Some of these instruments are passively driven from the accessory gearbox of the engine, while others are electrically driven; therefore, only some will remain functioning with a total loss of electrical power.



NOTE: This aircraft makes use of custom turbine engine dynamics code. Users should research and anticipate the following potentially novel turbine engine phenomenon:

Torque Bloom: While accelerating on the runway, increased ram air pressure increases combustion efficiency and fuel flow. Caution must be used while setting takeoff power, as torque may rapidly increase beyond the redline while accelerating.

Residual Heat: After shutdown, the engine retains substantial temperature, and cooling via “dry motoring” may be required before starting again.

Increased ITT with Inertial Separator and Bleed Air: Aircraft configuration can have a substantial impact on ITT, which may cause limit exceedances if not managed properly.

Fuel Instrumentation & Imbalance

The fuel sender units in the Caravan are notoriously sensitive to lateral G-force, and how level the aircraft is resting on the ground. The fuel gauges may present inaccurate readings due to “sloshing” of fuel within the wing tanks; however, the gauges may also indicate a genuine fuel imbalance.

The simplistic fuel system of the Caravan allows fuel to crossfeed by gravity alone when the aircraft is not resting level, or is experiencing lateral acceleration during uncoordinated flight. Any time both fuel selector valves are open, fuel may crossfeed from the fullest/highest wing tank to the emptiest/lowest wing tank until an equilibrium is reached. In the event of severe imbalances, fuel may be lost overboard through the fuel vents if pressures are high enough to circumvent the anti-siphon feature.

Closing the fuel selector valves after shutdown, and waiting until engine start to open them, will prevent inadvertent crossfeeding of fuel. If fuel is allowed to crossfeed while on the ground, repositioning the aircraft to an oppositely sloped section of the airfield may be necessary to restore balance. In flight, closing a single fuel valve can restore balance by consuming fuel from the fullest tank. Given that this aircraft is also capable of random fuel leaks, fuel levels should be checked prior to takeoff, just as in the real aircraft, when any potential discrepancy exists.

Duplicate Copilot Instrumentation

A duplicate six-pack of primary flight instrumentation is included on the co-pilot's side of the aircraft. Notably, the directional gyroscopic instrument is a traditional DG, and is not driven by the remote compass, and must be adjusted manually at startup, and continually for drift.



Avionics

Black Square aircraft have reconfigurable radio panels that allow you to fly with many popular radio configurations from old-school no GPS panels, to modern installations with touchscreen GPS navigators. Unlike previous Black Square aircraft, the radio configuration is selected via the options page of the tablet interface. The radio selection will be automatically saved and reloaded at the start of a new flight.

NOTE: For more information on radio hot-swapping and selecting an avionics package through the tablet interface, see the “Options Page” section of this manual.

Garmin GMA 340 Audio Panel

This audio controller is very common in light aircraft, and allows for the control of both receiving and transmitting audio sources on one panel. In addition, this implementation also supports listening to multiple VHF communication sources at once, and transmitting on both Com1 and Com2 by pressing the “COM 1/2” button. When you want to return to normal operation, press one of the “COM MIC” keys, and the integrated “COM 1/2” button indicator should extinguish.



Garmin GTN 750/650 (Com1/Com2)

This modern touchscreen GPS is implemented by a 3rd party developer. For installation instructions, and instructions on its use, see the installation section of this manual, or the developer's website. **Both PMS GTN 750/650 and TDS GTNxi 750/650 products are supported.** The aircraft will automatically switch between the installed software with no required user action.



PMS50 GTN 750/650



TDS GTNxi 750/650

NOTE: To switch between PMS and TDS products while the aircraft is loaded, toggle the PMS/TDS switch in the avionics selection section of the tablet interface's options page. For more information on radio hot-swapping and selecting an avionics package through the tablet interface, see the "Options Page" section of this manual.

Garmin GNS 530/430 (Com1/Com2)

This 2000's era full-color GPS is mostly or partially implemented by a 3rd party developer. For installation instructions, and instructions on its use, see the installation section of this manual, or the developer's website.



NOTE: To hear an audible radio station identifier, both the small adjustment knob on the GNS must be pressed, and the appropriate NAV receiver switch must be activated on the integrated audio control panel.

Bendix/King KLN-90B

This 1990's era monochrome GPS with limited graphical mapping ability comprises a highly capable GPS unit with many features that are found in modern GPS units for pilots willing to learn the subtleties of the system. This GPS is implemented by a 3rd party developer. For installation instructions, and instructions on its use, see the installation section of this manual, or the developer's website.



NOTE: This GPS does not have integrated COM or NAV radios, and therefore must be used in conjunction with a KX-155 as COM/NAV1.

Mid-Continent MD41-328 GPS Annunciator Control Unit

The GPS Annunciator Control Unit is included to enable the full functionality of the KLN-90B, but retains limited functionality with other GPS units. The NAV/GPS button may be used to control the HSI and autopilot course signal with any GPS unit. The GPS/APR button is used specifically for arming the KLN-90B's approach mode. The OBS/LEG button may be used to toggle OBS mode for any GPS that has this functionality, but is specifically designed to be used with the KLN-90B. The annunciator lights will depict the present modes of operation for any GPS installed.



Bendix/King KX-155B (Com1/Com2)

This 1990's era Com/Nav receiver allows you to control audio and navigation source inputs from two independent communication and navigation antennas, the left side controlling the VHF Com radio, and the right controlling the VHF Nav radio. Frequency tuning increments can be toggled by pulling on the inner knob of the COM side (labeled "PULL 25K"). The small adjustment knob on the Com side of the unit controls receiver volume, and can be pulled to toggle between US and European frequency spacing. The smallest tunable increment in US mode is 25 kHz, and the smallest possible increment in European mode is 8.33 kHz. The COM display will show frequencies with three decimal places when in 8.33 kHz mode, and two decimal places in 25 kHz mode. When the inner frequency adjustment knob on the NAV side is pulled, the same frequency adjustment knob will tune the active NAV frequency, and the standby frequency will be flagged with dashes. Additionally, a small "T" symbol will be displayed between the active and standby COM frequencies whenever the radio is transmitting. The small adjustment knob on the Nav side of the unit controls Nav receiver identifier volume, and can be pulled for an audible identifier tone.

NOTE: To hear an audible radio station identifier, both the small, right adjustment knob on the KX155 must be pulled out, and the appropriate NAV receiver indicator light must be illuminated on the GMA 340 Audio panel.



Bendix/King KNS-80 RNAV Navigation System

See the standalone section of this manual for instructions on using the KNS-80, below. All stored frequencies, radials, and offsets associated with this unit will be automatically saved and recalled at the beginning of a new flight.

NOTE: The autopilot in this aircraft is capable of receiving navigation input from the KNS-80, but will only do so when the no-GPS avionics configuration is selected from the tablet interface. When operating without a GPS, the navigation source selector panel's integrated annunciators will read "NAV/RNAV", instead of "NAV/GPS". For more details, see the "Flying an RNAV Course with the Autopilot" section of this manual.

Bendix/King KR 87 ADF

The KR 87 ADF receiver allows for standby ADF frequencies to be selected with the dual concentric rotary knobs on the right of the unit. When tuning a frequency, you will be editing the standby frequency, which can be swapped into the active frequency by pressing the “FRQ <->” push button. The two push buttons to the right of the “FRQ <->” button are for controlling the integrated flight timer. The “FLT/ET” push button toggles between the flight duration timer, which is automatically started when power is applied, and the elapsed time timer, which is started, stopped, and reset with the “SET/RST” push button. The “ADF” push button toggles the receiver’s antenna mode between normal operation, and listening to the sense-only antenna (disabling the loop antenna), which makes receiving low signal strength audio-only transmissions easier. The “BFO” push button toggles the unit’s beat frequency oscillator, which is used to listen to low signal strength morse code identifiers. A secondary click the power knob will increment the standby frequency by 0.5 kHz, indicated with a dot to the left of the frequency.



Bendix/King KDI 572R DME

This implementation of a KDI 572 behaves similarly to any other Distance Measuring Equipment (DME) receiver, displaying a nautical mile distance to the selected and tuned station, the current speed of the aircraft relative to the selected and tuned station, and a time-to-go until over the station. It should be noted that, like all other DME displays, this one is similarly dependent on being within the VOR service volume, and having good line-of-sight reception of the station. It should also be noted that these distances, speeds, and times, are based on slant-range to the station, not distance along the ground, as one would draw on a map. In order to receive DME information on the KDI 572, the station must be tuned in one of the two navigation radios, the station must be equipped with DME transmitting equipment, the station must have adequate signal strength, and the KDI 572 must have the appropriate navigation source selected via the selector knob mounted on its face.



Selecting “HLD” mode will hold the current DME frequency and information on the unit, while allowing the user to change the tuned NAV frequencies on the NAV1 or NAV2 radios. This can be useful for some specific instrument approaches. This unit’s state will be automatically saved and reloaded at the start of the next flight.

Bendix/King KAP 140 Autopilot

The KAP 140 is a relatively simple autopilot, with standard modes of control. The unit has an autopilot master push button, and can be disabled via the yoke-mounted autopilot disconnect push buttons. The autopilot’s mode selections include (left to right along the row of push buttons), heading hold mode, lateral navigation mode, approach coupling mode, back course mode, and altitude hold mode. When the autopilot is disabled by any means except loss of power, the “AP” annunciator will flash for five seconds, and an audible tone will be heard.

The unit’s display consists of a right section with annunciators, and an altitude pre-selector, which can also be used to display the current barometric setting, and a left section with four annunciator locations for active and armed modes. On the left, active modes will appear in the top row, with lateral modes on the left, and vertical modes on the right. The bottom row will display armed modes for lateral and vertical control underneath their respective active modes. For instance, “ALT” will display in the upper row when an altitude has been captured, and the autopilot is holding that altitude. When a new altitude has been selected, and vertical speed mode has been activated to capture that altitude, “VS” will appear in the top row, and “ALT” in the bottom row to indicate that altitude holding is armed. On the right of the unit, the numerical display will show the currently selected altitude, adjusted with the dual concentric rotary encoder. When in altitude holding mode, this value can also be nudged by 100ft with the “UP” and “DN” buttons. Selecting a new altitude will not cause the aircraft to immediately attempt to capture that altitude. Pressing the “ALT” push button again, however, will activate vertical speed mode, which will automatically arm the altitude capture. The “ARM” push button has become unnecessary with updates to the KAP140 software over the years that incorporate automatically altitude arming. The vertical speed can then be adjusted with the “UP” and “DN” buttons.

NOTE: The KAP140 has its own dedicated electronic altimeter. This means that the aircraft will not climb or descend to match the altitude shown on the primary altimeter. The unit’s dedicated altimeter must be adjusted by pressing the “BARO” push button and selecting the desired barometric setting. Barometric pressure units can be toggled by holding the “BARO” push button for three seconds.




Bendix RDR 1150XL Color Weather Radar

This implementation of the Bendix RDR 1150XL has six selectable modes via the mode select knob in the upper right-hand corner of the unit. When cycled through the “OFF” mode, the unit will perform a self-test upon startup, and will annunciate if signal is not received from the aircraft’s external weather radar transceiver unit.

In “STBY” mode, the unit is in a safe standby mode, which does not energize the radar transmitter. It is recommended that the unit be placed in standby mode whenever the aircraft is operating on the ground to avoid injuring ground personnel, or sensitive equipment on other nearby aircraft. In this mode, the unit will annunciate “STAND BY” in yellow in the center of the radar arc.


In “TST” mode, the unit will continuously display a sweeping test signal from the radar unit, which should subtend the full horizontal radar arc, and contain concentric arcs of magenta, red, yellow and green. The “RT FAILURE” flag will also display in cyan.

The “ON” mode is the normal mode of operation for this unit. In “ON” mode, the radar will display precipitation and severe turbulence in the above color spectrum, within the radar arc on the screen. The range of the display can be adjusted with the “RNG ^”, and the “RNG v” push buttons. Nautical mile distances are displayed adjacent to the range rings on the radar display. By pressing the “VP” button, the unit can be toggled between horizontal and vertical profile modes, which are annunciated in the upper left-hand corner of the display. The “<TK” and “TK>” buttons can be used to pan the radar transceiver to the right or left, and the “TILT” knob can be used to tilt the radar transceiver up or down. The position of the radar transceiver is annunciated on the display in yellow, but there is no effect on the underlying weather radar simulation. Lastly, “BRT”, and “GAIN” knobs on the left of the unit can be used to control the brightness and gain of the radar respectively. “NAV” and “LOG” modes are not implemented yet in this unit. This unit’s state will be saved automatically and reloaded.



This aircraft is equipped with an underlying software system that is capable of triggering a failure of almost any simulated aircraft system, either determined by the Mean Time Between Failure (MTBF) of each component, or at a scheduled time. Failures are configured via the tablet interface, discussed in the “Tablet Interface” section of this manual. The “NAV” and “LOG” pages of this weather radar interface have been replaced with quick access shortcuts for accessing the failure and engine condition options in this aircraft.

On the NAV page, you will be presented with a segmented bar graph indicating the current engine condition. Using the keys on the weather radar bezel indicated by the YELLOW text and accompanying arrows, you can reset engine conditions to 100% and restore all of their components to working order, refill the oxygen cylinder, or recharge the batteries.



On the LOG page, you will be presented with the current number of active failures. This can be useful if you wish to be alerted of new failures without having the tablet interface open, since the weather radar sits just within the forward view of the pilot. Pressing the corresponding button on the weather radar's bezel to reset all failures, will reset all the currently active failures.



Garmin GTX 327 Transponder

The GTX 327 transponder supports the typical transponder modes of operation; off, standby, on, and altitude reporting mode. This transponder also has a VFR preset button, which will automatically set the transponder code to your region's VFR flight code (such as 1200 in the United States). The unit is also equipped with an ident button for responding to ident requests from air traffic control. Pressing the "FUNC" button will cycle through the unit's function modes, which are as follows:

1. Pressure Altitude (in flight levels)
2. Flight Timer (triggered by weight-on-wheels sensor)
3. Outside Air Temperature & Density Altitude
4. Count Up Timer
5. Count Down Timer

Timers can be started and stopped by pressing the "START/STOP" button, and the time can be cleared/reset with the "CLR" button.



Electrical/Miscellaneous

Circuit Breakers

The Caravan's circuit breaker panel is located on the electrical pedestal to the left of the pilot's seat. Breakers may be pulled or pushed to disable electrical circuits and bus connections within the aircraft. All the corresponding electrical circuits are modeled. The status of the electrical system may be monitored via the multi-function volt/amp meter discussed below. In an emergency situation, such as the detection of smoke, acrid burning smells, loss of engine, or alternator failure, all non-essential electrical systems should be switched off, workload permitting. In the case of the Caravan Professional, two circuit breakers pertaining to the control of retractable landing gear on floats will be removed or added as appropriate. It should be noted that the left-hand column of circuit breakers in the Caravan are actually "bus feeders", which supply each row of equipment with power. In essence, pulling the first breaker of each row, such as "BUS 1 PWR" in the first row, is the same as pulling all the breakers in that row. Similarly, the first two rows of circuits are also connected to the standby alternator, which energizes when electrical loads on the main generator exceed a preset value, and the gas generator is operating above idle RPM.

Multi-Function Volt/Amp Meter

A multi-function meter and associated rotary selector knob provides access to all the onboard electrical systems in the Caravan. The inner scale of the meter displays voltage, while the outer scale displays amperage. The selector knob allows for monitoring of the current (amps) being drawn or produced (positive or negative amps) from the starter-generator ("GEN"), the standby alternator ("ALT"), and the aircraft battery ("BATT"). To test the ammeter, try switching to the "ALT" setting while in-flight, and moving the generator control switch to the "TRIP" position. Current draw on the starter-generator should fall to zero, and the standby alternator and battery should momentarily take over to share the load. The last position on the selector switch is "VOLT", which allows for the monitoring of the main bus voltage, which should mirror the aircraft battery voltage. This indication is important during engine starting to ensure the battery can supply sufficient voltage for an effective start.



Bendix/King KA 51B Remote Compass Synchroscope

This aircraft contains a Bendix/King remote compass, and remote compass controller with integrated synchroscope. The purpose of a remote compass is to supply several instruments, autopilots, or navigation systems with a reliable source of magnetic compass direction that is continuously correcting for gyroscopic drift. This is accomplished by integrating a fluxgate magnetometer's sensing of magnetic direction with a larger gyroscope than could fit within the housing of a single panel-mounted instrument. This remote compass erects to the correct magnetic heading when powered on, and will automatically correct for gyroscopic drift throughout the flight when the remote compass controller's mode switch is placed in the "SLAVE" position. In this mode, the integrated synchroscope should display a white line, centered between the stationary + and - markings.



Should the position of the remote compass become unreliable, such as during flight through magnetic disturbances or over the earth's poles, the remote compass can be placed in a manual mode by placing the mode switch in the "FREE" position. In this mode, the input of the magnetometer will be ignored, and the unit will behave like a normal directional gyroscope. The position of the remote compass can be advanced in one direction or another by holding the remaining switch on the remote compass control in either the clockwise ("CW") direction, or the counter-clockwise ("CCW") direction. In this mode, the synchroscope will show the set compass position's deviation from the detected magnetic heading.

Propeller Amps Indicator

The propeller ammeter gauge indicates the flow of current to the propeller hub during deicing.



Vacuum Indicator

The vacuum indicator shows the vacuum suction generated by the engine-driven vacuum pump on the engine's accessory gearbox. The scale on the gauge has indicators for appropriate vacuum suctions at various pressure altitudes of operation.



Oxygen Pressure Gauge

In the overhead panel of the Caravan, a recessed gauge indicates the oxygen pressure available in the onboard, refillable oxygen cylinder. This cylinder is normally pressurized to 1,850 PSI when serviced on the ground. Oxygen pressure will deplete as it is consumed by passengers and crew, when activated. To activate the Caravan's built-in demand-type oxygen regulators for crew, place the oxygen supply lever in the overhead panel in the "ON" position. Oxygen will be consumed by the crew only in accordance with the current pressure altitude of the aircraft, and the weights of the crew members. The oxygen pressure is saved between flights, and can be refilled via the payload page of the tablet interface, or the "SYSTEMS" page on the weather radar display, or the payload page of the tablet interface. When the cabin oxygen system is activated, the sound of pressurized gas flowing through pipes will be audible.




Quartz Analog Chronometer

A precision (second counting) quartz chronometer for timing IFR approach legs or departure clearance void times.



Hobbs Timer


The included Hobbs timer in the aircraft runs from when the master switch is activated, to when it is shut off. Indicated in tenths of an hour, this meter should be a reliable source of timing for your logbook recordings, or emergency leg timing in IMC, should you find yourself in a really unusual and dire situation.



Lighting Controls

Cockpit Lighting

Cockpit flood lighting is controlled by the dual concentric rheostats under the pilot's yoke. Three overhead flood lights (pilot, co-pilot, and pedestal area) are controlled via the outer concentric knobs in this area of the panel. These floodlights are very bright, and should only be used during pre/post flight operations, or during an emergency. An additional floodlight is provided to illuminate the circuit breaker panel to the left of the pilot's seat. This light is controlled via an inner concentric knob, colocated with the pedestal floodlight dimmer.



Panel Lighting

Panel lighting is also controlled by the dual concentric rheostats under the pilot's yoke. The majority of panel lighting is provided through post lights affixed to the instrument panel, while some instruments have integrated lighting. The panel lighting is divided into the following zones: pilot's side panel, co-pilot's side panel, engine instruments, and radio backlighting. Care should be taken to always use the minimum amount of interior lighting necessary to clearly read the instruments in order to preserve crew night vision quality.



Courtesy Lighting

Interior and exterior courtesy lights are provided to facilitate aircraft loading. The exterior lights are mounted behind the leading edges of each wing to illuminate the pilot and copilot boarding doors. The interior courtesy lights are mounted along the center aisle of the cabin and above the aft loading doors. The “CABIN LIGHTS” toggle switch on the lower-left main instrument panel activates these lights, regardless of main bus power. These lights are powered via the hot battery bus, so they have the potential to drain the aircraft of power if left illuminated for multiple hours.



Individual Reading Lights

There are a total of fourteen individual reading lights above the passenger seats, and over the aft baggage area. Unlike the courtesy lights, these lights require the aircraft's main bus to be powered. The lights are activated by pressing their associated toggling push button. Ensure that cabin lighting is turned off during all flight and ground operations, as light bleeds from the cabin into the cockpit area, diminishing the quality of crew night vision. Keep in mind that incandescent, direct current (DC), cabin lighting presents a significant drain on the aircraft battery during operation.

Map Lights

Small map reading lights on each yoke are aimed at the floor of the cabin, and can be illuminated by adjusting the rheostat on the right horn of each yoke.



Voltage-Based Light Dimming

Black Square's aircraft implement an advanced dynamic interior and exterior lighting, and panel backlighting system that simulates several characteristics of incandescent lighting. Mainly, real world pilots will be intimately familiar with interior lights dimming during engine starting, or becoming brighter when an alternator is switched on. The brightness of the lights in this aircraft are now calculated as the square of the available voltage.

The lights in this aircraft will react to even the smallest changes in the electrical system's load. For example, a generator failure in flight will result in the dimming of lights. Should a second, or standby generator, not provide sufficient power to support the remaining systems on the aircraft, this is signaled by the dimming of lights in response to even small additional loads, such as exterior lighting.

The incandescent lights also simulate the dynamics of filaments, creating a noticeably smoother effect to changes in their intensity. This system has the advantage of allowing for easier dimmer setting with L:Vars, and preset configurations when loading the aircraft in different lighting conditions.

State Saving

This aircraft implements “selective” state saving, meaning that not all variables are saved and recalled at the next session, but some important settings are, primarily to enhance the user experience. Of primary interest, the radio configuration is saved, as well as any preset frequencies/distances/radials/etc that are entered into radio memory. Many radio and switch settings are also saved for recall, including cabin environmental controls, and the state of other cabin aesthetics, such as sun visors, armrests, and windows. No action is required by the user to save these configurations, as they are autosaved periodically. The state of switches that affect the primary operation of the aircraft, such as battery switches, de-icing, etc, are not saved, and are instead set when the aircraft is loaded based on the starting position of the aircraft. Engine health and oxygen pressure are saved between flights, and can be reset via the tablet interface, or the “SYSTEMS” screen on the Weather Radar.

Fuel tank levels will be restored from the last flight whenever a flight is loaded with the default fuel levels. Due to a currently missing feature in MSFS, payload and passenger weights cannot be restored in the same method, although the code has been implemented to do so.

Whether or not the engine covers, pitot covers, and wheel chocks are deployed when loading the aircraft on the ground is controlled via the “Load with Covers & Chocks Deployed” option on the tablet’s options page.

Note: Since this aircraft uses the native MSFS state saving library, your changes will only be saved if the simulator is shut down correctly via the “Quit to Desktop” button in the main menu.

Environmental Simulation & Controls

This aircraft is equipped with a simulated environmental control system, allowing the user to learn the essentials of passenger comfort while operating this aircraft. Cabin temperature is calculated distinctly from outside air temperature. Since the walls of the aircraft are insulated, it will take time for the cabin temperature of the aircraft to equalize with the outside air temperature. The cabin will also heat itself beyond the outside air temperature during warm sunny conditions, and slowly equalize with the outside air temperature after sunset.

Without the need for any aircraft power, the cabin temperature can be partially equalized with the outside air temperature by opening any of the cabin doors, and fully equalized by ram air cooling, so long as the airspeed of the aircraft is great enough. Cabin temperature can also be equalized with the use of the air conditioning system in “VENTILATE” mode. Ventilate mode does not engage the air conditioning compressor, but instead, only the three ventilation fans. The rate of temperature equalization, active heating, or active cooling can be increased by placing the air conditioning switch in either the “COOL” or “VENTILATE” position, and positioning the “AC FAN” switches in their “HIGH” positions. Be aware that these ventilation systems increase the load required from the current power source substantially, and therefore should be used predominantly while under power, or when external power is supplied to the distribution bus.

Cabin Temperature Monitoring

A temperature monitoring system is available in this aircraft to monitor cabin temperature, and alert the pilot to when cabin temperatures have become unacceptably hot or cold. The digital LCD temperature display on the right side of the panel, above the co-pilot standby instrumentation, will display temperatures from -99° to 999° Celsius, or Fahrenheit, toggleable with the small blue push button. Backlighting for this instrument is dimmed via the “RADIO” light dimmer, along with the other avionics backlighting. In addition to this LCD display, two small LED’s are located outboard of the prop-amps gauge to indicate when cabin temperatures are unacceptably hot or cold within the pilot’s primary field of view, and call their attention to the cabin temperature settings. The “CABIN TEMP LOW” light illuminates when cabin temperatures are below approximately 50°F, or 10°C. The “CABIN TEMP HIGH” light illuminates when cabin temperatures are above approximately 90°F, or 32°C.



Cabin Environmental Controls

The primary environmental controls are located below the center of the main instrument panel behind the throttle quadrant. As discussed above, placing the air conditioning control switch in ventilate mode will begin equalizing the cabin temperature with the outside air temperature, so long as the cabin air intake vents are opened with the “VENT AIR” knobs on the overhead panel. These valves admit air into the cabin through the two screened intakes at the top of the wing strut fairings. The fresh cabin air is sourced from the inlets on the wings to avoid possible carbon monoxide contamination from the engine’s exhaust. The cabin temperature can also be equalized with ram air from the pilot and copilot’s side ram air doors, which are extended by pulling on the “VENT PULL” knobs on either side of the instrument panel.



Cabin heating is provided by engine compressor bleed air. To increase the cabin temperature, the red “BLEED AIR HEAT” toggle switch must be placed in the “ON” position. This will provide hot bleed air from the running engine to the air mixing valve so long as the gas generator RPM is above 30%, and the red firewall shutoff handle on the pedestal is pushed in. The temperature control knob is used to set a target temperature for both the heating and cooling systems. The knob can rotate approximately 180° to select temperature targets from 50°F (10°C), to 100°F (38°C). The target temperature is displayed on the cabin visualizer page of the tablet interface.



Three pull handles to the right of the other climate controls actuate valves, which control the direction of heating air. The first, marked “CABIN HEAT MIXING AIR” is used to select whether lower temperature bleed air from the P2.5 compressor stage, or yet cooler cabin return air, is mixed with the hotter P3 air from the engine before passing through a cooling muffler and into the cabin.



When the handle is pushed into the “FLT-PUSH” position, only cabin return air is mixed with the P3 bleed air, effectively cooling the bleed air before it is regulated to the desired vent temperature. When the handle is pulled out to the “GND-PULL” position, P2.5 bleed air is mixed with the P3 bleed air instead, resulting in hotter vent temperatures. This position should only be used when trying to heat the cabin on the ground in very cold ambient temperatures. Pulling the handle out to the “GND-PULL” position in flight will isolate the hot P3 bleed air with no cabin return air or P2.5 bleed air, because the P2.5 high pressure valve is fully closed above approximately 92% gas generator RPM to provide maximum engine power.

Failing to use the “FLT-PUSH” position during flight may result in a vent over-temperature, and subsequent cabin heating failure. The P2.5 bleed valves and their function are discussed further in the “P2.5 Bleed Air Valves” section of this manual. If the incoming bleed air from the engine is too hot to be regulated down to the desired cabin temperature, the cabin temperature target display on the cabin visualizer page of the tablet interface will display in red, which should be the operator’s cue to push in the cabin heat mixing air handle.

The middle of the three handles is used to select whether the heating air should be routed to the vents in the cockpit area, or the vents in the aft side walls of the passenger cabin. Leaving the handle halfway deployed will result in equal airflow between the forward and aft cabins. The rightmost knob controls the defroster diverter louvers in the cockpit heating air distribution ducts. When this handle is pulled outwards, and the middle handle discussed above is pushed fully forwards, any heating air produced from the engine bleed air will be directed upwards at the inside of the aircraft’s windshield, rather than outwards towards the crew members.



Placing the air conditioning mode switch in the “COOL” position will engage the air conditioning compressor clutch and begin to cool the cabin to the target air temperature so long as the engine’s gas generator RPM is above approximately 55%. Sometimes it is necessary to place the condition lever into the high idle position to activate the air conditioning system on the ground. The rate of cooling can also be increased by positioning the “AC FAN” switches in their “HIGH” positions. The air conditioning system can be defeated by the hot bleed air entering the cabin, assuming the bleed air mixture is hotter than the desired cabin temperature. This may happen if the cabin heat mixing air handle is pulled out into the “GND-PULL” position, at which time the in temperature target display on the cabin visualizer page of the tablet interface will display in red.

Air Conditioning Temperature Effects

When the air conditioning compressor clutch is engaged, the load is increased on the engine's accessory gearbox. The load is proportional to the differential between the outside air temperature and the desired cabin temperature. This increased load on the engine can cause internal temperatures to increase. The temperature increase is proportional to the airflow through the engine nacelle, which is influenced by the aircraft's speed, and propeller RPM. Particularly while operating on the ground, the operator should keep an eye on engine temperatures. During low airspeed climbs or while operating at low altitudes, the additional cooling air required by the engine may send interstage turbine temperatures and oil temperatures into a dangerous regime if not properly managed. This may require a reduction of power during climbs to observe ITT limits.



Ambient cooling air is passed over the air conditioning condenser coils in the engine compartment through a pair of louvered grills on the pilot's side of the engine cowling.

Oxygen Duration Table (Hours)

This aircraft is equipped with an **upgraded 115 cubic foot** composite oxygen cylinder.

# of Occupants	10,000 ft	15,000 ft	20,000 ft	25,000 ft	30,000 ft
1	38.4	25.6	19.2	15.4	12.8
2	19.2	12.8	9.6	7.7	6.4
3	12.6	8.4	6.3	5.0	4.2
4	9.6	6.4	4.8	3.8	3.2
5	7.8	5.2	3.9	3.1	2.6
6	6.6	4.4	3.3	2.6	2.2
7	5.4	3.6	2.7	2.2	1.8
8	4.3	2.9	2.2	1.7	1.4
9	3.9	2.6	1.9	1.6	1.3
10	3.4	2.3	1.7	1.4	1.1
11	3.1	2.1	1.6	1.3	1.0
12	3.0	2.0	1.5	1.2	1.0
13	2.7	1.8	1.3	1.1	0.9
14	2.6	1.7	1.2	1.0	0.9

Approximate duration of useful consciousness following a cabin depressurization event:

35,000 ft MSL - less than 1 minute
 30,000 ft MSL - 1 to 2 minutes
 28,000 ft MSL - 2-1/2 to 3 minutes
 25,000 ft MSL - 3 to 5 minutes
 22,000 ft MSL - 5 to 10 minutes
 18,000 ft MSL - greater than 30 minutes

Turboprop Engine Operation

Inertial Separator

Most turboprop engines possess a method of separating particulate from engine induction air by method of repositioning louvers within the engine air intake. These louvers can be inspected from the exterior of the aircraft. When operating normally, incoming air takes a direct path to the PT6's internal radial intake. When the inertial separator (sometimes called an ice deflector, or simply "bypass") is activated, the airflow must take a sharp turn, which ejects particulate through a vent at the side of the engine. Inertial separators have the disadvantage of reducing free airflow to the engine, thus reducing maximum torque, or torque available at for a given ITT for a given set of conditions. This aircraft simulates damage from foreign objects caused by operation on unimproved surfaces. For more information, see the "Foreign Object Debris Damage" section of this manual.



The inertial separator in this aircraft is activated manually by rotating and pulling a large, black control handle away from the instrument panel. The inertial separator should be used whenever operating on unimproved or marginal surfaces, and whenever entering visible moisture. Unlike other aircraft, the manual actuation of this inertial separator can be accomplished in a few seconds, so it is not necessary to anticipate sky conditions several miles away from the aircraft.

Proper functioning of the inertial separator door can be confirmed from the exterior of the aircraft. When the control handle is pulled out in the "bypass" position, a clear path can be observed from the induction air inlet, through the engine nacelle, and out the bypass duct, emerging forward of the pilot's boarding door.

Turbine Engine Ignition

This turboprop engine is equipped with a continuous ignition system that can be energized with the “IGNITION” switch on the electrical control panel. In the “ON” position, the igniters arc continuously. This position should be used during extreme weather conditions to prevent engine flameout, such as heavy precipitation. In the “NORM” position the igniters will only be energized when the starter switch is in the on position.

Turbine Engine Fuel Control Failures

This aircraft implements two types of partial engine failures that are unique to turbine engines. The first is a fuel control failure, resulting in the power lever having minimal or zero control over the engine’s fuel flow. This failure can occur during any phase of flight. In the case of the Caravan Professional, this failure may not necessitate an engine shutdown, as the fuel control manual override lever can be used to restore throttle control. Should this occur, follow the loss of engine power checklist, and advance the manual override lever slowly out of its detent. Operators should take extreme caution when applying power changes through the manual override control, as the mechanical control system of the primary fuel control unit is not present when operating through the backup control.

The second type of failure is engine compressor surging. Turboprop engine surging is the result of disrupted airflow to the engine, and manifests as unstable gas generator RPM, or sudden changes in engine performance. This may occur as the result of severe turbulence, ingestion of large debris (such as birds), or catastrophic failure of internal engine components. At the first indication of compressor stall or surging, engine power should be reduced, and continuous ignition activated to prevent flameout. The surging will be less severe when power is reduced, but the flight should only be continued to the nearest practical field for landing.

Propeller Governor

The propeller governor is an essential component of a high performance aircraft that controls the pitch of the propeller blades, usually by metering oil pressure to the propeller hub. In free turbine engine aircraft, the propeller blade pitch system is usually configured to drive the blades into their fully feathered position automatically when oil pressure is lost. For this reason, a decrease in indicated oil pressure is expected while exercising propeller pitch on the ground. To ensure that these systems are functioning properly, a governor test button is provided for use during the runup procedure. Holding the red “OVERSPEED GOVERNOR PUSH TO TEST” button, located above the electrical control panel, will offset the overspeed propeller governor to a lower RPM, limiting the propeller to around 1,750 RPM. Should the governor fail to maintain the expected RPM in flight, or on the ground, the flight should be discontinued as soon as practical.

Residual Heat & Dry Motoring

After shutdown, engine temperatures (measured as ITT) may remain sufficiently hot as to require dry motoring of the engine to reduce temperatures to safe levels before attempting a start. This limitation may present itself during quick turnarounds in high ambient temperatures with little wind to provide cooling. Should the ITT remain above around 150°C, cranking the engine with the electric starter motor will promote airflow through the compressor section, more quickly cooling the engine. Repositioning the aircraft into the wind will also help cool the engine before attempting a restart.

P2.5 Bleed Air Valves

The P2.5 Bleed Air valves are a feature of the PT6A engine, which stabilize the engine at lower power settings by allowing excess air to escape from the gas generator section of the engine, thus reducing the amount that makes its way into the combustion chamber. Both valves are operated by the pressure differential between the higher pressure P3, and lower pressure P2.5 compressor air. When the engine is not running, the valves rest in the open position. The low pressure P2.5 bleed valve closes around 68% Ng, while the high pressure P2.5 bleed valve closes around 92% Ng. Both valves can fail, becoming stuck in their open positions. This will prevent the combustion chamber from receiving the air it needs to produce full power. Should aircraft not develop the full power expected on takeoff, but all other indications are normal, a stuck P2.5 bleed air valve should be suspected.

External Power

Aircraft batteries are sized much smaller for their application than automotive batteries to save on weight. Running all the aircraft systems on the ground will be enough to drain the battery completely in 20-30 minutes. Starting in cold weather can also prove difficult, as batteries will provide less current with a greater voltage drop in cold conditions. For this reason, this simulation is equipped with an external battery cart. The cart is capable of supplying many times the capacity of the aircraft's onboard batteries, with almost no voltage drop due to high instantaneous loads while starting the aircraft. The external power cart is deployed from the "Exterior Elements" menu on the payload page of the tablet interface.



In this aircraft, the external power is not connected directly to the aircraft's main electrical distribution bus when the connector is fitted into the receptacle on the outside of the aircraft. The guarded "External Power" switch on the electrical panel must also be placed in either the "STARTER" position to apply power to only the aircraft's starter motor, or the "BUS" position to apply power to the entire aircraft via the main distribution bus.

Engine Power Settings (Without Cargo Pod)

All figures at max. gross weight. Do not exceed 765°C ITT during climb, or 740°C during cruise.

*Applicable only at gross weight of 8,300 lbs or less.

Take-Off Power - Standard Day (ISA) No Wind

Press. Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	T/O Ground Roll (ft)	50ft Obstacle T/O Dist. (ft)	Rate of Climb (ft/min)
SL	1,865	1,900	465	1,365	2,420	975
2,000	1,865	1,900	445	1,537	2,725	940
4,000	1,865	1,900	430	1,750	3,080	925
6,000	1,865	1,900	427	2,000	3,500	895
8,000	1,780	1,900	425	2,295	4,000	805

Maximum Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,865	1,900	426	181	850
8,000	1,750	1,900	389	182	910
12,000	1,585	1,900	362	181	955
16,000	1,350	1,900	310	174	1,046
22,000*	1,110	1,900	257	165	1,162

Normal Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,600	1,750	365	164	887
8,000	1,500	1,750	334	164	945
12,000	1,400	1,750	308	164	1,011
16,000	1,335	1,750	284	163	1,076
22,000*	1,175	1,750	256	162	1,170

Long Range Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,445	1,600	327	151	924
8,000	1,355	1,600	298	150	992
12,000	1,330	1,600	281	152	1,049
16,000	1,295	1,600	268	154	1,104
22,000*	1,250	1,600	255	158	1,182

Climb Performance 115 KTS - Standard Day (ISA)

Target Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	Time to Climb (min)	Fuel to Climb (gal)	Dist. to Climb (nm)
4,000	1,865	1,900	465	4	5	9
8,000	1,780	1,900	413	9	10	18
12,000	1,600	1,900	408	15	15	32
16,000	1,550	1,900	400	24	25	48
20,000	1,350	1,900	360	33	30	65
24,000*	1,060	1,900	332	52	43	107

Descent Performance 140 KTS -800 FPM - Standard Day (ISA)

Target Alt. (ft)	Fuel Flow (PPH)	Time to Descend (min)	Fuel to Descend (gal)	Dist. to Descend (nm)
24,000	232	30	17	91
20,000	242	25	15	75
16,000	255	20	13	59
12,000	256	15	8	43
8,000	264	10	6	28
4,000	276	5	3	14

Engine Power Settings (Cargo Pod & Cargomaster)

All figures at max. gross weight. Do not exceed 765°C ITT during climb, or 740°C during cruise. Shaded areas denote operation at max. ITT. *Applicable only at weights of 8,300 lbs or less.

Take-Off Power - Standard Day (ISA) No Wind

Press. Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	T/O Ground Roll (ft)	50ft Obstacle T/O Dist. (ft)	Rate of Climb (ft/min)
SL	1,865	1,900	465	1,405	2,500	915
2,000	1,865	1,900	445	1,582	2,815	882
4,000	1,865	1,900	430	1,800	3,182	868
6,000	1,865	1,900	427	2,060	3,616	840
8,000	1,780	1,900	425	2,362	4,132	755

Maximum Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,865	1,900	426	172	808
8,000	1,750	1,900	389	172	861
12,000	1,585	1,900	362	169	892
16,000	1,350	1,900	310	161	967
22,000*	1,110	1,900	257	151	1,063

Normal Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,600	1,750	365	156	843
8,000	1,500	1,750	334	155	894
12,000	1,400	1,750	308	153	944
16,000	1,335	1,750	284	151	994
22,000*	1,175	1,750	256	148	1,071

Long Range Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,445	1,600	327	143	878
8,000	1,355	1,600	298	142	937
12,000	1,330	1,600	281	142	980
16,000	1,295	1,600	268	142	1,021
22,000*	1,250	1,600	255	144	1,081

Climb Performance 115 KTS - Standard Day (ISA)

Target Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	Time to Climb (min)	Fuel to Climb (gal)	Dist. to Climb (nm)
4,000	1,865	1,900	465	5	5	9
8,000	1,780	1,900	413	10	10	20
12,000	1,600	1,900	408	17	17	35
16,000	1,550	1,900	400	25	26	45
20,000	1,350	1,900	360	37	35	72
24,000*	1,060	1,900	332	68	54	125

Descent Performance 140 KTS -800 FPM - Standard Day (ISA)

Target Alt. (ft)	Fuel Flow (PPH)	Time to Descend (min)	Fuel to Descend (gal)	Dist. to Descend (nm)
24,000	264	30	20	91
20,000	271	25	17	75
16,000	282	20	14	59
12,000	288	15	11	43
8,000	292	10	7	28
4,000	300	5	4	14

Engine Power Settings (Amphibian)

All figures at max. gross weight. Do not exceed 765°C ITT during climb, or 740°C during cruise. Shaded areas denote operation at max. ITT. *Applicable only at weights of 7,800 lbs or less.

Take-Off Power - Standard Day (ISA) No Wind (Land/Water)

Press. Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	T/O Ground Roll (ft)	50ft Obstacle T/O Dist. (ft)	Rate of Climb (ft/min)
SL	1,865	1,900	465	1,810 / 1,982	3,027 / 4,082	751
2,000	1,865	1,900	445	2,038 / 2,232	3,408 / 4,596	724
4,000	1,865	1,900	430	2,319 / 2,539	3,853 / 5,196	712
6,000	1,865	1,900	427	2,654 / 2,906	4,378 / 5,904	689
8,000	1,780	1,900	425	3,043 / 3,332	5,003 / 6,747	620

Maximum Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,865	1,900	426	164	770
8,000	1,750	1,900	389	164	821
12,000	1,585	1,900	362	161	851
16,000	1,350	1,900	310	154	922
20,000*	1,270	1,900	292	150	983

Normal Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,600	1,750	365	149	804
8,000	1,500	1,750	334	148	852
12,000	1,400	1,750	308	146	900
16,000	1,335	1,750	284	144	948
20,000*	1,185	1,750	265	142	996

Long Range Cruise Power - Standard Day (ISA)

Pressure Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	True Airspeed	Range (nm)
4,000	1,445	1,600	327	136	837
8,000	1,355	1,600	298	135	893
12,000	1,330	1,600	281	135	934
16,000	1,295	1,600	268	135	974
20,000*	1,280	1,600	262	136	1,001

Climb Performance 115 KTS - Standard Day (ISA)

Target Alt. (ft)	Torque (FT-LBS)	Prop RPM	Fuel Flow (PPH)	Time to Climb (min)	Fuel to Climb (gal)	Dist. to Climb (nm)
4,000	1,865	1,900	465	5	6	8
8,000	1,780	1,900	413	9	10	17
12,000	1,600	1,900	408	15	16	29
16,000	1,550	1,900	400	23	23	45
20,000*	1,350	1,900	360	36	33	72

Descent Performance 140 KTS -800 FPM - Standard Day (ISA)

Target Alt. (ft)	Fuel Flow (PPH)	Time to Descend (min)	Fuel to Descend (gal)	Dist. to Descend (nm)
20,000	285	25	20	75
16,000	300	20	16	59
12,000	305	15	13	43
8,000	311	10	8	28
4,000	325	5	5	14

Gyroscope Physics Simulation

This aircraft is equipped with the most realistic gyroscope simulation for MSFS yet, which simulates many of the effects real world pilots are intuitively familiar with from their flying.

Most recognizable of these effects is the “warbling” of a gyroscope while it is spinning up, such as after starting the aircraft’s engines. This is simulated with a coupled quadrature oscillator, and is not merely an animation. Unlike the default attitude indicators, the attitude indicators in this aircraft are simulated with physics, and their ability to display correct attitude information is dependent on the speed of an underlying gyroscope.

Gyroscope Physics

Gyroscopes function best at the highest possible speeds to maximize inertia. When the gyroscope speed is high, the attitude indicator display will appear to settle rapidly during startup, and is unlikely to stray from the correct roll and pitch, except during the most aggressive flight maneuvers, such as spins. When gyroscope speed is slower than optimal, precession of the gyroscope may cause the display to warble about the correct reading, before eventually settling out on the correct reading, if unperturbed. When gyroscope speed is slow, and well below operating speeds, the forces imparted on it by its pendulous veins, which usually keep the gyroscope upright without the need for caging, can be enough to prevent the gyroscope from ever settling. Gyroscope speeds generally increase to operating speed quickly (within a few seconds), whether electric or pneumatic, but will decrease speed very slowly (10-20 minutes to fully stop spinning).

When these effects are combined, a failed gyroscope may go unnoticed for several minutes while performance degrades. So long as torque is not applied to the gyroscope by maneuvering the aircraft, or turbulence, the attitude display will remain upright. Either when the gyroscope speed gets very low, or when small torques are applied in flight, the display will begin to tumble uncontrollably. This can be extremely jarring to a pilot during instrument flight, especially if the condition goes unnoticed until a maneuver is initiated.

NOTE: All of the above effects are simulated in this aircraft, and both total and partial gyroscope failures are possible.

Pneumatic Gyroscopes

Pneumatic gyroscopes are powered by either positive (“Instrument Air”) or negative (“Vacuum Suction”) pressure differential in aircraft. The earliest aircraft attitude gyroscopes were powered by venturi suction generators on the exterior of the aircraft, as this did not require the aircraft to have an electrical system to operate. Later, vacuum pumps, or sometimes positive pressure pumps, were added to the engine’s accessory gearbox to reduce drag on the exterior of the aircraft, and also to supply air to the instruments before takeoff. With a pneumatic instrument air system, the dynamics of an air pump compound the dynamics of the gyroscope itself.

The speed of a pneumatic gyroscope is controlled by the air pressure (positive or negative) available to it from the source (usually a pump in modern aircraft). The pressure the pump can generate is directly proportional to engine shaft RPM. At lower engine RPM, the performance of a gyroscope may noticeably degrade over time. For this reason, some aircraft operators recommend a higher engine idle RPM before takeoff into instrument conditions. This ensures the attitude indicating gyroscopes are spinning as quickly as possible before takeoff. Notable to nighttime and instrument flying, an engine failure means an eventual gyroscope failure. Once the engine is no longer running, the gyroscope performance will begin to degrade for several minutes until it provides no useful information. Some pneumatic attitude indicators are equipped with an “OFF” or “ATT” flag to indicate when gyroscope speed is no longer suitable for use, but many do not.

When a pneumatic pump fails, it is possible for it to experience a complete failure, or a partial failure. A partial failure may cause a slow degradation of gyroscope performance to a level that still provides usable attitude information, but with significant procession and warbling effects. A complete vacuum failure rarely results in a completely stopped gyroscope and stationary attitude display, however. During a complete failure, there is often a rotating shaft or blade debris in the pneumatic pump housing, and minimal venturi suction effects on a vacuum pump exhaust pipe. These effects may cause the gyroscope to continue tumbling indefinitely while in flight, only coming to a stop when on the ground. This can be distracting during instrument flight, so some pilots prefer to cover up the erroneous information on the attitude display to avoid spatial disorientation.

Electric Gyroscopes

Electrically powered gyroscopes avoid many of the complications of pneumatic powered gyroscopes, but are often only used as backup instrumentation in light aircraft. The internal components of an electric gyroscope often result in a more expensive replacement than an external pneumatic pump, however, and allow for less system redundancy, especially in multi-engine aircraft. A total electrical failure in the aircraft will result in the failure of electric gyroscope information, and often more quickly than a pneumatic gyroscope, due to the additional resistance of the motor windings on the gyroscope. Unlike a pneumatic gyroscope, an electric gyroscope will often settle almost completely after an in flight failure.

Tips on Operation within MSFS

Turboprop Engine Simulation

The aircraft makes use of Black Square's new gas generator and engine temperature simulation, which offers a vast improvement over the default behavior. Along with the new beta range implementation, these systems produce one of the most realistic turboprop simulations in MSFS. Expect realistic hot starts based on numerous environmental factors, accurate ITT and oil temperature behavior that becomes limiting at high altitude, and precise beta operations while taxiing. The gas generator RPM is also influenced by many factors, and follows a more realistic speed curve at different throttle settings.

Engine Limits and Failures

When you operate an engine beyond its limits, damage to the aircraft is accumulated according to the severity of the limit exceedance, and the type of limit exceeded. For instance, exceeding starting ITT limits will destroy an engine in seconds, while a slight exceedance of the maximum governed propeller RPM would not cause an engine failure for quite some time. When engine health is reduced to 25% of its initialized value, the CHIP DETECT annunciator light will illuminate. If engine parameters are not brought back within limits soon, the engine will fail.

NOTE: The "Engine Stress Failure" option must be enabled in the MSFS Assistance menu for the engine to fail completely.

Exceeding the engine starter limitations stated in this manual significantly will permanently disconnect the starter from electrical power. Be aware that this aircraft does not possess an annunciator pertaining to starter motor overheat, so failure may arise unannounced.

Beta Range

Due to the large static thrust produced by turboprop engines, they are often equipped with a "beta range". When the power levers are moved over a gate into this range below the normal flight idle position, the propeller pitch is further flattened to reduce thrust. This aids in controlling the aircraft on the ground without causing excessive brake wear.

This aircraft makes use of Black Square's new beta range implementation, which is designed to provide accurate ground handling for advanced users, while not interfering with the basic functionality for novices. Beta range is incorporated into the bottom 15% of forward throttle input. Users can assign this 0-15% range to their hardware using 3rd party applications, or with physical detents. The remaining throttle input, including reverse, is assigned normally. By default, the beta range will be inaccessible during flight. An optional power lever beta range annunciator has been added to the annunciator panel for those who do not have hardware or software detents for their throttle input. The annunciator is enabled by default, but can be disabled from the options page of the tablet interface.

NOTE: Inadvertent activation of propeller beta range will be prevented anytime the aircraft is airborne, unless the “Unrestricted Beta Range” option is enabled on the options page of the tablet interface. Use of beta range in flight is not permitted by this aircraft’s operating limitations.

Electrical Systems

The native MSFS electrical simulation is greatly improved from previous versions of Flight Simulator, but the underlying equations are unfortunately inaccurate. Users familiar with electrical engineering should keep in mind that the battery has no internal resistance; however, battery charging rate is correctly simulated in this aircraft, meaning that the battery charge rate in amps is proportional to the voltage difference between the aircraft generators and the battery. Battery charging rate should be kept to a minimum whenever possible, and takeoff limits should be observed.

Third Party Navigation and GPS Systems

There now exist a number of freeware and payware products to enhance or add advanced navigation systems to MSFS. For example, the TDS GTNxi 750/650, the PMS50 GTN 750/650, and the Working Title GNS 530/430. Several of these advanced GPS units implement their own autopilot and flight plan managers out of necessity, with the Working Title GNS being the latest to do so. They may also require the use of their own special variables to be compatible with an aircraft’s radionavigation equipment. Accommodating all these different products is not trivial. Black Square’s hot-swappable avionics system, and failure system to a lesser extent, have compounded the difficulty. Be aware that swapping a GPS unit is also swapping the autopilot, and that all these software options may not behave exactly the same, as they were developed by entirely different teams with different priorities.

Deicing and Anti-Icing Systems

Ice accumulation and mitigation has been buggy since the release of MSFS. As of Sim Update 11 (SU11), the underlying variables for airframe, engine, pitot-static, and windshield icing have been verified to be working correctly. Unfortunately, the exterior visual airframe icing may continue to accumulate regardless of attempted ice mitigation. Apart from the visual appearance, this should not affect the performance of the aircraft. Windshields are always able to be cleared by deicing equipment, thankfully.

This aircraft is equipped with propeller deicing, pitot heat, stall warning heat, windshield heat, deicing boots, windshield defrosters, and an inertial separator. Electrical anti-icing for the propellers, pitot-static probes, stall warning heat, and windshield heat, work continuously, and will slowly remove ice from these areas of the aircraft. Window defrosting is provided by the cabin heating system, and requires the following conditions to be met: the cabin air distributor pull handle must be pushed in towards the “FWD CABIN” position, the “DEFROST” cabin air pull handle must be pulled away from the instrument panel, and the environmental control system must be operating with bleed air available. For more information on cabin temperature and environmental controls, see the “Environmental Control Panel” section of this manual.

Lastly, the aircraft is also equipped with deicing boots that use regulated bleed air to inflate, thereby shedding ice from the leading edges of the aircraft. The three-position airframe deicing switch can be used to automatically inflate all three deicing boot zones in sequence, or manually inflate all zones at once. In the momentary “AUTO” position, first the boots on the tail surfaces will inflate, followed by the inboard wings and landing gear struts, and lastly the outboard wings and wing struts.



Similarly to the deicing boots, the propeller deicing three-position switch activates a 90-second timer when placed in the “AUTO” position; however, the timer system can be bypassed to manually heat the electric propeller deicing boots by placing the switch in the “MANUAL” position. If using the manual position, the operator must manually cycle the switch to the “OFF” position approximately every 90 seconds to prevent ice buildup beyond the base of the propeller.

The windshield heat switch functions in a similar manner. When in the “AUTO” position, a temperature sensing system cycles power to the windshield deicing elements to prevent ice buildup. If the sensing circuitry fails, placing the switch in the “MANUAL” position will apply continuous voltage to the elements, but the heated windshield could become damaged if the elements overheat due to improper use of the manual switch setting.

Foreign Object Debris Damage


This aircraft simulates damage caused to turbine engines by the ingestion of particulate matter, better known as foreign object debris, or “FOD”. FOD can include dust, sand, gravel, ice, etc., and is typically associated with operating on unimproved runways. The amount of damage caused by the FOD is calculated based on which of the 25 recognizable surface types the aircraft is currently operating on, the thrust of the propeller, and the position of the inertial separator vanes. In order to prevent damage, be sure to use the inertial separator whenever operating on unimproved surfaces, including all ground operations, and whenever ice is present.

Control Locks

Functioning control locks are provided for the pilot's yoke. The control lock can be removed by clicking on it. The control lock is stowed beside the pilot's seat, leaning against the electrical console.




This aircraft is also equipped with an integral rudder lock, which is engaged via a lever on the exterior of the aircraft, or the toggle switch on the payload page of the tablet interface. As a safety feature, the rudder lock will disengage if the yoke is pulled fully aft.



Engine & Pitot Covers

Unlike some other Black Square aircraft, it is essential to remove the engine intake cover and pitot covers before starting the aircraft, as they will not be removed automatically. Engine covers left deployed will cause almost instantaneous destruction of the engines, as the cooling air is almost completely restricted. Users should suspect that the engine covers have been left in place in response to suspiciously low gas generator RPM during the start sequence. The engine intake cover has an attached flag, visible from the pilot's seated position from over the glareshield to help avoid catastrophic starts. Engine intake and pitot covers "REMOVE BEFORE FLIGHT" flags can also act as wind indicators.



Realistic Strobe Light Bounce

Most light aircraft possess a placard somewhere in the cockpit containing the warning, "turn off strobe lights when operating in clouds or low visibility." While this message may appear a polite suggestion, real world pilots who have ignored this advice will have experienced the disorienting effects of bright strobe lights bouncing off the suspended water particles in surrounding clouds, and back into their cockpit. The strobe lights on Black Square aircraft will now produce this blinding effect while in clouds or reduced visibility. While the disorienting effects are best experienced in VR, photosensitive users should be strongly cautioned against flying into clouds at night with the strobe lights operating. This feature can be disabled via the options page of the tablet interface.

Headphone Isolation

Simulated active noise cancelling headphones can be toggled by clicking on the pilot's headphone jacks. When the headphone cables are visible, the headphone sound isolation is active. The amount of noise cancellation can be adjusted by scrolling the mouse wheel while hovering over the headphone jack clickspot. The headphone isolation only affects engine and wind noise, allowing you to enjoy subtle sounds and hear interaction feedback without overpowering engine sounds.




Magnetic Compass Effects

This aircraft is equipped with Black Square's new magnetic compass simulation, which filters inputs from the simulation's magnetosphere environment and combines it with the influence of onboard magnetic fields. This means that the magnetic compass will respond more realistically to aircraft movement, and take a realistic amount of time to settle on a new heading.

Complex aircraft have many high power electrical loads onboard that can produce their own magnetic fields, which disturb the compass and produce false readings. The "magnetic compass is erratic when propeller heat is on" placards in the cockpit now have meaning. The largest electrical loads on the aircraft will now cause a deflection in the indicated magnetic heading corresponding to their magnitude, location in the aircraft, and the direction of the field generated relative to the compass' location.

Tablet Interface

The Black Square tablet interface is an invaluable resource for the enhanced understanding of complex aircraft systems. The tablet also allows the user to configure all options, manage payload, control failures, monitor engines, electrical schematics, and environmental control systems, all from within the simulator.



To show or hide the tablet, click on the tablet or cabin side wall, beside the pilot's seat. The tablet can be moved around the cockpit by dragging the frame of the tablet.

NOTE: Due to the large amount of information rendered on some pages of the tablet interface, it may have a noticeable impact on the graphical performance of the simulator on less powerful systems. This is only a symptom of rendering the graphics, and the rest of the aircraft has been designed to be as frame rate friendly as possible, often outperforming the default aircraft with large glass panel instrumentation. If you experience this, simply hide the tablet interface when it is not in use, and it will have no further impact on performance. In testing, the impact of the visualizer has been observed to be less than 2-3 fps when open.

Options Page

Your selections on the options page will be saved and restored next time you load the aircraft.

1. Primary Avionics Selection

The primary avionics choice will occupy the role of the COM1 and NAV1 radios. This selection could limit the available choices for secondary and tertiary avionics selections. When a GPS is selected as the primary avionics choice, it will always be the unit driving the pilot's HSI and autopilot. This selection will be saved and recalled at the start of your next flight.

2. Secondary Avionics Selection

The secondary avionics choice will occupy the role of the COM2 and NAV2 radios. This selection could limit the available choices for tertiary avionics selections. When a GPS is selected as the secondary avionics choice, it will only drive the pilot's HSI and autopilot if no GPS is selected as the primary avionics selection, and the capability exists for the secondary choice. For example, a secondary PMS50 GTN 650 or TDS GTNxi 650 will drive the autopilot and pilot's HSI if the KX155 is selected as the primary radio.

NOTE: This NAV2 control of the autopilot is not currently possible with the WT GNS 530 installed as NAV2 in this aircraft, but may be at some point in the future, and is possible with other avionics combinations in other Black Square aircraft.

This selection will be saved and recalled at the start of your next flight.

3. PMS50 GTN / TDS GTNxi Switch

To switch between the PMS50 and TDS offerings of GTN GPS units, toggle this switch. This selection will be saved and recalled at the start of your next flight.

4. Confirm Avionics Selection

Your avionics selection will only take effect once you have pressed the confirm button. Once pressed, the button will display a series of messages while the avionics are reconfigured. This takes a few seconds, and should not be interrupted due to the complexity of new avionics software. The autopilot will be disengaged when this change takes effect. Once the change is complete, the confirm button will remain grayed out until you make a change to your avionics selection with the buttons above.

5. Options List

The scrolling options list contains all configuration options for the aircraft. Your selections will be saved and recalled at the start of your next flight.

Options

Payload

Engine

Elec

Cabin

Failures

Avionics Selection

Primary

Secondary

KX 155B

KX 155B

KLN 90B

GNS 430

GNS 530

GTN 650

GTN 750

3

PMS50 GTN

TDS GTNxi

4

Confirm

Options

Unrestricted Beta Range

Show Beta Annunciator

Instant Beta On Touchdown

Cloud Strobe Effect

Load with Covers & Chocks Deployed

VR Tablet Static Position

Show Copilot from Inside

Payload Page

NOTE: Using the payload configuration tools in this tablet interface is optional.

You may always use the simulator's native payload and fuel interface, though the two may be desynchronized when the aircraft is first loaded. This is a simulator limitation.

1. Payload Data

This text area contains real-time weight and balance information, as well as range and endurance estimates. The toggle switch above the payload data block can be used to switch units from gal/lbs to L/kg. The maximum gross weight will appear in red when it exceeds limits.

2. Exterior Actions

The buttons in this list execute actions pertaining to the exterior of the aircraft, such as opening doors, and refilling the oxygen cylinder. All cabin doors and baggage compartment doors can also be opened from the inside of the aircraft without the tablet interface. If a door fails to open, its operation is being impeded by the aircraft's condition, such as airflow around the aircraft, or the cabin pressurization. The oxygen cylinder can also be refilled via the weather radar display.

3. Fuel Stations

Each fuel tank in the aircraft is represented by a fuel block. Each block depicts the current fraction of the tank that is filled in the color of the fuel type appropriate to the aircraft, the total gallons or liters of fuel in the tank, and the weight of the fuel. Below each block is the name of the tank, and its maximum capacity. The quantity of the fuel in the tank can be adjusted with the up and down buttons, or the simulator's native payload interface.

4. Payload Stations

Each payload station in the aircraft is represented by a payload block. When occupied by passengers or cargo, each block shows the current weight of the station in its center. Clicking in the center of the block will toggle the payload between empty, and the default station weight. The weight of the payload station can be adjusted with the up and down buttons, or the simulator's native payload interface.

5. Exterior Elements

The toggle switches in this list control the visibility of exterior elements around the aircraft, such as wheel chocks and engine covers. The functioning wheel chocks can also be toggled by clicking on the stowed wheel chocks in the aircraft cabin.

6. Center of Gravity

This relative depiction of the center of gravity limitations can be used to assess the balance of your payload. When the aircraft's center of gravity exceeds the lateral or longitudinal limits, the crosshair will turn red.

Engine Visualizer Page

While the engine visualizer does not depict every operating parameter of the engine, as this would be a nearly impossible task, it depicts many of the parameters and conditions designed by Black Square that were previously invisible to users. This visualizer is probably most helpful for ensuring cool engine starts, but also for troubleshooting failures.

Cold Engine

This is how the engine visualizer will appear when the aircraft is first loaded on the ground.

1. Repair Engine

Clicking the Repair Engine button will reset only the engine's core condition, which can be observed on the adjacent engine condition bar. This action requires confirmation. Resetting the engine condition will not perform any of the actions performed by the column of buttons on this page, such as clearing the engine, or recharging the batteries. The engine condition can also be reset via the legacy weather radar systems display.

The engine condition is represented by a percentage of total engine health. When the engine's condition reaches 0%, a catastrophic failure will occur, and the engine will become inoperable. When the engine condition falls below 20%, the engine's performance will begin to suffer, making further degradation likely if power is not reduced immediately.

2. Engine Condition Reset Buttons

These buttons will not reset the engine's overall condition, but instead will reset individual elements of the engine's operating condition that may have become damaged or inoperable due to mismanagement, as opposed to failure.

The Clear Engine button will reset the engine temperatures to ambient, remove all fuel from the lines and combustion chamber, and prepare the engine for a normal cold start.

The Repair Starter button will reconnect the starter with the aircraft's electrical system, and set the starter's casing to the ambient temperature. The starter may become disconnected from the electrical system due to overuse, which results in a high temperature.

The Clean Filters button will remove any contaminants from the oil and fuel filters. These filters are depicted by cross-hatched rectangles in this visualizer. Clogged filters may result in higher than normal oil temperatures, or lower than normal fuel pressures, accompanied by a warning light.

The Recharge Battery button will fully recharge the battery, set its internal temperature to the ambient, and reconnect it with the hot battery bus. The battery may become disconnected from the hot battery bus if it is charged or discharged too quickly, which results in high temperatures.

3. Fuel & Oil Lines

This aircraft has an electric fuel boost pump and an engine driven pump, an inline primary fuel filter which can become clogged, and an oil-to-fuel heat exchanger.

As oil is circulated through the engine's galleries, a brown slug of oil will move down the lines depicted on the engine visualizer. The speed at which oil permeates the engine is determined by the oil's viscosity. Oil viscosity is determined mostly by temperature. The color of the oil depicts its temperature. Dark browns indicate very cold and viscous oil. The oil has a large normal operating temperature span, throughout which its color will be the brown seen below.

4. Output Shaft

On the front of the engine is the output shaft, which is directly connected to the propeller. This shaft drives the propeller governor, and incorporates the torqometer, and beta feedback ring.

5. Planetary Reduction Gearbox

The planetary reduction gearbox is responsible for reducing the 30,000+ shaft RPM of the power turbine to a higher torque and more useful speed to drive the propeller. Since this is such a high wear area of the engine, it receives a constant flow of oil, and has its own oil sump.

6. Power Turbine

The power turbine blades are positioned just downstream of the combustion chamber, and capture the energy of the rapidly expanding exhaust gasses. One of the three turbines in this section returns power back to the gas generator to sustain combustion. Important to the understanding of free turbines, the power turbine and the gas generator are not connected by a common shaft or gears. There is no mechanical connection between the two sections. Instead, only the airflow that passes between the two connects them.

7. Gas Generator

The gas generator comprises a set of turbines and stators that progressively compress ram air to about ten times its ambient density. This air is then distributed through small holes into the combustion chamber. The gas generator is driven by expanding exhaust gasses when the engine is running, and the starter motor while starting.

8. Accessory Gearbox

The accessory gearbox resides on the back of the engine, and is used to transfer power from the gas generator to accessory equipment, such as fuel and oil pumps, the fuel control unit, and the starter-generator. The gearbox contains reduction gears to reduce the high RPM, low torque output of the gas generator to lower RPM, higher torque output for the accessories. It is important to remember that in a free turbine engine, accessories are driven by the gas generator, not the propeller output shaft. The main oil reservoir and sump separate the accessory gearbox from the rest of the engine.

9. Induction & Bleed Air Controls


Control of the engine's intake and bleed air relies on a series of valves and louvers. Ambient air enters the induction system through the air inlet under the engine, at the bottom of the visualizer. This air is always at the same temperature and pressure as the air surrounding the aircraft.

The air used to heat the cabin is extracted from the high pressure P2.5 and P3 bleed air valves. See the "Cabin Environmental Controls" section of this manual for more information on bleed air sources and climate control.

When ambient pressure and temperature ram air reaches the gas generator, it is pressurized before entering the combustion chamber. This air is metered by the bleed air controller, before passing through the cooling muffler, and sent into the cabin air ducts. Also pictured here is the cabin heat mixing air valve, which either admits P2.5 bleed air into the cabin heating duct with the hotter P3 bleed air, or dumps the P2.5 bleed air overboard whenever the P2.5 bleed valve is open during engine operation at gas generator speeds below ~89%.

10. Active & Inactive Batteries

The capacity of each battery is displayed as a percentage of total amp-hours remaining. Batteries should generally not be discharged below 70-80% of their total capacity, unless they are specially designed "deep-cycle" batteries. When a battery is not connected to the main bus of the aircraft, it will appear grayed out.



Starting Engine

This visualizer can be very helpful for understanding the starting sequence of a free turbine engine, and learning how to keep the engine as cool as possible during starting.

1. Fuel Pumps

When the electric boost pump or engine-driven fuel pump runs, fuel will flow from the selected tank into the fuel control unit (FCU). As the fuel lines are pressurized, a slug of fuel will travel from the tanks to the FCU. Dashed lines indicate the rate of fuel flow. Not until this slug reaches the FCU will the engine be capable of sustaining combustion.

2. Ignitors

In order to ignite the relatively non-volatile jet fuel, several ignitors are mounted radially around the combustion chamber. Not unlike spark plugs in a reciprocating engine aircraft, an exciter coil sends a high voltage pulse of electricity to these electrodes to produce a spark. The ignitors can be run automatically, whenever the engine is at low power output, or manually, usually when the aircraft encounters severe turbulence or precipitation. See the “Turbine Engine Ignition” section of this manual for more information

3. Fuel Control Unit & Starter Motor

The fuel control unit (FCU) is a purely mechanical control system in a turbine engine that meters the amount of fuel injected into the combustion chamber to achieve the desired power output level set by the power lever. A combination of pressurized fuel and pressurized bleed air are provided as inputs to the FCU. When the FCU is receiving pressurized fuel and functioning normally, its internal volume will be shown in green. When an FCU failure has occurred, it will be shown in red. For more information on the FCU and its possible failures, see the “Turbine Engine Fuel Control Failures” section of this manual.

When the starter motor is in use, the interior body of the starter will be depicted in green. Should the starter fail, it will turn red. Since the starter motor is also the generator, the interior body will also be green when the generator is in use, except the letter “G” will be shown, instead of “S” for starter.

The exterior casing of the starter-generator will change color to indicate its temperature. When the starter-generator is cold, the casing color will be gray. As it warms the color will change from blues and greens, to ambers and reds.

4. Intake Air

The gasses in the intake manifold are color-coded not for temperature, but pressure. Fully saturated, bright blue indicates sea level pressure. Darker blues indicate higher pressures, and greens and yellows indicate lower than sea level pressures. Seen here, the intake air is at the same pressure as the ambient air, but the air in the combustion chamber has been compressed by the gas generator. Before the engine is sustaining combustion the P2.5 bleed air valves will


be open, as there is no P3 bleed air pressure to close them. For more information on P2.5 bleed valve operation and failures, see the “P2.5 Bleed Air Valves” section of this manual.

5. Battery Temperature

The exterior casing of the battery will change color to indicate the temperature of the battery’s terminals and electrodes. When the battery is cold, the casing color will be gray. As the battery warms the color will change from blues and greens, to ambers and reds. For more information on battery charging and temperature, see the “Battery Temperature” section of this manual.

6. Inertial Separator Stowed

With the inertial separator in the stowed (normal) position, ram air will flow unimpeded through the intake manifold and into the engine’s radial inlet. While this configuration is best for engine performance and cooling, it allows foreign object debris (FOD) to enter the engine. For best practices regarding the inertial separator, see the “Inertial Separator” section of this manual.



Running Engine

While the engine is running, the engine visualizer is best used for detecting component failure, monitoring air intake valve positions, and bleed air valve activation.

1. Propeller Governor

The propeller governor controls the pitch of the propeller to indirectly control engine torque and output shaft RPM. The governor's flyweights are driven by a mechanical connection to the output shaft, and meter the high pressure oil supply to the propeller hub. When the propeller governor is receiving oil and functioning properly, it will be depicted with a green body. The body will become red if the governor fails. For information on the testing and failure modes of the governor, see the "Propeller Governors" section of this manual.

2. Exhaust Gasses

When the engine has achieved self-sustaining combustion, the resultant exhaust gasses are expelled through the power turbine, and out the exhaust stubs on either side of the engine. While the intake gasses are color-coded for pressure, the exhaust gasses are color-coded for temperature. The color spectrum is the same as for the other elements discussed above. As the gasses warm, their color will change from yellows and oranges, to reds and magentas. Magenta should be considered dangerously hot for any equipment depicted in this visualizer.

3. Combustion Chamber

When the ignitors successfully light off self-sustaining combustion, flame will emanate from the fuel injector nozzles. This engine has two injector circuits, primary and secondary. The primary injectors work alone when the engine is spooling up from a cold start, while the secondary injectors begin to function at around 40% Ng. Should an injector fail, fuel will not be shown in the pipeline, and the flame will be absent.

4. Bleed Air Valves

This engine has three bleed air valves. P3 bleed air is drawn from just prior to the combustion chamber, and is used to supply the heating and pressurization system. The low pressure and high pressure P2.5 bleed valves help maintain the correct engine operating RPM, and are sometimes used for heating and pressurization in other aircraft. The position of these valves is indicated on the visualizer. Should a valve fail and become stuck open, the valve body will be shown in red. For more information on P2.5 bleed valve operation and failures, see the "P2.5 Bleed Air Valves" section of this manual.

5. Oil Pumps, sumps & Lines

While dark brown oil in the lines indicated very cold and viscous oil, red indicates oil that is too hot. Here, the engine driven oil pump can also be seen running inside the main engine oil sump. The oil cooler door is also now shown in the open position.

6. Chip Detector

The chip detector is a magnetic pair of electrodes at the bottom of the planetary reduction gearbox oil sump. This is the most likely location in the engine for metallic particles to collect due to wear. The magnet attracts the particulate, and the electrodes allow for a complete circuit to be created when the metallic particles collect on them. When the presence of metal particles in the oil is detected, the body of the chip detector will show red, and a warning light will illuminate on the instrument panel. A chip detect warning is usually indicative of an incipient engine failure, and power should be reduced immediately.

7. Standby Alternator

This aircraft incorporates a belt-driven standby alternator, the depiction of which here is similar to that of the main generator, described in the “Fuel Control Unit & Starter Motor” section, above. Since the standby alternator is not also a starter motor, it will always display the letter “A”, for alternator, so as not to be confused with “S” for starter.


8. Foreign Object Debris (FOD)

It is possible to encounter Foreign Object Debris (FOD) whenever operating on the ground, particularly on unimproved or worn surfaces. FOD can also enter the engine in flight in the form of ice, heavy precipitation, or birds. An icon representing the current type of FOD being encountered will appear on this visualizer. The intensity of the FOD is expressed as a number from 0 to 100%. Particles of FOD can be seen entering the air inlet, and flowing either into the engine or out the ejection ports, depending on how the inertial separator is positioned. For more information on the avoidance of FOD, and the consequences of encountering FOD, see the “Foreign Object Debris Damage” section of this manual.



9. Inertial Separator Deployed

When the inertial separator is in the fully deployed (bypass) position, any Foreign Object Debris (FOD) that enters the engine air intake below the propeller will flow harmlessly out the ejection ports at the rear of the nacelle. If the inertial separator’s louvers fail to fully deploy, the amount of FOD admitted to the engine is proportional to their position. For best practices regarding the inertial separator, see the “Inertial Separator” section of this manual.



Live Schematic Page

The live schematic in the tablet interface is an almost identical recreation of the static schematic in the “Overview Electrical Schematic” section of this manual. For more information on the enhanced electrical simulation of this aircraft, also see the “Electrical Systems” section of this manual.

1. Voltmeter

Voltmeters measure the electrical potential between two points in the aircraft’s electrical system. Here, the direct current (DC) voltmeter measures the voltage between the main bus, and the chassis (ground) of the aircraft. As opposed to current measuring devices, voltmeters are depicted beside the point at which they measure voltage, or across two points between which the potential is measured, rather than as in-line devices.

2. Active & Inactive Equipment

When a circuit component, such as a starter motor, is inactive, it will be grayed out.

3. Buses & Circuit Connections

An electrical bus is any point in an electrical system at which multiple circuits, or other buses, attach. They are often solid pieces of conductive metal to which many wires attach, though they can also be purely conceptual, and used to aid your understanding of the system.

Connections between circuit elements and buses are depicted with solid lines and “hop-overs” wherever two lines must cross without making contact. In this live schematic, buses and circuit connections receiving any voltage from the battery, generators, or external power are highlighted in green, and are otherwise red. For the sake of readability, some circuit connections appear in red when no apparent switch isolates that part of the circuit from normally powered buses. For example, the circuit connection to the external power plug remains red, even when the main bus is powered.

Logic or signal connections, which do not carry any meaningful current, are depicted as dashed lines. For example, in this aircraft, the generator control switch sends a trigger voltage to the generator controller to energize the generator field windings, thus supplying output voltage to the main distribution bus through the generator controller.

4. Switches

Toggle switches control whether a circuit is open or closed. Wherever possible, the switches in the live schematic will be oriented so that the head of the toggle switch points towards the direction of current flow when it is in the on position.

5. Loadmeters

The load meters in most light aircraft do not indicate the total load required of the aircraft's electrical system for all of its electrical equipment. Instead, the loadmeters indicate the load on each generator. This will always be a positive number, as opposed to ammeters in aircraft that can be used to observe battery charge and discharge rates. As opposed to voltmeters, current measuring devices are depicted as in-line with their load, rather than as point measurements. In this aircraft, the only ammeter is positioned in-line with the battery, so that the operator can determine whether the battery is being charged or discharged.

6. Standby Alternator & Controllers

Several pieces of equipment in this aircraft have intelligent controllers that monitor their status, or control their output, such as the standby alternator or starter-generator. These controllers are depicted as green rectangles, which are illuminated when they are receiving power. For example, in this aircraft, no power can be used from the standby alternator unless the standby alternator controller is also receiving power and the alternator is activated by logic power from the standby alternator switch.

7. Circuit Breakers


Circuit breakers will show their red collar when the breaker has been tripped by excessive current. The breaker can be reset manually by clicking on the tripped breaker in the cockpit. If the breaker has tripped due to a failure, it will trip again soon, assuming the circuit is still under load and producing heat. For more information on the circuit breaker layout and power distribution logic, see the "Circuit Breakers" section of this manual.

8. Amphibious Gear Control

This aircraft is equipped with the electromechanical systems for landing gear control on amphibious floats. When this package is not installed on the exterior of the aircraft, these systems will appear grayed out on the live schematic page.

9. Emergency Avionics Power

In this aircraft, two guarded switches allow for power to be routed through the two normally independent avionics buses in the event of a power distribution failure. The avionics standby power switch is used to feed the number 1 avionics electrical bus directly from the standby alternator while bypassing all other electrical distribution. The avionics bus tie switch can be used to directly connect the number 1 and number 2 avionics electrical buses, to bypass one of the bus feeder circuit breakers.



Cabin Climate Visualizer Page

Although the Caravan Professional is a simple aircraft in many respects, it also has a large cabin with many passengers to keep comfortable. The climate control system has several manual controls that must be correctly configured to effectively heat or cool the cabin.

Heating Cabin

When the desired cabin temperature is warmer than the outside ambient air, heating is provided by the P2.5 or P3 bleed air. The bleed air is heated by compression, and by proximity to the engine's combustion chamber. For more information on the environmental control systems, see the "Environmental Simulation & Controls" section of this manual.

1. Engine Bleed Air Supply

The heating system in this aircraft derives hot air primarily from the P3 bleed valve on the engine. Cooler air can also be sourced from the P2.5 bleed air valve and mixed with the P3 bleed air instead of cabin return air to raise the temperature of the heating air before it enters the cabin. Here, we see two valves for the P3 and P2.5 bleed air sources, which are controlled via the red "BLEED AIR HEAT" switch on the instrument panel.

2. Cabin Heat Mixing Valve

The cabin heat mixing valve is controlled via a pull handle on the instrument panel, and selects whether P2.5 bleed air, or cabin return air is mixed with the P3 bleed air before entering the cooling muffler, and then the cabin. P2.5 bleed air that is not mixed with the P3 bleed air is exhausted overboard.

3. Firewall Shutoff Valve

A red pull handle on the lower pedestal controls a valve capable of isolating the cabin from engine bleed air in the event of an emergency. This valve is located downstream of the other bleed air valves discussed above, at the aft of the engine compartment.

4. Ear Discomfort Index

Ear discomfort is a frequent consideration while operating both pressurized and unpressurized aircraft. The colored dot in this visualizer gives some sense of ear discomfort due to pressure equalization between the outer ear and the middle ear. While everyone's physiology is different, rates of climb/descent in excess of 700 ft/min will create noticeable discomfort if pressure is not consciously equalized through the eustachian tubes. For those used to flying in light aircraft, climb/descent rates of 1,500 ft/min can be a routine affair; however, climb/descent rates of 3,000 ft/min or above will be very uncomfortable for most occupants.

5. Air Vents & Air Flow Selector Valves

Cabin heating air can be directed forward through the cockpit vents, or aft, through the cabin side wall vents by pulling the middle of the three heating air control pull handles on the instrument panel. Air that is directed towards the cockpit can be further diverted towards the windshield through the defroster ducts. For more information on the environmental control systems, see the “Environmental Simulation & Controls” section of this manual.


6. Main Cabin Volume & Vents

The temperature of the main cabin, and all ducts and vents in the visualizer, can be estimated from the same absolute temperature scale used elsewhere in this tablet interface. Dark blues are the coldest, greens and yellows are moderate, and reds and magentas are the hottest. The cabin’s current temperature is shown in Fahrenheit and Celsius at the bottom of the visualizer.

7. Climate Control Modes & Target

The operating mode of the climate control system is implied by the position of the “BLEED AIR HEAT” and air conditioning and ventilation switches. This mode is annunciated, along with the temperature controller’s target cabin temperature. For instance, if the air conditioning switch is placed in the “COOL” position, but the “BLEED AIR HEAT” switch is also in the “ON” position, the displayed climate control system mode will be “heat”, as the heating air has the potential to overpower the air conditioner.

The target temperature will display the numeric set point of the “TEMP HOT” rotary selector knob, when the active climate control system is receiving power. Otherwise, the target will appear as “None”. When the target temperature is not attainable in the current ambient conditions, the target value will appear in red. This should be the operator’s cue to adjust the cabin heat mixing air pull handle while attempting to heat the cabin. When attempting to cool the cabin, this either indicates that the ambient temperature is too hot to adequately cool the cabin, or that the air conditioner is being defeated by the hot bleed air. Here, the heating target temperature can be seen in degrees Fahrenheit and Celsius.



Cooling Cabin

When the desired cabin temperature is below the outside ambient air temperature, cooling is provided by the vapor cycle cooling system, more commonly known as an air conditioner. For more information on the environmental control systems, see the “Environmental Simulation & Controls” section of this manual.

1. Oxygen System

The pressure of oxygen in the cylinder (a surrogate for the quantity remaining) is indicated by the green volume in the cylinder. This quantity can be refilled on the payload page of the tablet interface. The valve immediately below the cylinder, here seen in the open position, depicts the position of the oxygen isolation valve, which can only be operated from the outside of the aircraft. The second valve controls the flow of oxygen to the cabin oxygen mask outlets in the ceiling, here also seen in the open position.

2. Air Conditioning Condenser Ram Air

The vapor cycle cooling system requires cool ram air from the exterior of the aircraft to function, which is passed over the air conditioning condenser. This air is admitted to the engine cowling through a louvered grill on the pilot’s side of the engine cowling, and then exhausted through a similar louvered grill directly aft of the inlet.

3. Air Conditioning Compressor & Condenser

The air conditioning system (also known as the vapor cycle cooling system), is driven by a clutched compressor on the accessory gearbox of the engine. The clutch will only engage when the gas generator RPM of the engine is high enough, at which point the compressor will indicate with green on this visualizer, and the impeller will begin to rotate.

The uninsulated air conditioning refrigerant pipes pass through a condenser on the pilot’s side of the engine cowling, which requires cooler ambient air to operate. For more information on the air conditioning operation, see the “Environmental Simulation & Controls” section of this manual.

4. Ram Air Cockpit Vents

Two pull handles, marked “VENT PULL ON”, on either side of the main instrument panel can be used to deploy two small doors on the exterior of the aircraft, just forward and below the windshields. These vents admit ambient temperature ram air into the cabin.

5. Cabin Air Inlet Valves

Each wing strut fairing has a grilled air inlet, which can be used to admit ambient temperature air into the cabin by rotating the “VENT AIR” knobs on the overhead panel. When attempting to actively heat or cool the aircraft, these valves should be in the closed position to prevent conditioned air from escaping through the wing intakes, and to prevent unconditioned air from being forced into the cabin during flight.

6. Ventilation Fans & Air Conditioning Evaporators

Just downstream of the cabin vent air control valves and at the aft of the cabin are the air conditioning evaporators coils, and air conditioning ventilation fans. When the air conditioning compressor is operating, chilled refrigerant will be passed through the evaporator coils. The fans will run any time the air conditioning switch is positioned either in the “VENTILATE” or “COOL” position. The ventilation fan speed can be increased with the three “AC FANS” switches, which will affect the overall rate of heating or cooling.

7. Pulse Oximeter


Loss of consciousness and impaired cognitive functioning in low oxygen environments does not happen instantaneously. Except in the case of the most severe decompression events, oxygen must leave the blood supply in order for hypoxia to take effect. This process can take over an hour at lower cruising altitudes, or a few seconds at high altitude. Use the pulse oximeter to monitor the concentration of oxygen in the pilot’s bloodstream. If the concentration becomes too low, descend immediately to a lower altitude, or open the oxygen valve to use supplemental oxygen.

Generally speaking, 98% oxygen saturation (SpO_2) is normal at sea level for a healthy adult.

The recommended, and legally required, altitudes for supplemental oxygen use of around 12,000 - 14,000 feet correspond to an SpO_2 of roughly 90-92% for exposure under 60 minutes.

An SpO_2 below 90% results in cognitive impairment, possibly detrimental to flight safety.

An SpO_2 below 80% can lead to incapacitation after exposure of just a few minutes.



Failures Page

This aircraft is equipped with an underlying software system that is capable of triggering a failure of almost any simulated aircraft system, in response to the users mismanagement of the aircraft, at appropriately timed random (MTBF) intervals, or within a scheduled window of time. These failures are managed through the failures page of the tablet interface. A list of all possible failures is provided below in the “List of Possible Failures” section of this manual. Failures are saved between flights, leaving you to discover what failed on the previous flight during your before flight checklists.

MTBF Failures

In Mean Time Between Failure (MTBF) mode, the user can set custom failure probabilities in the form of a mean time between failure time in hours. While real world electromechanical components follow an exponentially decaying failure probability after their fabrication, this would be inconvenient for users of virtual aircraft, since it would subject new users to high component mortality rates just after purchasing the product; therefore, the probability of component failure is constant throughout aircraft operation. This means that the probability of failure can be considered to be exactly the mean at all times.

While many of these failures may be randomly generated, they will feel like an authentic system failure (which are essentially random in real life), because they will only fail while the system is in use, and at a rate appropriate to the real world system.

1. Restore Defaults & Reset All Failures

The Restore Defaults button can be used to reset all MTBF times to their default value. As adjustments to MTBF times are saved and restored for the next flight, this action requires a confirmation to complete. For instructions on adjusting the MTBF time for individual components see point 6, below. The reset all failures button can be used to reset all currently active failures at once. For instructions on triggering individual failures, see point 7, below.

2. MTBF / Scheduled Mode Switch & Show Only Active Failures

Use the MTBF / Scheduled Mode switch to toggle between the two modes of operation for the failure system. The Show Only Active Failures switch can be used to filter the results of the scrolling failure list to only those that are currently active. This also applies to the results of the search function.

3. Global Failure Rate Slider

The global failure slider is used to control the global failure rate, indicated by the text below the slider. The maximum allowable rate is 1000 times real-time. All MTBF and scheduled failures can be disabled completely by positioning the slider all the way to the left, until “Failures Off” appears below the slider. The global failure rate multiplies the probability of random failures occurring while in MTBF mode, but does nothing in scheduled failure mode.

For Example, if a specific failure is expected to occur once in every 5,000 hrs of flight time, a global failure rate of 1000x, will result in this failure occurring roughly once in every 5 hrs of flight time instead. Settings between 10x and 50x are recommended to add a little excitement to your virtual flying experience, as many hundreds of hours can be flown at 1x real-time failures without encountering a single failure, while settings above 250x almost guarantee multiple failures per flight.

4. Active Failures

The current number of active failures can be seen at all times below the global failure rate slider. This number is also shown on the systems page of the weather radar display so that the number of current failures can be monitored from the cockpit without the tablet visible.

5. Search Failures

All failures shown in the scrolling list are searchable. Click in the search window and start typing to search. The text entry mode should deactivate automatically a few seconds after you stop typing. When the “show only active failures” option is selected, the search will only return results among the currently active failures.

6. Adjust MTBF

Upon loading the aircraft for the first time, default MTBF values will be displayed for each system, which are representative of their real world counterparts in accordance with published NASA guidelines whenever available. These failure probabilities can be modified by pressing the left and right arrow buttons beside the MTBF value. The minimum allowable MTBF is 100 hrs, and the maximum is 1,000,000 hrs. If adjusted from the default, the selected MTBF time will be saved and restored on the next flight.

7. Instantaneously Fail or Reset Failure

After being triggered by any means, individual failures can be reset by pressing the “RESET” button. Failures can also be triggered manually in this mode by pressing the “FAIL NOW” button.

8. Restore Default MTBF

Clicking on the displayed MTBF value will restore it to the default for that specific component. When the button is grayed out, the component’s MTBF is already set to the default value.

9. Failure Names & Color Codes

Failures are color coded into groups. Magenta is used for catastrophic engine failures, red for major systems failures, white for power distribution failures, and cyan for circuit breaker protected electromechanical failures. The failure names as they appear in this list can be used to trigger the failures via any 3rd party software or hardware interface that is capable of sending HTML (H:Events) to the simulator. See the “Failure System HTML Interface” section of this manual for more information.

Options Payload L Eng R Eng Elec Cabin Failures

Restore Defaults 1 Reset All Failures

Global Failure Rate 3

MTBF Mode ☐ Scheduled Mode 2

☐ Show Only Active Failures

Search... 5 X

Active Failures 4

CABIN HEATER CO LEAK

MTBF: < 3,000 > FAIL NOW

L ENG CO LEAK 6

MTBF: < 10,000 > FAIL NOW

R ENG CO LEAK 7

MTBF: < 8,000 > RESET

CO DETECTOR 8

MTBF: < 5,000 > FAIL NOW

CONDENSER LIMIT 9

MTBF: < 3,000 > FAIL NOW

ELEC BUS 1 LEFT

MTBF: < 2,000 > FAIL NOW

ELEC BUS 2 LEFT

MTBF: < 2,000 > FAIL NOW

Scheduled Failures

In scheduled failures mode, individual failures can be scheduled to occur within a specific time window after the present time. Failures have a constant probability of occurring between the two times shown, and will occur only after the failure has been armed. This allows for variability in scenario training, while ensuring that a given failure occurs in the desired phase of flight.

1. Restore Defaults & Reset All Failures

The Restore Defaults button can be used to reset all scheduled failure windows to the default. This action requires a confirmation to complete. For instructions on adjusting the scheduled failure time window for individual components see point 6, below. The Reset All Failures button can be used to reset all currently active failures at once.

2. MTBF / Scheduled Mode Switch & Show Only Active Failures

Use the MTBF / Scheduled Mode switch to toggle between the two modes of operation for the failure system. The Show Only Active Failures switch can be used to filter the results of the scrolling failure list to only those that are currently active. This also applies to the results of the search function.

3. Global Failure Rate Slider

The global failure rate has no effect on the rate of failures in the scheduled failure mode; however, it will prevent all failures from occurring when placed in the “No Failures” position.

4. Active Failures

The current number of active failures can be seen at all times below the global failure rate slider. This number is also shown on the systems page of the weather radar display so that the number of current failures can be monitored from the cockpit without the tablet visible.

5. Search Failures

All failures shown in the scrolling list are searchable. Click in the search window and start typing to search. The text entry mode should deactivate automatically a few seconds after you stop typing. When the “show only active failures” option is selected, the search will only return results among the currently active failures.

6. Adjust Time Window

The time window in which a specific failure will occur can be adjusted with the arrow buttons beside the “after” and “before” times. These times are expressed in minutes. The minimum time after which a failure will occur is one minute, and the maximum time before which a failure will occur is ninety minutes. When the time cannot be adjusted up or down as it would exceed the minimum or maximum, or when it is constrained by the other time, the adjustment buttons will be grayed out.

7. Arm or Reset Failure

Clicking the “ARM?” button will arm the failure with the currently selected time window. Once armed, this button will appear in yellow, with the text “ARMED”. Clicking the button again anytime before the failure has occurred will disarm the failure. After the failure has occurred, the button will read “RESET”, and clicking the button will reset the failure, returning it to an unarmed state.

8. Failure Names & Color Codes

Failures are color coded into groups. Magenta is used for catastrophic engine failures, red for major systems failures, white for power distribution failures, and cyan for circuit breaker protected electromechanical failures. The failure names as they appear in this list can be used to trigger the failures via any 3rd party software or hardware interface that is capable of sending HTML (H:Events) to the simulator. See the “Failure System HTML Interface” section of this manual for more information.

Options
Payload
L Eng
R Eng
Elec
Cabin
Failures

Restore Defaults
Reset All Failures

MTBF Mode
Scheduled Mode

Show Only Active Failures

Search...
X

Global Failure Rate
1x Real-Time

Active Failures

AVIONICS BUS RIGHT

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARM?

GEN OVERVOLT DETECT

BETWEEN:
< 1 >
AND
< 2 >
MIN
RESET

GEN OVERVOLT DETECT R

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARMED

CABIN TEMP CONTROL

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARM?

CABIN PRESS CONTROL

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARM?

VENT BLOWER

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARM?

AIR CONDITIONING

BETWEEN:
< 10 >
AND
< 30 >
MIN
ARM?

Failure System HTML Interface

To facilitate users who wish to initiate failures instantaneously via an external software interface, such as an instructor station, webpage, or tablet interface, access has been provided into the failure system using MSFS's HTML events. Any software that is capable of sending HTML events (also known as H:Vars), is capable of triggering failures without any additional configuration. These failures will appear in the in-cockpit tablet interface's failures page, and can be reset from the same interface, or by sending the same HTML event again.

This interface allows users to create and share profiles for popular 3rd party interface applications to trigger and reset failures, or even mimic more complex emergency scenarios. Popular software capable of sending HTML events to MSFS include:

- Air Manager
- Axis and Ohs
- Mobiflight
- SPAD.neXt
- FSUIPC
- Many other SimConnect-based interfaces

To trigger or reset any failure in any Black Square aircraft, simply send an HTML event with the prefix "BKSQ_FAILURE_", and the exact name of the failure as it appears in the in-cockpit tablet interface's failures page with spaces replaced by underscores.

For example, to trigger or reset a failure named "L FUEL QTY", the HTML event would be:

```
>H:BKSQ_FAILURE_L_FUEL_QTY
```

All failures can be reset at once by issuing the following command:

```
>H:BKSQ_FAILURE_RESET_ALL_FAILURES
```

Depending on your programming environment, be sure to check the exact syntax needed to trigger HTML events. Some graphical programming environments may require you to omit the leading ">" from the event, while others may require this ">" to be expressed as ">", such as in reverse polish notation.

List of Possible Failures

Major System Failures

ENGINE FAILURE
ENGINE FIRE
MAIN GENERATOR
STANDBY ALTERNATOR
PROPELLER GOVERNOR
FUEL CONTROLLER
ENGINE SURGE
PRIMARY INJECTORS
SECONDARY INJECTORS
LP BLEED
HP BLEED
FUEL FILTER
ENG DRIVEN FUEL PUMP
MAIN FLAP MOTOR
STBY FLAP MOTOR
VACUUM PUMP
PARTIAL VACUUM
PITOT BLOCKAGE
STATIC BLOCKAGE
L BRAKE
R BRAKE
OXYGEN LEAK
OXYGEN ISOLATION VALVE
L FUEL LEAK
R FUEL LEAK
DEICE BOOT INTEG
BLEED OVERTEMP
DOOR LATCH
MANUAL GEAR EXTENSION
WATER RUDDER CABLE

Electrical Bus Failures

ELEC BUS 1-1
STBY POWER 1
ELEC BUS 2-1
STBY POWER 2
ELEC BUS 1-2
ELEC BUS 2-2
ELEC BUS 1-3
ELEC BUS 2-3

Breaker Protected Failures

IGNITION
STARTER CONTROLLER
GEN CONTROLLER
GEN FIELD
AUX FUEL PUMP
ANNUNCIATOR PANEL
FIRE DETECTOR
AP ANNUNCIATOR PANEL
REMOTE COMPASS GYRO
L TURN COORDINATOR
R TURN COORDINATOR

ITT GAUGE
OIL TEMP GAUGE
FUEL FLOW GAUGE
L FUEL QUANTITY
R FUEL QUANTITY
OVERSPEED TEST
BLEED AIR VALVE
L PITOT HEAT
R PITOT HEAT
WSHLD ANTI-ICE
WSHLD ANTI-ICE CONTROL
DE-ICE BOOTS
PROP ANTI-ICE
PROP ANTI-ICE CONTROL
FUEL CONTROL HEATER
L LANDING LIGHT
R LANDING LIGHT
STROBE LIGHT
BEACON LIGHT
TAXI LIGHT
NAV LIGHTS
MAP LIGHTS
INSTRUMENT LIGHTS
RADIO LIGHTING
CABIN LIGHTS
WING ICE LIGHT
L VENT BLOWER
R VENT BLOWER
AFT VENT BLOWER
STALL WARNING
AIR CONDITIONING
BLIND ALT ENCODER
STBY HORIZON
ALT ENCODER
ELEC TRIM
COMM 1
NAV 1
XPNDR
GLIDESLOPE 1
ADF
HSI
GYRO MAG SLAVING
AUDIO PANEL
AP ACTUATORS
AP CONTROLLER
COMM 2
NAV 2
GLIDESLOPE 2
DME
RNAV
RADAR ALT
AVIONICS FAN
AUDIO AMPLIFIER
FUEL SELECTOR WARN
WX RADAR CONTROLLER
WX RADAR ANTENNA
AMPHIB GEAR CONTROL
AMPHIB GEAR PUMP

Miscellaneous Systems

Audible Warning Tones

This version of the Caravan comes equipped with several warning tones to alert the operator to important configuration changes, or potentially dangerous situations. These tones can be disabled by pulling the circuit breaker for the respective tone's underlying warning system. These tones are as follows:

- **Altitude Alerter Tone:** A beeping tone will sound five times quickly when the aircraft is within 1,000 ft of the selected altitude displayed on the KAP140 Autopilot.
- **Autopilot Disconnect Tone:** Whenever the autopilot is disconnected via the autopilot master push button, the control yoke mounted disconnect buttons, or automatically disconnects when overpowered, a soft warning chime will sound.
- **Stall Warning Horn:** When the aircraft is within approximately 5-10 knots of stalling speed, a constant tone warning horn will sound.
- **Overspeed Horn:** When the aircraft exceeds the VNE (red line) airspeed on the airspeed indicator, a repeating beeping tone warning will sound until the speed of the aircraft is reduced to below VNE.
- **Engine Fire Siren:** When a fire is detected in the engine, a loud siren will sound to alert the pilot to take immediate action. This tone cannot be canceled or silenced except by extinguishing the engine fire, or pulling the fire detector circuit breaker. Through completing the engine fire checklists, the pilot will close the fuel shutoff valve and disable the aircraft's power sources. This will cease the warning sound. The fire warning siren can be tested by pressing the red fire detector test button adjacent to the annunciator panel. This warning siren will be accompanied by the RED "ENGINE FIRE" annunciator.
- **Fuel Selector Off Tone:** Added to later model Caravans as the result of early accidents, a warning tone is incorporated to alert the pilot of when the engine has been disconnected from all potential fuel supplies, either by the overhead fuel selectors, or by the firewall valve pull handle on the lower pedestal. The warning system is also activated anytime either fuel selector is off during engine starting, or when only one fuel tank is feeding, and that fuel tank's quantity is less than approximately 25 US gallons.

This warning tone can be disabled by pulling the fuel selector warning circuit breaker at the bottom of the circuit breaker panel, but the annunciator will continue to indicate normally. The system can be completely disabled by pulling both the fuel selector warning circuit breaker, and the starter controller circuit breaker. The tone can be tested by pressing the annunciator test button when Avionics Bus #1 is receiving power. This warning tone will be accompanied by a red "FUEL SELECT OFF" annunciator.

Amphibious Gear Advisory System

The amphibian package includes a gear advisory system to remind the operator of the correct gear configuration for the surface type below the aircraft. When the aircraft descends below 400ft AGL, a laser system assesses the surface type under the aircraft. If the gear is correctly positioned for the surface type, the system will announce once either, “gear is up for water landing”, or “gear is down for runway landing”. If the surface type is not correct, the system will announce, “check gear” continuously, until the correct gear position is selected, or the gear advisory push button is pressed. When climbing through 1,500ft AGL, If the landing gear is not retracted after takeoff, the system will announce, “check gear position” until the gear is raised, or the gear advisory push button is pressed.

VOR & ADF Signal Degradation


Unlike in the real world, navigation receivers in Microsoft Flight Simulator produce only ideal readings. Signal strength is not affected by distance, altitude, terrain, or atmospheric conditions. When a station is out of range, the signal is abruptly switched off. This is unrealistic, and does not give the feel of navigating with the physical systems of the real aircraft.

All Steam Gauge Overhaul and Standalone Black Square aircraft solve this problem by providing variables for VOR and ADF indications with distance and height above terrain based signal attenuation and noise. This noise is mathematically accurate for the type of signal (phased VHF for VOR, and MF for NDB), and adheres to the international standards for station service volumes. Combined with the two-pole filtering and physics of the instrument’s needles in the cockpit, this creates a very convincing facsimile of the real world instrument’s behavior. The To-From indicators of the VOR instruments will even exhibit the fluttering that is characteristic of the “cone of confusion” directly over the ground-based stations that pilots are taught to recognize during instrument training.


Overview Electrical Schematic

The Caravan Professional’s electrical system is relatively simple for an aircraft of its size, but contains a few safety features to mitigate the risk posed by an electrical distribution failure.

NOTE: The aircraft’s electrical system can be monitored via the electrical page of the tablet interface, where a schematic nearly identical to this one is presented. For more information on the tablet’s engine pages, see the “Live Schematic Page” section of this manual.



Using the KNS-80 RNAV Navigation System



The Concept

When most pilots hear the acronym “RNAV”, they probably think of the modern RNAV, or GPS approach type, or precision enroute navigation for airliners; however, long before this type of navigation, there was the onboard RNAV computer. This 1980’s era digital computer allowed pilots to fly complex routes with precision away from traditional ground-based radionavigation sources, such as VOR’s and NDB’s, and fly much shorter routes as a result. As the technology improved, even an early form of RNAV approaches became possible. Before GPS, the onboard RNAV computer allowed for GPS-like flying in a sophisticated package of digital electronics, marketed towards small to mid-size general aviation aircraft.

How it Works

To understand how the RNAV computer works, consider the utility of being able to place a ground-based VOR antenna anywhere you like along your route. If your destination airport does not have a radionavigation source on the field, you could simply place one there, and fly directly to or from it. You could also place an antenna 10 miles out from a runway to set up for a non-precision approach. You could even place an antenna on the threshold of a runway, set your HSI course to the runway heading, and fly right down to the runway with lateral guidance; in fact, this is how an ILS receiver works. The KNS-80 Navigation System allows the user to “move” a virtual VOR antenna anywhere they like within the service volume (area of reliable reception) of an existing VOR antenna.

“Moving” a VOR

To “move” a VOR antenna to somewhere useful, we must know how far from the tuned VOR station we would like to move it, and in what direction. These quantities are defined by a nautical mile distance, and a radial upon which we would like to move the antenna. For

example, to place a virtual VOR 10 miles to the Southwest of an existing station, we would need to enter the station's frequency, a displacement radial of 225°, and a displacement distance of 10.0 nm. Once we have entered this data into the RNAV computer, the resulting reading from this new virtual VOR station will be indicated on our HSI in the same manner as any other VOR, assuming the HSI source selector switch is set to "RNAV", and not "NAV1". This means that you can rotate the course select adjustment knob to any position you like, to fly to/from the new virtual station on any radial or bearing, so long as you stay within the service volume of the tuned VOR station.

Data Entry

Now that you understand the basics of RNAV navigation, let's learn how to enter the data from above into the KNS-80. On the right side of the unit, you will find the "DATA" push button, and the adjacent data entry knob. Between the two exists a marking, reading, "FREQ-RAD-DST", to remind you of the order in which data should be entered, frequency first, then radial, and finally distance. At any given time, either "FRQ", "RAD", or "DST" is shown on the LCD screen to indicate which type of data is being entered. Press the "DATA" push button to cycle through the data entry process, and use the data entry knob to tune a frequency, enter a radial, and finally a distance.

Data Storage Bins

Below the data entry area on the screen, there are two numbers shown, 1-4, in either the "USE" or the "DSP" (Display) positions. The KNS-80 can hold up to four different combinations of frequency, radial, and distance data at one time. This can be greatly useful while planning a flight on the ground. The data channel being edited is indicated by the "DSP" number, and the data being used by the computer and subsequently displayed on the HSI is indicated by the "USE" number. To cycle through the two numbers, press the "USE" or "DSP" push buttons to the left of the "DATA" push button. Whenever the two numbers are different, indicating that one data channel is being edited, but another is being displayed on the navigation equipment, the "USE" numeral will flash continuously.

Distance Measuring Equipment

On the top left-hand side of the LCD display is a traditional Distance Measuring Equipment (DME) display, with a nautical mile distance to the virtual VOR station, a current speed of the aircraft relative to the station, and a time-to-go until over the station. It should be noted that, like all other DME displays, this one is similarly dependent on being within the VOR service volume, and having good line-of-sight reception of the station. It should also be noted that these distances, speeds, and times, are based on slant-range to the station, not distance along the ground, as one would draw on a map. For most procedures, it was determined that this fact did not make such a large difference as to be detrimental to the procedure, but pilots should still be aware of the distinction. Pressing the "HOLD" push button will place the unit in DME hold mode, which will hold the current DME frequency and information on the unit's display while allowing the user to change the tuned NAV frequency. This can be useful for some specific instrument approaches. This feature cannot be used in RNAV modes of operation.

Modes of Operation

Lastly, in the bottom left-hand corner of the LCD display, the KNS-80's many modes are annunciated. The KNS-80's modes fall into two categories; VOR and RNAV, and are activated by the "VOR" and "RNAV" push buttons. Further subcategories of modes are activated by pressing the appropriate push button multiple times. The VOR modes allow for the driving of an HSI with traditional VOR and ILS (including glideslope) data from the unit's third VHF navigation receiver. The VOR mode allows for behavior identical to a standard VOR receiver, with 10° of full-scale deflection to either side of the HSI's course deviation indicator (CDI). Pressing the VOR button again will enter PAR mode, which puts the CDI in a "PARallel" mode of operation, and linearizes the course deviation to +/- 5 nm full-scale deflection. This can be useful for tracking airways more accurately. Pressing the RNAV push button will enter the RNAV modes, where the CDI deflection is based on the displaced virtual VOR shown in the "USE" numeral. There are two RNAV modes, "RNAV/ENR" (Enroute), which drives the CDI with linear deflections of +/- 5 nm full-scale, and "RNAV/APR" (Approach), which drives the CDI with linear deflections of +/- 1.25 nm full-scale. Finally, when an ILS frequency is tuned in the currently USED RNAV data, "ILS" will annunciate on the screen.

Modes in Summary:

- VOR:** Angular course deviation, 10° full-scale deflection, just like a third NAV radio.
- VOR/PAR:** Linear course deviation, 5 nm full-scale deflection, useful for existing airways.
- RNAV/ENR:** Linear course deviation, 5 nm full-scale deflection, displaced VOR waypoints.
- RNAV/APR:** Linear course deviation, 1.25 nm full-scale deflection, displaced VOR waypoints.

Other Possible Uses

Another possible use for the RNAV Navigation System is simply determining your distance away from an arbitrary point within a VOR service volume. This can be useful for many applications, such as ensuring that you remain clear of controlled airspace, or a temporary flight restriction (TFR). It could also be used for maintaining a certain distance away from a coastline, or flying circles around a target on the ground. A further possible use for the RNAV Computer is enhanced VOR "Fencing", such as for avoiding special use airspace, military operations areas, international airspace borders, or Air Defense Identification Zones (ADIZ), or descent planning, or radionavigation switchover points. Finally, one of the most useful applications of the RNAV System is in establishing holding patterns. Before GPS, holding pattern entry and flight could be even more confusing than it already is today. With an RNAV computer, a holding point entry waypoint can be placed anywhere, and flown around like there is a purpose-placed ground-based transmitter at the entry point.

Flying an RNAV Course with the Autopilot

The autopilot will only use the KNS-80 as a navigation source when the no-GPS avionics configuration is selected from the tablet interface. Press the navigation source button to illuminate its "RNAV" annunciator. Use the toggle switch below the localizer to select "RNAV" as the HSI source. Then, select the desired course with the HSI's course select knob.

Recommended Skills

1. Direct Route Navigation
2. Parallel Flight along Airways
3. Location & Distance from Waypoints
4. Enhanced Geo-Fencing
5. Maintaining Distance from Ground Points
6. Holding Pattern Entries
7. Fly a Rectangular Course

Direct Flight to Airport Tutorial


Lastly, as a first illustration of the power within the RNAV navigator, follow these steps to fly from any location within the chosen VOR service volume directly to an airport of your choosing without the need for any colocated navigational aid.

1. Locate the nearest VOR station to your desired destination, and its frequency, radial, and distance from the destination airport. While other station frequencies, radials, and distances can be found on approach, arrival, and departure charts, the easiest place to start is often with a mobile app or website that lists nearby stations along with other airport information. Examples include: ForeFlight, Garmin Pilot, FltPlan Go, SkyVector.com, and Airnav.com. These radials and distances can also be calculated during preflight planning by hand with a plotter, or with most flight planning software applications. In this case, we will use SkyVector.com to search for a destination airport, in this case, Beverly Airport in the US state of Massachusetts.

Nearby Navigation Aids							
ID	Name	Freq	Radial / Range		ID	Name	Freq Bearing / Range
 LWM	LAWRENCE	112.50	154°	12.3	 OW	STOGE	397 198° 29.4
 BOS	BOSTON	112.70	029°	14.0	 MJ	FITZY	209 302° 31.9
 NZW	SOUTH WEYMOUTH	133.40	017°	26.1	 ESG	ROLLINS	260 005° 38.4
 MHT	MANCHESTER	114.40	145°	26.3	 CO	EPSOM	216 323° 39.9

In the fourth block of data, we are presented with four nearby VOR stations (on the left), all providing good coverage to Beverly Airport. To assess whether or not a VOR provides good service to your destination, reference the following chart for VOR service volumes published by the Federal Aviation Administration. For the vast majority of VOR stations, reception will be acceptable within 40 nm of the station while in-flight, and is usually the only volume worth considering for low altitude general aviation flights.

For this example, we will choose the nearest VOR at Lawrence Airport, (LWM). This VOR has a frequency of 112.50 Mhz, a radial to Beverly Airport of 154°, and a distance of 12.3 nm. These are all three pieces of data that we need to fly directly to Beverly.



- Enter the three pieces of data we located above into the KNS-80 RNAV computer. Once the KNS-80 is powered on, all your data entered during previous flights will be loaded from memory, and the active “display”, and “use” data channels will be set to 1, and 1. First, we will use the dual concentric rotary knobs on the right of the unit to enter the frequency 112.5 Mhz into data channel 1, just as we would with any other navigation radio.



- Once our desired frequency has been set we will use the “DATA” push button to page through the three required pieces of data in this data channel in the order “FREQ-RAD-DST”. Press the “DATA” button once, and then enter the radial 154.0, again with the dual concentric rotary knobs. Should your desired radial include a decimal component, the inner rotary knob can be pulled and rotated for decimal entry.




- When our desired radial is set, press the “DATA” push button once again to enter our desired distance offset of 12.3 nm. Again, should your desired distance include a decimal component, the inner rotary knob can be pulled and rotated for decimal entry.



5. Data entry is now complete; however, before we can begin following the CDI to the airport, we need to choose an RNAV mode of operation, probably RNAV/ENR for enroute operation, unless we need increased precision for some reason. Press the “RNAV” push button until “ENR” and “RNAV” are annunciated above the button. In RNAV modes of operation, our CDI will guide us to the displaced VOR waypoint at Beverly Airport that we just created, and all displayed DME information will be relative to that new waypoint.

NOTE: VOR modes of operation WILL NOT provide CDI or DME information relative to the active waypoint. They are for operation as a conventional navigation radio with reference to existing VOR stations, in either angular or linear course deviation mode.



6. Lastly, make sure the HSI SOURCE switch in your aircraft is set to RNAV; otherwise, we will not see the RNAV information displayed on the HSI.



7. To fly directly to the displaced VOR waypoint at our destination airport, simply rotate the omni-bearing selector (OBS) or course (CRS) knob on your HSI, as you would to fly to a VOR, and follow the CDI needle with a TO indication. Countdown the distance and time remaining until arriving at your destination with the DME information provided on the KNS-80. When you have arrived, the TO/FROM indication will reverse, and DME distance will approach zero, just like with a conventional VOR receiver. Even at distances of 40 nm, this system is usually precise enough to place your route of flight inside the airport perimeter fence at your destination.

Normal Checklists

*Amphibious Model Only

Before Starting Engine

Preflight Inspection	Complete
Passenger Cabin Doors	Unlocked
Cabin Doors	Latched
Parking Brake	Set
Control Lock	Removed
Seats & Seatbelts	Secure
Switches	Off
*Landing Gear	Up Water/Down Land
Ignition Switch	Norm
Circuit Breakers	All In
Fuel Selectors	Both On
Oxygen Pressure	1850 psi
Ventilation & A/C	Off
Bleed Air Heat	Off
Cabin Mixing Air	FLT-PUSH
Emergency Power Lever	Normal
Power Lever	Idle
Propeller Lever	Full Forward
Fuel Condition Lever	Cutoff
Fuel Cutoff	Pushed In
Firewall Valve	Pushed In
Battery Switch	On
Annunciators	Test
Fire Detector/Warning	Test
Flap Lever	Up
No Smoking/Seatbelt Lights	As Required

Engine Start (Battery)

Beacon Light	On
Avionics Switch 1	On
Bus Volts	24V Min.
Emergency Power Annun	Extinguished
Propeller Area	Clear
Fuel Boost Pump	On
Fuel Press Low Annun	Extinguished
Fuel Flow	None
Starter Switch	Start
Oil Pressure	Rising
Ng RPM Stable	Greater than 12%
Fuel Condition Lever	Low Idle
Fuel Flow	90 to 140 lb/hr
ITT	1090 max. 2s
Ng RPM	Greater than 52%
Starter Switch	Off
Starter Engaged Annun	Extinguished
Engine Instruments	Check
Generator Switch	Reset
Generator Load	Positive
Battery Charging Current	Negative
Gen Off Annun	Extinguished
Fuel Boost Pump	Norm

Fuel Boost Pump Annun	Extinguished
Weather Radar	Off/Standby
Avionics Switch 2	On
Nav Lights	As Required
Suction	Check
Remote Compass	Slaved & Aligned
Ventilation & Defrost	As Required
Radios	Check

Engine Start (External Power)

Beacon Light	On
Avionics Switch 1	On
Battery Volts	20V Min.
External Power	Bus
Bus Volts	24-28.5V
Emergency Power Annun	Extinguished
Propeller Area	Clear
Fuel Boost Pump	On
Fuel Press Low Annun	Extinguished
Fuel Flow	None
Starter Switch	Start
Oil Pressure	Rising
Ng RPM Stable	Greater than 12%
Fuel Condition Lever	Low Idle
Fuel Flow	90 to 140 lb/hr
ITT	1090 max. 2s
Ng RPM	Greater than 52%
Starter Switch	Off
Starter Engaged Annun	Extinguished
Engine Instruments	Check
Generator Switch	Reset
Generator Load	Positive
Gen Off Annun	Extinguished
External Power	Off
Battery Charging Current	Negative
Fuel Boost Pump	Norm
Fuel Boost Pump Annun	Extinguished
Weather Radar	Off/Standby
Avionics Switch 2	On
Nav Lights	As Required
Suction	Check
Remote Compass	Slaved & Aligned
Ventilation & Defrost	As Required
Radios	Check

Taxi

Flight Instruments	Set & Check
Cabin Lights	Off
Cockpit Lighting	Dim for Taxi
Taxi/Recog Light	As Required
Inertial Separator	As Required
Parking Brake	Release
Brakes	Test
Remote Compass	Aligned
*Water Rudder	Down Water/Up Land

Before Takeoff (Runup)

Parking Brake	Set
Seats & Seatbelts	Secure
Flight Controls	Free & Correct
Standby Alternator	On
Standby Alternator	Check Zero Amps
Generator Load	Load to 30-60 Amps
Generator Switch	Trip
Standby Alternator Load	Positive
Generator Switch	Reset
Fuel Boost Pump	Norm
Fuel Selectors	Both On
Fuel Quantity	Check
Fuel Cutoff	Push In
Trims	Set for T/O
Flaps	10 (Norm) 20 (Short
Field)	
Power Lever	400 ft-lbs
Suction	Check
Bus Volts	24V Min.
Inertial Separator	On
ITT	Check Increase
Inertial Separator	Off
Engine Instruments	Check
Power Lever	1800 RPM
Overspeed Governor	Press & Hold
Propeller RPM	Check (1750 +/-60
RPM)	
Power Lever	Idle
Pitot Heat	On
Generator Load	Increase
Pitot Heat	Off
Windshield Anti-Ice	On
Generator Load	Increase
Windshield Anti-Ice	Off
Propeller De-Ice	On
Propeller Amps	20-24 Amps
Propeller De-Ice	Off
Airframe De-Ice	On
Airframe De-Ice Annun	Observe Cycle
Airframe De-Ice	Off
Pitot Heat	On if OAT less than 4c
Ice Protection	As Required
Heading Bug	30 Degrees Left
Autopilot Heading Mode	Engage
Yoke Movement	Observe
Heading Bug	30 Degrees Right
Yoke Movement	Observe
Autopilot Disconnect	Test
Autopilot	Set for Climb
Battery Charging Current	Less than 10A
Weather Radar	As Required
Strobe Lights	As Required
Annunciators	Test & Consider
Flight Instruments	Set & Check
Storm Windows	Closed
Cabin Mixing Air	FLT-PUSH
Fuel Condition Lever	High Idle
Parking Brake	Release

Takeoff

Transponder	ALT Mode
Landing Lights	On
Inertial Separator	As Required
*Water Rudder	Up
Power Lever	Set for T/O (See POH)
Annunciators	Check
Engine Instruments	Green
Brakes	Release
ITT	805 max
*Landing Gear Up	No Rwy Remaining
Flaps	Retract at 95kts

Max Performance Climb

Propeller Lever	1900 RPM
Power Lever	1865 ft-lbs
ITT	Less than 765
Air Conditioning / Heat	As Required

Enroute Climb

Pitot Heat	On if OAT less than 4c
Ice Protection	As Required
Propeller Lever	1600-1900 RPM
Power Lever	1865 ft-lbs
ITT	Less than 740
Air Conditioning / Heat	As Required

Cruise

Landing & Taxi Lights	Off
Pitot Heat	On if OAT less than 4c
Ice Protection	As Required
No Smoking/Seatbelt Lights	As Required
Oxygen	As Required
Inertial Separator	As Required
Propeller Lever	1600-1900 RPM
Power Lever	Set for Cruise (See
POH)	

Descent

Pitot Heat	On if OAT less than 4c
Ice Protection	As Required
No Smoking/Seatbelt Lights	On
Propeller Lever	1600-1900 RPM
Power Lever	Reduce

Before Landing

Seats & Seatbelts	Secure
Fuel Selectors	Both On
Oxygen	Off
Landing Lights	On
Inertial Separator	As Required
Condition Lever	High Idle
Propeller Lever	Full Forward

Flaps
*Landing Gear
*Water Rudder
Autopilot

As Required
Up Water/Down Land
Up
Disconnect

Propeller RPM:
1600-1900 RPM (GREEN)
1900 RPM (RED)

Landing

Flaps
Power Lever
Brake
Power Lever

Full
Beta after Landing
As Required
Idle before 25kts

Interstage Turbine Temperature (ITT):
100-740 °C (GREEN)
765-805 °C (YELLOW)
805 °C (RED)
1090 °C (RED)

Balked Landing

Power Lever
Flaps
Airspeed
*Landing Gear Up
Flaps

Set for T/O (See POH)
20 Degrees
80kts min.
No Rwy Remain
Retract when Safe

Gas Generator RPM (Ng):
520-102% (GREEN)
102% (RED)

Oil Pressure:
40-85 psi (YELLOW)
85-105 psi (GREEN)
105 psi (RED)

After Landing

*Water Rudder
Flaps
Pitot Heat
Ice Protection
Strobe Lights
Taxi/Recog Light
Landing Lights
Condition Lever
Weather Radar
Inertial Separator

Down Water/Up Land
Up
Off
Off
Off
On
Off
Low Idle
Off/Standby
As Required

Oil Temperature:
-40-40 °C (YELLOW)
40-104 °C (GREEN)
104 °C (RED)

Fuel Flow:
0 PPH (MINIMUM)
500 PPH (MAXIMUM)

Shutdown & Securing

Parking Brake
Avionics
Standby Alternator
Fuel Boost Pump
Heat & A/C
Power Lever
Propeller Lever
Condition Lever
Exterior Lights
Battery Switch
Fuel Selectors
Oxygen
Inertial Separator

Set
Off
Off
Off
Off
Idle for 1 min
Feather
Cutoff
Off
Off
Both Off
Off
Off

Fuel Quantity:
0 lbs / 0 gal (MINIMUM)
1100 lbs / 160 gal (MAXIMUM)

Oxygen Pressure:
0-500 psi (YELLOW)
1550-1850 psi (GREEN)
1950-2000 psi (RED)

Vacuum Suction:
4.5-5.5 inHg to 15,000 ft (GREEN)
4.0-5.5 inHg to 20,000 ft (GREEN)
3.5-4.0 inHg to 25,000 ft (GREEN)
3.0-3.5 inHg to 30,000 ft (GREEN)

Instrument Markings & Colors

Propeller Torque:
0-1970 ft-lbs (GREEN)
1865 ft-lbs (RED)
1970 ft-lbs (RED)

Propeller Ammeter:
20-24 amps (GREEN)

Airspeed Indicator:
SEE V-SPEEDS

Abnormal & Emergency Checklists

Engine Fire (Ground)

Condition Lever	Cutoff
Ignition Switch	Norm
Fuel Cutoff	Pull Out
Fuel Selectors	Both Off
Starter Switch	Motor
Observe	If fire continues...
Battery Switch	Off

Engine Failure (Takeoff)

Power Lever	Idle
Braking	Maximum
Flaps	Retract
Condition Lever	Cutoff
Fuel Cutoff	Pull Out
Fuel Selectors	Both Off
Battery Switch	Off

Engine Failure (In Flight)

Airspeed	95 kts
Fuel Cutoff	Push In
Fuel Selectors	Both On
Fuel Boost Pump	On
Ignition Switch	Norm
Engine Power	If Not Restored...
Flaps	Retract
Propeller Lever	Feather
Airspeed	97 kts
Air Conditioning	Off
Nonessential Equipment	Off
Favorable Landing Site	Select

Engine Fire (In Flight)

Power Lever	Idle
Propeller Lever	Feather
Condition Lever	Cutoff
Fuel Cutoff	Pull Out
Firewall Valve	Pull Out
Cockpit Vents	Push Off
Ventilation Fans	Maximum
Overhead Fans	Maximum
Flaps	20 Degrees
Favorable Landing Site	Select

Starter Does Not Disengage

Battery Switch	Off
External Power	Off
Condition Lever	Cutoff

Hot or Hung Start

Condition Lever	Cutoff
Starter Switch	Motor
Starter Switch	Off when ITT > 400

Engine Clearing

Propeller Lever	Feather
Condition Lever	Cutoff
Power Lever	Idle
Starter Switch	Motor
Starter Switch	Off after 30s

Engine Surges

Power Lever	Reduce
Observe	If Surging is Severe...
Power Lever	Idle
Land	As Soon as Practical

CHIP DETECTOR Illuminated

Possible Engine Failure	Anticipate
Power Lever	Reduce
Land	As Soon as Practical

Fuel Control Unit Failure

Power Lever	Idle
Emergency Power Lever	As Required
Ng RPM	Greater than 65%

Fuel Imbalance

Coordinated Flight	Maintain
If Fuel Imbalance...	Greater than 200lbs
Fuel Selector	Emptiest Off
Fuel Flow	Monitor
When Fuel Balance...	Restored
Fuel Selectors	Both On

Prop Governor Failure

Power Lever	Reduce
Oil Pressure	Check
Exercise Propeller	If No Control...
Airspeed	Reduce
Power Lever	To Maintain RPM
Land	As Soon as Practical

Battery Overheat (AMBER Annun.)

Battery Switch	Off
Battery Charging Current	If Charging...
Generator Switch	Trip
Standby Alternator	Off
Bus Circuit Breakers	Pull Off (6)
Avionics	Off
Standby Alternator	On
Standby Avionics Power	On
Standby Bus Tie	On
Standby Alternator Load	Monitor

Battery Hot (RED Annun.)

Battery Switch	Off
Generator Switch	Trip
Standby Alternator	Off
Bus Circuit Breakers	Pull Off (6)
Avionics	Off
Standby Alternator	On
Standby Avionics Power	On
Standby Bus Tie	On
Standby Alternator Load	Monitor

Generator Failure

Bus Volts	If less than 25V...
Circuit Breakers	Check In
Generator Load	If Zero...
Generator Circuit Breakers	Check In
Generator Switch	Reset
Generator Load	If Zero...
Generator Load	Reduce
Avionics 2	Off
Air Conditioning / Heat	Off
Ice Protection	Off
Exterior Lights	Off
Generator Circuit Breakers	Pull Off
Standby Alternator	On
Standby Alternator Load	Monitor

Electrical Fire

Battery Switch	Off
Generator Switch	Trip
Standby Alternator	Off
Cockpit Vents	Push Off
Air Conditioning / Heat	Off
Oxygen	On & Use
Avionics	Off
Bus Circuit Breakers	Pull Off (8)
Restore Essential Power	Bus by bus
Restore Essential Power	Circuit by Circuit

Severe Icing Encounter

Ignition Switch	On
Inertial Separator	On
Ice Protection	All On
Ice Inspection Light	On
Ice Build-Up	Monitor
Propeller Lever	1900 RPM
Bleed Air Heat	On
Temperature Control	Maximum
Defrost & Mixing Air	Full On

Air Start with Starter (Preferred)

Generator Load	Reduce
Standby Alternator	Off
Avionics	Off
Ignition Switch	Norm
Air Conditioning / Heat	Off
Emergency Power Lever	Normal
Power Lever	Idle
Propeller Lever	Minimum RPM
Condition Lever	Cutoff
Fuel Cutoff	Push In
Fuel Selectors	Both On
Battery Switch	On
Fuel Boost Pump	On
Aux Fuel Pump Annun	Illuminated
Fuel Press Low Annun	Extinguished
Altitude	Less than 20,000 ft
Starter Switch	Start
Ignition Annun	Illuminated
Oil Pressure	Rising
Ng RPM Rising	Greater than 12%
Condition Lever	Low Idle
ITT	1090 max. 2s
Ng RPM	Greater than 52%
Starter Switch	Off
Ignition Switch	As Required
Fuel Boost Pump	Norm
Condition Lever	High Idle

Air Start Windmilling

Generator Switch	Trip
Standby Alternator	Off
Avionics	Off
Air Conditioning / Heat	Off
Emergency Power Lever	Normal
Power Lever	Idle
Propeller Lever	Minimum RPM
Condition Lever	Cutoff
Fuel Cutoff	Push In
Fuel Selectors	Both On
Battery Switch	On
Fuel Boost Pump	On
Aux Fuel Pump Annun	Illuminated
Fuel Press Low Annun	Extinguished
Ignition Switch	On

Airspeed
Altitude
Ng
Condition Lever
ITT
Ng RPM
Ignition Switch
Fuel Boost Pump
Condition Lever
Generator Switch

Greater than 100 kias
Less than 20,000 ft
Non-Zero
Low Idle
1090 max. 2s
Greater than 52%
As Required
Norm
High Idle
Reset

Emergency Descent

Seats & Seatbelts	Secure
Power Lever	Idle
Propeller Lever	Full Forward
Flaps	10 Degrees
Airspeed	175 kts

Maximum Glide

Flaps	Retract
Propeller Lever	Feather
Airspeed	97 kts
Air Conditioning	Off
Nonessential Equipment	Off

Flap Failure

Flap Circuit Breakers	Check In
Standby Flap Mode	Standby
Standby Flap Motor	As Desired

*Landing Gear Manual Extension

Amphib Gear Motor	Pull Off
Landing Gear	Handle Down
Manual Gear Select	Gear Down
Pump Handle	20+ Pumps
Gear Indicators	Four Green

*Landing Gear Up after Manual Extension

Manual Gear Select	Gear Up
Amphib Gear Motor	Push On
Landing Gear	Handle Up
Gear Indicators	Four Blue

Remote Compass Misalignment

Gyro Slave Circuit Breaker	Pull & Reset
Remote Compass Alignment	If Misaligned...
Remote Compass	Free Mode
Compass Position	Slew to Mag. Heading

Autopilot Failure or Trim Runaway

Autopilot	Disconnect
Autopilot Circuit Breakers	Pull Off

Cabin Door Open

Airspeed	Reduce
Increased Drag	Anticipate
Land	As Soon as Practical

More Information on Operation

Black Square aircraft are created by an avid pilot who believes that every switch, knob, and button should be interactable, and the user should be able to follow real world procedures without compromising results from the simulation. This aircraft was designed and tested using real world handbooks and procedures, and leaves little to the imagination in terms of functionality. For the most immersive experience, it's recommended that you seek out manuals, handbooks, checklists, and performance charts from the real aircraft represented in this simulation. Although this aircraft and simulation is not suitable for real world training, and should not be used for such, every effort has been taken to ensure that the simulation will represent the real aircraft until the fringe cases of instrument flying, or system failure.

In the case of this particular product, featuring the KNS-80 Navigation System, and the RDR 1150XL, additional resources are available online for the real world counterparts of these units. In particular the **“KNS-80 Pilot's Guide”**, available on Bendix/King's website, and the **“Weather Radar Pilot Training DVD”** on Bendix/King's YouTube channel. Additionally, the **“KLN-90B Pilot's Guide”** is also available on Bendix/King's website.

Hardware Inputs & Outputs

A nearly complete list of input and output variables and events is provided below for home cockpit builders. If this list is not enough to accomplish the amount of interactivity you are looking to achieve in your home cockpit, anything is possible with a little code. Nothing in any Black Square aircraft is "hard coded", or made inaccessible behind encrypted or compiled files. If you have further questions, contact Just Flight Support, or reach out to me directly in the Just Flight Community forums, where I will be happy to help.

Inputs

Exterior & Cabin Element Variables

Description	Variable	Range
Yoke Control Lock	L:bksq_ControlLocks	Boolean
Rudder Lock	L:bksq_RudderLock	Boolean
Pitot Covers	L:bksq_PitotCovers	Boolean
Engine Covers	L:bksq_EngineCovers	Boolean
Wheel Chocks	L:bksq_WheelChocks	Boolean
Tablet Visibility	L:bksq_TabletVisible	Boolean
Tablet Horizontal Position	L:var_efb_rot_x	-1 - 1
Tablet Vertical Position	L:var_efb_rot_y	-1 - 1
Cargo Pod Doors	L:bksq_CargoPodDoors	Boolean
Pilot's Window	L:bksq_StormWindow	Boolean
Copilot's Door Override	L:var_DoorLockOverride	Boolean
Pilot's Sun Visor Position	L:var_Visor_L	0 - 100
Copilot's Sun Visor Position	L:var_Visor_R	0 - 100
Pilot's Left Armrest	L:var_ArmrestLL	0 - 100
Pilot's Right Armrest	L:var_ArmrestLR	0 - 100
Copilot's Left Armrest	L:var_ArmrestRL	0 - 100
Copilot's Right Armrest	L:var_ArmrestRR	0 - 100

Primary Control Variables

Description	Variable	Range
Hide Pilot's Yoke	L:XMLVAR_YokeHidden1	Boolean
Hide Copilot's Yoke	L:XMLVAR_YokeHidden2	Boolean
Control Wheel Steering Yoke Button	L:var_PilotCws	Boolean
Emergency Power Control Lever	L:var_emergencyPowerLeverPosition	0 - 100
Inertial Separator Pull Handle	L:XMLVAR_InterSep	Boolean
External Power Switch Cover	L:var_ExternalPowerCover	Boolean
External Power Switch	L:var_ExternalPowerSwitch	1=Starter, 2=Bus
Generator Switch	L:var_GeneratorSwitch	1=Reset, 2=Trip
Fuel Boost Pump Switch	L:var_FuelPumpSwitch	1=Norm, 2=On
Standby Alternator Switch	L:var_StandbyAlternatorSwitch	Boolean
Standby Avionics Power Switch Cover	L:var_StandbyAvionicsPowerCover	Boolean
Avionics Bus Tie Switch Cover	L:var_AvionicsBusTieCover	Boolean
Standby Avionics Power Switch	L:var_StandbyAvionicsPowerSwitch	Boolean
Avionics Bus Tie Switch	L:var_AvionicsBusTieSwitch	Boolean
Pitot Heat Switch	L:var_PitotHeat_L	Boolean
Stall Warning Heat Switch	L:var_PitotHeat_R	Boolean
Windshield Deicing Switch	L:var_WindshieldDeiceSwitch	0=Auto, 2=Man
Propeller Heat Switch	L:var_PropDeiceSwitch	0=Auto, 2=Man
Airframe Deicing Boots Switch	L:var_AirframeDeiceSwitch	0=Auto, 2=Man
Friction Lock	L:var_FrictionLockKnob	0 - 100
Fuel Cutoff Pull Handle	L:var_FuelCutoffHandle	0 - 100
Firewall Cutoff Pull Handle	L:var_FirewallCutoffHandle	0 - 100
Prop Governor Overspeed Test Button	L:var_PropOverspeedTestButton	Boolean
Fire Detector Test Button	L:var_FireTest	Boolean
Annunciator Panel Test Button	L:var_AnnunciatorLightTestButton	Boolean

Annunciator Dimming Switch	L:var_AnnunciatorDim	Boolean
Electrical Multimeter Mode	L:var_meterMode	0-3
Alternate Static Air Pull Handle	L:XMLVAR_Cabin_Air_8_Position	0 - 100
Standby Flap Actuator Switch Cover	L:var_StandbyFlapMovementCover	Boolean
Standby Flap Mode Switch Cover	L:var_StandbyFlapModeCover	Boolean
Standby Flap Actuator Switch	L:var_StandbyFlapMovementSwitch	Boolean
Standby Flap Mode Switch	L:Flap_Stby_Mode_Switch	Boolean
Water Rudder Handle	L:var_WaterRudderHandle	0 - 100
Amphibious Gear Pump Selector	L:var_AmphibianManualGearSelector	0 - 100
Amphibious Gear Pump Handle	L:var_ManualGearHandle	Boolean
Amphibious Gear Warning Cancel	L:var_GearAdvisoryLatching	2=Cancel

Lighting Control Events & Variables

Description	Variable	Range
Wing/Ice Light	B:LIGHTING_WING_1_Toggle (K:TOGGLE_WING_LIGHTS)	
Taxi Light	B:LIGHTING_TAXI_1_Toggle (K:TOGGLE_TAXI_LIGHTS)	
Left Landing Light	B:LIGHTING_LANDING_1_Toggle (1 K:LANDING_LIGHTS_SET)	
Right Landing Light	B:LIGHTING_LANDING_2_Toggle (2 K:LANDING_LIGHTS_SET)	
Strobe Lights	B:LIGHTING_STROBE_1_Toggle (K:STROBES_TOGGLE)	
Navigation Lights	B:LIGHTING_NAVIGATION_1_Toggle (K:TOGGLE_NAV_LIGHTS)	
Beacon Light	B:LIGHTING_BEACON_1_Toggle (K:TOGGLE_BEACON_LIGHTS)	
No Smoking Sign	L:var_NoSmokingSign	Boolean
Seat Belt Sign	L:var_SeatbeltSign	Boolean
Cabin Overhead Lights	L:var_CabinLights	Boolean

Pilot's Panel Lights	L:var_PanellightKnob_L	0 - 100
Copilot's Panel Lights	L:var_PanellightKnob_R	0 - 100
Engine Instrument Lights	L:var_EngineInstrumentLightsKnob	0 - 100
Pilot's Panel Flood Light	L:var_FloodLightKnob_L	0 - 100
Copilot's Panel Flood Light	L:var_FloodLightKnob_R	0 - 100
Pedestal Flood Light	L:var_PedestalLightKnob	0 - 100
Circuit Breaker Panel Lights	L:var_CircuitBreakerLightKnob	0 - 100
Radio/Avionics Lighting Dimmer	L:var_RadioLightsKnob	0 - 100

Environmental Control Variables

Description	Variable	Range
Oxygen Flow Valve	L:var_OxygenOn	Boolean
Pilot Ram Air Door	L:XMLVAR_Cabin_Air_1_Position	0 - 100
Copilot Ram Air Door	L:XMLVAR_Cabin_Air_2_Position	0 - 100
Bleed Air Cabin Heat Mixing Valve	L:XMLVAR_Cabin_Air_3_Position	0 - 100
Fore-Aft Cabin Diverter Valve	L:XMLVAR_Cabin_Air_4_Position	0 - 100
Defroster Valve	L:XMLVAR_Cabin_Air_5_Position	0 - 100
Left Wing Cabin Air Inlet	L:var_OverheadFan_L	0 - 100
Right Wing Cabin Air Inlet	L:var_OverheadFan_R	0 - 100
Cabin Temperature Target Knob	L:var_CabinTemperatureKnob	50 - 100
Bleed Air Heat Switch	L:var_BleedAirSwitch	Boolean
Ventilation Mode Switch	L:var_AirconMode	0=AC, 2=Ventilate
Left A/C Fan Speed Switch	L:var_AirConditioningFan_L	Boolean
Aft A/C Fan Speed Switch	L:var_AirConditioningFan_Aft	Boolean
Right A/C Fan Speed Switch	L:var_AirConditioningFan_R	Boolean

Instrument Variables

Description	Variable	Range
RNAV Drives HSI	L:var_rnavDrivesHsi	Boolean
Gyro Slaving Mode	L:var_GyroSlaveModeSwitch	Boolean
Dme Mode	L:var_dmeMode	0 - 4
True Airspeed Calculator	L:var_trueAirspeedRing	0 - 100

Primary Control Events Events

Description	Event
Condition Lever	B:FUEL_1_Condition_Lever_High_Idle B:FUEL_1_Condition_Lever_Low_Idle B:FUEL_1_Condition_Lever_Cut_Off
Battery Master Switch	K:BATTERY1_SET
Avionics Bus 1 Master Switch	B:ELECTRICAL_Avionics_Bus_1_Toggle
Avionics Bus 2 Master Switch	B:ELECTRICAL_Avionics_Bus_2_Toggle
Ignition Switch	B:ENGINE_Ignition_1_Set
Starter Switch	B:ENGINE_Starter_Ignition_1_Set

Instrument Events

Description	Variable
Autopilot Master	H:KAP140_Push_AP (K:AP_MASTER)
Autopilot Heading Mode	H:KAP140_Push_HDG (K:AP_PANEL_HEADING_HOLD)
Autopilot NAV Mode	H:KAP140_Push_NAV (K:AP_NAV1_HOLD)
Autopilot Approach Mode	H:KAP140_Push_APR (K:AP_APR_HOLD)
Autopilot Backcourse Mode	H:KAP140_Push_REV (K:AP_BC_HOLD)
Autopilot Altitude Hold Mode	H:KAP140_Push_ALT (K:AP_ALT_HOLD)
Autopilot UP Button	H:AUTOPILOT_Push_VerticalSpeed_UP_1

Autopilot DOWN Button	H:AUTOPILOT_Push_VerticalSpeed_DOWN_1
Autopilot ARM Button	H:KAP140_Push_ARM
Autopilot BARO Adjust Button	H:KAP140_Push_BARO
Autopilot Outer Knob	H:KAP140_Knob_Outer_INC / H:KAP140_Knob_Outer_DEC
Autopilot Inner Knob	H:KAP140_Knob_Inner_INC / H:KAP140_Knob_Inner_DEC
Power Lever Go-Around Mode	K:AUTO_THROTTLE_TO_GA
Autopilot & Flight Director Disengage	K:AUTOPILOT_DISENGAGE_TOGGLE
Transponder Ident	K:XPNDR_IDENT_ON
VLOC/GPS (when using GNS 530)	K:TOGGLE_GPS_DRIVES_NAV1 (H:AS530_CDI_Push)
Toggle COM1 Receive	K:COM1_RECEIVE_SELECT
Toggle COM2 Receive	K:COM2_RECEIVE_SELECT
Toggle COM3 Receive	K:COM3_RECEIVE_SELECT
Toggle NAV1 Receive	K:RADIO_VOR1_IDENT_TOGGLE
Toggle NAV2 Receive	K:RADIO_VOR2_IDENT_TOGGLE
Toggle ADF Receive	K:RADIO_ADF_IDENT_TOGGLE
Toggle DME Receive	K:RADIO_DME1_IDENT_TOGGLE
Toggle Marker Receive	K:MARKER_SOUND_TOGGLE
Toggle Marker High Sensitivity	K:MARKER_BEACON_SENSITIVITY_HIGH
Toggle RNAV Receive	K:RADIO_VOR3_IDENT_TOGGLE
Altimeter Baro Increase	K:KOHLSMAN_INC
Altimeter Baro Decrease	K:KOHLSMAN_DEC
Decision Height Increase	K:INCREASE_DECISION_HEIGHT
Decision Height Decrease	K:DECREASE_DECISION_HEIGHT

Avionics Variables & Events

Not all variable and event names are listed here for multiple instances of avionics. For instance, to control a GTN 650, just replace “GTN750” with “GTN650”, or “H:AS530_1_MENU_Push” with “H:AS430_1_MENU_Push”. For communications radios, change the index to the corresponding radio, such as “K:COM1_VOLUME_INC” to “K:COM2_VOLUME_INC”. For Black Square aircraft with multiple GNS 530 units installed, increment the index, as well, such as “H:AS530_1_DRCT_Push” to “H:AS530_2_DRCT_Push”.

PMS50 GTN

Description	Variable or Event
Volume Knob Set	L:GTN750_Vol
Volume Knob Increase	H:GTN750_VolInc
Volume Knob Decrease	H:GTN750_VolDec
Home Button	H:GTN750_HomePush
Direct-To Button	H:GTN750_DirectToPush
Inner Knob Increase	H:GTN750_KnobSmallInc
Inner Knob Decrease	H:GTN750_KnobSmallDec
Knob Push	H:GTN750_KnobPush
Outer Knob Increase	H:GTN750_KnobLargeInc
Outer Knob Decrease	H:GTN750_KnobLargeDec

TDS GTNxi

Description	Variable or Event
Volume Knob Increase	L:TDSGTNxi750U1_LKnobInc
Volume Knob Decrease	L:TDSGTNxi750U1_LKnobDec
Home Button	L:TDSGTNxi750U1_HomeKey
Direct-To Button	L:TDSGTNxi750U1_DTOKey
Inner Knob Increase	L:TDSGTNxi750U1_RKnobInnerInc
Inner Knob Decrease	L:TDSGTNxi750U1_RKnobInnerDec

Knob Push	L:TDSGTNXI750U1_RKnobCRSR
Outer Knob Increase	L:TDSGTNXI750U1_RKnobOuterInc
Outer Knob Decrease	L:TDSGTNXI750U1_RKnobOuterDec

Working Title GNS 530

Description	Variable or Event
COM Volume Knob Increase	K:COM1_VOLUME_INC
COM Volume Knob Decrease	K:COM1_VOLUME_DEC
NAV Volume Knob Increase	K:NAV1_VOLUME_INC
NAV Volume Knob Decrease	K:NAV1_VOLUME_DEC
Radio Knob Push	H:AS530_1_LeftSmallKnob_Push
Radio Inner Knob Right	H:AS530_1_LeftSmallKnob_Right
Radio Inner Knob Left	H:AS530_1_LeftSmallKnob_Left
Radio Outer Knob Right	H:AS530_1_LeftLargeKnob_Right
Radio Outer Knob Left	H:AS530_1_LeftLargeKnob_Left
GPS Knob Push	H:AS530_1_RightSmallKnob_Push
GPS Inner Knob Right	H:AS530_1_RightSmallKnob_Right
GPS Inner Knob Left	H:AS530_1_RightSmallKnob_Left
GPS Outer Knob Right	H:AS530_1_RightLargeKnob_Right
GPS Outer Knob Left	H:AS530_1_RightLargeKnob_Left
Direct-To Button	H:AS530_1_DRCT_Push
Menu Button	H:AS530_1_MENU_Push
Clear Button Short	H:AS530_1_CLR_Push
Clear Button Long	H:AS530_1_CLR_Push_Long
Enter button	H:AS530_1_ENT_Push
COM Swap Button	H:AS530_1_COMSWAP_Push
NAV Swap Button	H:AS530_1_NAVSWAP_Push
NAV Ident Button	H:AS530_1_ID

CDI Button	H:AS530_1_CDI_Push
OBS Button	H:AS530_1_OBS_Push
Message Button	H:AS530_1_MSG_Push
Flightplan Button	H:AS530_1_FPL_Push
VNAV button	H:AS530_1_VNAV_Push
Procedure Button	H:AS530_1_PROC_Push

KLN90B

Description	Variable or Event
Brightness Knob Increase	H:KLN90B_Brt_Inc
Brightness Knob Decrease	H:KLN90B_Brt_Dec
Power Knob Push/Pull	H:KLN90B_Power_Toggle
Left Knob Outer Right	H:KLN90B_LeftLargeKnob_Right
Left Knob Outer Left	H:KLN90B_LeftLargeKnob_Left
Right Knob Outer Right	H:KLN90B_RightLargeKnob_Right
Right Knob Outer Left	H:KLN90B_RightLargeKnob_Left
Left Knob Inner Right	H:KLN90B_LeftSmallKnob_Right
Left Knob Inner Left	H:KLN90B_LeftSmallKnob_Left
Right Knob Inner Right	H:KLN90B_RightSmallKnob_Right
Right Knob Inner Left	H:KLN90B_RightSmallKnob_Left
Right Knob (Scan) Push/Pull	H:KLN90B_RightScan_Toggle
Left Cursor Button	H:KLN90B_LeftCursor_Toggle
Right Cursor Button	H:KLN90B_RightCursor_Toggle
Message Button	H:KLN90B_MSG_Push
Altitude Button	H:KLN90B_ALT_Push
Direct Button	H:KLN90B_DCT_Push
Clear Button	H:KLN90B_CLR_Push
Enter Button	H:KLN90B_ENT_Push

MD41 Approach Arm Button	H:KLN90B_ApprArm_Push
MD41 OBS Button	K:GPS_OBS
MD41 VLOC/GPS Button	K:TOGGLE_GPS_DRIVES_NAV1
MD41 Test Button	L:var_md41Test

KNS80

Description	Variable or Event
Data Knob Outer Increase	H:KNS80_bigInc
Data Knob Outer Decrease	H:KNS80_bigDec
Data Knob Inner Increase	H:KNS80_smallInc
Data Knob Inner Decrease	H:KNS80_smallDec
VOR Mode Button	H:KNS80_vorModeButton
RNAV Mode Button	H:KNS80_rnavModeButton
Hold Button	H:KNS80_dmeHoldButton
Use Button	H:KNS80_useButton
Display Button	H:KNS80_displayButton
Data Entry Knob Push/Pull	L:var_rnavKnobPulled
Volume Knob	L:var_RNAV_VOLUME

KX155B

Description	Variable or Event
COM Knob Outer Increase	H:RADIO1_COM_Knob_Large_INC
COM Knob Outer Decrease	H:RADIO1_COM_Knob_Large_DEC
COM Knob Inner Increase	H:RADIO1_COM_Knob_Small_INC
COM Knob Inner Decrease	H:RADIO1_COM_Knob_Small_DEC
COM Knob Push/Pull	H:RADIO1_COM_Knob_Small_PUSH
NAV Knob Outer Increase	H:RADIO1_NAV_Knob_Large_INC

NAV Knob Outer Decrease	H:RADIO1_NAV_Knob_Large_DEC
NAV Knob Inner Increase	H:RADIO1_NAV_Knob_Small_INC
NAV Knob Inner Decrease	H:RADIO1_NAV_Knob_Small_DEC
NAV Knob Push/Pull	H:RADIO1_NAV_Knob_Small_PUSH
COM Volume Increase	K:COM1_VOLUME_INC
COM Volume Decrease	K:COM1_VOLUME_DEC
COM Frequency Spacing Toggle	H:RADIO1_COM_Freq_Spacing_PUSH
NAV Volume Increase	K:NAV1_VOLUME_INC
NAV Volume Decrease	K:NAV1_VOLUME_DEC
NAV Ident Toggle	K:RADIO_VOR1_IDENT_TOGGLE
COM Swap Button	K:COM1_RADIO_SWAP
NAV Swap Button	K:NAV1_RADIO_SWAP

KR87 ADF

Description	Variable or Event
Tuning Knob Push/Pull	L:var_adfKnobPulled
Tuning Increase by 100	K:ADF_100_INC
Tuning Decrease by 100	K:ADF_100_DEC
Tuning Increase by 10	K:ADF_10_INC
Tuning Decrease by 10	K:ADF_10_DEC
Tuning Increase by 1	K:ADF_1_INC
Tuning Decrease by 1	K:ADF_1_DEC
Antenna Button	H:adf_AntAdf
BFO Button	H:adf_bfo
Frequency Swap Button	H:adf_frqTransfert
Timer Mode Button	H:adf_FltEt
Timer Reset Button	H:adf_SetRst

GTX 327 Transponder

Description	Variable or Event
Off Button	H:TRANSPONDER_Push_OFF
Standby Button	H:TRANSPONDER_Push_STBY
Test Button	H:TRANSPONDER_Push_TST
On Button	H:TRANSPONDER_Push_ON
Altitude Reporting Mode Button	H:TRANSPONDER_Push_ALT
0 Button	H:TRANSPONDER_Push_0
1 Button	H:TRANSPONDER_Push_1
2 Button	H:TRANSPONDER_Push_2
3 Button	H:TRANSPONDER_Push_3
4 Button	H:TRANSPONDER_Push_4
5 Button	H:TRANSPONDER_Push_5
6 Button	H:TRANSPONDER_Push_6
7 Button	H:TRANSPONDER_Push_7
8 Button	H:TRANSPONDER_Push_CLR
9 Button	H:TRANSPONDER_Push_VFR
Function Button	H:TRANSPONDER_Push_FUNC
Cursor Button	H:TRANSPONDER_Push_CRSR

Weather Radar

Description	Variable or Event	Range
Mode Knob	L:var_radarMode	0 - 5
Brightness Knob	L:var_RadarBrightness	0 - 100
Gain Knob	L:var_RadarGain	0 - 100
Tilt Knob	L:var_RadarTilt	0 - 100
Alert Button	H:bksq_wradar1_radarAlertToggle	

Vertical Profile Button	H:bksq_wradar1_radarProfile	
Map Button	H:bksq_wradar1_radarMap	
Hold Button	H:bksq_wradar1_radarHold	
Range Increase Button	H:bksq_wradar1_radarRangeInc	
Range Decrease Button	H:bksq_wradar1_radarRangeDec	
Track Left Button	H:bksq_wradar1_radarTrackLeft	
Track Right Button	H:bksq_wradar1_radarTrackRight	

Outputs

Since the Caravan Professional has many custom underlying simulations beyond that of the native simulator, the following variables should be used to access what would normally be a simulator-level value. If the quantity you are interested in does not appear in this list, it is safe to assume it should be accessed via the native simulator variable.

Aircraft & Engine Variables

Description	Variable	Units
Indicated Airspeed (with pitot error)	L:BKSQ_AIRSPEED_CORRECTED	knots
Propeller Torque	L:BKSQ_CARAVAN_TQ	Number (FT-LBS)
Interstage Turbine Temperature	L:BKSQ_CARAVAN_ITT	Number (°C)
Gas Generator RPM	L:BKSQ_CARAVAN_NG	Number (%)
Left Fuel Pressure	L:BKSQ_CARAVAN_FUELPRESSURE	PSI
Propeller RPM	A:PROP RPM:1	RPM
Left Fuel Flow	L:BKSQ_CARAVAN_FuelFlow	Number (PPH)
Oil Pressure	L:BKSQ_CARAVAN_FUELPRESSURE	PSI
Oil Temperature	L:BKSQ_CARAVAN_OILTEMPERATURE	CELSIUS
Left Fuel Quantity	A:FUEL TANK LEFT MAIN QUANTITY	GALLONS
Right Fuel Quantity	A:FUEL TANK RIGHT MAIN QUANTITY	GALLONS
Turn Coordinator Ball	L:BKSQ_TurnCoordinatorBall	0 - 100
Magnetic Compass (with field error)	L:BKSQ_MagneticCompassHeading	0 - 100
Oxygen Pressure	L:var_oxygenPressure	PSI

Radio Navigation Variables

While these variables may seem redundant, Black Square aircraft incorporate a signal degradation system, and physics based needles. Even the TO-FROM flags exhibit non-boolean behavior for a more realistic experience.

Description	Variable	Range
HSI CDI Needle	L:BKSQ_CARAVAN_HSI_LOC	0 - 100
HSI CDI Flag	L:BKSQ_CARAVAN_HSI_LOC_FLAG	Boolean
HSI Glideslope Needle	L:BKSQ_CARAVAN_HSI_GLIDE	0 - 100

Localizer 2 CDI Needle	L:BKSQ_CARAVAN_LOC_2	0 - 100
Localizer 2 CDI Flag	L:BKSQ_CARAVAN_LOC_2_FLAG	Boolean
Localizer 2 TO Flag	L:BKSQ_CARAVAN_LOC_2_TO_FLAG	0 - 100
Localizer 2 FROM Flag	L:BKSQ_CARAVAN_LOC_2_FROM_FLAG	0 - 100
Localizer 2 Glideslope Needle	L:BKSQ_CARAVAN_GLIDE_2	0 - 100
Localizer 2 Glideslope Flag	L:BKSQ_CARAVAN_LOC_2_GS_FLAG	Boolean
RMI ADF Needle	L:BKSQ_CARAVAN_RMI_ADF_NEEDLE	0 - 100
RMI VOR Needle	L:BKSQ_CARAVAN_RMI_VOR_NEEDLE	0 - 100
RNAV CDI Linear Deviation Mode	L:var_rnavCourseLinearFlag	Boolean
RNAV CDI Approach Deviation Mode	L:var_rnavApproachMode	Boolean
RNAV Data Entry Mode	L:var_rnavDataEntryMode	Number
RNAV Waypoint Number	L:var_RNAV_WAYPOINT_NUMBER	1 - 10
RNAV CDI Needle	L:BKSQ_RNAV_CDI_Degraded	-127 - 127
RNAV CDI TO Flag	L:BKSQ_RNAV_TO_Degraded	0 - 1
RNAV CDI FROM Flag	L:BKSQ_RNAV_FROM_Degraded	0 - 1
RNAV Bearing Pointer	L:BKSQ_RNAV_BRG_Degraded	0 - 360
RNAV DME Distance Output	L:var_RNAV_DME	0.0 - 999.9
RNAV DME Speed Output	L:var_RNAV_DMESPEED	0.0 - 999.9
RNAV Frequency Data Display	A:NAV STANDBY FREQUENCY:3	Hz
RNAV Radial Data Display	L:var_RNAV_RADIAL_NUMBER	0 - 360
RNAV Distance Data Display	L:var_RNAV_DISTANCE_NUMBER	0.0 - 999.9

Annunciator Lights

The over 100 annunciators and indicator lamps in this aircraft are also accessible to home cockpit builders and 3rd party UI creators. There are too many to list here, but they can all be located in the CaravanProfessional_INT.XML. Search for BKSQ_DIMMABLE_ANNUNCIATOR” to find them all. Each one is accessible via an L:Var named according to the “NODE_ID” of the annunciator in the XML file, following the pattern (L:var_#NODE_ID#_readonly, bool).

For example, the master warning annunciator NODE ID is “MasterWarning_EM”, therefore...

The master warning annunciator L:Var is (L:var_#MasterWarning_EM_readonly, bool).

Frequently Asked Questions

How do I open/close or move the tablet interface?

Click the back of the tablet **forward of the circuit breaker panel**. Click the same area to close the tablet. The tablet can be moved by dragging its frame. The tablet can also be moved by dragging the bezel using legacy interaction mode. For advanced users, the tablet position can also be set manually using `L:var_efb_rot_x`, `L:var_efb_rot_y`, and `L:var_efb_dist`.

How do I change which avionics/radios are installed?

The current avionics configuration is selected on the **options page of the tablet interface**. Once you've chosen your avionics, click the confirm button. Wait a few seconds for the change to take effect. For more information, see the "Tablet Interface" section of this manual.

How do I choose between the TDS and PMS GTN 750?

The current avionics configuration is selected on the **options page of the tablet interface**. The "PMS50 - TDS" toggle switch selects which GPS provider is used for the GTN 750/650. For more information, see the "Tablet Interface" section of this manual.

Why does the aircraft crash if I open the cockpit door?

Turn off "Aircraft Stress Damage" in the MSFS realism settings menu. This is the case for almost every addon aircraft with opening doors. The simulator interprets an open door as a catastrophic failure of the airframe.

Is beta range simulated?

Yes! This is a new addition to the Black Square turbine aircraft family. An accurate beta range is now fully simulated and **incorporated into the bottom 15% of forward throttle input travel**. Users who do not create virtual detents or have physical detents on their hardware peripherals will be using beta range anytime their throttle is below 15%. See the "Beta Range" section of this manual for more information on beta range and the new turboprop engine simulation.

Do I have to use the tablet interface to set fuel & payload?

Absolutely not. If you prefer to use the native fuel/payload interface, you may always do so. Be aware that, due to a core simulator bug, the native payload interface may become desynchronized with the actual state of the aircraft. This has no effect on operation, and making any change will resynchronize the native interface.

Why is the autopilot behaving strangely, not changing modes, showing HDG/NAV simultaneously, or not capturing altitudes?

This is indicative of GPS addon incompatibility. Please make sure that you have updated all the avionics packages that you are using, including the TDS GTNxi 750, the PMS50 GTN 750, and the WT GNS 530, and that you do not have any outdated packages, such as the original PMS50 GNS 530 modification.

No additional packages should be required for the autopilot to work correctly with the various GPS choices. The product is tested with ONLY the TDS GTNxi 750, the freeware PMS50 GTN 750, and the free WT GNS 530 marketplace package installed. Please see the “Third Party Navigation & GPS Systems” section of this manual for more information.

Why do my engines always fail or lose health?

Managing a turboprop engine without FADEC or automatic torque limiters may be easier than managing a reciprocating engine in some ways, but damage can happen much more easily. The most likely culprit is exceeding engine torque or ITT limits. Be sure to watch the engine instrumentation and **engine data monitor for flashing exceedance warnings**. See the “Turboprop Engine Operation” section of this manual for more information.

Why does it take so much power to get the aircraft moving?

The aircraft will begin moving on level ground as soon as the power lever is out of the beta range (15% throttle input). As this implementation of beta range may differ from other turboprop aircraft that you are used to flying, it may appear as if significantly more power is required to get the aircraft moving, when **in reality, you’re just advancing the power lever through the beta range**, where almost no thrust is produced. For more information on the realistic beta range implementation in this aircraft, see the “Beta Range” section of this manual.

Why is the GTN 750 GPS or KLN-90B GPS screen black?

Make sure you have the PMS GTN 750 or TDS GTNxi 750 installed properly in your community folder. **The free addon can be obtained for free from the following link.**

<https://pms50.com/msfs/downloads/gtn750-basic/>

Make sure you have the Falcon71 KLN-90B installed properly in your community folder. **The free addon can be obtained for free from the following link.**

<https://github.com/falcon71/kln90b/releases>

For more detailed Installation instructions see the “Installation, Updates & Support” section of this manual.

Why do some switches not work, or avionics logic seem broken?

This is almost always caused by default control binding of hardware peripherals, especially the Honeycomb yoke and throttle system. Due to how the electronics in these peripherals work, they often “spam” their control events, or set them, rather than toggle them. In either case, this can interfere with the operation of more complex aircraft, such as this one. Either create a control binding profile for this aircraft that does not attempt to send control inputs in the same manner as you would for default aircraft, but instead use the suggested method for this aircraft, or seek advice on using 3rd party hardware binding software, such as Axis and Ohs, SPAD.neXt, and FSUIPC.

Can the autopilot track KNS-80 RNAV waypoints?

Yes! This is a new feature in this aircraft. By the nature of how the KNS-80 autopilot has been implemented, it cannot conflict with other GPS sources of navigation; therefore, the KNS-80 can only drive the autopilot’s NAV mode in the no-GPS avionics configuration. For more information, see the “Using the KNS-80 RNAV Navigation System” or the “Bendix/King KNS-80 RNAV Navigation System” section of this manual.

Why is the state of my aircraft and radios not saved/recalled?

In order for the MSFS native state saving to work correctly, you must **shut down MSFS correctly** via the main menu, by clicking “Quit to Desktop”, NOT by pressing the red “X” on the application window, or otherwise terminating the application window.

Why does the engine not fail when limits are clearly exceeded?

The engine will not fail immediately upon limit exceedances, as is true of the real engine. Different engine parameters contribute differently to reducing the health of the engine. The **“Engine Stress Failure” option must also be enabled in the MSFS Assistance menu** for the engine to fail completely. Engine condition can be monitored via the engine pages of the tablet interface, or on the “SYSTEMS” page of the weather radar display.

Why do screens flicker at night when adjusting lighting intensity?

This is a long standing bug in MSFS with some graphics settings and hardware. It happened rarely in MSFS 2020, but constantly in MSFS 2024. **Disabling NanoVG from the “Experimental” menu in General Settings** will stop the flickering in MSFS 2020. (Black Square products do not use legacy XML gauges.) **Using the “Legacy” interaction mode in MSFS 2024** will also eliminate the flickers, as they are caused by the blue control highlight.

Why does pitch control seem overly sensitive in MSFS 2024?

For some reason, control reactivities appear to be much higher by default in MSFS 2024 than MSFS 2020. Since this will affect all aircraft, try changing your hardware sensitivities in the controls menu by clicking the gear icon beside your hardware input device.

Why does the HUD airspeed not match the cockpit instrument?

MSFS only has a very rudimentary sense of Calibrated Airspeed (CAS). Instead, all indicated airspeeds (IAS) are generally assumed to be ideal. In a real aircraft, an airspeed indicator does not always accurately depict the ram pressure at the pitot tube. The angle of attack, flap setting, and installed position of the pitot tube can all affect the airspeed seen by the pilot on the airspeed indicator. For most aircraft, the difference between CAS and IAS is usually only a few knots at high angles of attack. This difference can be as much as 15 kts for the Caravan. As such, it was necessary to calculate an accurate CAS to IAS difference, and apply this to the airspeed indicator to properly reflect the documented stalling speeds. Unfortunately, it is not possible to mirror this value on the simulator's default HUD. For cockpit builders, the accurate airspeed can be accessed using the `L:Var, L:BKSQ_AIRSPEED_CORRECTED`.

Why is it hard to slow the aircraft down after landing on unimproved surfaces or water?

The power lever should be moved into the beta range after touchdown to help slow the aircraft; however, the beta range is locked out while the aircraft is airborne to aid users without hardware throttle detents. Bumpy surfaces or waves can cause the aircraft to become momentarily airborne, thus returning the power lever to flight idle. For the Caravan Professional, consider activating the "Unrestricted Beta Range" option on the tablet's options page to disable this safety lockout.

Change Log

v1.0 - Initial Release (after public preview build)

New Features:

- Improved propeller dynamics to provide better aerodynamic “braking” effect at low power settings, allowing for steeper descents and easier spot landings.
- Changed a configuration parameter and associated code which should provide enhanced engine response during reverse thrust. This also appears to improve secondary aerodynamic effects of the reverse thrust, previously limited by the `prop_reverse_max_vel` parameter.
- More amphibious water sounds to add variation during taxi and takeoff while the floats are in full displacement mode.

Bug Fixes:

- Decoupled propeller animation from the frame rate for smoother transitions to the blurred propeller, due to a lapse in reverse compatibility in MSFS 2024.
- Fixed a dependency, which caused the avionics to fail to load if some files present in other Black Square aircraft were not also present in the Community Folder. Thank you, Trevor from FSElite for your assistance!
- Improved side propeller sounds in external view for better fly-by sounds.
- Improved propeller beta transition sound within cockpit.

Credits

Caravan Professional	Nicholas Cyganski
Publishing	Just Flight
Audio	Boris Audio Works
Liveries	Ryan "ryanbatc" Butterworth
	Tim "TimHH" Scharnhop
Manual	Nicholas Cyganski
Console Testing	Just Flight Testing Team

Dedication

My second aircraft for Microsoft Flight Simulator is dedicated to John A. Orr, a close family friend, and the man without whom I would likely only have had a small fraction of the adventures and experiences in aviation that I have been fortunate enough to have. Soon after getting my pilot's license, John was willing to share fractional ownership of his Piper Warrior with me, potentially risking disaster by letting a newly minted pilot enjoy the freedoms of aircraft ownership. Rather than obsessing over my every move, John taught by example, and I credit him with many of my safe flying strategies. Going far beyond the role of a pilot mentor, John introduced me to all aspects of aircraft ownership, which I've done my best to pass onto others since. As an increasing number of flight schools become disinterested in renting their aircraft, most new pilots find themselves with the ability to fly, but suddenly without anything *to* fly, lacking a personal introduction to aircraft ownership. My other influences, to whom several of my products are now dedicated, have inspired me to pursue certain skills in life, but John inspired me to be generous with those skills and resources, and to share them with the next generation of pilots, engineers, and software developers.

This dedication also appeared at the end of the Analog Caravan manual.

Copyright

©2026 Nicholas C. Cyganski. All rights reserved. All trademarks and brand names are trademarks or registered trademarks of the respective owners and their use herein does not imply any association or endorsement by any third party.



ALSO AVAILABLE

