

Aermacchi MB.339

for Microsoft Flight Simulator

FLIGHT MANUAL
Version 1.4.2 — May 2023



CHANGE LOG

04-May-2023

Version 1.4.2

Minor fixes

- Minor Fix to Pony 1 "100 Anni" special livery
- Fixed incorrect helmet assignment for MLU variant
- Fixed incorrect helmet assignment for PAN backseat figure
- Fixed regression causing external tanks not to work on PAN variant

30-Mar-2023

Version 1.4.1

HOTFIX

- Fixed bug causing the elevator trim needle not to work

29-Mar-2023

Version 1.4.0

100 ANNI UPDATE

- Added 100 Anni Special Livery
- Added working backseat
- Reworked external lights rendering
- Fixed minor animation glitch on pilot stick naimation
- Fixed minor glitch in oxygen dilution control
- Fixed minor glitch in gear silencer
- COM1, COM2, TACAN and VOR/ILS Volume Knob are now functional
- Flood, instruments and formation lights can be adjusted
- Nav lights can be dimmed
- Reworked smoke effect colors
- Solved minor bugs in AHRS/GPS display
- Added flaps and rudder to cockpit model
- Redone glass material

12-Dec-2022

Version 1.3.9

Minor update and new liveries:

- Fixed minor bug preventing GEN switches from working with joypad
- Fixed minor bug causing missing texture in VC
- Minor fix to Peruvian Air Force livery
- Minor fix to Malaysian Air Force livery
- Minor fix to UAE livery
- Added Nigerian Air Force livery
- Added Ghana Air Force livery
- Added Italia Air Force Special Color "Ab Initio"
- Minor tweaks to flight model (higher MOIs, tweaked control effectiveness) for smoother flight behavior
- RECOMPILED WITH SU11 TOOLS

03-Oct-2022

Version 1.3.8

Minor update

- Fixed bug introduced in 1.3.7 preventing NAV distance to show on HSI
- Fixed minor bug in HSI behavior
- Reworked fuel system to overcome limitations in sim GUI:
Wingtip tanks will appear as Auxiliary tanks in the interface, but at least External tanks appear correctly and can be loaded.
- Implemented CDI for pure TACAN (non-VORTAC) stations

28-Sep-2022

Version 1.3.7

Minor update

RECOMPILED FOR SU10

- Fixed wingtip fuel quantity in MLU model
- Fixed minor text misalignment in DATA 2 GPS page
- General optimization of virtual cockpit code
- Rework of virtual cockpit code to solve minimal incompatibility with SU10
- Basic support of Tacan-only stations (bearing/range only if the station is not a VORTAC)
- Moved flight manual to "Docs" folder, as opposed to a SimObject subfolder
- Draft implementation of external tanks functionality:
By setting a load of 150 lbs on STA2 and STA5, it is now possible to load fuel on EXTERNAL1 and EXTERNAL2 tanks.

09-Jan-2022

Version 1.3.6 – 1.3.5 – Quick fix to solve throttle control problems introduced by MSFS update 1.21.18.0 and minor mistake preventing wingtip tanks to show in virtual cockpit.

- Added reference to Asobo Common Template to solve the throttle not working if the user had a physical control bound to THROTTLE LEVER AXIS
- Fixed wingtip tanks visibility introduced in 1.3.5

19-Dec-2021

Version 1.3.4 – Flight model improvements, new livery and other minor fixes

- Improvements to high speed roll rate
- High speed drag is now more realistic (resulting in higher speeds)
- Fixed minor bug in GEN1 and GEN2 needles animation
- Fixed minor bug in the behavior of the gear handle warning light
- Redone smoke effects to fix problems due to SU6 and SU7 changes
- Linked IFF mode knob to MSFS transponder state
- Removed custom high G breathing sound (using default sounds now)
- Implemented canopy defrost command
- Added 214mo Gruppo Special Color
- Cockpit shadowing improvements

15-Sep-2021

Version 1.3.3 – Minor improvements and new liveries

- Added special color liveries for 60th Anniversary of the Freccie Tricolori
- Added older Freccie Tricolori livery
- Fixed bug causing smoke tanks to appear in Virtual Cockpit on A variant
- Changed token weight of pylons to 50 lbs (more realistic value)

- Changed token weight of external fuel tanks to 150 lbs (more realistic value)
- Fixed incorrect A-MLU engine configuration
- Fixed incorrect A-MLU fuel quantity
- Fixed minor glitch in armament panel animation

08-Sep-2021

Version 1.3.2 – Minor improvements and new liveries

- Changed RPM indicator reference variables, as the previous ones did not work as intended after SU5
- Added Pony 0 Special Color for Frecce Tricolori 60th Anniversary
- Added "Al Fursan" livery for aerobatic version
- Added blue smoke for Al Fursan livery
- Added Peruvian Air Force livery
- Increased special effects visibility distance and persistence

27-Aug-2021

Version 1.3.1 – Miscellaneous fixes for Marketplace release

- Fixed bug causing landing/taxi light switch animation not to work
- Fixed bug causing incorrect interaction while pressing the G-Valve test pushbutton
- Fixed reversed animation in Cabin Press switch
- Fixed incorrect material assignment in ejection handle base
- Improved mouse interaction with some knobs (altimeter setting, HDG and CRS)
- Fixed missing description localization for A-MLU version

18-Aug-2021

Version 1.3.0 – NOTE: starting from this version, release numbering will follow the three digit format of the Microsoft Marketplace

- Fixed glitch causing heat blur effect to disappear in certain conditions
- Internal reorganization of 3D models (nodes and hierarchy)
- Added high altitude contrail effect
- Added Sim Update V landing special effects
- Redone ADI and backup ADI animation
- Repackaged to Sim Update V standards
- Improved fuel flow indications, consumption and range*
- Minor improvements to flight model
- Implemented Sim Update V cockpit interface (necessary for Xbox)
- Restored Mouse Drag functionality on many controls
- Fixed minor misalignment of ADI bank needle
- Fixed glitch preventing proper placement of HSI lubber line
- Fixed several minor glitches in virtual cockpit model
- Fixed several minor glitches in external models
- Copilot figure is now optional: will disappear if copilot weight is set to 70lbs or less
- Added backup ADI setting and mouse area
- Added Marker Sensitivity Switch
- Cabin Press switch now functional, also cabin press indications are now more realistic
- VOR and TACAN power switches must now be set to ON to get readings on the HSI
- Added several animations in the cockpit (cosmetic only, may receive proper implementation in future)

- Armament will now display "TANK" if a tank is loaded on a pylon on A and AMLU variants
- Added smoke system (white and colored)**
- Added PAN model variants loaded with green and red smoke

* NOTE: it seems that there still a problem with fuel flow vs. altitude vs. Mach no. dependency in MSFS. This new version implements a new formula to calculate fuel flow indication, which should provide values closer to the real aircraft in many conditions. However, actual fuel consumption (and range) is calculated differently by the sim engine: this is set to provide the best range in most conditions, so actual range of the aircraft can be now overestimated at low altitudes (but should be correct and medium and high altitudes).

** NOTE: the smoke system is implemented to work as in real life, that is, in order to operate it:

- SMOKE switch must be set to ON (this is the master power switch for the smoke system)
 - WHITE switch must be set to ON (this is the power switch for the white tank)
 - COLOR switch must be set to ON (this is the power switch for the color tank)
- ...then, to activate the smoke, you will need to use the following toggle switches (you may want to assign them to stick buttons):

WING LIGHT TOGGLE -> WHITE SMOKE

RECOGNITION LIGHT TOGGLE -> COLOR SMOKE

When the system is working, the relevant advisory lights will illuminate.

The default PAN model has white smoke on both tanks.

Red and Green smoke variants are available as "repaints".

NOTE: due to a simulator bug, effects may not show if activated in the internal views in certain conditions.

12-Apr-2021

Version 1.22

- Updated localization file for World Update IV
- Fixed minor glitch in cockpit view canopy reflection
- Fixed minor glitch causing gunsight to appear on PAN external model

27-Mar-2021

Version 1.21

- Added A-MLU Model (as separate aircraft)
- Improved internal engine sounds (jet whine volume increased)
- Rear pilot figure of MB-339 pan has now HGU-55 helmet and olive drab suit (as most commonly seen IRL)

14-Mar-2021

Version 1.20

Quality of Life improvements:

- remastered all external textures with higher detail
- changed HSI DME last digit animation (now continuous)
- fixed landing gear extraction and damaging speeds
- fixed bug that caused deletion of panel cover if gunsight is removed from A model
- decreased FD vertical bar sensitivity

- changed rule of GS engagement from GS ARM
- improved engine dynamics
- redone Wwise engine sounds, based on real world samples
- fixed minor bug in Tacan/Frequency conversion
- fixed minor bug in RDU display not showing the correct frequencies for COM1 in some case
- added indication of X/Y Tacan channel
- improved cockpit self shadowing
- rear view mirror are now foldable
- added gear warning sound and silencer
- added streamers and covers if the aircraft is parked
- added underwing pylons to A model (add any weight to the relevant load station)
- added external fuel tanks to A model (add at least 51lbs to releval station - cosmetic only)
- fixed VR cockpit collisions
- fixed external light bug introduced by Sim Update 3
- fixed external views HUD
- added g-stain sound
- fixed minor inaccuracies in warning test switch behavior
- fixed minor bug preventing fine adjustment of OBS in some cases
- GPS number keys can now be used to select waypoints (1 to 10)

1-Dec-2020

Version 1.13

Hotfix for vesion 1.12 ADI/GS problem

***** IMPORTANT! STARTING FROM VERSION 1.12 THE PACKAGE HAS BEEN RENAMED TO "indiafoxtecho-mb339" - PLEASE DELETE THE OLDER VERSION AND REPLACE IT WITH THIS NEW ONE ******

- Fixed bug in ADI GS animation
- Fixed bug in FD GS needle animation
- Reduced sensitivity of FS ALT HOLD
- Implemented additional check to engage FD GS from GS ARM

30-Nov-2020

Version 1.12

Quality-of-life update and further refinements to flight model

***** IMPORTANT! STARTING FROM THIS VERSION THE PACKAGE HAS BEEN RENAMED TO "indiafoxtecho-mb339" - PLEASE DELETE THE OLDER VERSION AND REPLACE IT WITH THIS NEW ONE ******

- Fixed misalignment of control stick geometry
- Fixed bug preventing TACAN Channel Selection on PAN variant
- Fixed bug preventing TACAN Channel numbering stop at 99X
- Fixed behavior of ADI GS Flag
- Added ADI GS animation
- Fixed orientation of NAV lights
- Added checklists courtesy of Lucas Aulen aka Laulenture
- Fixed minor smoothing artifacts in geometry

- Light Effects redone
- Fixed bug preventing beacon to show correctly in some cases
- Added timer function
- Further tweaks to flight model, with better pitch behavior and low speed characteristics
- Package renamed due to new naming restrictions
- Fixed bug preventing beacon switch from working
- Added possibility to remove gunsight from A model (just click on the gunsight)
- Canopy scratch effect redone

15-Nov-2020

Version 1.10

Flight model upgrade and miscellaneous fixes and improvements:

- complete remake of the flight model in order to fix Modern flight model instability and Legacy model compatibility
- adjustmentst to flap, gears and speed brake cycle time
- improvements to HGU-33 helmet geometry
- added animation to rear pilot figure
- fixed DME not working for Tacan (NAV 2)
- fixed bug preventing correct DME behaviour in some cases
- fixed ADI glideslope indicator not working correctly in some cases
- fixed incorrect behavior of ADI indexer
- fixed miscellaneuos geometry issues
- fixed miscellaneyos geometry smoothing issues
- improved altimeter animations
- fixed bug preventing GSARM to work with VOR/ILS
- cleaned up canopy textures
- WWise sound configuration courtesy of Christophe de Bortoli (Erkin)

18-Oct-2020

Flight manual update only:

- clarified installation instructions
- clarified "modern" flight model implementation

17-Oct-2020

INITIAL RELEASE

WELCOME

The Aermacchi MB-339 is a military jet trainer and light attack aircraft designed and manufactured by Italian aviation company Aermacchi.

The MB-339 was developed during the 1970s in response to an Italian Air Force requirement that sought a replacement for the service's existing fleet of Aermacchi MB-326. Its design was derived from that of the MB-326, rather than a new design, and thus the two aircraft share considerable similarities in terms of their design. Aermacchi had found that the MB-339 was capable of satisfying all of the specified requirements while being the most affordable option available. The maiden flight of the MB-339 took place on 12 August 1976; the first production aircraft were delivered two years later.

Roughly half of all MB-339s entered service with the Italian Air Force, while the remainder have been sold to various export customers. As well as being used for training, the type is also flown by the Frecce Tricolori aerobatic display team. The type has been used in combat by both the Eritrean Air Force during the Eritrean–Ethiopian War of 1998-2000 and the Argentine Naval Aviation during the Falklands War of 1982. In both conflicts, the MB-339 was typically flown as an attack aircraft.

MINIMUM HARDWARE REQUIREMENTS

Due to the high-detail model and textures, we suggest to use the MB-339 on systems that meet or exceed the following requirements:

CPU: 3.5GHz dual core processor or better

GPU: at least 4Gb dedicated memory, Nvidia 960 or better recommended

RAM: 4.0Gb minimum

Hard Disk: 1.8Gb required for installation


INSTALLATION

IMPORTANT – IF YOU ARE UPGRADING YOUR PACKAGE FROM A PREVIOUS VERSION, PLEASE DELETE THE PREVIOUS VERSION FIRST!

This package is distributed both on the Microsoft Marketplace and by external vendors.

If you have purchased the package through the Marketplace and you have followed the on-screen instructions, no further action is required from your end. The plane should be available in the aircraft selection menu as the other default planes.

If you have purchased the package from an external vendor and the aircraft is provided as a .zip file without any installer, just unzip the content of the file into your COMMUNITY folder. The exact location of the folder will depend on your selection when you have installed Microsoft Flight Simulator. Once you have indicated where your COMMUNITY folder is, just follow the on-screen instructions. The picture below shows the case in which the MSFS files are located in the G: drive in the MSFS folder – the MB-339 is highlighted in LIGHT BLUE.



If you have purchased the package from an external vendor and the product comes with an .exe installer, just follow the instructions on the screen. You will be asked to locate the COMMUNITY folder. The exact location of the folder will depend on your selection when you have installed Microsoft Flight Simulator. Once you have indicated where your COMMUNITY folder is, just follow the on-screen instructions.

If you have purchased the package from an external vendor with automatic install (e.g. Orbx Direct)

the file should be automatically installed and available the next time you start the simulator.

The aircraft will be available in the aircraft selection menu next time you start Flight Simulator. If Flight Simulator was running during the install process, you need to close it and restart it for the aircraft to appear.

NOTE: If you do not know where the community folder is located, you can follow this procedure:

Go to Options / General.

1. Click on "Developers" which you will find at the bottom of the list on the left.
2. Switch Developers Mode on.
3. On the Dev Menu select Tools / Virtual File System.
4. The community folder location can be found under "Watched Bases"

NOTE: If the copying the folder in the Community folder fails because of the fact that files names are too long you can proceed as follows:

1. Extract the package folder on your desktop or in any known and easily acceptable location.
2. Rename the package folder from "indiafoxtecho-indiafoxtecho-mn339pan" to anything short and recognizable such as "339" or just "3"
3. Place the renamed package folder in the Community folder

IMPORTANT NOTE ON THE FLIGHT MODEL

Please note that the MB-339 flight model is designed to work with the new Flight Simulator flight model (Options->General->Flight Model->MODERN) . This is the default option for Microsoft Flight Simulator and it should be your setting unless you have changed it.

However, some users may have changed the flight model to "LEGACY" in order to use older FSX-derived add-on planes. Starting from version 1.10 there is a limited support to the LEGACY model too, but we still suggest you use the MODERN one.

With the modern flight model, the MB-339 should behave well and be quite stable and easy to fly within the regular flight envelope (90 to 400 kts) – although it may exhibit some instability in extreme flight or weather conditions.

CREDITS

Frecce Tricolori Virtuali.....3d modeling, texturing, flight modeling and testing.
(FTV Development team: Giuseppe Didiano, Camillo Perniciolo, Nicolò Carraro, Fabio Grasso, Erik Dattilo, Roberto Scolari)

Wwise sound configuration.....Christophe de Bortoli (Erkin)

Dino Cattaneoconversion to Flight Simulator, 3D animation, system and avionics programming, project management and project lead.

We'd like to thank the Beta testing Team and everyone who supported this project and IndiaFoxtEcho.

For questions, support and contact please write an email to indiafoxtecho@gmail.com or contact us on Facebook <https://www.facebook.com/Indiafoxtecho-594476197232512/>

This software package has been produced by IndiaFoxtEcho Visual Simulations, via Dei Giustiniani 24/3B 16123 Genova, Italy – copyright 2020.

ABOUT THIS MANUAL

This manual is partially based on the real world flight manual for the MB-339 but it has been vastly cut and edited to reflect the Microsoft Flight Simulator rendition.

Sections *blue italics* apply only to the simulated version of the aircraft.

THIS MANUAL SHALL NOT BE CONSIDERED A SOURCE FOR REAL-WORLD INFORMATION OR OPERATION OF THE MB-339 AIRCRAFT!

UPDATES

We will try our best to keep the product updated and squash significant bugs as soon as possible. Our update policy is as follows:

- major updates, which either require a new installer or a major changes to a significant number of files, are typically deployed as new installers and will be available from your distributor.

- minor updates or quick-fixes will be typically deployed as patches for manual installation on our blog indiafoxtecho.blogspot.com

COPYRIGHT AND LEGAL STATEMENTS

This SOFTWARE PRODUCT is provided by INDIAFOXTECHO VISUAL SIMULATIONS "as is" and "with all faults."

INDIAFOXTECHO VISUAL SIMULATIONS makes no representations or warranties of any kind concerning the safety, suitability, lack of viruses, inaccuracies, typographical errors, or other harmful components of this SOFTWARE PRODUCT.

There are inherent dangers in the use of any software, and you are solely responsible for determining whether this SOFTWARE PRODUCT is compatible with your equipment and other software installed on your equipment. You are also solely responsible for the protection of your equipment and backup of your data, and INDIAFOXTECHO VISUAL SIMULATIONS will not be liable for any damages you may suffer in connection with using, modifying, or distributing this SOFTWARE PRODUCT.

REVERSE ENGINEERING OF ANY PART OF THIS PACKAGE, INCLUDING THE EXTRACTION OF 3D AND 2D ASSETS WITH ANY MEAN, IS PROHIBITED.

PLEASE REFRAIN FROM MAKING ILLEGAL COPIES OF THIS SOFTWARE.

INDIAFOXTECHO DOES NOT INCLUDE COPY PROTECTION IN ITS SOFTWARE AS WE BELIEVE THAT LEGITIMATE CUSTOMERS ARE ENTITLED TO INSTALL THIS SOFTWARE WITHOUT ANY HASSLE OR WITHOUT WORRYING ABOUT PRODUCT KEYS, LICENSE EXPIRATION AND AVAILABILITY.

OUR COPY-PROTECTION IS MADE OF CONTINUOUS IMPROVEMENT, CUSTOMER SERVICE AND A FANTASTIC FAN BASE.

THAT BEING SAID, IF YOU MAKE AN ILLEGAL COPY OF THIS SOFTWARE, NOT ONLY YOU ARE INFRINGING THE LAW – YOU ARE ALSO REDUCING THE RESOURCES FOR DEVELOPMENT OF UPDATES AND NEW PRODUCTS.

...let alone the fact that the world of simulation communities is small, and we receive notifications of copyright infringements or reverse engineering attempts directly from our loyal fans very quickly.



AIRCRAFT

The MB-339A is a single-engine, two-seat subsonic aircraft manufactured by Alenia Aermacchi S.p.A. in Venegono S. (Varese). The aircraft primary role is basic and advanced training. Its features, including external armament stores, allow it to fulfill the operational training and ground attack roles. The aircraft is powered by a 17.8 kN (4000 lbf) thrust Rolls-Royce Viper MK632-43 turbojet engine, and can takeoff and land with a mass up to 5900 kg (13000 lb).

AIRCRAFT DIMENSIONS

The maximum dimensions of the aircraft, under normal conditions of mass, shock-absorber compression and tire inflation, are as follows:

wing span (aircraft fitted with elliptic tip tanks)	10.86 m
wing span (aircraft fitted with cylindrical tip tanks)	11.22 m
wing span (configuration with no tip tanks)	10.23 m
fuselage length	10.97 m
height at the top of the fin	3.53 m

AIRCRAFT GROSS MASS

The aircraft basic mass with JP8 fuel is approx. 3225 kg with elliptic tip tanks and approx. 3280 kg with cylindrical tip tanks (this includes hydraulic fluid, unusable engine oil and unusable fuel).

The aircraft basic mass in a configuration without wing tip tanks and with 4 underwing pylons is approx. 3295 kg (this includes hydraulic fluid, unusable engine oil and unusable fuel).

The aircraft gross mass in some typical configurations is as follows:

Flight training

(two pilots plus internal fuel) 4530 kg (A)
4875 kg (B)

Flight training in a configuration with no wing tip tanks (two pilots, internal fuel and 4 underwing pylons) 4072 kg

Air-to-ground firing training
(two pilots plus internal fuel,
2 machine gun pods of 12.7 mm and
1 rocket and bomb container with
2 rockets and 4 MK 106 bombs) . . 4915 kg (A)
5265 kg (B)

Ferry mission (crew of two,
plus internal and external fuel) . . 5115 kg (A)
5505 kg (B)

The above mass data are based on calculated averages and are therefore given for reference only.

NOTE

Masses marked with letter A refer to the aircraft with elliptic tanks. Masses marked with letter B refer to the aircraft with cylindrical tanks.

GENERAL AIRCRAFT ARRANGEMENT

The fuselage is built in two sections to permit engine removal.

The forward section contains the nose landing gear and the electronic equipment compartment, the two cockpits, the two-cell fuel tank, a dorsal compartment for the installation of additional electronic equipment, the speedbrake in the fuselage underside and the engine bay.

The cockpits are enclosed by a canopy hinged to the fuselage right side, and are fitted with ejection seats which are staggered in height to ensure maximum visibility from the rear cockpit. Each cockpit is equipped with an instrument panel and side consoles, a throttle lever and control stick.

The central equipment compartment, located below the rear cockpit, contains the cockpit air conditioning heat exchanger unit. The aft section, to which the horizontal and vertical stabilizers are attached, contains the jet pipe. Bays for the retracted main landing gear and four oxygen cylinders are provided in the wings, and underwing stations are fitted for the attachment of six pylons designed to carry armament stores or jettisonable fuel tanks.

Non-droppable fuel tanks of 320 l or cylindrical tip tanks of 500 l each capacity are mounted at the wing tips.


SIMULATION NOTE:

The Flight Simulator rendition covers two MB-339 configurations: the MB-339A (with tip tanks and no external loads) and the MB-339PAN (special aerobatic version) with no tip tanks but with mixed smoke/fuel underwing tanks. These two models have separate flight models with different fuel capacity and different aerodynamics.


Note: the PAN external model is depicted in the Mid-Life Update (MLU) configuration, while the A model is the legacy version. However, for both models, the cockpit is depicted in the MLU configuration.

Note: only the front cockpit is depicted in the simulation.

GENERAL ARRANGEMENT




FRONT CREW STATION TYPICAL




FRONT INSTRUMENT PANEL

CENTRAL PANEL




1. CLOCK
2. LONGITUDINAL TRIM INDICATOR
3. ANGLE-OF-ATTACK INDICATOR
4. "CANOPY" WARNING LIGHT
5. MACH-AIRSPD INDICATOR
6. UHF FREQUENCY INDICATOR
7. "MASTER CAUTION" LIGHT
8. GUNSIGHT CONTROL PANEL
9. ATTITUDE DIRECTOR INDICATOR (ADI)
10. "FIRE" WARNING LIGHT
11. REMOTE DISPLAY UNIT (RDU)
12. ENCODER ALTIMETER
13. OXYGEN FLOW INDICATOR
14. "OVERHEAT" CAUTION LIGHT
15. TACHOMETER
16. JET PIPE TEMPERATURE INDICATOR
17. OXYGEN PRESSURE GAUGE




18. ANTI-ICE INDICATORS
19. FUEL QUANTITY INDICATOR
20. CABIN ALTIMETER
21. FLOWMETER
22. ENGINE OIL PRESSURE GAUGE
23. HSI CONTROL PANEL
24. MARKER BEACON CONTROL PANEL
25. VERTICAL VELOCITY INDICATOR
26. HORIZONTAL SITUATION INDICATOR (HSI)
27. STAND-BY ATTITUDE INDICATOR
28. "FLIGHT DIRECTOR" CONTROL PANEL
29. EXTERNAL STORES RELEASE PUSH-BUTTON
30. ARMAMENT CONTROL PANEL
31. FLAP POSITION INDICATOR
32. SPEED BRAKE POSITION INDICATOR
33. ACCELEROMETER

FRONT INSTRUMENT PANEL

LATERAL PANEL AND CENTERSTAND




FRONT CONSOLES




FRONT INSTRUMENT PANEL

CENTRAL PANEL

(AIRCRAFT POST-MOD. PTA -322)



1. CLOCK
2. LONGITUDINAL TRIM INDICATOR
3. ANGLE-OF-ATTACK INDICATOR
4. "CANOPY" WARNING LIGHT
5. MACH-AIRSPEED INDICATOR
6. RADIO FREQUENCY INDICATOR (COMM1 & COMM2)
7. "MASTER CAUTION" LIGHT
8. GUNSIGHT CONTROL PANEL
9. ATTITUDE DIRECTOR INDICATOR (ADI)
10. "FIRE" WARNING LIGHT
11. REMOTE DISPLAY UNIT (RDU)
12. ENCODER ALTIMETER
13. OXYGEN FLOW INDICATOR
14. "OVERHEAT" CAUTION LIGHT
15. TACHOMETER
16. JET PIPE TEMPERATURE INDICATOR
17. OXYGEN PRESSURE GAUGE




18. ANTI-ICE INDICATORS
19. FUEL QUANTITY INDICATOR
20. CABIN ALTIMETER
21. FLOWMETER
22. ENGINE OIL PRESSURE GAUGE
23. HSI CONTROL PANEL
24. MARKER BEACON CONTROL PANEL
25. VERTICAL VELOCITY INDICATOR
26. HORIZONTAL SITUATION INDICATOR (HSI)
27. STAND-BY ATTITUDE INDICATOR
28. "FLIGHT DIRECTOR" CONTROL PANEL
29. EXTERNAL STORES RELEASE PUSH-BUTTON
30. ARMAMENT CONTROL PANEL
31. FLAP POSITION INDICATOR
32. SPEED BRAKE POSITION INDICATOR
33. ACCELEROMETER

FRONT INSTRUMENT PANEL


LATERAL PANEL AND CENTERSTAND

(AIRCRAFT POST-MOD. PTA -322)





FRONT CONSOLES


(AIRCRAFT POST-MOD. PTA -322)





ENGINE THROTTLE




CONTROL STICKS




VIPER MK 632-43 ENGINE



ENGINE FUEL SYSTEM



ENGINE CONTROLS AND INDICATORS



3

2

1


4




5



6



7




8

9

10

AIRCRAFT FUEL SYSTEM



FUEL

AIR

NON RETURN VALVE


CAPACITANCE PROBE

FUEL TANKS LOCATION AND USABLE FUEL

AIRCRAFT FITTED WITH 320 I TIP TANKS


NOTE

- Figures are estimates only. The mass of the fuel is based on a fuel density of 0.803 Kg/dm³ (nominal density).
- Density of F-34 fuel can change from 0.775 to 0.840 Kg/dm³.
- See para "Correct interpretation of Fuel Quantity Indicator Readings".






TANKS	USABLE FUEL	
	VOLUME	QUANTITY NATO F-34 (JP8) (0.803 kg/dm ³)
	litres	kg
MAIN FUSELAGE TANK	780	626
TIP TANKS (2)	640	514
TOTAL	1420	1140
PYLON TANKS (2)	660	530
TOTAL	2080	1670

FUEL SYSTEM CONTROLS AND INDICATORS



OKT SKR	FUEL LOW
AIR SERVO	FUEL PRESS
OXY LOW	OIL PRESS
DUCT ANT-ICE	ICE
PYL TK EMPTY	ANTI-SKID
FUEL TRANS	IFF
TIP TK UNBAL	IFF MODE 4


ELECTRICAL SYSTEM CONTROLS AND INDICATORS




7

14	NO 1 DC GEN	CKT BKR
13	NO 2 DC GEN	AIR SERV
12	NO 1 BATT	OXY LOW
11	NO 2 BATT	DUCT ANT ICE
10	BATT HOT	PYL TK EMPT
9	AC ESS BUS	FUEL TRANS
8	AC SEC BUS	TIP TK UNBAL


PITOT-STATIC SYSTEM




PRIMARY AND SECONDARY FLIGHT CONTROLS AND INDICATORS



HYDRAULIC POWER SYSTEM




AILERON CONTROL SYSTEM




9AA/FM/0101_01

LANDING GEAR CONTROLS AND INDICATORS



9AA/FM/0016D01

LANDING GEAR SYSTEM




ANGLE-OF-ATTACK INDICATION DURING APPROACH PHASE




Pointer well above upper edge of approach index marker

Approach speed too low (more than 5 knots) as regards optimum.
Nosedown correction needed.
Engine as necessary to maintain glide slope.




Pointer just above center of approach index marker

Approach speed slightly low (3 to 5 knots) as regards optimum.
Slight nosedown correction needed.
Engine as necessary to maintain glide slope.




Pointer near center of approach index marker

Angle of attack and approach speed at optimum.
No correction needed.




Pointer just below lower edge of approach index marker

Approach speed slightly fast (3 to 5 knots) as regards optimum.
Slight noseup correction needed.
Engine as necessary to maintain glide slope.




Pointer well below lower edge of approach index marker

Approach speed too fast (more than 5 knots) as regards optimum.
Noseup correction needed.
Engine as necessary to maintain glide slope.




WARNING, CAUTION AND ADVISORY LIGHTS - FRONT COCKPIT

(AIRCRAFT PRE-MOD. PTA -322)




CANOPY CONTROLS





94A/MMGV/1986_02

MK IT-10F EJECTION SEAT CONTROLS




EJECTION SEAT SAFETY PINS



EJECTION SEAT SAFETY PINS


MAINTENANCE CONDITION



EJECTION SEAT FIRING SYSTEM




EJECTION SEAT EQUIPMENT




AVIONIC EQUIPMENT

ANTENNA LOCATION


(AIRCRAFT PRE-MOD. PTA -322)



(AIRCRAFT POST-MOD. PTA -322)



EXTERIOR LIGHTS



PROCEDURES

The procedures described in this section are given in detail, where possible.

In some cases, the controls in the simulation have no effect on the aircraft behavior but are reported in the checklists for information – those actions are written in *italics*.

The following checklists have been kept as close as practical to the real-world checklists.

CONTROL AVAILABILITY IN THE TWO COCKPITS

The procedures given in this section are relevant to the pilot in the front cockpit. The controls in the front cockpit are not fully duplicated and available in the rear cockpit. Therefore the rear pilot, when in control, must instruct the front pilot to actuate the following controls, available in the front cockpit only:

- Electrical power supply switches: "BATT", "GEN 1", "GEN 2", "AC POWER", "BUS RESET".
- Engine switches: "STARTER", "JPT LMTR", "MASTER".
- "FUEL TRANSFER" switch.
- "IN GPS" switch.
- Air-conditioning panel: "CABINTEMP" switch, "CABIN PRESS", "WINDSHIELD/DEMIST" and "WINDSHIELD/RAIN RMVL" switches.
- "NAV", "BCN", "LDG/LT/TAXI LT" light switches and "FORM LIGHTS" knob.
- "IFF" panel.
- Armament and gunsight controls.
- "LG EMERG SEL" handle.
- "MKR" panel.
- "WARN LT TEST" push-button.
- "RAM-AIR SCOOP" handle.
- "ANTI-ICE/ENGINE" switch.
- Engine throttle friction.
- "MASTER CAUTION" "reset" control.
- ELT switch.
- "PARKING BRAKE" handle.

Note: only the front cockpit is depicted in the simulation.

PRE-FLIGHT CHECKS BEFORE EXTERIOR INSPECTION, FRONT COCKPIT

1. In case of strong wind make sure the aircraft is heading into wind.

CAUTION

STRONG TAILWIND CAN CAUSE AN INCREASE IN THE JET PIPE TEMPERATURE AND WORSEN ANY FIRE SITUATION.

2. Check the aircraft log book for aircraft serviceability, servicing and inspections carried out.
3. Canopy - Locked fully open.

4. FUEL DUMP - White line horizontal.

5. Flight controls - Unlocked.

CAUTION

IN STRONG WIND, DO NOT UNLOCK THE FLIGHT CONTROLS UNTIL THE COCKPIT CHECKS ARE COMPLETED OR DAMAGE MAY RESULT TO THE CONTROL SURFACES AND ASSOCIATED CONTROL LINKAGES.

6. External power supply - As required.

7. Stand-by attitude indicator - Caged.

8. BATT - OFF.

9. GEN 1 - OFF.

10. GEN 2 - OFF.

11. AC POWER - NORM.

12. GROUND FIRE - OFF.

13. Ground utilities control panel:

- a. IGN - Guard down.
- b. FUEL PUMP - Guard down.
- c. LG SW ORIDE - Guard down.

14. If necessary, insert the data card in the receptacle of the front "AHR/GPS" control panel.

EXTERIOR INSPECTION

The exterior inspection procedures are based on the assumption that maintenance personnel have performed all post-flight and pre-flight inspections specified in the applicable technical publications. The pilot is not required to repeat the same operations, except those which are flight critical. When performing exterior inspection, the pilot must check for the aircraft general conditions as indicated in figure.

REAR COCKPIT CHECKS FOR "SOLO" FLIGHTS

1. Ejection seat safety pin in place in the firing handle.
2. Make sure that the survival pack, seat belts, communication lead, normal and emergency oxygen hoses are fastened by means of the special cover assembly.

CAUTION

ONLY DURING FERRY FLIGHT IF A COVER ASSEMBLY IS NOT AVAILABLE, THE PARACHUTE AND SURVIVAL PACK MAY BE FASTENED BY MEANS OF THE SEAT BELTS OR OTHER FASTENING SYSTEM.

THE PILOT SHALL CHECK THAT FASTENING IS SECURE.

WARNING

AEROBATICS ARE FORBIDDEN WHEN THE COVER ASSEMBLY IS NOT INSTALLED ON THE REAR SEAT.

3. Oxygen regulator supply lever – OFF.
4. ANTI-SKID - NORM.
5. FUEL SHUT OFF - OPEN (guard down).
6. AIL SERVO - ON (guard down).
7. FUEL DUMP - White line horizontal.
8. FIRE (on the armament repeater panel) - ON (guard down).
9. Stand-by altitude indicator - CAGED.
10. All switches - OFF.
11. Circuit breaker panel - All circuit breakers in.

BEFORE ENTERING THE COCKPIT

1. Don the leg restraint garters (below the knees, rings forward, the buckle inward).
2. Carry out the following seat checks:
 - a. Safety pin in place in the seat firing handle.
 - b. Other safety pins stowed in the backrest.
 - c. Gun sear extraction link fitted and safety pin not fitted to the sear.
 - d. Leg restraint garters correctly attached to the cabin floor.
 - e. Manual override handle - Down and locked.
 - f. Manual override safety pin - Removed.
 - g. Time release unit control rod - Secured and safety pin removed.
 - h. Safety link of the “U” ring in the ejection parachute and every other visible link - Check for integrity.
 - i. Seat correctly locked on ejection gun. Make sure that the indicator spigot is flush with the threaded end of the latch plunger and that the latch plunger is level with or slightly below the housing face.
 - j. Parachute extraction rope secured to the

drogue gun piston.

k. Drogue gun control rod - Bound to the crosspiece of the gun with safety pin removed.

l. Shoulder harness retraction trip lever - In rear position.

m. Rocket pack initiator safety pin -Removed.

n. Emergency oxygen cylinder - Indicator in the green.

o. Emergency oxygen handle - Lowered.

p. Secure fastening in the lock points of the belts.

q. Check connection between survival pack retain belt and parachute belts.

r. Sticker strap lugs engaged in clips.

3. Ejection sequence control (rear cockpit) - As required.


EXTERIOR INSPECTION

CONDITIONS:

- Flaps and speedbrake - Down
- Flight controls - Unlocked
- Covers - Removed
- Areas, free from objects that could be ingested by the engine
- Fire extinguisher - Available

GENERAL ITEMS:

- Damage, distortion, loose screws or rivets
- Damage to metal skins
- Incomplete fastening of panels or doors
- Fuel, oil and hydraulic fluid leakage



1. FUSELAGE NOSE

- Left and right Pitot - Unobstructed.
- Upper IFF antenna - Conditions.
- Formation lights - Check conditions.
- AOA transmitter - Unobstructed and free to rotate.

2. NOSE LANDING GEAR

- Landing gear door - Check conditions.
- Taxi light - Conditions and security.
- Shock-absorber - Check proper extension.
- Splash guard - Conditions and fastening.
- Tire - Conditions and inflation.
- Microswitch - Check conditions.

3. RIGHT FORWARD FUSELAGE

- Ram air intake - Closed.
- Windshield and canopy - Check conditions.
- Canopy severance external handle - Stowed.
- Air conditioning intake - Unobstructed.
- Engine air intake - Unobstructed and conditions.
- Speedbrake compartment - Check conditions.

4. RIGHT MAIN LANDING GEAR

- Landing gear door - Check conditions.
- Shock-absorber - Check proper extension.
- Landing gear locking strut - Removed.
- Wheel chock - As required.
- Tire - Conditions and inflation.
- Brake wear indicator pin - Protrusion dimension (> 0 mm, maximum 12 mm).
- Microswitch - Check conditions.

5. RIGHT WING

- Underwing fuel tank (if installed) - Check security, conditions, safety pin inserted and electrical cable connected.
- Luggage pod (if installed) - Security, conditions and safety pin inserted.
- Tip tank - Check conditions.
- Filler cap - Closed.
- Navigation light - Check conditions.
- Formation lights - Check conditions.
- Aileron and trim tab - Conditions, movement and free play.
- Flap - Conditions, free plays, grounding wire and actuating rods.

6. FUSELAGE (Right Aft side)

- GPS Antenna - Check conditions.
- Battery compartment:
 - Batteries condition.
 - Hydraulic reservoir cap tightening.
- Engine bay:
 - Oil tank cap for security.
 - Power relay box circuit breakers - IN.
- TACAN upper antenna - Check conditions.
- Top navigation light - Check conditions.
- Static port - Unobstructed.
- Engine bay cooling intake - Unobstructed.
- Strake - Check conditions.
- Formation light - Check conditions.
- ELT Antenna - Check conditions and security.

7. EMPENNAGES

- Rudder and trim tab - Conditions, movement and free play.
- Ice detector - Conditions and security.
- VOR/LOC/GS antenna - Conditions and security.
- Anti-collision light - Check conditions.
- Navigation light - Check conditions.
- Elevator and trim tabs - Conditions, movement and free play.
- Jet pipe - Dry and condition.
- Temperature sensor - Conditions and security.

8. LEFT AFT FUSELAGE

- Engine bay cooling intake - Unobstructed.

- Static port - Unobstructed.
- Formation light - Check condition.
- Strake - Check condition.
- MKR BCN antenna - Conditions and security.
- Lower TACAN antenna - Conditions and security.
- Lower IFF Antenna - Conditions and security.
- Electrical panel - Circuit breakers engaged.
- Engine bay - BOV unobstructed and clean.
- Battery compartment:
 - Batteries for condition.
 - Hydraulic accumulator pressure gauges for correct pressure indication (860 psi at +15 °C).

9. LEFT WING

- Flap - Conditions, free play, bonding and actuating rods.
- Aileron and trim tab - Conditions, movement and free play.
- Tip tank - Security and conditions.
- Filler cap - Closed.
- Navigation light - Check conditions.
- Formation light - Conditions.
- Underwing fuel tank (if installed) - Security, conditions and safety pin inserted.
- Luggage pod (if installed) - Security, conditions and safety pin inserted.
- Landing light - Check conditions.

10. LEFT MAIN LANDING GEAR

- Landing gear door - Check conditions.
- Shock-absorber - Check proper extension.
- Landing gear locking strut - Removed.
- Wheel chock - As required.
- Tires - Conditions and inflation.
- Brake wear indicator pin - Protrusion dimension (> 0 mm, maximum 12 mm).
- Microswitch - Check conditions.

11. LEFT FORWARD FUSELAGE

- UHF antenna - Check condition.
- Navigation light - Check condition.
- Engine air intake - Unobstructed and conditions.
- Canopy severance external handle - stowed.
- Windshield and canopy - Check conditions.

NOTE

The position of the command ejection sequence lever is at pilot's discretion. However, for non-aircrew occupants, the lever must be set to OFF.

WARNING

WHEN ENTERING OR LEAVING THE COCKPIT, THE CREW MUST PAY ATTENTION TO THE HOOKS PROTRUDING FROM THE CANOPY LOWER EDGE.

IN THE COCKPIT

Once seated in the cockpit, proceed as follows:

1. Adjust the rudder pedal position by means of the "PEDAL ADJ" knob.
2. Connect the anti-g suit hose to the anti-g valve connector.
3. Adjust the rocket pack angle by setting the own weight in the relevant window.
4. Connect the personal survival pack lowering line to the flying suit, routing the lowering line outside the left console.
5. Route the leg restraint lines through the leg garters ring and engage the free ends in the lock located on the two side protections of the seat. Adjust the length.
6. Make sure that the go-forward control lever is in locked position.
7. Place the quick-release fitting mounted to the negative-g restraint strap to the center position.

NOTE

To insert the lugs into the quick-release fitting, turn the faceplate until the yellow line and dots on the plate are aligned with the line and the dots on the body.

8. Route the crotch straps in the D-rings of the straps.
9. Pass the shoulder straps down through the end loops of the crotch straps and secure the end lugs into the quick-release fitting.
10. Fully tighten the lap straps ensuring that the quick-release fitting remains central then tighten the shoulder straps.
11. Don the flying helmet and connect the connector fitted to the oxygen mask hose to the oxygen hose.
12. Connect the oxygen hose to the socket on the left shoulder strap.
13. Move the oxygen supply lever to ON and check the correct operation of the mask and of the oxygen system. Check that the "EMG" lever is pressed aft and the diluter lever is at N.
14. Connect the radio jack.
15. Move the go-forward control lever forward and check for freedom of movement.
16. Make sure that the safety pin of the canopy severance system handle is in the handle.
17. Underwing fuel tanks and luggage pod (if installed) - Safety pins removed.

INTERIOR INSPECTIONS

1. Flight controls - Unlocked.

CAUTION

DO NOT UNCAGE THE STAND-BY ATTITUDE INDICATOR BEFORE ELECTRICAL POWER HAS BEEN ENERGIZED TO THE "BATT" SWITCH.

2. "ENGINE" panel - JPT LMTR ON.

3. BATT - ON.

Initialization of the AHRS/GPS system

1. IN GPS - ON.
2. *If required, load the data base from the data card.*
3. *Ensure that the AHRS/GPS system is set to AHR/GPS mode.*

Left to right checks

LEFT CONSOLE

1. CKT BKR BOX No. 1 - All circuit breakers in.
2. GROUND FIRE - Check OFF (guard down).
3. LG EMERG SEL - Fully in and wirelocked.
4. AIL SERVO - ON (guard down).
5. VHF - (aircraft pre-mod. PTA -322) or V/UHF (COMM2) (aircraft post-mod. PTA -322) - As required.
6. UHF (COMM1) - As required.
7. Flap control lever - Match flaps actual position.
8. Engine throttle - Check for free movement, adjust the friction knob and move to STOP. Move forward to 90% RPM position and check for flashing of "CANOPY" warning light.
9. RUDDER TRIM - Set to neutral position.
10. ANTI-SKID - Check set to NORM.
11. FUEL TRANSFER - PYL (if underwing fuel tanks are installed and refueled); otherwise TIP.
12. FUEL SHUT OFF - OPEN (guard down).
13. "ENGINE" panel - MASTER check OFF.

LEFT QUARTER PANEL

1. Trim neutral position indicators - Both green.
2. LDG LT/TAXI LT - OFF.
3. Landing gear control panel:
 - a. Landing gear control lever - LG DOWN.
 - b. Landing gear position indicators (3) - On (green light).
4. PARK & EMER. BK handle - Out.

FRONT INSTRUMENT PANEL

1. Weapon control panel:
 - a. *MASTER ARMT switch -Override(DOWN position).*
 - b. *Checks in accordance with armament configuration.*
2. Speedbrake indicator: Extended (1st mark).
3. Flap indicator - Check. DOWN position.
4. Accelerometer - Check and reset.
5. Clock - Check.
6. Longitudinal trim indicator - Neutral.
7. ANGLE OF ATTACK - OFF flag out of view.
8. CANOPY warning light - ON (if the canopy is unlocked)
9. MASTER CAUTION - Press to reset.
10. Mach-airspeed indicator - Check and set index for the desired reading.
11. *SALVO JETTISON - Check cover for integrity.*
12. "FLT DIR" control panel - STBY light on.
13. Gunsight control panel - PWR switch - Check OFF.
14. STEER light - OUT.
15. FIRE warning light - OUT.
16. Altimeter - Set as required.
17. Vertical velocity indicator -Check for zero indication.
18. OVERHEAT light - OUT.

19. Tachometer - Check for zero indication.

20. Jet pipe temperature indicator - Outside air temperature.

21. Flow meter - Check.

22. Engine oil pressure gauge - Check.

23. "OXY" indicator - Check pressure.

24. "ANTI-ICE" indicator panel - All OFF.

25. "FUEL QTY" indicator - According to the fuel quantity on board.

26. Cabin altimeter - Check field baro pressure.

INSTRUMENT PANEL RIGHT SIDE

1. Hydraulic system pressure gauges -Conditions.

2. WARN LT TEST - Press to test and check for landing gear audible warning signal in the headset and illumination of the following lights:

- a. "MASTER CAUTION"

- b. "FIRE"

- c. "OVERHEAT"

- d. "STEER"

- e. Landing gear control lever.

- f. Caution light panel.

3. GEN 1 - ON.

4. GEN 2 - ON.

5. AC POWER - NORM.

6. MASTER CAUTION light - Press to RESET.

CENTER PEDESTAL

1. CONTROL SHIFT - Press the relevant pushbutton lights and check operation.

RIGHT CONSOLE

1. ICS panel - Set as necessary.

2. *ELT switch - TEST/RST, then release. Check the light flashes three times simultaneously with the emission of the three audio signals.*

3. "TCN" control panel – OFF.

4. SEAT ADJ - Adjust the seat pan height.

WARNING

SETTING THE SEAT PAN TOO HIGH MAY CAUSE INJURIES TO THE PILOT IN CASE OF EJECTION.

5. "VOR/ILS" panel – OFF.

6. "IFF" panel - *Pre-select the mode and code; check that the "MASTER" selector is set to OFF.*

7. ANTI-ICE/ENGINE - OFF.

8. ANTI-ICE/PITOT - TEST ("PITOT" and "AOA" indicators: ON) then OFF.

9. Cabin air-conditioning panel:

a. CABIN TEMP - AUTO, set to the desired temperature (normally to 12 o'clock).

b. WINDSHIELD/DEMIST - OFF.

c. WINDSHIELD/RAIN RMVL - OFF.

d. CABIN PRESS -ON (guard down).

10. "LIGHTS" control panel:

a. BCN - ON.

b. Other controls - As required.

11. BUS RESET - OFF (guard down).

12. RAM AIR SCOOP - Fully in (scoop closed).

13. CKT BKR BOX No. 2 - All circuit breakers IN.

PRE-START CHECKS

1. ENGINE/MASTER -ON. The "FUEL PRESS" light must go out. If the external power source is connected, check that the "No 1 BATT" and "No 2 BATT" lights go out.

CAUTION

- ENGINE STARTING IS PERMITTED ONLY IN PRESENCE OF THE FOLLOWING CONDITIONS:

--- GROUND TEMPERATURE BETWEEN ---26 °C AND + 50 °C WITH EXTERNAL POWER SOURCE.

--- GROUND TEMPERATURE BETWEEN ---15 °C AND + 45 °C WITH AIRCRAFT BATTERIES. THESE LIMITATIONS ARE APPLICABLE ONLY TO THE AIRCRAFT THAT HAVE BEEN EXPOSED TO TEMPERATURES EXCEEDING THE SPECIFIED LIMITS FOR A LONG TIME. IN ENVIRONMENTS WHERE THE TEMPERATURE

IS BEYOND THE ABOVE LIMITS, AIRCRAFT CAN BE USED ONLY AFTER IT HAS BEEN PARKED IN AREAS WHERE THE TEMPERATURE IS WITHIN THE ABOVE LIMITS.

- IF, AFTER STARTING, THE OIL PRESSURE REMAINS BELOW THE MINIMUM LIMITS, THE ENGINE MUST BE SHUT DOWN AND THE CAUSE INVESTIGATED.

- THE JPT LIMITS MUST BE CAREFULLY COMPLIED WITH, ESPECIALLY DURING THE ENGINE STARTING AND RELIGHTING AS THE FLIGHT SAFETY AND THE ENGINE OVERHAUL LIFE MAY BE AFFECTED.

2. RELIGHT - Press to test. An irregular double sparking of the igniter plugs should be audible.

STARTING ENGINE WARNING

BEFORE STARTING THE ENGINE, MAKE SURE THAT THE DANGEROUS AREAS ARE CLEAR OF PERSONNEL AND EQUIPMENT.

1. Engine throttle – STOP.

2. STARTER and TIME hack -Press for 2 seconds and release.

3. When reaching 10% RPM - Engine throttle set to IDLE. The engine normally lights up within 4 to 12 seconds.

4. Flowmeter - Positive indication.

5. Jet Pipe Temperature - Check for normal increase.

6. Engine speed -Check for normal RPM increase.

7. Oil pressure - Check for normal indication.

8. FIRE and OVERHEAT - OUT.

9. Hydraulic pressure - Increasing.

10. MASTER CAUTION - Check OUT.

11. Caution lights - OUT.

12. External power - Disconnected (if plugged in).

CAUTION

- IF THE JET PIPE TEMPERATURE RISES TOO QUICKLY AND APPROACHES THE MAXIMUM LIMIT, IMMEDIATELY MOVE THE THROTTLE TO STOP. ALLOW THE ENGINE TO STOPS AND COOLS, THEN INVESTIGATE THE CAUSE.

- IF THE TEMPERATURE EXCEEDS THE SPECIFIED LIMITS, REPORT THE OVER TEMPERATURE CONDITION AND TIME SINCE FLIGHT SAFETY AND ENGINE LIFE ARE AFFECTED.

- IF AFTER 15 SECONDS FROM MOVING THE THROTTLE TO IDLE THE ENGINE DOES NOT LIGHT UP (BY REFERENCE TO THE JET PIPE TEMPERATURE AND THE ENGINE SPEED), MOVE TH THROTTLE LEVER TO STOP AND THE "ENG MSTR" SWITCH TO OFF.

- MOVE THE AIRCRAFT IF THE GROUND BENEATH THE TAIL BECOMES SOAKED WITH FUEL.

- PRIOR TO ATTEMPTING A NEW START ALLOW AT LEAST 5 MINUTES FOR THE STARTER TO COOL AND THE ENGINE TO DRAIN; THEN CARRY OUT A DRY MOTORING CYCLE UNTIL EGT VALUES BELOW 200 °C ARE OBTAINED.

- IF THE ENGINE DOES NOT START AFTER THE SECOND ATTEMPT, INVESTIGATE THE CAUSE.

- IF THE "BATT HOT" CAUTION LIGHT COMES ON AFTER ENGINE STARTING, IMMEDIATELY DISCONNECT THE BATTERIES AND ABORT THE MISSION. DISCONNECTION OF BATTERIES IS CONFIRMED BY ILLUMINATION OF "BATT 1/2" CAUTION LIGHT.

NOTE

- *In order to properly investigate the cause of the missed engine start, perform the starting procedure selecting the JPT LMTR switch to OFF.*

- *The "AIL SERVO" light goes out with a delay, i.e. when the hydraulic pressure exceeds 85 to 90 bar.*

DRY CRANK

1. BATT - Check ON.
2. Engine throttle - Check to STOP.
3. FUEL SHUT OFF - OPEN (guard down).
4. IGN (ground utilities panel) -OFF (guard open and toggle down).

5. ENGINE MASTER - ON.

6. FUEL PRESS - OUT.

7. STARTER - Press for 2 seconds (the motoring cycle will be automatically completed in 23 seconds).

CAUTION

AFTER THREE MOTORING CYCLES IN RAPID SUCCESSION, ALLOW 15 MINUTES, FOR THE STARTER TO COOL, BEFORE A FURTHER CYCLE.

8. IGN - ON (guard down).

CHECKS BEFORE TAXIING

NOTE

At ambient temperatures below 6° C and relative humidity above 50% engine icing conditions may be encountered. The most severe icing conditions will occur when operating in fog with visibility less than 500 meters. During ground runs in the above condition, it is necessary to move the "ANTI-ICE/ENGINE" switch to ON and reduce the taxiing time to a minimum, in particular when using engine RPM above IDLE.

1. *Stand-by attitude indicator - Uncage and adjust the alignment.*

2. "LOAD/GEN 1" loadmeter - Check for indication.

3. "LOAD/GEN2" loadmeter - Must indicate load values lower than those of the "LOAD/GEN 1" indicator.

NOTE

The two loadmeters provide identical indications only when engine RPM rise above 60%.

4. "TCN" control panel - Function selector as required.

5. "VOR/ILS" control panel - PWR.

6. "IFF" control panel - MASTER STBY.

7. *CABIN PRESS -OFF (guard up and toggle aft) and check that the air flow from the pressurization outlets stops. Then, ON (guard down).*

NOTE

- The above check can be carried out only before the first flight of the day.

- If required temporarily increase the engine RPM to ease check accomplishment.

8. ADI - Check that the OFF flag is out of view and the attitude indicator is aligned.

9. HSI - Compare the indication of the compass card to that of the stand-by compass. If required, set the alignment indicator on the compass panel AHRS to zero.

CAUTION

BEFORE CARRYING OUT THE TWO FOLLOWING OPERATIONS, INFORM THE CREW CHIEF ABOUT THE NEED TO ACTUATE THE SPEEDBRAKE AND THE FLAPS.

10. On crew chief's signal:

a. Speedbrake -Retracted: check the indicator and wait for the crew chief confirmation of speedbrake position.

b. Flaps - UP, then TAKE OFF. Check indicator andwait for the crewchief confirmation of flap position.

11. Hydraulic pressure -Check that the indications on both pressure gauges are within the limits.

12. Control stick - Free movement and correct response of elevator and ailerons.

13. Rudder pedals - Free movement and correct response of rudder.

14. Canopy -As necessary.Closed or partially open.

WARNING

THE BLIND FLYING HOOD, IF INSTALLED, MUST BE KEPT IN THE OPEN POSITION DURING TAKEOFF IN ORDER TO ENSURE SEAT SAFE EJECTION IN THE CASE OF AN EMERGENCY.

15. On aircraft with cylindrical tip tanks and with underwing fuel tanks:

a. FUEL TRANSFER - TIP. Check possible fuel leakages.

16. Remove the safety pin of the seat handle and plug it in the appropriate seat on the canopy frame.

17. Radio call - As required.

TAXIING

WARNING

IF DURING TAXIING THE CANOPY IS KEPT PARTIALLY OPEN, THE SAFETY PIN OF THE SEAT FIRING HANDLE MUST BE IN PLACE ON THE SEAT.

CAUTION

- DURING TAXIING, THE CANOPY MUST BE CLOSED OR OPEN AND LOCKED IN THE INTERMEDIATE POSITIONBUTNOTFULLYOPEN.

- MAKE SURE THAT THE AREA BEHINDTHEAIRCRAFTISCLEAR OF OBSTACLES, PERSONNEL OR OTHER AIRCRAFT.

- WHEN TAXIING BEHIND ANOTHER AIRCRAFT OF THE SAME CATEGORY, MAINTAIN A MINIMUM DISTANCE OF 25 METERS FROM THE EXHAUST BLAST TO PREVENT DAMAGETO THE CANOPY.

- NO PROBLEMS ARE EXPERIENCED WHEN TAXIING FIVE METERS Laterally APART FROM THE PATH OF THE PRECEDING AIRCRAFT.

- WITHTHECANOPYCLOSED,THE AIRCRAFT CAN CROSS THE BLAST OF ANOTHER AIRCRAFT OF THE SAME CATEGORY RUNNING AT IDLE, ATMINIMUM DISTANCE OF 15 METERS.

1. Have the wheel chocks removed.

2. Press the push-button for nose wheel steering engagement. Check for "STEER" light: ON.

3. PARK & EMER. BK - Release.

4. Brakes - Test for proper response.

5. Taxi at idle and at safe speed.

Approx. 60% RPMis required to start the aircraftmoving. Once the aircraft ismoving it can be taxied with the throttle at IDLE on a hard level surface at a safe speed.

NOTE

Fuel consumption is about 5 kg perminute with the engine at 40% RPM and 29 kg per minute at max RPM.

6. Maintain directional control of the aircraft by use of nosewheel steering.

CAUTION

- DO NOT STEER THE AIRCRAFT WITH BRAKES WITH NOSE WHEEL STEERING ENGAGED BECAUSE DAMAGE COULD BE CAUSED TO THE NOSEWHEEL STEERING SYSTEM.

- BE PREPARED TO DISENGAGE THE NOSE WHEEL STEERING IN CASE OF SYSTEM MALFUNCTION.

7. Oxygen diluter lever - As required.

CAUTION
IF COMBUSTION GASES CONTAMINATION IS SUSPECTED DURING GROUND OPERATION (IN CASE OF TAXIING CLOSE TO ANOTHER AIRCRAFT OR WHEN THE AIRCRAFT IS STANDING IN STRONG TAIL WIND), IT IS ADVISABLE TO USE OXYGEN WITH THE DILUTER LEVER AT 100%.

8. Flight and navigation instruments - Check. Check the ADI, the stand-by attitude indicator and the HSI for correct indications during turns while taxiing.

9. PARK & EMER. BK - Check operation.

10. BCN - Temporarily to OFF, if required.

NOTE

At night, switch the "BCN" to off in proximity of other aircraft to avoid blinding effects.

PRE-TAKEOFF CHECKS

1. FUEL TRANSFER - PYL or TIP.

CAUTION
IF ALL TANKS ARE REFUELED, THE CORRECT SEQUENCE TO BE PERFORMED IS AS FOLLOWS:
1° - PYL (UNDERWING TANKS) UP TO COMPLETE EMPTYING.
2° - TIP (TIP TANKS).

NOTE

To optimize the longitudinal attitude of aircraft fitted with 500 l cylindrical tip tanks, underwing fuel tanks and single pilot, the following tank selection sequence is suggested:

1° - PYL (underwing tanks) only during starting to check leakages.

2° - TIP (tip tanks). For take-off and the first climbing phase until the tip tank fuel residual quantity is approx. 300 kg (660 lb).

3° - PYL until underwing fuel tanks are empty.

4° - TIP.

2. LDG LT/TAXI LT - TAXI LT.

3. Aileron, rudder and longitudinal trim -Neutral

position.

4. Flaps - TAKE OFF (Second mark).

5. Speedbrake - Fully retracted (First mark).

6. Canopy closed and locked ("CANOPY" light out).

7. Seat safety pin - Check that it is removed and put in the appropriate housing on the canopy.

8. Flight instruments - Check.

a. ADI - Check for correct indications and coherence with stand-by attitude indicator.

b. HSI - Check that indication is consistent with the runway magnetic heading.

9. Oxygen:

a. Pressure - Check.

b. OXY FLOW - Check for correct "blinker" operation.

c. Oxygen diluter lever - As required.

10. Hydraulic systems - Pressures within the limits.

11. Caution and warning lights - OUT.

12. Interior and exterior lights - As required.

13. Safety checks:

a. Quick-release fitting for correct locking of the belts.

b. Shoulder harness for locking.

c. Helmet chin straps for correct locking.

d. Helmet visor in down position.

e. Garters and leg restraint garters for correct position.

14. Take-off briefing.

15. IFF Master - NORM. Check codes entered.

TAKE-OFF

NORMAL TAKE-OFF

Engine test

1. With the engine throttle at IDLE, check that all warning and caution lights are out and engine oil pressure and idle RPM are within the limits.

2. Slam the engine throttle to FULL. The engine

must accelerate smoothly without any stall or surge phenomenon.

3. When the engine parameters are stabilized, check:

- a. Engine RPM - Within limits.
- b. JPT - Within limits.
- c. Oil pressure - In normal range.
- d. Warning and caution lights - OUT.

4. After a minimum time of 5 seconds with the engine throttle on FULL, chop (less than 1 second) to IDLE. The engine must decelerate without abnormal stall, undershoot, vibrations, roughness and noise.

System test

- 5. Engine throttle - 60% RPM.
- 6. "GEN1" and "GEN2" loadmeters - Check that the max difference between the two readings does not exceed 0.1.
- 7. ANTI-ICE/ENGINE - TEST (as required).
- 8. ANTI-ICE/PITOT - ON. Check "ANTI-ICE/PITOT" ON.
- 9. Engine throttle - FULL.

Take-off

10. *Disengage nosewheel steering - Check "STEER" indicator light is OUT.*

- 11. Release the brakes.
- 12. Maintain directional control by differential braking. The rudder becomes effective at approximately 45 to 50 KIAS.

CAUTION
DO NOT RE-ENGAGE STEERING
DURING THE TAKE-OFF RUN.

- 13. At approximately 10 KIAS below the calculated lift off speed, raise the nose.
- 14. After lift off and with positive rate of climb, proceed as follows:
 - a. Landing gear lever - LG UP. Check that the green landing gear position lights and the red light in the lever grip are out. Retraction of the landing gear requires approx. 5 seconds.

CAUTION
THE LANDING GEAR SHOULD BE
COMPLETELY UP AND LOCKED
BEFORE THE LIMIT AIRSPEED (175
KIAS) IS REACHED. EXCESSIVE
AERODYNAMIC LOADS MAY DAMAGE
THE LANDING GEAR DOORS
AND PREVENT THEIR SUCCESSIVE
OPERATION.

- b. Flap control lever - UP. Between 120 and 175 KIAS. The trim change is negligible. Check for retraction.

CAUTION
TO PREVENT STRUCTURE OVERSTRESSING,
THE FLAPS SHALL BE
RAISED BEFORE THE AIRSPEED
LIMIT (175 KIAS) IS EXCEEDED.

- 15. Hydraulic pressures - Check within limits.
- 16. Engine data readings - Check within limits.

CROSS-WIND TAKE-OFF

During a cross-wind take-off, use the same procedure as for normal take-off. It is however recommended that the control stick be moved upwind and the nose wheel lifted off at the speed recommended in the "Performance Data" manual to improve aircraft control. During ground run the aircraft tends to weathervane. After the nosewheel leaves the ground, act as necessary on the rudder to remain along the centerline track during the take-off run and following take-off. After breaking ground, be prepared to counteract the aircraft drift.

WARNING

CROSSWIND EFFECT INCREASES
AS A FUNCTION OF THE EXTERNAL
STORES CONFIGURATION.

TAKE-OFF FROM WET RUNWAYS

Take-off from wet runways may result in compressor stalls or flame out due to ingestion of water splashed by the nose wheel into air intakes. To prevent such occurrences, following precautions should be taken:

- A. Taxi at the lowest possible speed, avoiding puddles and water-covered areas.
- B. During the take-off run and until lift-off, hold the "RELIGHT" push-button pressed.
- C. Lift the nose wheel from the ground as soon as possible.

WARNING
CHECK THE INSTRUMENTS AND
SHUT DOWN THE ENGINE TO

ABORT TAKE-OFF IF COMPRESSOR STALL IS SUSPECTED. THE SYMPTOMS OF A TYPICAL STALL ARE LOW FREQUENCY NOISE AND ENGINE VIBRATION, A CONSIDERABLE DECELERATION OF THE AIRCRAFT AND A POSSIBLE RAPID DROP OF ENGINE RPM TO 70 TO 80%, WITH JPT INCREASE AFTER APPROX. 1 SECOND.

INSTRUMENT TAKE-OFF

Carry out the normal take-off procedure up to the steering disengagement then proceed as follows:

1. With the "HEADING SET" knob of the HSI control panel, set a heading consistent with the aircraft heading when aligned for the take-off.
2. Press the "HDG" push-button light on the "FLT DIR" panel and check that the ADI vertical bar is centered.
3. Release the brakes.
4. Maintain direction by differential braking up to approx. 50 KIAS using runway markings and lights.
5. At a speed of approximately 10 KIAS less than the calculated lift off speed, set a nose-up attitude of 7 degrees on the ADI.
6. Once lift off speed with 7 degrees nose up has been reached, the aircraft will become airborne. Maintain lateral and longitudinal control by using the ADI as main reference.
7. When the vertical velocity indicator indicates climb and the altimeter indicates altitude increase, retract the landing gear. Between 120 and 175 KIAS retract the flaps.
8. Maintain the attitude and allow the aircraft to accelerate up to 275 KIAS. Standard turns (max bank angle of 30 degrees) can be performed during acceleration provided airspeed is above 150 KIAS and altitude is above 500 feet AGL.

CLIMB

Refer to the "Performance data" manual for the table of the climbing speeds, distances travelled in climb, times to climb and fuel consumptions. Maintain the best climb speed for minimum time to altitude.

1. Start climb at 275 KIAS: engine as required.
2. Altimeter setting - As required.
3. Engine readings - Within limits.

NOTE

The normal JPT Limiting System operation can be affected by temporary EGT overshoots during climbs at 100% RPM.

This phenomenon (EGT raise above the limit of 756°C without the illumination of the JPT LMTR caution) can be originated by adverse combination of the operating tolerances of the JPT Limiting System components and is acceptable, provided that the EGT returns within the limits prescribed at section 5 in not more than 10 seconds, with EGT overshoot never exceeding the value of 790°C.

4. HSI - Correct indication.
5. ADI and stand-by attitude indicator - Correct operation.
6. Cabin pressurization - Check the cabin altimeter above 8000 ft (see fig. 1-59).

A brief check of the pressurization system can be carried out by checking the cabin altimeter and proceeding as follows:

--- From 8000 to 16000 ft (actual altitude), the cabin altimeter reading should remain almost constant at 8000 ft.

--- Between 16000 ft and 24000 ft the cabin altimeter should read half the aircraft altitude $\pm$ 500 ft.

--- Above 24000 ft the cabin altimeter should read half the aircraft altitude plus 1000 to 2000 ft.

7. Fuel transfer and quantity – Check.
8. Oxygen:
 - a. Pressure - Check.
 - b. OXY FLOW - Check operation.
 - c. OXY diluter level - As required.
9. Pitot and AOA heating - Check ON indication.
10. Hydraulic pressures - Within limits.

NOTE

The decrease of pressure of the emergency hydraulic system during a fast climb is normal. This is due to the cooling of the emergency accumulator resulting in a nitrogen pressure drop. The correct pressure is restored as soon as the aircraft reaches lower altitudes. In the event of a quick pressure drop in the emergency system in other flight conditions, the cause could be a nitrogen or hydraulic fluid leakage.

11. Electric loadmeters - Normal readings.

WARNING

IN ALL FLIGHT PHASES THE OPERATION OF THE ADI SHOULD

BE CROSS-CHECKED WITH THE STAND-BY ATTITUDE INDICATOR. IN CASE OF INCONSISTENT INDICATIONS IT IS OF THE UTMOST IMPORTANCE TO READ THE OTHER FLIGHT INSTRUMENTS IN ORDER TO DEFINE WHICH ONE PROVIDES THE CORRECT INDICATIONS.

12. LDG LT/TAXI LT – OFF.

CRUISE

The engine throttle, when necessary, can be slammed open to obtain a fast acceleration, but the engine life and characteristics will be maintained longer the throttle is operated slowly and abrupt RPM variations are kept to a minimum.

WARNING

DURING ENGINE RPM SETTING ENSURE THAT THE THROTTLE IS NOT MOVED BEYOND IDLE POSITION.

1. Every 10 to 15 minutes, check the following:

a. Engine instruments - Within limits.

NOTE

The normal JPT Limiting System operation can be affected by temporary EGT overshoots in level flight at high altitude, when gradually setting the throttle to 100% RPM.

This phenomenon (EGT raise above the limit of 756°C without the illumination of the JPT LMTR caution) can be originated by adverse combination of the operating tolerances of the JPT Limiting System components and is acceptable, provided that the EGT returns within the limits prescribed at section 5 in not more than 10 seconds, with EGT overshoot never exceeding the value of 790°C.

b. Electric load meters - Check load.

c. Hydraulic pressures - Within limits.

d. Oxygen - Check.

e. Cabin pressurization - Within limits.

f. CABIN TEMP - As required.

NOTE

During flight with fixed throttle setting, changes of RPM may occur (RPM creep) by varying speed and/or altitude. This phenomenon is an acceptable characteristic of the engine fuel system.

DESCENT

Refer to the "Performance Data" manual for the recommended descent speeds, time required, fuel consumed and distances travelled in descent. Refer

to Section VI for the chart of altitude lost during dive recovery.

WARNING

DURING ENGINE RPM SETTING ENSURE THAT THE IDLE DETENT IS NOT ENGAGED AND THE THROTTLE IS NOT MOVED BEYOND IDLE POSITION.

1. WINDSHIELD/DEMIST – ON.

NOTE

To prevent the formation of misting on the windshield and canopy interior surfaces during rapid descents from high altitude, several minutes before starting a descent adjust the cabin temp to maximum temperature by using the manual control.

2. ANTI-ICE/ENGINE - As required.

3. Navigations Systems - As required.

4. LDG LT/TAXI LT - As required.

5. ADI and HSI - Check for correct indications and compare to with the stand-by instruments.

6. Altimeter setting – Adjust.

7. ANTI-ICE/PITOT - Indication ON.

8. Fuel - Check quantity.

9. Hydraulic pressures - Check.

10. Shoulder harness - Locked.

11. MASTER ARMT – OFF.

CAUTION

AS NECESSARY, REVIEW THE APPROACH PROCEDURES AND CHECK FUEL REQUIRED TO ALTERNATE AIRFIELD.

INSTRUMENT APPROACH

HOLDING, PENETRATION AND TACAN APPROACH

Holding Pattern (Any Altitude)

1. Configuration - Cruise.

2. Speed - 180 KIAS.

3. Engine - 75% to 80% RPM.

Penetration descent and turn

4. Airspeed - 250 KIAS/.6 Mach.

5. Speedbrake - OUT.

6. Engine - 75% RPM.

Level-off

7. Below 175 KIAS:

- a. Landing gear - LG DOWN.
- b. Speedbrake - IN.
- c. Flap - TAKE OFF position.
- d. Airspeed - 140 KIAS.
- e. Throttle - As required to maintain speed (approx. 80% RPM).

Final approach

- 8. Flaps - DOWN (when starting descent).
- 9. Airspeed - 115 KIAS plus corrections (.45 AOA).
- 10. Landing gear - Check DOWN (three green lights on).
- 11. Speedbrake - Check retracted.
- 12. Engine - As required (75% to 80% RPM).

Go-around

- 1. Engine throttle - FULL.
- 2. Speedbrake - IN.
- 3. Attitude - 7 degrees nose-up, wings level.
- 4. Landing gear - LG UP (with positive climb indications).
- 5. Flaps - UP between 120 and 150 KIAS.
- 6. Throttle - Retard as necessary approaching 200 KIAS. Maintain this speed to regain the missed approach altitude.

RADAR APPROACH

Downwind

- 1. Configuration - Cruise.
- 2. Speed - 200 KIAS.
- 3. Engine - 75% to 80% RPM.
- 4. Speedbrake - Retracted.

Base leg

- 5. Speedbrake - OUT.

6. At 175 KIAS:

- a. Landing gear - LG DOWN.
- b. Speedbrake - IN.
- c. Flaps - TAKE OFF.
- d. Airspeed - Reduce to 140 KIAS.

7. Engine - As required to maintain 140 KIAS (approx. 80% RPM).

Final turn

- 8. Airspeed - 140 KIAS.
- 9. Landing gear - Check DOWN (three green lights on).
- 10. Flaps - Check TAKE OFF.
- 11. Speedbrake - Check retracted.
- 12. Engine - As required to maintain 140 KIAS (approx. 80% RPM).

Final approach (Glideslope)

- 13. Flap - DOWN (starting descent).
- 14. Speed - 115 KIAS plus corrections (.45 AOA).
- 15. Landing gear - Check DOWN (three green lights on).
- 16. Speedbrake - Check IN.
- 17. Engine - As required to maintain the airspeed (75% to 80% RPM).

Go-around

- 1. Engine throttle - FULL.
- 2. Speedbrake - IN.
- 3. Attitude - 7 degrees nose-up, wings level.
- 4. Landing gear - LG UP (with positive climb indications).
- 5. Flaps - UP between 120 and 150 KIAS.
- 6. Throttle - Retard as required approaching 200 KIAS. Maintain this speed to regain the missed approach altitude.

ILS APPROACH

Approach to glideslope

- 1. Speedbrake - OUT.

2. At 175 KIAS:

- a. Landing gear - LG DOWN.
 - b. Speedbrake - IN.
 - c. Flaps - TAKE OFF.
 - d. Airspeed - Reduce to 140 KIAS.
3. Throttle - As required to maintain 140 KIAS.
4. Maintain speed and configuration until the glideslope is intercepted.

Final approach (Glideslope)

- 5. Flaps - DOWN (starting descent).
- 6. Airspeed - 115 KIAS plus corrections (.45 AOA).
- 7. Landing gear - Check down (three green lights on).
- 8. Speedbrake - Check IN.
- 9. Engine - As required to maintain airspeed (75% to 80% RPM).

Go-around

- 1. Engine throttle - FULL.
- 2. Speedbrake - IN.
- 3. Attitude - 7 degrees nose-up, wings level.
- 4. Landing gear - LG UP (with positive climb indications).
- 5. Flaps - UP between 120 and 150 KIAS.
- 6. Throttle - Retard as required attaining 200 KIAS. Maintain this speed to regain the missed approach altitude.

APPROACH AND LANDING

For a normal landing procedure refer to figure 2-9.

Entering pattern

- 1. Airspeed - 250 KIAS.
- 2. Altitude - 1500 ft AGL.
- 3. ANTI-ICE/ENGINE - As required.

Break

- 4. Engine - 60% RPM.
- 5. Speedbrake - OUT.

Downwind

- 6. Shoulder harness - Check locked.
- 7. Landing gear - LG DOWN (below 175 KIAS). Check that the three green lights are on.

NOTE

The illumination of the taxi light is conditional on the correct locking of the landing gear in the down position. To permit the control tower check for landing gear down, move the "LDG LT/TAXI LT" switch to TAXI LT.

- 8. Speedbrake - IN. Check the indicator.
- 9. Flap - TAKEOFF (below 175 KIAS). Check the flap indicator for corresponding position.
- 10. Hydraulic pressures - Check.

CAUTION

ZERO PRESSURE INDICATION IN THE EMERGENCY HYDRAULIC SYSTEM MAY BE CAUSED BY A LEAK OF HYDRAULIC FLUID IN THE EMERGENCY SYSTEM. IN THE PRESENCE OF SUCH FAILURE CONDITION, AFTER CONTACT WITH RUNAWAY, IF A PRESSURE DECREASE HAPPENS ALSO IN THE MAIN HYDRAULIC SYSTEM, IT IS NECESSARY TO PERFORM A FULL STOP LANDING AS BEFORE THE TOTAL LOSS OF HYDRAULIC PRESSURE.

- 11. Engine - As required to maintain 140 KIAS.

Base turn - Final

- 12. Before starting base turn: flap DOWN (below: 150 KIAS). Check full extension of flaps on the indicator.
- 13. Base turn speed - Maintain 130 KIAS plus corrections.

NOTE

- On approach (until landing is assured) it is recommended that at least 60% RPM be maintained in order to obtain optimum engine acceleration time in the event of go-around. The acceleration time increases by approx 0.5 second for every 5% RPM below 60%.

- The landing gear down position can be confirmed if requested from the control tower by operating the relevant push-button on the engine throttle.

- 14. Level wings at 400 ft AGL.

15. On final - Maintain 115 KIAS plus corrections (optimum AOA).

16. LDG LT/TAXI LT - As required.

WARNING

THE BLIND FLYING HOOD, IF INSTALLED, MUST BE KEPT IN THE OPEN POSITION IN ORDER TO ENSURE SEAT SAFE EJECTION IN THE CASE OF AN EMERGENCY.

17. Threshold speed - 110 KIAS plus corrections.

Flare

18. Engine throttle - IDLE.

19. Touchdown speed - 95 to 100 KIAS plus corrections.

NOTE

Increase standard speeds 1.5 KIAS every 100 kg in excess of 3700 kg.

NORMAL LANDING CAUTION

THE ILLUMINATION OF THE "STEER" ADVISORY LIGHT WHEN THE LANDING GEAR CONTROL LEVER IS MOVED DOWN, INDICATES A FAILURE IN THE STEERING SYSTEM. IN THIS CASE, BEAR IN MIND THAT THE NOSE WHEEL COULD AUTOMATICALLY BE SLAVED TO THE RUDDER PEDALS.

During landing use the AOA indicator as the primary reference throughout the final approach phase.

If the runway length and conditions permit, aerodynamic braking may be carried out to conserve brakes and tires. To perform aerodynamic braking, increase the aircraft nose-up attitude after touch-down by gradually pulling the control stick back to the full aft position. Lower the aircraft nose and bring the nose-wheel in contact with the runway before the elevator becomes ineffective (at about 70 KIAS). Maintain directional control during the landing roll by use of rudder. Do not engage nose wheel steering. At a speed below 50 KIAS maintain directional control by differential braking. At the end of the landing run, engage the nose wheel steering ("STEER" indicator light on), then use the rudder pedals combined with this control.

WARNING

- PRIOR TO ENGAGING THE STEERING CONTROL, ENSURE THAT THE RUDDER PEDALS ARE CENTERED.

- BE PREPARED TO DISENGAGE THE NOSE WHEEL STEERING IN CASE OF SYSTEM MALFUNCTION.

CROSS-WIND LANDING

Cross-wind landings may be performed by using the normal landing procedures. However, while using normal approach speeds, counteract drift by the crab method, by the wing down method or by a combination of both, to keep the aircraft track aligned with the runway, leveling the wings just before touchdown.

In case of strong crosswind and/or with gusty wind with possibility of wind shear, it is recommended to maintain the flaps in the TAKE OFF position during landing, to improve the aircraft lateral control and to obtain, if needed, a quicker increase of airspeed with engine thrust. After touchdown, keep the control stick upwind and lower the nose wheel smoothly to the runway as soon as practical, maintaining a centerline track with rudder and, if needed, moderate use of brakes.

NOTE

Refer to the cross-wind take-off and landing chart in the "Performance Data" manual for effect of cross-winds.

LANDING AT HIGH MASS

When a landing at high mass must be performed, bear in mind that the maximum sinking speed at touchdown, in order not to effect the aircraft structural integrity, is much lower with increased weight than with normal landing weight (See limitations chart in Section V). A straight-in approach should therefore be flown at the airspeed specified in the "Performance Data" manual, using power to control the sinking rate. Flare should be gradual and touchdown smooth. A stall prior to touchdown could result in an abrupt and uncontrollable increase of the sinking speed with possibility of exceeding the permissible limits.

CAUTION

THE VERTICAL VELOCITY INDICATOR READINGS ARE SUBJECT TO LAG; THEREFORE THEY ARE RELIABLE DURING AN APPROACH UNDER CONSTANT CONDITIONS BUT NOT IN TRANSIENT PHASES SUCH AS FLARE AND TOUCHDOWN.

USE OF BRAKES WITH ANTI-SKID SYSTEM ON DRY RUNWAY

During a normal landing, the use of maximum aerodynamic braking and of the full length of the runway to stop the aircraft will conserve the wheel brakes and tire. However, when a minimum landing run is required, after touchdown, the nose wheel should be quickly lowered. Apply the brakes firmly and fully and allow the anti-skid system to provide the maximum deceleration. The anti-skid system will operate to give maximum performance braking.

WARNING

- WHENEVER A NON CONTROLLED INTERRUPTION OF THE BRAKING ACTION OCCURS DURING DECELERATION AT AN APPROX SPEED OF 40 KIAS, APPLY THE PROCEDURE FOR FAILURE OF THE GROUND SENSING CIRCUIT OF THE ANTI-SKID SYSTEM.
- MAXIMUM PERFORMANCE BRAKING AT HIGH MASS AND SPEED CAN CAUSE TIRE DEFLATION WHEN THE MAXIMUM ENERGY ABSORPTION LIMIT HAS BEEN EXCEEDED.
- IN CASE OF OVERHEATING (OR SUSPECTED OVERHEATING) OF THE BRAKE/WHEEL SYSTEM, THE AIRCRAFT SHOULD BE PARKED IN AN ISOLATED AREA AND PERSONNEL SHALL AVOID APPROACHING THE AIRCRAFT. THE AIRCRAFT SHOULD BE PARKED SO THAT WIND IS BLOWING FROM THE RIGHT SIDE TO PREVENT ANY FUEL DRAIN (FROM LEFT WING) FROM GETTING IN CONTACT WITH THE BRAKE/WHEEL SYSTEM.
- THE MAXIMUM TEMPERATURE OF THE BRAKE/WHEEL SYSTEM IS ATTAINED 5 TO 15 MINUTES AFTER BRAKING, IT IS THEREFORE NECESSARY TO WAIT AT LEAST 30 MINUTES FOR BRAKES AND TIRES TO COOL DOWN BEFORE PERFORMING ANY POST-FLIGHT AND PRE-FLIGHT OPERATIONS.

USE OF BRAKES WITHOUT ANTI-SKID SYSTEM ON DRY RUNWAY (ANTI-SKID DISCONNECTED OR INOPERATIVE)

In order to obtain optimal braking performance without anti-skid system, operate the brakes in a single smooth application with a constant increase of the pedal pressure. Extreme care should be used in applying brakes at high speed to prevent locking and skidding of the tires. When there is still a significant wing lift it is sufficient to apply a minimum braking pressure to cause a tire skidding. If skidding occurs, momentarily release pressure and again gradually increase brake pressure. This procedure will provide the shortest stop distance in the absence of the anti-skid system.

USE OF BRAKES WITH ANTI-SKID SYSTEM ON WET/ICY RUNWAY

The wet or icy runway landing technique is essentially the same as a normal landing. As for a normal landing, reduce the engine speed to IDLE immediately after the contact, and lower the nose wheel to the runway. Apply decisively the brakes when the nose wheel comes in contact with the runway then gradually move the control stick fully backward to obtain the maximum braking effect during landing run. The anti-skid system will avoid locking the wheels by efficiently producing the maximum possible deceleration in safe conditions depending on the existing conditions of the runway. During the high-speed part of the landing run the deceleration obtained will be minimum as the braking capacity is very low. As the speed decreases, the braking effectiveness will consequently increase and the anti-skid system will increase the deceleration. In case of cross-wind use the technique recommended for this cases.

USE OF BRAKES WITHOUT ANTI-SKID SYSTEM ON WET/ICY RUNWAYS (ANTI-SKID DISCONNECTED OR INOPERATIVE)

In case of disconnected or inoperative anti-skid the braking on wet or icy runways will require further attentions. The more effective technique is to apply the brakes in an intermittent way. When a skidding is perceived, the brakes must be momentarily released and re-applied. This procedure will provide the shortest stop distance for braking with inoperative anti-skid system. In case of wet or icy runway and without anti-skid system the wheels can be easily locked.

LANDING ON SHORT RUNWAYS WITHOUT ANTI-SKID SYSTEM

For landings on short runways, without anti-skid, the prescribed speed values for approach and touchdown shall be strictly adhered to. After touchdown, lower the aircraft nose by bringing the nose wheel in contact with the runway and move flaps to UP position. Gradually operate the brakes, in a single application with a constant and progressive increase of the pedals pressing as the speed decreases, by avoiding the tire skidding. Gradually move the control stick fully backward to obtain the maximum braking effect during landing run.

GO-AROUND

BEFORE TOUCHDOWN

WARNING

IF NECESSARY, TAKE THE DECISION TO GO AROUND AS SOON AS POSSIBLE USING FULL POWER. IF CONDITIONS DO NOT ALLOW A GO AROUND, DO NOT TRY TO MAINTAIN THE AIRCRAFT OFF THE

RUNWAY; CONTINUE TO FLIGHT
THE AIRCRAFT TO TOUCHDOWN
AND FOLLOW THIS PROCEDURE.

1. Engine throttle – FULL.
2. Speedbrake - IN, if extended.

NOTE

- Continue a normal approach (or the descent) until the engine is at the full throttle and the airspeed increases.

- If the touchdown is made, slightly lower the nose and accelerate to takeoff speed, then give the aircraft the take-off attitude and allow it to fly off the ground.

TOUCH AND GO

The following procedure is to be adopted when a normal landing has been attempted, the wheels are in contact with the runway and it is found necessary to take-off again immediately, before allowing the aircraft to stop:

1. Engine throttle - FULL.
2. Speedbrake - IN, if extended.
3. Engine instruments - Check.
4. Leave the flaps in the position selected for landing.
5. Accelerate to take-off speed then establish the take-off attitude.

AFTER TAKE-OFF

1. Landing gear - LG UP (with positive climb indications).
2. Between 120 KIAS and 150 KIAS - Flaps UP.
3. LDG LT/TAXI LT - OFF.
4. Check the landing gear, speedbrake and flaps indicators.

AFTER LANDING

After completion of the landing roll and when clear of the runway:

1. Flaps - UP.
2. Speedbrake - IN.
3. Hydraulic pressures - Within limits.
4. Trims - In neutral position.
5. Landing light - OFF (if ON).

6. Taxi light - As required.
7. Stand-by attitude indicator - Caged.
8. IFF - OFF.
9. TACAN - OFF.
10. VOR/ILS - OFF.
11. WINDSHIELD/DEMIST --- OFF.
12. ANTI-ICE/ENGINE and ANTI-ICE/PITOT - OFF.
13. Seat safety pin - In place.
14. Canopy - As required.

CAUTION

- IF CANOPY IS OPEN AND THERE IS STRONG WIND, FIRMLY HOLD THE CANOPY HANDLE, OPEN IT AND CHECK THAT IT IS LOCKED.

- DURING TAXIING, THE CANOPY MUST BE CLOSED OR OPEN AND LOCKED IN THE INTERMEDIATE POSITION BUT NOT FULLY OPEN.

ENGINE SHUT-DOWN

1. LDG LT/TAXI LT - OFF (if ON).
2. Parking brake - Applied.

CAUTION

AVOID APPLYING THE PARKING BRAKES IF BRAKES ARE SUSPECTED TO BE OVERHEATED.

3. On crew chief's signal:
 - a. Speedbrake - OUT.
 - b. Flaps - DOWN.
4. Engine throttle - Approx. 60% RPM.
5. Engine throttle - STOP.
6. UHF (COMM1) and VHF (aircrafts pre-mod. PTA -322) or V/UHF (COMM2) (aircraft postmod. PTA -322) – OFF.
7. IN GPS - OFF.
8. Gunsight - OFF (if installed).
9. BCN - OFF.
10. When the engine stops:

- a. ENGINE/MASTER - OFF.
- b. GEN 1 and GEN 2 - OFF.
- c. BATT - OFF.

CAUTION

KEEP CLEAR OF THE TAIL PIPE
AND DO NOT MOVE THE AIRCRAFT
INTO A HANGAR FOR AT
LEAST 15 MINUTES AFTER SHUTDOWN BECAUSE
OF THE POSSIBILITY
OF EXPLOSION FROM FUEL
VAPOR ACCUMULATION.

BEFORE LEAVING THE AIRCRAFT

CAUTION

WHEN PERFORMING THE
FOLLOWING OPERATIONS, PAY
ATTENTION TO AVOID PLACING
BULKY MATERIAL ON THE
INSTRUMENT PANEL COWLING
NOT TO CAUSE SCRATCHES AND
NICKS TO THE WINDSHIELD
INTERIOR SURFACE.

- 1. Wheel chocks - In place.
- 2. PARK & EMER BK-Released, if previously set.
- 3. Check that the safety pin is in place in the seat firing handle.
- 4. Disconnect the following:
 - a. Oxygen supply line and mask.
 - b. Radio connection.
 - c. Anti-g suit hose.

NOTE

Fasten the oxygen hose end to the cabin side by using the relevant special snap fastener.

- 5. Move the oxygen supply lever to OFF.
- 6. Release the straps by rotating 90 degrees the quick-release fitting disc and by firmly pressing it. Move back the knob in locked position.
- 7. Operate the release lever of the leg restraint garters and slide the lines out of the garters.
- 8. Disconnect the survival pack lowering line from the life jacket.
- 9. Leave the aircraft.

WARNING



- WHEN RISING OUT OF THE SEAT, PAY ATTENTION NOT TO BUMP WITH THE HEAD AGAINST THE HOOKS PROTRUDING FROM THE CANOPY FRAME.
- THE EXIT PROCEDURE FROM THE REAR COCKPIT MUST BE CARRIED OUT WITH FREE HANDS AND CAREFULLY.

- 10. If necessary, close and lock the canopy:

WARNING

USE THE SPECIAL HANDLE WHEN CLOSING THE CANOPY FROM THE OUTSIDE TO AVOID THE RISK THAT PLACING THE HANDS ELSEWHERE MAY RESULT IN THEM BEING TRAPPED IN THE NARROW SPACE EXISTING BETWEEN THE SEAT LEFT RAM AND THE CANOPY FRAME.

- 11. Underwing tanks and luggage pod (if installed)
 - Check the safety pins are inserted.
- 12. Report on the aircraft logbook the possible failures detected and the limitations exceeded during the flight.


DANGER AREAS**TEMPERATURE AND VELOCITY****ENGINE AT IDLE****FULL THROTTLE**

DANGER AREAS**NOISE LEVEL**



NOISE PROTECTION REQUIREMENTS	
DECIBEL	REQUIRED EAR PROTECTION
0-85 dB	No protection required
85-120 dB	Ear muffs or ear plugs
120-135 dB	Ear muffs and ear plugs
135-145 dB	Ear muffs and ear plugs
Above 145 dB	Limited time exposure Prohibited

FULL THROTTLE**NOTE**


- NOISE LEVEL AREAS IDENTICAL ON EACH SIDE OF AIRCRAFT.
- CONTOURS MAY BE ALTERED BY SURROUNDING OBSTACLES.



TURNING RADIUS AND GROUND CLEARANCE




TAKEOFF (TYPICAL)



INSTRUMENT TAKEOFF (TYPICAL)


- NORMAL TAKEOFF GROSS MASS OF 4400 kg.
- REFER TO "PERFORMANCE DATA" MANUAL FOR TAKEOFF DISTANCE AND SPEED AT OTHER GROSS MASSES.



- 8 BRAKE - RELEASE
- 7 ADI - VERTICAL BAR CENTERED
- 6 HSI HEADING SET ON RUNWAY HEADING
- 5 STEERING - DISENGAGED (STEER LIGHTS - OFF)
- 4 WARNING LIGHTS - OFF
- 3 ENGINE INSTRUMENTS - CHECK
- 2 THROTTLE - FULL
- 1 AIRCRAFT - LINED UP ON THE RUNWAY

HOLDING, PENETRATION AND TACAN APPROACH

(TYPICAL)



RADAR APPROACH (TYPICAL)

FINAL TURN

SPEED - 140 KIAS
ENGINE - 80% RPM

BASE LEG

SPEEDBRAKE - OUT
AIRSPEED - BELOW 175 KIAS
LANDING GEAR - LG DOWN
SPEEDBRAKE - IN
FLAPS - TAKEOFF
AIRSPEED - 140 KIAS
ENGINE - 80% RPM

DOWNWIND

CONFIGURATION - CRUISE
AIRSPEED - 200 KIAS
ENGINE - 75% ÷ 80% RPM

FINAL APPROACH (GLIDESLOPE)

FLAPS - DOWN
SPEED - 115 KIAS PLUS CORRECTION (.45 AOA)
ENGINE - 75% ÷ 80% RPM

GO-AROUND


THROTTLE - FULL
SPEEDBRAKE - IN
ATTITUDE - 7-DEGREE NOSE-UP
LANDING GEAR - LG UP
FLAPS - UP, 120/150 KIAS
THROTTLE - RETARD AS NECESSARY
ATTAINING 200 KIAS TO
REGAIN THE MISSED
APPROACH ALTITUDE

NOTE

TYPICAL RADAR APPROACH
PATTERN REQUIRES 80 kg
OF FUEL

ILS APPROACH

(TYPICAL)



LANDING AND GO-AROUND

(TYPICAL)

- NORMAL LANDING MASS OF 3700 kg.
- INCREASE CHARACTERISTIC SPEEDS BY 1.5 KIAS FOR EACH ADDITIONAL 100 kg.

BREAK

ENGINE - 60%
SPEEDBRAKE - OUT
BANK - 50 to 60 DEG

NOTE

- MAINTAIN RPM AT 60% ON FINAL UNTIL LANDING IS ASSURED.
- IN PRESENCE OF GUST WIND ADD HALF THE VALUE OF THE MAX GUST TO FINAL APPROACH SPEED.

FLAP-UP

DOWNWIND

SPEED - 175 KIAS
LANDING GEAR - LG DOWN
SPEEDBRAKE - IN
FLAPS - TAKE OFF
ENGINE AS NECESSARY TO MAINTAIN 140 KIAS

ENTERING PATTERN

SPEED - 250 KIAS
ALTITUDE - 1500 ft AGL
ANTI-ICE/ENGINE AS NECESSARY

LANDING GEAR-UP

TOUCHDOWN

THROTTLE - IDLE
TOUCHDOWN SPEED - 95 to 100 KIAS PLUS CORRECT.

THROTTLE-FULL SPEEDBRAKE-IN

SPEED - 150 KIAS
FLAPS - DOWN

THRESHOLD

SPEED - 110 KIAS

BASE TURN

SPEED - 130 KIAS
ENGINE - 60% RPM
TO BE COMPLETED AT ALTITUDE NOT BELOW 400 ft AGL

FINAL APPROACH

SPEED - 115 KIAS PLUS CORRECT. (.45 AOA)

NOTE

FUEL REQUIRED FOR GO-AROUND IS APPROX 25 kg.

9AA/FM/0128A03

GO-AROUND

SMOKE SYSTEM (BETA)

Starting from version 1.3.0, the MB-339 for MSFS implements a smoke system through the Visual Effects Editor (Beta) of the MSFS SDK.

In order to operate the smoke system, it is necessary to activate the smoke system switches in the Virtual Cockpit panel. These are:

- MASTER → Smoke system master switch
- WHITE → Energizes the WHITE smoke system
- COLOR → Energizes the COLOR smoke system



Once the switches are turned on, the smoke system is activated by toggling with wing and recognition lights respectively (this was done since, in real life, the smoke system is associated to triggers on the stick).

WING LIGHT (toggle) will activate / deactivate WHITE smoke

RECOGNITION LIGHT (toggle) will activate / deactivate COLOR smoke



The color smoke is dependent on the aircraft selection: in the liveries selection, you can pick the default MB339PAN (white smoke loaded in the color tank), or variants with green or red smoke.

Two advisory lights are mounted on the MB-339PAN cockpit to indicate that the smoke system is currently working.



NOTE: The smoke system is only available on the MB.339PAN

NOTE: The smoke system will operate correctly only on external views (apparently due to a bug in MSFS) and may not work correctly in multiplayer.

NOTE: Since the Visual Effects Editor is still in Beta, there is a (limited) chance that the smoke system may not work correctly in future releases.

SPECIAL VISIBILITY CONDITIONS

The external visual model features some “special visibility” conditions provided as eye-candy only.

WHEELCHOKS AND “REMOVE BEFORE FLIGHT” RIBBONS

These will appear automatically when the Battery and Generator Switches are off, with the aircraft stationary on the ground and engine RPM below 1% and the canopy is open. They will disappear if any of these conditions is not met.



BACKSEAT PILOT FIGURE

The backseat pilot figure is optional, but is present by default. It will disappear if the COPILOT weight is set to 0 in the FUEL and LOADOUT manager

PYLONS AND FUEL TANKS

Selecting any weight other than 0 for the PYLONS in the FUEL and LOADOUT manager will make the relevant pylon to appear (applies only to A and A-MLU models).

Selecting any weight greater or equal to 150 lbs for PYL 2 and PYL 5 will make external fuel tanks to appear.

NOTE: If underwing fuel tanks are loaded (by applying a 150 lbs fuel load to PYL2 or PYL5) you can add fuel to EXTERNAL1 and EXTERNAL2 fuel tanks.

If the fuel tanks are not present, any fuel applied to those tanks will be immediately deleted.

At the moment, it is not required to use the fuel transfer pump to use that fuel.

LIST OF KNOWN BUGS AND INACCURACIES

These are the known bugs and inaccuracies at the moment of the initial release. We will try to fix these with updates in future, but at the moment we were either not able to find satisfactory solutions to the problems, or felt that the specific feature was not essential or was above the scope of the project:

PANEL BACKLIGHTING AT NIGHT ALWAYS ON

At the moment, the panel backlight will turn on automatically at night, regardless of the switches status and of the electrical power. Reason for this is that when we implemented the knob-controlled backlighting, we faced a number of visual glitches and anomalies in the cockpit that we were not able to solve completely. Backlighting documentation in the MSFS SDK is incomplete and subject to change, hence we preferred to leave it as it is.

INVERTED FLIGHT

Like many jets, the real MB-339 has a limit to the duration of the inverted flight due to its fuel system. Any negative-G flight longer than 25 seconds may cause an engine flameout due to absence of fuel. This is currently not simulated, as the fuel system in MSFS seems to have some malfunctions.

LOMCOVAK

The real MB-339 is one of the very few jets capable of this manoeuvre – but at the moment it is not currently supported in the flight model.

CUSTOMIZABLE LOADOUTS AND WEAPONS

The real MB-339 can be and has been employed as a light attack fighter, and it is capable of carrying a variety of gun pods, rockets and bombs. At the moment these are not supported and the configuration is fixed. NOTE: MICROSOFT DOES NOT ALLOW WEAPONS (even non functional, graphic only models) TO BE REPRESENTED IN THE MARKETPLACE.

GPS FUNCTIONALITY

The GPS functionality is limited to the DATA mode at the moment.