



MOONEY

PILOT'S OPERATING HANDBOOK

**AND
FAA APPROVED**

AIRPLANE FLIGHT MANUAL

M20R - OVATION

**ORIGINAL ISSUE - 06-1994
REVISION G - 03-2000**

P/N: POH-003600

Copyright 2013 - All Rights Reserved

MOONEY AVIATION COMPANY, INC. *Louis Schreiner Field, Kerrville, Texas 78028 tel: 830-896-6000*
www.mooney.com

PILOT'S OPERATING HANDBOOK

AND

FAA APPROVED AIRPLANE FLIGHT MANUAL

MOONEY M20R

THIS HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED
TO THE PILOT BY THE FEDERAL AVIATION REGULATIONS, AND
CONSTITUTES THE FAA APPROVED AIRPLANE FLIGHT MANUAL.


THIS DOCUMENT MUST BE CARRIED IN THE AIRCRAFT AT ALL TIMES.

MOONEY AIRCRAFT CORPORATION
LOUIS SCHREINER FIELD
KERRVILLE, TEXAS 78028

SERIAL NUMBER 29-0045

REGISTRATION NUMBER OE-KGG

FAA APPROVED:



Michele M. Oswley
Manager, Airplane Certification Office
FEDERAL AVIATION ADMINISTRATION
2601 Meacham Boulevard
Fort Worth, Texas 76137-0150

FAA APPROVED in Normal Category based on CAR PART 3 and applicable portions of
FAR PART 23; applicable to Model M20R S/N listed above only;

Section VI, page 6-5 Revised Weight and Balance sheet dated 10/4/12 inserted
by Erik Rosdol on 15-Nov-2014

ORIGINAL ISSUE- 6-94
Revision F 9-96
Revision G 3-00

POH/AFM NUMBER - 3600

CONGRATULATIONS

WELCOME TO MOONEY'S NEWEST DIMENSION IN SPEED, QUALITY AND ECONOMY. YOUR DECISION TO SELECT A MOONEY AIRCRAFT HAS PLACED YOU IN AN ELITE AND DISTINCTIVE CLASS OF AIRCRAFT OWNERS. WE HOPE YOU FIND YOUR MOONEY A UNIQUE FLYING EXPERIENCE, WHETHER FOR BUSINESS OR PLEASURE, THE MOST PROFITABLE EVER.

- NOTICE -

This manual is provided as an operating guide for the Mooney Model M20R. It is important that you —regardless of your previous experience — carefully read the handbook from cover to cover and review it frequently.

All information and illustrations in the manual are based on the latest product information available at the time of publication approval and all sections including attached supplements are mandatory for proper operation of the aircraft. The right is reserved to make changes at any time without notice. Every effort has been made to present the material in a clear and convenient manner to enable you to use the manual as a reference. Your cooperation in reporting presentation and content recommendations is solicited.

REVISING THE MANUAL

The "I" pages of this manual contain a "List of Effective Pages" containing a complete current listing of all pages i.e., Original or Revised. Also, in the lower right corner of the outlined portion, is a box which denotes the manual number and issue or revision of the manual. It will be advanced one letter, alphabetically, per revision. With each revision to the manual a new List of Effective Pages showing all applicable revisions with dates of approval and a "Log of Revisions" page(s) with only the latest Revision shown, will be provided to replace the previous ones. It is the operators responsibility to ensure that this manual is current through the latest published revision.

This handbook will be kept current by Mooney Aircraft Corporation when the yellow information card in front of this handbook has been completed and mailed to :

**Mooney Aircraft Corporation
Service Parts Department
Louis Schreiner Field,
Kenville, TX., 78028.**

LIST OF EFFECTIVE PAGES

ORIGINAL	6-94
Revision A	7-94
Revision B	8-94
Revision C	9-94
Revision D	1-95
Revision E	9-95
Revision F	9-96
Revision G	3-00

Always destroy superseded pages when inserting revised pages.

TITLE PAGE G

CONGRATULATIONS ORIGINAL

i thru iv G
v, vi ORIGINAL

1-1, 1-2 ORIGINAL
1-3 F
1-4 C
1-5 ORIGINAL
1-6 thru 1-8 G
1-9, 1-10 ORIGINAL

2-1 G
2-2 B
2-3, 2-4 G
2-5 F
2-6, 2-7 ORIGINAL
2-8 G
2-9, 2-10 E
2-11, 2-12 G
2-13 D
2-14, 2-15 G
2-16, 2-17 A
2-18 ORIGINAL

3-1 thru 3-4 ORIGINAL
3-5 G
3-6 thru 3-7 E
3-8 A
3-9, 3-10 E
3-11 ORIGINAL
3-12 E
3-13 F
3-14, 3-15 E
3-16 ORIGINAL

4-1 F
4-2 thru 4-4 ORIGINAL
4-5 F
4-6 C
4-7, 4-8 E

POH/AFM NUMBER 3600 (G)

This POH/AFM effective beginning with M20R S/N 29-0001


LIST OF EFFECTIVE PAGES (con't.)

4-9 thru 4-12	ORIGINAL	F
4-13, 4-14	ORIGINAL	E
4-5, 4-16	ORIGINAL	
5-1	ORIGINAL	C
5-2	ORIGINAL	A
5-3	ORIGINAL	G
5-4 thru 5-12	ORIGINAL	C
5-13	ORIGINAL	E
5-14 thru 5-18	ORIGINAL	C
5-19	ORIGINAL	C
5-20 thru 5-30	ORIGINAL	
6-1 thru 6-6	ORIGINAL	F
6-7, 6-8	ORIGINAL	E
6-9	ORIGINAL	F
6-10	ORIGINAL	G
6-11	ORIGINAL	G
6-12	ORIGINAL	F
6-13, 6-14	ORIGINAL	G
6-15	ORIGINAL	G
6-16	ORIGINAL	G
6-17	ORIGINAL	G
6-18, 6-19	ORIGINAL	G
6-20 thru 6-22	ORIGINAL	F
6-23	ORIGINAL	G
6-24	ORIGINAL	G
6-25 thru 6-29	ORIGINAL	
6-30	ORIGINAL	
7-1, 7-2	ORIGINAL	G
7-3 thru 7-4	ORIGINAL	G
7-5 thru 7-30	ORIGINAL	
8-1	ORIGINAL	G
8-2	ORIGINAL	A
8-3 thru 8-6	ORIGINAL	
8-7	ORIGINAL	
8-8 thru 8-10	ORIGINAL	
9-1 through 9-4 (plus Applicable Supplements inserted)	ORIGINAL	
10-1	ORIGINAL	D
10-2 thru 10-10	ORIGINAL	D
10-11	ORIGINAL	
10-12	ORIGINAL	

POH/AFM NUMBER - 3600 (G)

This POH/AFM effective beginning with M20R S/N 29-0001

LOG OF REVISIONS

REVISION NUMBER	REVISED PAGES	DESCRIPTION OF REVISIONS	FAA APPROVED	DATE
G	Title Page, LOEP, Log of Revisions, 1-6, 1-7, 1-8, 2-1, 2-3, 2-8, 3-5, 7-1, 7-2, 7-5 thru 7-3, 8-2 2-4 5-13, 6-15, 6-16, 6-17, 6-20, 6-21, 6-22, 6-25 thru 6-29 2-11 thru 2-15	Revised Data Added Data Revised Chart Added Placard	 3/13/00	

The revised portions of affected pages are indicated by vertical black lines in the margin.

REVISION NUMBER	REVISED PAGES	DESCRIPTION OF REVISIONS	FAA APPROVED	DATE

POH/AFM NUMBER 3600 (G)

iv

TABLE OF CONTENTS

TITLE	SECTION
GENERAL	I
LIMITATIONS	II
EMERGENCY PROCEDURES	III
NORMAL PROCEDURES.	IV
PERFORMANCE	V
WEIGHT & BALANCE.	VI
AIRPLANE & SYSTEM DESCRIPTIONS	VII
HANDLING, SERVICE & MAINTENANCE.	VIII
SUPPLEMENTAL DATA	IX
SAFETY & OPERATIONAL TIPS.	X

BLANK

TABLE OF CONTENTS

TITLE	PAGE
THREE VIEW	1-2
INTRODUCTION	1-3
DESCRIPTIVE DATA	1-3
ENGINE	1-3
PROPELLER	1-3
FUEL	1-4
OIL	1-4
LANDING GEAR	1-4
MAXIMUM CERTIFICATED WEIGHTS	1-4
STANDARD AIRPLANE WEIGHTS	1-4
CABIN & ENTRY DIMENSIONS	1-5
BAGGAGE SPACE AND ENTRY DIMENSIONS	1-5
SPECIFIC LOADINGS	1-5
IDENTIFICATION PLATE	1-5
SYMBOLS, ABBREVIATIONS & TERMINOLOGY	1-5
GENERAL AIRSPEED TERMINOLOGY & SYMBOLS	1-5
ENGINE POWER TERMINOLOGY	1-6
AIRPLANE PERFORMANCE & FLIGHT PLANNING TERMINOLOGY	1-6
ENGINE CONTROLS & INSTRUMENTS TERMINOLOGY	1-7
METEOROLOGICAL TERMINOLOGY	1-7
WEIGHT & BALANCE TERMINOLOGY	1-8
MEASUREMENT CONVERSION TABLES	1-8




FIGURE 1 - 1 THREE VIEW - M20R

SECTION I
GENERAL
FUEL

MOONEY
M20R

Minimum Fuel Grade (Color)	100 LL (Blue) or 100 Octane (Green)
Total Capacity	95 U.S. Gal. (359.6 Liters)
Usable	89.0 U.S. Gal. (336.9 Liters)

OIL

Oil Specification	MHS-24()
and as Approved by TCM. (Reference Engine Maintenance & Operators Manual)	
All Temperatures	15W50 or 20W50
Above 30°F (-1°C) Ambient Air (S.L.)	SAE 50
Below 50°F (10°C) Ambient Air (S.L.)	SAE 30, 10W30
Total Oil Capacity	8 Qts. (7.57 liters)
Oil Filter	Full Flow

Oil grades, specifications and changing recommendations are contained in SECTION VIII.

LANDING GEAR

TYPE: Electrically operated, fully retractable tricycle gear with rubber shock discs. The main wheels have hydraulically operated disc brakes. The nose wheel is fully steerable 11° left to 13° right of center.

Wheel Base	79 9/16 in. (198.91 cm)
Wheel Track	110 in. (279.4 cm)

Tire Size:	
Nose	5.00 x 5 (6 ply)
Main	6.00 x 6 (6 ply)
Tire Pressure	
Nose	49 PSI
Main	42 PSI

Minimum Turning Radius (No brakes applied)	
Right	40 ft. (12.0 m)
Left	48 ft. (14.4 m)

MAXIMUM CERTIFICATED WEIGHTS

Gross Weight	3368 Lbs. (1528 Kg)
Maximum Landing Weight	3200 Lbs. (1452 Kg)
Baggage Area	120 Lbs. (54.4 Kg)
Rear Storage Area	10 Lbs. (4.5 Kg)
Cargo (Rear Seats Folded Down)	340 Lbs. (154.2 Kg)

STANDARD AIRPLANE WEIGHTS

Basic Empty Weight	See Page 1-8
Useful Load	Varies with installed equipment.

See SECTION VI for specific airplane weight (pg. 6-5).

INTRODUCTION

This Operators Manual conforms to GAMA Specification No. 1 and includes both Manufacturers material and FAA APPROVED material required to be furnished to the Pilot by the applicable Federal Aviation Regulations. Section IX contains supplemental data supplied by Mooney Aircraft Corporation.

Section I contains information of general interest to the pilot. It also contains definitions of the terminology used in this Operators Manual.

This Pilot's Operating Handbook is not designed as a substitute for adequate and competent flight instruction, knowledge of current airworthiness directives, applicable federal air regulations or advisory circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in an up to date status.

All limitations, procedures, safety practices, servicing and maintenance requirements published in this POH/AFM are considered mandatory for the Continued Airworthiness of this airplane in a condition equal to that of its original manufacture.

DESCRIPTIVE DATA**ENGINE**

Number of engines	1
Engine Manufacturer	Teledyne Continental Motors (TCM)
Model	IO-550-G(5)*
Recommended TBO	2000 Hours
Type	Reciprocating, air cooled, fuel injected
Number of cylinders	6, Horizontally opposed
Displacement	550 Cu. In. (9014 cc)
Bore	5.25 In. (13.3 cm)
Stroke	4.25 In. (10.8 cm)
Compression ratio	8.5 : 1

Fuel System

Type	Fuel Injection
Make	TCM
Fuel-Aviation Gasoline	100 octane - 100LL

Accessories

Magnetos	Bendix - S6RN-25
Ignition Harness	Shielded/Braided
Spark Plugs	AC 273 (or equivalent) (18 m/m)
Oil Cooler	TCM Full Flow
Alternator	28 Volt DC, 100 AMPS
Starter	24 volt DC

Ratings:

Maximum Takeoff Sea Level BHP/RPM	280/2500
-----------------------------------	----------

PROPELLER

Number	1
Manufacturer	McCauley
Model Number	3A32C418/(G)-82NRC-9*
Number of Blades	3
Diameter (1/2 in. cutoff allowed)	73 in. (185.4 cm)
Type	Constant Speed
Governor (McCauley)	Hydraulically controlled by engine oil
Blade Angles @ 30.0 in. Sta.:	
Low	16.1 degrees + /- 0.2 degrees
High	40 degrees + /- 0.5 degrees

* Refer to TCDS for engine/propeller configuration required.

CABIN AND ENTRY DIMENSIONS

Cabin Width (Maximum)		43.5 in. (110.5 cm)
Cabin Length (Maximum)		126 in. (315 cm)
Cabin Height (Maximum)		44.5 in. (113 cm)
Entry Width (Minimum)		29.0 in. (73.4 cm)
Entry Height (Minimum)		35.0 in. (88.9 cm)

BAGGAGE SPACE AND ENTRY DIMENSIONS

Compartment Width		24 in. (60.9 cm)
Compartment Length		43 in. (109.2 cm)
Compartment Height		35 in. (88.9 cm)
Compartment Volume		20.9 cu. ft. (.592 cu. m)
Cargo Area (with rear seat folded down)		38.6 cu. ft. (1.09 cu. m)
Entry Height (Minimum)		20.5 in. (52.1 cm)
Entry Width		17.0 in. (43.2 cm)
Ground to Bottom of Sill		46.0 in. (116.8 cm)

SPECIFIC LOADINGS

Wing Loading - @ Maximum Gross Weight		19.26 lbs./sq. ft. (94 kg/sq. m)
Power Loading - @ Maximum Gross Weight		12.02 lbs./HP (5.46 kg/HP)

IDENTIFICATION PLATE

All correspondence regarding your airplane should include the Serial Number as depicted on the Identification plate. The identification plate is located on the left hand side, aft end of the tail cone, below the horizontal stabilizer leading edge. The aircraft Serial Number and type certificate are shown.

SYMBOLS, ABBREVIATIONS & TERMINOLOGY**GENERAL AIRSPEED TERMINOLOGY & SYMBOLS**

GS	GROUND SPEED - Speed of an airplane relative to the ground.
KCAS	KNOTS CALIBRATED AIRSPEED - The indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KIAS	KNOTS INDICATED AIRSPEED - The speed of an aircraft as shown on its airspeed indicator. IAS values published in this handbook assume zero instrument error.
KTAS	KNOTS TRUE AIRSPEED - The airspeed of an airplane relative to undisturbed air which is the KCAS corrected for altitude and temperature.
V _a	MANEUVERING SPEED - The maximum speed at which application of full available aerodynamic control will not overstress the airplane.
V _{fe}	MAXIMUM FLAP EXTENDED SPEED - The highest speed permissible with wing flaps in a prescribed extended position.
V _{lo}	MAXIMUM LANDING GEAR EXTENDED SPEED - The maximum speed at which an aircraft can be safely flown with the landing gear extended.

GENERAL AIRSPEED TERMINOLOGY & SYMBOLS (con't.)

V_{lo}	MAXIMUM LANDING GEAR OPERATING SPEED - The maximum speed at which the landing gear can be safely extended or retracted.
V_{ne}	NEVER EXCEED SPEED - The speed limit that may not be exceeded at any time.
V_{no}	MAXIMUM STRUCTURAL CRUISING SPEED - The speed that should not be exceeded except in smooth air and then only with caution.
V_s	STALLING SPEED - The minimum steadyflight speed at which the airplane is controllable.
V_{so}	STALLING SPEED - The minimum steady flight speed at which the airplane is controllable in the landing configuration.
V_x	BEST ANGLE-OF-CLIMB SPEED - The airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
V_y	BEST RATE-OF-CLIMB SPEED - The airspeed which delivers the greatest gain in altitude in the shortest possible time with gear and flaps up.

ENGINE POWER TERMINOLOGY

BHP	BRAKE HORSEPOWER - Power developed by the engine.
CHT	CYLINDER HEAD TEMPERATURE - Operating temperature of engine cylinder(s) being monitored by sensor unit. Expressed in °F.
EGT	EXHAUST GAS TEMPERATURE - The exhaust gas temperature measured in the exhaust pipe manifold. Expressed in °F.
MCP	MAXIMUM CONTINUOUS POWER - The maximum power for takeoff, normal, abnormal or emergency operations.
MP	MANIFOLD PRESSURE - Pressure measured in the engine's induction system and expressed in inches of mercury (Hg).
RPM	REVOLUTIONS PER MINUTE - Engine speed.

AIRPLANE PERFORMANCE AND FLIGHT PLANNING TERMINOLOGY

Demonstrated Crosswind Velocity	The velocity of the crosswind component for which adequate control of the airplane during takeoff and landing test was actually demonstrated during certification. The value shown is not considered to be limiting.
g	Acceleration due to gravity.
Service Ceiling	The maximum altitude at which aircraft at gross weight has the capability of climbing at the rate of 100 ft/min.

ENGINE CONTROLS & INSTRUMENTS TERMINOLOGY

Propeller Control	The control used to select engine speed.
Throttle Control	The control used to select engine power by controlling MP.
Mixture Control	Provides a mechanical linkage to the fuel injector mixture control to control the size of the fuel feed aperture, and therefore the air/fuel mixture. It is the primary method to shut the engine down.
CHT Gauge	Cylinder head temperature indicator used to determine that engine operating temperature is within manufacturers specifications.
Tachometer	An instrument that indicates rotational speed of the engine. The speed is shown as propeller revolutions per minute (RPM).
Propeller Governor	The device that regulates RPM of the engine/propeller by increasing or decreasing the propeller pitch, through a pitch change mechanism in the propeller hub.

METEOROLOGICAL TERMINOLOGY

AGL	Above ground level.
Density Altitude	Altitude as determined by pressure altitude and existing ambient temperature. In standard atmosphere (ISA) density and pressure altitude are equal. For a given pressure altitude, the higher the the temperature, the higher the density altitude.
Indicated Altitude	The altitude actually read from an altimeter when, and only when barometric subscale (Kollsman window) has been set to Station Pressure.
ISA	INTERNATIONAL STANDARD ATMOSPHERE assumes that (1) The air is a dry perfect gas; (2) The temperature at sea level is 15 degrees Celsius (59°F); (3) The pressure at sea level is 29.92 inches Hg (1013.2 mb); (4) The temperature gradient from sea level to the altitude at which the temperature is -56.5°C (-69.7°F) is -0.00198°C (-0.003564°F) per foot.
OAT	OUTSIDE AIR TEMPERATURE - The free air static temperature, obtained either from inflight temperature indications or ground meteorological sources. It is expressed in °C.
Pressure Altitude	The indicated altitude when Kollsman window is set to 29.92 in. Hg. or 1013.2 MB. In this handbook, altimeter instrument errors are assumed to be zero.
Station Pressure	Actual atmospheric pressure at field elevation.

WEIGHT AND BALANCE TERMINOLOGY

Arm	The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Basic Empty Weight	The actual weight of the airplane and includes all operating equipment (including optional equipment) that has a fixed location and is actually installed in the aircraft. It includes the weight of unusable fuel and full oil.
Center of Gravity (C.G.)	The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.

WEIGHT AND BALANCE TERMINOLOGY (con't.)

C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. in % MAC	Center of Gravity expressed in percent of mean aerodynamic chord (MAC).
C.G. Limits	The extreme center of gravity locations within which the airplane must be operated at a given weight.
MAC	Mean Aerodynamic Chord.
Maximum Weight	The maximum authorized weight of the aircraft and its contents as listed in the aircraft specifications.
Maximum Landing Weight	The maximum authorized weight of the aircraft and its contents when a normal landing is to be made.
Moment tations	The product of the weight of an item multiplied by its arm: (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Reference Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Tare	The weight of chocks, blocks, stands, etc. used when weighing an airplane, and is included in the scale readings. Tare is deducted from the scale reading to obtain the actual (net) airplane weight.
Unusable Fuel	Fuel remaining after a runout test has been completed in accordance with governmental regulations.
Usable Fuel	Fuel available for aircraft engine combustion.
Useful Load	The basic empty weight subtracted from the maximum weight of the aircraft. This load consists of the pilot, crew (if applicable), useable fuel, passengers, and baggage.

MEASUREMENT CONVERSION TABLES

LENGTH

U. S. Customary Unit	Metric Equivalents
1 inch	2.54 centimeters
1 foot	0.3048 meter
1 yard	0.9144 meter
1 mile (statute, land)	1,609 meters
1 mile (nautical, international)	1,852 meters

AREA

U. S. Customary Unit	Metric Equivalents
1 square inch	6.4516 sq. centimeters
1 square foot	929 sq. centimeters
1 square yard	0.836 sq. meter

VOLUME OR CAPACITY

U. S. Customary Unit Metric Equivalents

1 cubic inch		16.39 cubic centimeters
1 cubic foot		0.028 cubic meter
1 cubic yard		0.765 cubic meter

U.S. Customary Liquid Measure Metric Equivalents

1 fluid ounce		29.573 milliliters
1 pint		0.473 liter
1 quart		0.946 liter
1 gallon		3.785 liters

U.S. Customary Dry Measure Metric Equivalents

1 pint		0.551 liter
1 quart		1.101 liters

British Imperial Liquid and Dry Measure U. S. Equivalents Metric Equivalents

1 fluid ounce		. 0.961 U.S. fluid ounce, 1.734 cubic inches		28.412 milliliters
---------------	-----------	---	-----------	--------------------

1 pint		. 1.032 U.S. dry pints, 1.201 U.S. liquid pts., 34.678 cubic inches		568.26 milliliters
--------	-----------	---	-----------	--------------------

1 quart		. 1.032 U.S. dry quarts 1.201 U.S. liquid qts., 69.354 cubic inches		1.136 liters
---------	-----------	---	-----------	--------------

1 gallon		. 1.201 U.S. 277.420 cubic inches		4.546 liters
----------	-----------	-----------------------------------	-----------	--------------

WEIGHT

U. S. Customary Unit (Avoirdupois) Metric Equivalents

1 grain		. 64.79891 milligrams
1 dram		. 1.772 grams
1 ounce		. 28.350 grams
1 pound		. 453.6 grams

PRESSURE

U.S. Customary Unit Metric Equivalents

1 PSIG		6.895 KPA
1 Inch Hg		3.388 KPA
1 Inch Hg		25.40 mm Hg

COMMON CONVERSIONS

1 pound/square foot	.	.	.	.	.	.	.	.	0.488 kg/ meter square
1 pound /sq. inch	.	.	.	.	.	.	.	.	.2036 inch Hg.
1 Pound/HP	.	.	.	.	.	.	.	.	. 0.4538 kg/HP

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	2-2
NOISE LIMITS	2-2
AIRSPED LIMITATIONS	2-3
AIRSPED INDICATOR MARKINGS	2-4
POWER PLANT LIMITATIONS	2-5
POWER PLANT INSTRUMENT MARKINGS	2-6
FUEL LIMITATIONS	2-7
WEIGHT LIMITS	2-7
CENTER OF GRAVITY (GEAR DOWN)	2-7
MANEUVER LIMITS	2-8
FLIGHT LOAD FACTOR LIMITS	2-8
FLIGHT CREW	2-8
OPERATING LIMITATIONS	2-8
OXYGEN SYSTEM LIMITATIONS.	2-8
KINDS OF OPERATION LIMITS	2-8
KINDS OF OPERATION EQUIPMENT LIST	2-8
DECALS & PLACARDS	2-11
CABIN INTERIOR	2-11
FUSELAGE INTERIOR	2-15
EXTERIOR	2-16

INTRODUCTION

SECTION II includes the mandatory operating limitations, instrument markings, and basic placards necessary for the safe operation of the airplane, its engine, standard systems and standard equipment.

The limitations included in this section have been approved by the Federal Aviation Administration.

When applicable, limitations associated with optional systems or equipment such as autopilots are included in SECTION IX.

NOTE

The airspeeds listed in the Airspeed Limitations chart (Figure 2-1) and the Airspeed Indicator Markings chart (Figure 2-2) are based on Airspeed Calibration data shown in SECTION V with the normal static source. If the alternate static source is being used, ample margins should be observed to allow for the airspeed calibration variations between the normal and alternate static sources as shown in SECTION V.

Your Mooney is certificated under FAA Type Certificate No. 2A3 as a Mooney M20R.

NOISE LIMITS

The certificated noise level for the Mooney M20R at 3368 lbs. (1528 Kg.) maximum weight is 72.6 dB(A). No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into, or out of, any airport.

AIRSPEED LIMITATIONS

Airspeed limitations and their operational significance are shown in Figure 2-1. This calibration assumes zero instrument error.

V / SPEED		KCAS/KIAS	REMARKS
V _{NE}	Never Exceed Speed	196/195	Do not exceed this speed in any operation.
V _{NO}	Maximum Structural Cruising Speed	175/174	Do not exceed this speed except in smooth air, and then only with caution.
V _A	Maneuvering Speed at:		
	lbs. /Kg.		
	2232/1012	104/103	Do not make full or abrupt control movement above this speed.
	2430/1102	109/108	
	3300/1497	127/126	
3368/1528	128/127		
V _{FE}	Maximum Flap Extended Speed	111/110	Do not exceed this speed with flaps in full down position.
V _{LE}	Maximum Landing Gear Extended Speed	166/165	Maximum speed at which the aircraft can be safely flown with the landing gear extended.
V _{LO} (EXT)	Max. Speed for Gear Extension	141/140	Max. speed at which the landing gear can be safely extended.
V _{LO} (RET)	Max. Speed for Gear Retraction	107/106	Maximum speed at which the landing gear can be safely retracted.
	Maximum Pilot Window Open Speed	133/132	Do not exceed this speed with pilot window open.

=====

FIGURE 2-1 AIRSPEED LIMITATIONS

AIRSPEED INDICATOR MARKINGS

Airspeed indicator markings, their color code and operational significance are shown in Figure 2-2.

MARKING	IAS VALUE or RANGE (KIAS)	SIGNIFICANCE
White Arc (Flap Operating Range)	59-110 KIAS	Lower limit is maximum weight V_{SO} in landing configuration. Upper limit is maximum speed permissible with flaps extended.
Green Arc (Normal Operating Range)	66-174 KIAS	Lower limit is maximum weight V_S with flaps retracted. Upper limit is maximum structural cruising speed.
Yellow Arc (Caution Range)	174-195 KIAS	Operations must be conducted with caution and only in smooth air.
Radial Red Line	195 KIAS	Maximum speed for all operations.

FIGURE 2-2 AIRSPEED INDICATOR MARKINGS

POWER PLANT LIMITATIONS

Number of Engines 1

Engine Manufacturer Teledyne Continental Motors (TCM)

Engine Model Number IO-550-G(5) *

Engine Operating Limits for Takeoff and Continuous Operations:

Maximum Continuous Power	280 BHP
Maximum Continuous RPM	2500 RPM
Transient RPM Limit	2600 RPM
Maximum Cylinder Head Temperature	460° F (237.7° C)
Maximum Oil Temperature	240° F (115° C)
Minimum Oil Temperature-Takeoff	75° F (24° C)
Recm'ded Cruising Temperature	170° F-200° F (76° C-93° C)
Oil Pressure	
Normal Operating	30-60 PSI
Minimum (IDLE ONLY)	10 PSI

Oil Specification MHS-24(), MHS-25() and TCM Approved oils

Fuel Grade (Color) 100LL (Blue)** or 100 octane (Green) **

Number of Propellers 1

Propeller Manufacturer McCauley
Propeller/Blade Model Number 3A32C418/(G)-82NRC-9 *

Number of Blades 3

Propeller Diameter: McCauley

Min	72.5 in. (184.2 cm)
Max	73 in. (185.4 cm)

McCauley - Propeller Blade Angles @ 30.0 in. sta.:

Low	16.1 Degrees + /- 0.2 Degrees
High	40.0 Degrees + /- 0.5 Degrees

Propeller Operating Limits (McCauley) 2500 RPM

* Refer to TCDS for engine/propeller configuration required.

** 100LL fuel is calibrated at 5.82 lb/gal(.69 Kg/liter)
100 octane fuel is calibrated at 6.0 lb.gal. (.72 Kg/liter)

POWER PLANT INSTRUMENT MARKINGS

INSTRUMENT	REDLINE MINIMUM LIMIT	GREEN ARC NORMAL OPERATING	YELLOW ARC	REDLINE MAXIMUM LIMIT
=====				
Tachometer	600 RPM No Redline	2200-2500 RPM	—	2500 RPM
Cylinder Head Temperature		250-420° F (121 - 215.5° C)	420 - 460° F (215.5-237.7° C)	460° F (237.7° C)
Oil Temperature	No Redline	170 -220° F (76.6 - 104° C)	100 - 170° F (37.7-76.6° C) 220° - 240° (104° - 115.5° C)	240° F (115.5° C)
Oil Pressure	10.0 PSI (IDLE ONLY)	30-60 PSI	10 - 30 PSI 60 - 100 PSI	100 PSI
Exhaust Gas Temperature		1400-1450° F (760-788° C) (BLUE ARC =	recommended climb)	1650° F (899° C)
=====				
NOTE Refer to TCM Engine Maintenance and Operators Manual Section on Engine Specifications and Operating Limits for recommended cruise power and temperature limitations.				

FIGURE 2 - 3 POWER PLANT INSTRUMENT MARKINGS

FUEL LIMITATIONS

//////////
//WARNING//
 //////////

Takeoff maneuvers, when the selected fuel tank contains less than 12 gallons (45.4 liters) of fuel, have not been demonstrated.

[NOTE]

Each fuel quantity gauge is calibrated to read zero (RED LINE) only in coordinated level flight when remaining quantity of fuel can no longer be safely used.

[NOTE]

An optional, visual fuel quantity gauge is installed on top of each tank and is to be used as a reference for refueling tanks only.

Standard Tanks (2)		47.5 U.S. Gal. each (179.8 liters)
Total Fuel		.95 U.S. Gal. (359.6 liters)
Usable Fuel:		.89 U.S. Gal. (336.8 liters)
Unusable Fuel:		6 U.S. Gal. (22.7 liters)

Fuel Grade (and color): 100LL (low lead) (blue) or 100 octane (green) is approved.

~~~~~  
**~CAUTION~**  
 ~~~~~

To reduce possibility of ice formation within the aircraft or engine fuel system it is permissible to add ISO-PROPYL alcohol to the fuel supply in quantities NOT TO EXCEED 3% of total fuel volume per tank. DO NOT add other additives to fuel system due to potential deteriorating effects within the fuel system.

WEIGHT LIMITS

Maximum Weight - Takeoff		3368 lb. (1528 Kg.)
Maximum Weight - Landing		3200 lb. (1452 Kg)
Maximum Weight in Baggage Compartment		120 lb.
	(54.4 Kg.) @ Fus. Sta. 101.5 (253.7 cm)	
Maximum Weight in Rear Storage Area		10 lb.
	(4.54 Kg.) @ Fus. Sta. 131.0 (297.5 cm)	
Maximum Weight in Cargo Area (Rear seats folded down)		340 lbs.
	(154.2 KG) @ Fus. Sta. 70.7 (176.8 cm)	

CENTER OF GRAVITY LIMITS (GEAR DOWN)

Most Forward		Fus. Sta. 41.0 IN. (104.1 cm) @ 2430 LB. (1102 Kg)
		16.79% MAC
Intermediate Forward		Fus. Sta. 44 IN. (111.7 cm) @ 3300 lb. (1497 Kg)
		21.7% MAC
Forward Gross		Fus. Sta. 46.0 IN. (116.8 cm) @ 3368 lb (1528 Kg)
		24.98% MAC
Aft Gross		Fus. Sta. 51.0 IN (129.5 cm) @ 3368 lb. (1528 Kg)
		33.18% MAC
MAC (at Wing Sta. 94.85) (241 cm)		61.00 In.

Datum (station zero) is 13 inches (32.5 cm) aft of the center line of the nose gear trunion attach/pivot bolts.

FAA APPROVED
 ISSUED 6 - 94

AIRPLANE FLIGHT MANUAL

2 - 7

MANEUVER LIMITS

This airplane must be operated as a Normal Category airplane. Aerobatic maneuvers, including spins, are prohibited.

| NOTE |

Up to 500 foot altitude loss may occur during stalls at maximum weight.

FLIGHT LOAD FACTOR LIMITS

Maximum Positive Load Factor	
Flaps Up	+3.8 g.
Flaps Down (33 Degrees)	+2.0 g.
Maximum Negative Load Factor	
Flaps Up	-1.5 g.
Flaps Down	0.0 g.

FLIGHT CREW

Pilot	One
Maximum passenger seating configuration	Three

OPERATING LIMITATIONS

When aircraft is not equipped with an approved oxygen system and flight operations above 12,000 ft. are desired, this airplane must be, (1) equipped with supplemental oxygen in accordance with FAR 23.1441, (2) operate in accordance with FAR 91.32 and (3) equipped with avionics in accordance with FAR 91 or FAR 135.

ALTERNATOR OPERATING LIMITATIONS IS 94 AMPS.

KINDS OF OPERATION LIMITS

This is a Normal Category airplane certified for VFR/IFR day or night operations when the required equipment is installed and operational as specified in the KINDS OF OPERATION EQUIPMENT LIST and the applicable operating rules.

Optional equipment installations may not be required to be operational.

The pilot must determine that the applicable operating rules requirements for each kind of operation are met.

OPERATIONS IN KNOWN ICING CONDITIONS ARE PROHIBITED.

Autopilot Limitations - See SECTION IX.

KINDS OF OPERATION EQUIPMENT LIST

The following equipment was approved during Type Certification and must be installed and operable for each kind of operation as specified.

| NOTE |

The KINDS OF OPERATION EQUIPMENT list may not include all the equipment as required by applicable operating rules.

SEE NEXT PAGE FOR LISTINGS.

KINDS OF OPERATION EQUIPMENT LIST

SYSTEM or COMPONENT	VFR DAY *				VFR NIGHT				IFR DAY				IFR NIGHT			
AIRSPPEED INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
ALTIMETER, SENSITIVE	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
MAGNETIC DIRECTION INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
MANIFOLD PRESSURE GAUGE	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
TACHOMETER	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
FUEL QUANTITY INDICATOR	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
FUEL PRESSURE INDICATOR	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
OIL PRESSURE INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
OIL TEMPERATURE INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
CYLINDER HEAD TEMPERATURE INDICATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
EXHAUST GAS TEMPERATURE INDICATOR	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
AMMETER	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
ALTERNATOR	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
LANDING GEAR POSITION INDICATOR	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
SEAT BELT & SHOULDER HARNESS FOR EACH OCCUPANT **.	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
OXYGEN MASK FOR EACH OCCUPANT ***	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
POSITION LIGHTS	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3
STROBE LIGHTS (ANTI-COLLISION)	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3

* Equipment must be installed and operable for all operations.

** If inoperative for unoccupied seat(s), seat(s) must be placarded:
"DO NOT OCCUPY"

*** Only required when the operating rules require use of oxygen.

KINDS OF OPERATION EQUIPMENT LIST (con't.)

SYSTEM or COMPONENT (con't.)

	VFR DAY *			
			VFR NIGHT	
			IFR DAY	
			IFR NIGHT	
GYRO-HORIZON	1	1	1	1
DIRECTIONAL GYRO	1	1	1	1
TURN COORDINATOR or TURN & BANK INDICATOR	1	1	1	1
LANDING LIGHT ****	1	1	1	1
INSTRUMENT LIGHTS (INTERNAL or GLARESHIELD)	1	1	1	1
CLOCK (WITH SWEEP SECOND HAND or DIGITAL)	1	1	1	1
COMMUNICATION SYSTEM	1	1	1	1
NAVIGATION SYSTEM (APPROPRIATE TO FACILITIES BEING USED)	1	1	1	1
BATTERY	2	2	2	2
VACUUM SYSTEM/INDICATOR	1	1	1	1
FUEL BOOST PUMP	1	1	1	1
PILOT'S OPERATING HANDBOOK & AIRPLANE FLIGHT MANUAL	1	1	1	1
PITOT, Heated ****	1	1	1	1
OAT GAUGE ****	1	1	1	1
VSI ****	1	1	1	1
ALTERNATE STATIC SOURCE ****	1	1	1	1
STAND-BY VACUUM SYSTEM ****	1	1	1	1

* Equipment must be installed and operable for all operations.
 **** When required by the appropriate regulations.

DECALS AND PLACARDS**CABIN INTERIOR**

The following placards are relevant to proper operation of the airplane and must be installed inside the cabin at the locations specified.

OPERATING LIMITATIONS THE MARKINGS AND PLACARDS INSTALLED IN THIS AIRPLANE CONTAIN OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS AIRPLANE IN THE NORMAL CATEGORY. THIS AIRPLANE IS CERTIFIED FOR DAY AND NIGHT VFR/IFR OPERATION WHEN THE REQUIRED EQUIPMENT IS INSTALLED AND OPERATIONAL. FLIGHT INTO KNOWN Icing CONDITIONS IS PROHIBITED. NO AEROBATIC MANEUVERS, INCLUDING SPINS ARE APPROVED. OTHER OPERATING LIMITATIONS WHICH MUST BE COMPLIED WITH WHEN OPERATING THIS AIRPLANE IN THIS CATEGORY ARE CONTAINED IN THE AIRPLANE FLIGHT MANUAL. MANEUVERING SPEED (3368 LBS), 127 KIAS; (2600 LBS), 111 KIAS.	
EMERGENCY MANUAL GEAR EXTENSION 1. PULL LANDING GEAR ACTUATOR CIRCUIT BREAKER. 2. PUT GEAR SWITCH IN GEAR DOWN POSITION. 3. PUSH RELEASE TAB FORWARD AND LIFT UP RED HANDLE. 4. PULL T-HANDLE STRAIGHT UP (12 TO 20 INCHES). 5. ALLOW T-HANDLE TO RETURN TO ORIGINAL POSITION. 6. REPEAT UNTIL GEAR DOWN LIGHT COMES ON (12 TO 20 PULLS). IF TOTAL ELECTRICAL FAILURE-SEE MECHANICAL INDICATOR.	
CAUTION 1. TURN OFF STROBE LITES WHEN TAXING NEAR OTHER ACFT OR WHEN FLYING IN FOG OR IN CLOUDS. STD POSITION LITES MUST BE FOR ALL NIGHT OPERATIONS. 2. IN CASE OF FIRE TURN OFF CABIN HEAT. 3. DO NOT SCREW VERNIER CONTROLS CLOSER THAN 1/8" FROM NUT FACE.	

ON LEFT SIDE PANEL
IN PILOT'S VISION

-4055

CHECK LIST			
T A K E O F	CONTROLS	RUN-UP	DOOR
	FUEL	PROP	WINDOW
	INSTRUMENTS	WING FLAPS	ALT AIR
	TRIM	SEAT LATCH	PARK BRAKE
		BELT HARNESS	MIXTURE
	CONDUCT RUDDER AND ELEV TRIM CHECK PRIOR TO FLIGHT, SEE PILOT'S OPERATING HANDBOOK		
L D G	BELT/HARNESS	GEAR	MIXTURE
	FUEL	WING FLAPS	PROP
			PARK BRAKE

ON
CONSOLE

A4027

N285M

-4037

UPPER INSTRUMENT
PANEL-PILOT SIDE



ON LOWER
CONSOLE

UPPER L/H INSTRUMENT
PANEL

START STOP	CLEAR	MODE
---------------	-------	------

A4004

A4012

FAA APPROVED
ISSUED 6 - 94

REV. G

AIRPLANE FLIGHT MANUAL
2 - 11

FLAP UP

A4014




FLAP DOWN

A4015

CONSOLE
ABOVE &
BELOW
SWITCH

PILOT'S L/H
PANEL, FWD
OF ARM REST



(OPTIONAL) 130336-5

WARNING:

DO NOT EXCEED 170 LBS
(77.1 Kg) ON THIS SEAT BACK.
SEE AIRCRAFT LOADING SCHEDULE DATA
FOR BAGGAGE COMPARTMENT ALLOWABLE

-4045

FWD END OF
REAR SEAT
BOTTOM
STRUCTURE


FLOORBOARD
BETWEEN
SEATS

ON RADIO PANEL,
ADJACENT TO ELT
SWITCH
(OPTIONAL)


CAUTION

ABSENCE OF ELT LIGHT DURING FIRST
3 SECONDS OF TEST INDICATES
POSSIBLE G-SWITCH FAILURE

A4018



-4045



-213

BELOW INSTRUMENT
PANEL-EACH SIDE

ABOVE EACH
FUEL QTY.
GAUGE ON
BEZEL(S/N 29-
0170 THRU
29-0199)

44.5 GAL
USEABLE

INSTRUMENT/RADIO PANEL
(VARIES W/ INSTALLED EQUIP.)

FUEL FLOW MEMORY	MIKE ISOLATION	DME NAV 1	NAV1 IND VOR	INTERCOM NORMAL	DME AUDIO	A/P SEL NAV 1
ON ⊕	ON ⊕	⊕	⊕	⊕	ON ⊕	⊕
OFF	OFF	NAV 2	LORAN	PRIVATE	OFF	NAV 2

(TYPICAL-PLACARDS WILL VARY
WITH AIRCRAFT CONFIGURATION)





A2001

UPPER
CTR
INSTR.
PANELABOVE
INSIDE
BAGGAGE
DOOR
HANDLE


-4041

LWR INSTR PNL., BELOW
CONTROL WHEEL SHAFTPULL FOR ALT
STATIC SOURCE


A4001

ABOVE ENGINE INSTRUMENT
CLUSTER ON BEZEL (29-0170 - 29-0199)

-6049

BELOW
PILOT'S
STORM
WINDOWON MAGNETIC
COMPASS

-4015

AROUND EACH OXYGEN
OUTLET ON OVERHEAD
PANEL

CONSOLE ON CONTROL KNOB



917033-11

FAA APPROVED
ISSUED 6 - 94

REV. G



A4002

ABOVE
EACH
CONTROL
ON LWR
INSTR.
PANEL

A4003



A4005

AIRPLANE FLIGHT MANUAL

2 - 13

WARNING: DO NOT EXCEED 10 LBS (4.5 Kg) IN THIS COMPARTMENT
USE FOR STOWAGE OF LIGHT SOFT ARTICLES ONLY
SEE AIRCRAFT LOADING SCHEDULE DATA
FOR BAGGAGE COMPARTMENT ALLOWABLE

BAGGAGE COMPART-
MENT
ON HAT RACK SHELF

-6021

TOP OF BAGGAGE DOOR JAMB

WARNING: DO NOT EXCEED 120 LBS
(54.4 Kg) IN THIS COMPARTMENT
SEE AIRCRAFT LOADING SCHEDULE DATA
FOR BAGGAGE COMPARTMENT ALLOWABLE

-6020

INSTRUMENT PANEL

SPEEDBRAKE EQUIPPED: FOR OPERATING INSTRUCTIONS
AND LIMITATIONS SEE FAA APPROVED AFM SUPPLEMENT
OR PILOT'S OPERATING HANDBOOK.

(OPTIONAL)


-4057

ON UPPER INSTRUMENT PANEL

NXXXXXX

FLOORBOARD -
BETWEEN
SEATS


BETWEEN SEATS - ON
EMERGENCY GEAR RELEASE
EXTENSION HANDLE



-4009

← PUSH TO RELEASE

-6012




-6082

BAGGAGE DOOR
FRAME

14 VOLTS
3 AMPS MAX.
5 A INTERMITTENT

RT. RADIO PNL.
ADJACENT TO AUX.
←PWR. PLUG

FLOORBOARD - FWD OF
CO-PILOT SEAT---->



610258-

AIRPLANE FLIGHT MANUAL
2 - 14

REV. G

FAA APPROVED
ISSUED 6 - 94

FUSELAGE INTERIOR

The following placards must be installed inside the fuselage at the locations specified.

CAUTION

THIS DOOR SHALL BE
REMOVED AND STOWED
WHEN FIELD TEMPERATURES
EXCEED 30°F (-1°C)

ON KIT SLIDING DOOR AT OIL
COOLER.
IF KIT INSTALLED

**CAUTION
WINTERIZATION KIT INSTALLED**

WHEN OPERATING AT
TEMPERATURES ABOVE 30°F, (-1°C)
REMOVE OIL COOLER DOOR.

ON OIL FILLER DOOR
IF KIT INSTALLED

↓
MAINTAIN

LEVEL HERE

-6011

HYDRAULIC OIL
RESERVOIR

28 VOLTS
ONLY

-6080

BACKSIDE OF
AUX. PWR.
RECEPTACLE
DOOR

USE AVIATORS
OXYGEN ONLY

SEE PILOT'S OPERATING
HANDBOOK FOR
FILLING PRESSURES

INSIDE OXYGEN
FILLER DOOR

(OPTIONAL)

-4050

INSIDE ENGINE OIL FILLER DOOR

ENGINE OIL
OIL INSTALLED IN THIS ENGINE IS:

NEXT OIL CHANGE IS DUE AT _____ HRS.
(USE GREASE PENCIL) TACH TIME

-6041

ON BATTERY
ACCESS
PANELS
L/H & R/H

BOTH
BATTERIES
MUST BE
INSTALLED
FOR FLIGHT

-6060

FAA APPROVED
ISSUED 6 - 94

REV. G

AIRPLANE FLIGHT MANUAL
2 - 15

EXTERIOR

The following placards must be installed on the exterior of the aircraft at the locations specified.

NO STEP
-6000

ON INBOARD END OF FLAP,
WING LEADING EDGES AND
WING AHEAD OF FLAPS

UNDERSIDE OF WING (2 PLCS)
& AFT OF L/H COWL FLAP (1PLC)

HOIST POINT
-6002

DO NOT PUSH
-6001

HORIZ. STAB. L/E
RUDDER T/E (BOTH SIDES)

UNDER TAILCONE
AFT OF WING T/E

STATIC DRAIN

-6024

PITOT DRAIN

-6026

UNDER LEFT WING L/E
NEAR FUSELAGE

UNDER WING NEAR
SUMP DRAINS

FUEL DRAIN

-6028

GASCOLATOR
DRAIN

-6030

UNDER FUSELAGE RT. SIDE
AFT OF NOSE WHEEL WELL

ON MAIN LDG GEAR
DOOR

TIRE PRESSURE 42 PSI (2.95 Kg/cm²)
-6042

TIRE PRESSURE 49 PSI (3.44Kg/cm²)
-6044

ON NOSE
LANDING GEAR DOOR




TOWING LIMITS



-6035

ON NOSE
LANDING
GEAR
LEG ASSY

ON NOSE
LANDING
GEAR
SPINDLE
ASSY.



-6036

LWR L/H WING PANEL
OUT/BD OF HOIST PT.

MAGNETIC AZIMUTH
TRANSMITTER

LOCATED INSIDE THIS INSPECTION
COVER. USE ONLY NON-MAGNETIC
SCREWS FOR COVER INSTALLATION.

-6050

FUEL-100(GREEN) OR
100LL(BLUE) MIN OCT
44.5 U.S. GAL USABLE
168.5 LITERS USABLE

ON BOTH FUEL FILLER CAPS

-6059

BLANK

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	3-3
AIRSPEEDS FOR EMERGENCY OPERATIONS	3-4
ANNUNCIATOR PANEL WARNING LIGHTS	3-5
ENGINE	3-6
POWER LOSS - DURING TAKEOFF ROLL	3-6
POWER LOSS - AFTER LIFTOFF	3-6
POWER LOSS - IN FLIGHT (RE-START PROCEDURES)	3-6
POWER LOSS - PRIMARY ENGINE INDUCTION AIR	
SYSTEM BLOCKAGE	3-7
ENGINE ROUGHNESS	3-8
HIGH CYLINDER HEAD TEMPERATURE	3-8
HIGH OIL TEMPERATURE	3-8
LOW OIL PRESSURE	3-8
LOW FUEL PRESSURE	3-8
ENGINE DRIVEN FUEL PUMP FAILURE	3-8
FUEL VAPOR SUPPRESSION (FLUCTUATING FUEL PRESSURE)	3-9
FIRES	3-9
ENGINE FIRE - DURING START ON GROUND	3-9
ENGINE FIRE - IN FLIGHT	3-9
ELECTRICAL FIRE - IN FLIGHT (SMOKE IN CABIN)	3-9
EMERGENCY DESCENT PROCEDURE	3-10
GLIDE	3-10
FORCED LANDING EMERGENCY	3-11
GEAR RETRACTED OR EXTENDED	3-11
OVERWEIGHT LANDING PROCEDURES	3-11
SYSTEMS EMERGENCIES	3-11
PROPELLER	3-11
FUEL	3-11
ELECTRICAL	3-11
LANDING GEAR	3-12
VACUUM	3-13
OXYGEN	3-13
ALTERNATE STATIC SOURCE	3-13

TABLE OF CONTENTS (con't)

TITLE.	PAGE
UNLATCHED DOORS IN FLIGHT	3-14
ICING.	3-14
EMERGENCY EXIT OF AIRCRAFT.	3-15
SPINS	3-16
OTHER EMERGENCIES	3-16

INTRODUCTION

This section provides the recommended procedures to follow during adverse flight conditions. The information is presented to enable you to form, in advance, a definite plan of action for coping with the most probable emergency situations which could occur in the operation of your airplane.

As it is not possible to have a procedure for all types of emergencies that may occur, it is the pilot's responsibility to use sound judgement based on experience and knowledge of the aircraft to determine the best course of action. Therefore, it is considered mandatory that the pilot read the entire manual, especially this section before flight.

When applicable, emergency procedures associated with optional equipment such as Autopilots are included in SECTION IX.

[NOTE]

All airspeeds in this section are indicated (IAS) and assume zero instrument error unless stated otherwise.

AIRSPEEDS FOR EMERGENCY OPERATIONS

CONDITION RECOMMENDED SPEED

=====

ENGINE FAILURE AFTER TAKEOFF

Wing Flaps UP		85 KIAS
Wing Flaps DOWN		80 KIAS

BEST GLIDE SPEED

3368 lb/1528 kg		91.5 KIAS
3200 lb/1452 kg		89.0 KIAS
2900 lb/1315 kg		84.5 KIAS
2600 lb/1179 kg		80.0 KIAS

MANEUVERING SPEED

3368 lb/1528 kg		127 KIAS
3300 lb/1497 kg		126 KIAS
2430 lb/ 1102 kg		108 KIAS
2232 lb/1012 kg		103 KIAS

PRECAUTIONARY LANDING WITH ENGINE POWER

Flaps DOWN		75 KIAS
------------	-----------	---------

PRECAUTIONARY LANDING ABOVE 3200 LBS

Flaps DOWN		80 KIAS
------------	-----------	---------

EMERGENCY DESCENT (GEAR UP)

Smooth Air		196 KIAS
------------	-----------	----------

Turbulent Air

3368 lb/1528 kg		127 KIAS
3300 lb/1497 kg		126 KIAS
2430 lb/1102 kg		108 KIAS
2232 lb/1012 kg		103 KIAS

EMERGENCY DESCENT (GEAR DOWN)

Smooth Air		165 KIAS
------------	-----------	----------

Turbulent Air

3368 lb/1528 kg		127 KIAS
3300 lb/1497 kg		126 KIAS
2430 lb/1102 kg		108 KIAS
2232 lb/1012 kg		103 KIAS

=====

ANNUNCIATOR PANEL WARNING LIGHTS**WARNING LIGHT****FAULT & REMEDY**

GEAR UNSAFE

RED light indicates landing gear is not in fully extended/or retracted position. Refer to "FAILURE OF LANDING GEAR TO EXTEND ELECTRICALLY" procedure or "FAILURE OF LANDING GEAR TO RETRACT" procedure.

LEFT or RIGHT FUEL

RED light indicates 2 1/2 to 3 gals.(9.5 to 11.4 liters) S/N 29-0001 thru 29-0169); [6 to 8 gals.(23 to 30.3 liters) S/N 29-0170 thru 29-0199)] of usable fuel remain in the respective tanks. Switch to fuller tank.

SPEED BRAKE

AMBER light indicates Speed Brakes are activated.

ALT AIR

AMBER light indicates alternate induction air door is open.

PROP DE-ICE

BLUE light indicates power applied to De-Ice boots

PITOT HEAT

BLUE light indicates power is applied to heater. (Some Foreign A/C - AMBER light indicates power is NOT applied to heater.)

HI/LO VAC (Flashing)

Suction is below 4.25 in. Hg. (RED)
Turn Stand-by Vacuum pump - ON

HI/LO VAC (Steady)

Suction is above 5.5 in. Hg. (RED)
Turn Stand-by Vacuum pump - ON

| NOTE |

Attitude and Directional Gyros are unreliable when VAC light is illuminated (steady or flashing). Vacuum system should be checked and/or adjusted as soon as practicable.

ALT VOLTS
(Flashing)

RED light indicates alternator output low. Refer to "ALTERNATOR OUTPUT LOW".

ALT VOLTS
(Steady)

RED light indicates overvoltage and Alt. field. C/B tripped. Refer to "ALTERNATOR OVER-VOLTAGE".

START POWER

RED light indicates switch or relay is engaged and starter is energized. Flight should be terminated as soon as practicable. Engine damage may result. This is normal indication during engine start.

STBY VAC

AMBER light indicates stand-by vacuum pump is ON.

REMOTE RNAV

NOT USED AT THIS TIME

BOOST PUMP

BLUE light indicates power to auxiliary fuel boost pump.

ENGINE

POWER LOSS - DURING TAKEOFF ROLL

Throttle	CLOSED
Brakes	AS REQUIRED TO STOP AIRCRAFT
Fuel Selector	OFF
Magneto/Starter Switch	OFF
Master Switch	OFF

POWER LOSS - AFTER LIFTOFF

Airspeed	85 KIAS (Flaps UP)
	80 KIAS (Flaps TAKEOFF/DOWN)
KEEP THE AIRCRAFT UNDER CONTROL - then:	
Fuel Selector	SELECT OTHER TANK
Throttle	FULL FORWARD
Magneto switch	Verify on BOTH
Mixture	FULL FORWARD
Propeller	FULL FORWARD
LOW Boost Pump Switch	ON - to attempt re-start
If Engine Quits - then:	
HIGH BOOST Pump (guarded switch)	ON - to attempt re-start

LAND AS SOON AS PRACTICABLE; CORRECT MALFUNCTION PRIOR TO NEXT FLIGHT.
If engine does not re-start, proceed to **FORCED LANDING EMERGENCY**.

////////////////////
//**WARNING**//
////////////////////

Engine may run rough due to overrich mixture. Lean mixture until engine operates smoothly.

| NOTE |

If high power is required, mixture may require enrichening.

POWER LOSS - IN FLIGHT (RE-START PROCEDURES)

Airspeed	85 KIAS minimum
Fuel Selector	SELECT OTHER TANK (Verify fullest tank)
LOW Boost Pump Switch	ON - to attempt re-start
Throttle	FULL FORWARD
Propeller	FULL FORWARD
Mixture	AS REQUIRED to restore power
Magneto/Starter Switch	VERIFY on BOTH
LOW Boost Pump Switch	OFF if engine does not start immediately
HIGH BOOST Pump (guarded switch)	ON - to attempt re-start
Alternate Air Door	Manually Open

If engine does not start after initial attempts:

Mixture	IDLE CUT-OFF (Initially)
	then advance slowly toward RICH until engine starts.

If engine does not re-start after several attempts establish best glide speed (Refer to Maximum Glide Distance Chart) and proceed to **FORCED LANDING EMERGENCY**.

After engine re-start:

Throttle	ADJUST as required
Propeller	ADJUST as required
Mixture	RELEAN as required for power setting
HIGH BOOST Pump Switch	OFF

| NOTE |

If engine fails when HIGH BOOST pump is turned OFF, suspect engine driven fuel pump failure. Proceed to **ENGINE DRIVEN FUEL PUMP FAILURE**.

LAND AS SOON AS PRACTICABLE; CORRECT MALFUNCTION PRIOR TO NEXT FLIGHT.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Should engine excessively cool during engine out, care should be exercised during re-start to avoid excessive oil pressure. Allow engine to warm up.

OPERATING THE ENGINE AT TOO HIGH AN RPM BEFORE REACHING
MINIMUM OIL TEMPERATURES MAY CAUSE LOSS OF OIL PRESSURE.

POWER LOSS - PRIMARY ENGINE INDUCTION AIR SYSTEM BLOCKAGE

Blockage of the primary engine induction air system may be experienced as a result of flying in cloud or heavy snow with cold outside air temperatures (0°C or below). At these temperatures, very small water droplets or solid ice crystals in the air may enter the primary engine induction inlet in cowl opening and travel inside inlet duct to the induction air filter. Ice particles or water droplets may collect and freeze on the air filter causing partial or total blockage of the primary engine induction system.

If primary induction air system blockage occurs, the alternate engine induction air system will automatically open, supplying engine with an alternate air source drawn from inside the cowl rather than through the air filter. The alternate air system can also be manually opened at any time by pulling the control labeled ALTERNATE AIR. Automatic or manual activation of the alternate induction system is displayed in the cockpit by the illumination of the ALT AIR light in the main annunciator panel. When operating on the alternate air system, available engine power will be less for a given propeller RPM compared to the primary induction air system. This is due to loss of ram effect and induction of warmer inlet air.

The following checklist should be used if a **partial power loss** due to primary induction air system blockage is experienced:

Alternate Air	Verify OPEN (annunciator light ON)
Manifold Pressure	1 - 2 inches less than normal, due to warm induction air

[NOTE]

The alternate air door should open automatically when primary induction system is restricted. If alternate air door has not opened (Annunciator light-OFF) it can be opened manually by pulling alternate air control.

Throttle	INCREASE as desired
Propeller	INCREASE as required
Mixture	to maintain desired cruise power setting (Ref. SECTION V)
Flight	RELEAN to desired EGT
	CONTINUE - request altitude with warmer air, if able.

In the unlikely event that a **total power loss**, due to primary engine induction air blockage, is experienced, the following checklist should be used:

Airspeed	BEST GLIDE SPEED
Alternate Air	Manually OPEN
LOW Boost Pump Switch	ON
Throttle	Full FORWARD
Propeller	FULL FORWARD
Mixture	AS REQUIRED to restore power
Magnetto/Starter Switch	Verify on BOTH

After engine re-start:

Throttle	ADJUST as required
Propeller	ADJUST as required
Mixture	RELEAN as required for power setting
	(Refer to power charts - SECTION V)
LOW Boost Pump Switch	OFF

If engine does not re-start after several attempts, maintain best glide speed & proceed to **FORCED LANDING EMERGENCY**.

ENGINE ROUGHNESS

Engine Instruments CHECK
Fuel Selector OTHER TANK
Mixture READJUST for smooth operation
Magnetos/Starter Switch Select R or L or BOTH
If roughness disappears on single magneto, monitor power and continue on selected magneto.

/////////////////
//WARNING//
/////////////////

The engine may quit completely when one magneto is switched off if the other magneto is faulty. If this happens, close throttle to idle and mixture to idle cutoff before turning magnetos ON to prevent a severe backfire. When magnetos have been turned back ON, proceed to **POWER LOSS - IN FLIGHT**. Severe roughness may be sufficient to cause propeller separation. Do not continue to operate a rough engine unless there is no other alternative.

Throttle REDUCE
. check for a throttle setting that may cause roughness to decrease.
If severe engine roughness cannot be eliminated, **LAND AS SOON AS PRACTICABLE**.

HIGH CYLINDER HEAD TEMPERATURE

Mixture ENRICH As Required
Airspeed INCREASE As Required
Power REDUCE — if temperature cannot be maintained within limits

HIGH OIL TEMPERATURE

[NOTE]

Prolonged high oil temperature indications will usually be accompanied by a drop in oil pressure. If oil pressure remains normal, then a high temperature indication may be caused by a faulty gauge or thermocouple.

Airspeed INCREASE
Power REDUCE

PREPARE FOR POSSIBLE ENGINE FAILURE IF TEMPERATURE CONTINUES HIGH.

LOW OIL PRESSURE

Oil temperature and pressure gauges Monitor
Pressure below 10 PSI EXPECT ENGINE FAILURE,
. proceed to **FORCED LANDING EMERGENCY**.

ENGINE DRIVEN FUEL PUMP FAILURE

/////////////////
//WARNING//
/////////////////

When operating engine at moderate power with "HIGH BOOST" ON and engine driven fuel pump has failed, engine may quit or run rough when manifold pressure is reduced, unless manually leaned.

An engine driven fuel pump failure is probable when engine will only operate with HIGH BOOST pump ON. Operation of engine with a failed engine driven fuel pump and auxiliary fuel pump HIGH BOOST ON will require smooth operation of engine controls and corresponding mixture change when throttle is repositioned or engine speed is changed. When retarding throttle or reducing engine speed, adjust mixture to prevent engine power loss from an overrich condition. Enrich mixture when opening throttle or increasing engine speed to prevent engine power loss from a lean condition. Always lean to obtain a smooth running engine.

The following procedure should be followed when a failed engine driven fuel pump is suspected:

HIGH BOOST Pump (guarded switch) ON
Throttle CRUISE Position or as required for engine operation
Mixture ADJUST for smooth engine operation.
LAND AS SOON AS PRACTICABLE & CORRECT MALFUNCTION.

FUEL VAPOR SUPPRESSION (Fluctuating Fuel Flow)

Low Fuel Boost Pump Switch ON to clear vapors
Engine operation MONITOR
Low Fuel Boost Pump Switch OFF - (If condition still exists, REPEAT PROCEDURE).

FIRES

ENGINE FIRE - DURING START ON GROUND

Magneto/Starter Switch CONTINUE cranking or until fire is extinguished.

If engine starts:

Power 1500 RPM for several minutes
Engine SHUTDOWN; inspect for damage

If engine does NOT start:

Magneto/Starter Switch CONTINUE CRANKING
Mixture IDLE CUTOFF
Low Fuel Boost Pump Switch OFF
Throttle FULL FORWARD
Fuel Selector Valve OFF
Magneto/Starter Switch OFF
Master Switch OFF
FIRE EXTINGUISH with Fire Extinguisher

ENGINE FIRE - IN FLIGHT

Fuel Selector Valve OFF
Throttle CLOSED
Mixture IDLE CUTOFF
Magneto/Starter Switch OFF
Cabin Ventilation & Heating Controls CLOSED

[NOTE]

If fire is not extinguished, attempt to increase airflow over engine by increasing glide speed. Proceed with FORCED LANDING EMERGENCY. DO NOT attempt an engine restart.

If necessary, use fire extinguisher to keep fire out of cabin area.

ELECTRICAL FIRE - IN FLIGHT (Smoke in Cabin)

Master Switch OFF

/////////////////
//WARNING//
/////////////////

Stall warning and landing gear warning, not available with Master Switch OFF.

Alternator Field Switch OFF
Cabin Ventilation OPEN
Heating Controls CLOSED
Circuit Breakers CHECK to identify faulty circuit if possible
LAND AS SOON AS POSSIBLE.

If electrical power is essential for flight, attempt to identify and isolate faulty circuit as follows:

Master Switch ON
Alternator Field Switch ON

SECTION III EMERGENCY PROCEDURES

MOONEY
M20R

Select **ESSENTIAL** switches **ON** one at a time; permit a short time to elapse before activating an additional circuit.

EMERGENCY DESCENT PROCEDURE

In the event an emergency descent from high altitude is required, rates of descent of at least 3,000 feet per minute can be obtained in two different configurations:

(1) With landing gear and flaps retracted, an airspeed of 196 KIAS will be required for maximum rate of descent.


(2) With the landing gear extended and flaps retracted an airspeed of 165 KIAS will also give approximately the same rate of descent. At 165 KIAS and the gear extended, the angle of descent will be greater, thus resulting in less horizontal distance traveled than a descent at 196 KIAS. Additionally, descent at 165 KIAS will provide a smoother ride and less pilot work load.

THEREFORE; The following procedure is recommended for an emergency descent:

Power	RETARD INITIALLY
Airspeed	140 KIAS
Landing Gear	EXTEND
Airspeed	INCREASE TO 165 KIAS after landing gear is extended.
Wing Flaps	UP
Airspeed	MAINTAIN 165 KIAS during descent.
Speedbrakes (If installed)	EXTEND
Altitude	AS DESIRED
Power During Descent	AS REQUIRED
	to maintain CHT 250°F (121°C) minimum.

GLIDE

MAXIMUM GLIDE DISTANCE MODEL M20R



| NOTE |

Greater glide distances can be attained by moving the propeller control FULL AFT (LOW RPM).

FORCED LANDING EMERGENCY**GEAR RETRACTED OR EXTENDED**

Emergency Locator Transmitter	ARMED
Seat Belts/Shoulder Harnesses	SECURE
Cabin Door	UNLATCHED
Fuel Selector	OFF
Mixture	IDLE CUTOFF
Magneto/Starter Switch	OFF
Wing Flaps	Full DOWN
Landing Gear	DOWN-If conditions permit
Approach Speed	80 KIAS
Master Switch	OFF, prior to landing
Wings	LEVEL Attitude

OVERWEIGHT LANDING PROCEDURES

In the event it is necessary to land with weight exceeding 3200 Lbs. (1452 Kg.) (max. landing weight) the following procedure is recommended in addition to normal APPROACH FOR LANDING procedures:

Approach Airspeed 80 KIAS

Use a flatter approach angle than normal, with power as necessary until a smooth touch-down is assured.

Expect landing distance over a 50 foot obstacle (Ref. SECTION V) to increase at least 600 ft. Conduct Gear and Tire Servicing Inspection as required (Ref. SECTION VIII).

SYSTEMS EMERGENCIES**PROPELLER****PROPELLER OVERSPEED**

Throttle	RETARD
Oil Pressure	CHECK
Propeller	DECREASE RPM, re-set if any control available
Airspeed	REDUCE
Throttle	AS REQUIRED to maintain RPM below 2500 RPM

FUEL**LOW FUEL FLOW**

Check mixture	ENRICH
Fuel Selector	SWITCH TANKS

If condition persists, use Fuel Boost Pump as necessary. LANDING should be made as soon as PRACTICABLE.

ELECTRICAL**ALTERNATOR OVERVOLTAGE**

(Alternator warning light illuminated steady and Alternator Field circuit breaker tripped.)

Alternator Field Circuit Breaker	RESET
----------------------------------	-------

If circuit breaker will not reset, the following procedures are required:

1. Reduce electrical load, as required, to maintain essential systems.
2. Continue flight and LAND, when PRACTICABLE, to correct malfunction.

| NOTE |

The only source of electrical power is from the selected battery. Monitor battery voltage (min. 18V) and switch to other battery when necessary.

**ALTERNATOR OUTPUT LOW
(Alternator warning light flashing)**

REDUCE ELECTRICAL LOAD

If annunciator light still flashes:

Alternator Field Switch OFF

1. Reduce electrical load, as required, to maintain essential systems.
2. Continue flight and LAND, when PRACTICABLE, to correct malfunction.

| NOTE |

The only source of electrical power is from the selected battery. Monitor battery voltage (min. 18V) and switch to other battery when necessary.

Battery endurance will depend upon battery condition and electrical load on battery. If one battery becomes depleted, switch to other battery.

LANDING GEAR

FAILURE OF LANDING GEAR TO EXTEND ELECTRICALLY

Airspeed 140 KIAS or less
Landing Gear Actuator Circuit Breaker PULL
Landing Gear Switch DOWN
Gear Manual Emergency Extension Mechanism LATCH FORWARD/LEVER BACK
to engage manual extension mechanism

| NOTE |

Slowly pull "T" handle 1 to 2 inches (2.5 to 5.1 cm) to rotate clutch mechanism and allow it to engage drive shaft.

T-Handle PULL (12 to 20 times)
and RETURN until gear is down and locked
GEAR DOWN light ILLUMINATED; STOP when resistance is felt.
Visual Gear Down Indicator CHECK ALIGNMENT
by viewing from directly above indicator

~ CAUTION ~

Continuing to pull on T-Handle, after GEAR DOWN light ILLUMINATES, may bind actuator; electrical retraction MAY NOT be possible until binding is eliminated by ground maintenance. Return lever to normal position and secure with latch. Reset landing gear actuator circuit breaker.

////WARNING//

**Do not operate landing gear electrically with manual extension system engaged
Do not fly craft until maintenance/inspection is done on landing gear system.**

FAILURE OF LANDING GEAR TO RETRACT

AIRSPEED Below 107 KIAS
GEAR Switch UP Position
**GEAR FAILS TO RETRACT — GEAR HORN - SOUNDING;
GEAR ANNUNCIATOR LIGHT & GEAR SAFETY BY-PASS LIGHT — ILLUMINATED**

GEAR SAFETY BY-PASS SWITCH DEPRESS
 HOLD until landing gear is fully retracted

"GEAR UNSAFE" and "GEAR DOWN" Lights EXTINGUISHED
 "GEAR RELAY" Ckt. Bkr PULL
 (Warning Horn and Gear By Pass light will go OFF)

Check "Airspeed Safety Switch" or other malfunction as soon as practicable.
 "GEAR RELAY" Ckt. Bkr PUSH IN

WHEN READY TO EXTEND LANDING GEAR

Airspeed BELOW 140 KIAS
 Gear Relay C/B RESET
 Landing Gear Switch DOWN
 Gear Down Light ILLUMINATED

| NOTE |

If above procedures do not initiate retraction process, check gear emergency manual extension lever (on floor) for proper position.

GEAR FAILS TO RETRACT – GEAR HORN - DOES NOT SOUND
GEAR ANNUNCIATOR LIGHTS & GEAR BY-PASS LIGHT – NOT ILLUMINATED

GEAR EMERGENCY EXTENSION LEVER (on floor) Verify LATCHED in proper position
 GEAR ACTUATOR C/B RESET
 If gear will not extend electrically at this time, refer to FAILURE OF LANDING GEAR TO
 FLIGHT CONTINUE (if desired)

When ready to extend landing gear at next landing:

AIRSPEED Below 140 KIAS
 GEAR SWITCH DOWN Position
 If gear will not extend electrically at this time, refer to FAILURE OF LANDING GEAR TO
 EXTEND ELECTRICALLY (previous page).

VACUUM

When "HI/LO VAC" annunciator light illuminates (flashing or steady), vacuum operated instruments are considered to be unreliable. Push stand-by vacuum pump switch ON. The flashing HI/LO VAC annunciator light should extinguish and the STBY VAC annunciator will illuminate. The vacuum operated gyro instruments will be operating on the stand-by vacuum system. The steady RED annunciator light may not extinguish when the stand-by vacuum switch is ON. Continue flight, monitor non-vacuum gauges. Have vacuum system inspected prior to next flight.

OXYGEN

In the event of oxygen loss above 12,500 ft. return to 12,500 ft as soon as feasible. Refer to SECTION X for the physiological characteristics of high altitude flight.

ALTERNATE STATIC SOURCE

The alternate static air source should be used whenever it is suspected that the normal static air sources are blocked. Selecting the alternate static source changes the source of static air for the altimeter, airspeed indicator and rate-of-climb from outside of the aircraft to the cabin interior. When alternate static source is in use, adjust indicated airspeed and altimeter readings according to the appropriate alternate static source airspeed and altimeter calibration tables in SECTION V. The alternate static air source valve is located on the instrument panel below pilot's control wheel shaft.

| NOTE |

**When using Alternate Static Source, pilot's window and air vents
 MUST BE KEPT CLOSED.**

Alternate Static Source PULL ON
 Airspeed and Altimeter Readings CHECK Calibration Tables (Ref SECTION V)

UNLATCHED DOORS IN FLIGHT

CABIN DOOR

If cabin door is not properly closed it may come unlatched in flight. This may occur during or just after take-off. The door will trail in a position approximately 3 inches (7.6 cm) open, but the flight characteristics of the airplane will not be affected. There will be considerable wind noise; loose objects, in the vicinity of the open door, may exit the aircraft. Return to the field in a normal manner. If practicable, secure the door in some manner to prevent it from swinging open during the landing.

If it is deemed impractical to return and land, the door can be closed in flight, after reaching a safe altitude, by the following procedures:

Airspeed	95 KIAS
Pilot's Storm Window	OPEN
Aircraft	RIGHT SIDESLIP (Right bank with left rudder)
Door	PULL SHUT & LATCH

BAGGAGE DOOR

If baggage door is not properly closed, it may come unlatched in flight. This may occur during or after takeoff. The door may open to its full open position and then take an intermediate position depending upon speed of aircraft. There will be considerable wind noise; loose objects, in the vicinity of the open door, may exit the aircraft. There is no way to shut and latch door from the inside. Aircraft flight characteristics will not be affected; fly aircraft in normal manner; LAND AS SOON AS POSSIBLE and secure baggage door.

Baggage Door latching mechanism VERIFY MECHANISM PROPERLY ENGAGED
(inside latching mechanism) then shut from outside aircraft.

ICING

////////////////////
//WARNING//
////////////////////

DO NOT OPERATE IN KNOWN ICING CONDITIONS.

The Model M20R is NOT APPROVED for flight into known icing conditions and operation in that environment is prohibited. However, if those conditions are inadvertently encountered or flight into heavy snow is unavoidable, the following procedures are recommended until further icing conditions can be avoided:

INADVERTENT ICING ENCOUNTER

Pitot Heat	ON
Propeller De-Ice	ON (if installed)
Alternate Static Source	ON (if required)
Cabin Heat & Defroster	ON
Engine Gauges	MONITOR for any engine power reduction

Turn back or change altitude to obtain an outside air temperature less conducive to icing.

Move propeller control to maximum RPM to minimize ice build-up on propeller blades. If ice builds up or sheds unevenly on propeller, vibration will occur. If excessive vibration is noted, momentarily reduce engine speed with propeller control to bottom of GREEN ARC, then rapidly move control FULL FORWARD.

| NOTE |

Cycling RPM flexes propeller blades and high RPM increases centrifugal force which improves propeller capability to shed ice.

As ice builds on the airframe, move elevator control fore and aft slightly to break any ice build-up that may have bridged gap between elevator horn and horizontal stabilizer.

Watch for signs of induction air filter blockage due to ice build-up; increase throttle setting to maintain engine power.

| NOTE |

If ice blocks induction air filter, alternate air system will open automatically.

With ice accumulation of 1/4 inch or more on the airframe, be prepared for a significant increase in aircraft weight and drag. This will result in significantly reduced cruise and climb performance and higher stall speeds. Plan for higher approach speeds requiring higher power settings and longer landing rolls.

~ CAUTION ~

Stall warning system may be inoperative.

| NOTE |

The defroster may not clear ice from windshield. If necessary open pilot's storm window for visibility in landing approach and touchdown.

With ice accumulations of 1 inch or less, use no more than 15° wing flaps for approach and landing. For ice accumulation of 1 inch or more, fly approaches and landing with flaps retracted to maintain better pitch control. Fly approach speed at least 15 knots faster than normal, expect a higher stall speed, resulting in higher touchdown speed with longer landing roll. Use normal flare and touchdown technique.

Missed approaches **SHOULD BE AVOIDED** whenever possible because of severely reduced climb performance. If a go-around is mandatory, apply full power, retract landing gear when obstacles are cleared; maintain 90 KIAS and retract wing flaps.

— AVOID FURTHER ICING CONDITIONS —

EMERGENCY EXIT OF AIRCRAFT

CABIN DOOR

PULL latch handle AFT.
OPEN door and exit aircraft.

BAGGAGE COMPARTMENT DOOR (Auxiliary Exit)

Release (Pull UP) rear seat back latches on spar.
Fold rear seat backs forward, CLIMB OVER.
PULL off plastic cover from over inside latch.
PULL latch pin.
Pull red handle.
OPEN door and exit aircraft.

To **VERIFY RE-ENGAGEMENT** of baggage door, outside, latch mechanism:

Open outside handle fully.
Close inside RED handle to engage pin into cam slide of latch mechanism.
Place latch pin in shaft hole to hold RED handle DOWN.
Replace cover.
CHECK & operate outside handle in normal manner.

SPINS

/////////
//WARNING//
/////////

Up to 2,000 ft. altitude may be lost in a one turn spin and recovery;
STALLS AT LOW ALTITUDE ARE EXTREMELY CRITICAL.

[NOTE]

The best spin avoidance technique is to avoid flight conditions conducive to spin entry. Low speed flight near stall should be approached with caution and excessive flight control movements in this flight regime should be avoided. Should an unintentional stall occur, the aircraft should not be allowed to progress into a deep stall. Fast, but smooth stall recovery will minimize the risk of progressing into a spin. If an unusual post stall attitude develops and results in a spin, quick application of antispin procedures should shorten the recovery.

INTENTIONAL SPINS ARE PROHIBITED.

In the event of an inadvertent spin, the following recovery procedure should be used:

Throttle	.	.	.	.	.	.	.	.	.	RETARD to IDLE
Ailerons	.	.	.	.	.	.	.	.	.	NEUTRAL
Rudder	.	.	.	.	.	.	.	.	.	Apply FULL RUDDER opposite direction of spin
Control Wheel	.	.	.	.	.	.	.	.	.	FORWARD of neutral in a brisk motion

ADDITIONAL FORWARD elevator control may be required if rotation does not stop.

— — HOLD ANTI-SPIN CONTROLS UNTIL ROTATION STOPS — —

Wing Flaps (if extended)	.	.	.	.	.	RETRACT as soon as possible
Rudder	.	.	.	.	.	NEUTRALIZE when spin stops
Control Wheel	.	.	.	.	.	SMOOTHLY MOVE AFT

to bring the nose up to level flight attitude.

OTHER EMERGENCIES

Refer to SECTION IX for Emergency Procedures of Optional Equipment.

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	4-3
SPEEDS FOR NORMAL OPERATION	4-4
PREFLIGHT INSPECTION	4-5
BEFORE STARTING CHECK	4-7
ENGINE START	4-8
FLOODED ENGINE START	4-9
WARM ENGINE START	4-9
HOT ENGINE START	4-9
BEFORE TAXI	4-9
TAXI	4-10
BEFORE TAKEOFF	4-10
TAKEOFF	4-11
CLIMB	4-11
CLIMB (CRUISE CLIMB)	4-11
CLIMB (BEST RATE)	4-11
CLIMB (BEST ANGLE)	4-12
CRUISE	4-11
FUEL TANK SELECTION	4-12
OXYGEN SYSTEM	4-13
DESCENT	4-13
GEAR UP	4-13
GEAR DOWN	4-14
APPROACH FOR LANDING	4-14
GO AROUND (BALKED LANDING)	4-15
LANDING.	4-15
TAXI AFTER LANDING	4-15
SHUTDOWN.	4-16
SECURING AIRCRAFT	4-16

TABLE OF CONTENTS (con't.)

INTRODUCTION

This section describes the recommended procedures for the conduct of normal operations for the airplane. All of the required (FAA regulations) procedures and those necessary for operation of the airplane as determined by the operating and design features of the airplane are presented.

These procedures are provided to present a source of reference and review and to supply information on procedures which are the same for all aircraft. Pilots should familiarize themselves with the procedures given in this section in order to become proficient in the normal operations of the airplane.

Normal procedures associated with those optional systems and equipment which require handbook supplements are provided by SECTION IX (Supplemental Data).

SPEEDS FOR NORMAL OPERATION

Unless otherwise noted, the following speeds are based on a weight of 3368 pounds and may be used for any lesser weight. However, to achieve the performance specified in SECTION V for takeoff distance and climb performance, the speed appropriate to the particular weight must be used.

TAKEOFF:

Normal Climb Out 80-90 KIAS

Short Field Takeoff, Speed At 50 Ft. 75 KIAS

ENROUTE CLIMB, GEAR and FLAPS UP:

Best Rate of Climb 105 KIAS

Best Angle of Climb 85 KIAS

LANDING APPROACH (3200 lbs.):

Normal Approach, Flaps 10 degrees 80 KIAS

Normal Approach, Flaps 33 degrees 75 KIAS

Short Field Approach, Flaps 33 degrees 70 KIAS

BALKED LANDING (3200 lbs.):

Maximum Power, Flaps 10 degrees 85 KIAS

MAXIMUM RECOMMENDED TURBULENT AIR PENETRATION SPEED:

3368 lbs./1528 Kgs 127 KIAS

3200 lbs./1452 Kgs 123 KIAS

2900 lbs./1315 Kgs 117 KIAS


2600 lbs./1179 Kgs 111 KIAS

2400 lbs./1089 Kgs 106 KIAS

DEMONSTRATED CROSSWIND VELOCITY:

Takeoff or Landing 13 Knots
(This is NOT A LIMITATION, only a demonstrated number)

(See CROSSWIND COMPONENT CHART, SECTION V)



PREFLIGHT INSPECTION

1. Cockpit -

Gear Switch	DOWN
Magneto/Starter Switch	OFF
All Rocker Switches	OFF
Master Switch	ON
All Circuit Breakers	IN
Battery Select Switch	SELECT from 1 to 2 or 2 to 1.
CHECK Voltmeter after each selection. Leave on Battery with highest voltage.	
Internal/External Lights	CHECK operation
(Check for ammeter fluctuations as each light is checked)	
Pitot Heat Switch	ON
(Check Pitot Heat annunciator light illuminated BLUE *)	
Fuel Quantity Gauges	CHECK QTY
Fuel Selector	
It is recommended that wing tank sumps be drained prior to draining gascolator.	
	Rt. Tank: Pull Gascolator ring (5 seconds)
	Lt. Tank: Pull Gascolator ring (5 seconds)
Oxygen Supply Control Knob (if installed)	OFF
Oxygen Pressure Gauge	CHECK
Verify adequate oxygen supply for trip, (if use of oxygen is anticipated), refer to oxygen duration chart (Fig. 7-13).	
Also check that face masks and hoses are accessible and in good condition.	
2. Right Fuselage/Tailcone

Oxygen Filler Access Door and Filler Cap	SECURED
Battery # 2 Access Panel	SECURED
Instrument Static Pressure Port.	UNOBSTRUCTED
General Skin Condition	INSPECT
Tailcone/Emppennage Access Panel	SECURED
Tail tiedown rope/chain	REMOVE
3. Empennage

Elevator and rudder attach points and control linkage attachments	INSPECT
Empennage Freeplay-Vertical/Horizontal	INSPECT
General skin condition	INSPECT
Remove ice, snow, or frost.	

* If TKS system is installed, pitot heat annunciator will illuminate AMBER when switch is ON and Pitot Heat has failed. Annunciator will not be illuminated when switch is ON and system is operating properly.

SECTION IV NORMAL PROCEDURES

MOONEY
M20R

4. Left Fuselage/Tailcone	
Cabin Fresh Air Vent (Dorsal Fin)	UNOBSTRUCTED
Tailcone/Empennage Access Panel	SECURED
Instrument Static Pressure Port.	UNOBSTRUCTED
Avionics/Battery # 1 Access Panel	SECURED
Auxiliary Power Plug Access Door	SECURED
Static System Drain	PUSH Plunger UP, (Hold 3-5 Seconds)
General Skin Condition	INSPECT

5. Left Wing	
General Skin Condition	INSPECT-Remove ice, snow, or frost.
Wing Flap & attach points	INSPECT
Aileron & attach points	INSPECT
Control linkages	INSPECT
Wing Tip, Lights and Lens	INSPECT
Fuel Tank Vent	UNOBSTRUCTED
Pitot Tube	UNOBSTRUCTED/SECURED
	(Heat element Operative)
Landing/Taxi Lights	INSPECT Lens & Bulbs
Stall Switch Vane	CHECK operation
Fuel Tank	CHECK QUANTITY/SECURE CAP

| NOTE |

The optional visual fuel quantity gauge is to be use for partial refueling purposes only; DO NOT use for preflight quantity check.

Tiedown rope/chain	REMOVE
Wheel chock	REMOVE
Left Main Landing Gear, shock discs, tire & doors	INSPECT
Fuel Tank Sump Drain	DRAIN

Use sampler cup to VERIFY fuel is free of water, sediment & other contamination;
VERIFY proper fuel (BLUE/100LL)(GREEN/100 octane).

~CAUTION~

Some diesel may be BLUE, Verify by smell and feel that 100LL is being used.

	VERIFY drain closes and does not leak.
Pitot System Drain	PUSH plunger UP, (Hold for 3-5 seconds)
6. Left Cowl Area	
Windshield	CLEAN
Cabin Air Inlet	UNOBSTRUCTED
Left Side Engine Cowl Fasteners	SECURED
Exhaust Pipes	INSPECT SECURED
Engine Oil Filler Door	OPEN & INSPECT AREA

| NOTE |

The engine compartment must be free of foreign objects which could result in possible over heating and serious damage to the engine.

Engine Oil	CHECK QUANTITY
	8 Qts.(7.57 l)
Engine Oil Filler Door	CLOSE & SECURE
Cooling Air Inlet	Verify UNOBSTRUCTED
7. Propeller/Spinner & Front Cowl Area	
Propeller/Spinner	INSPECT for nicks, cracks, oil leaks/rotational movement.
Prop De-Ice Boots (if installed)	INSPECT condition
Induction Air Inlet/Filter	UNOBSTRUCTED
Nose gear, shock discs, tire & doors	INSPECT
Wheel chock	REMOVE

8. Right Cowl Area	
Right Side Engine Cowl Fasteners	SECURED
Cooling Air Inlet	Verify UNOBSTRUCTED
Windshield	CLEAN
Cabin Air Inlet	UNOBSTRUCTED

9. Right Wing

Fuel Tank Sump Drain	DRAIN
Use sampler cup to VERIFY fuel is free of water, sediment & other contamination.	
VERIFY proper fuel (BLUE/100LL) (GREEN/100 octane).	
SEE CAUTION on diesel fuel on previous page	
VERIFY drain closes and does not leak.	

Right main gear, shock discs, tire & doors	INSPECT
Wheel chock	REMOVE
General Skin Condition	INSPECT Remove ice, snow and frost.
Fuel Tank	CHECK QUANTITY/SECURE CAP

| NOTE |

The optional visual fuel quantity gauge is to be use for partial refueling purposes only; DO NOT use for preflight quantity check.

Tiedown rope/chain	REMOVE
Fuel Tank vent	UNOBSTRUCTED
Landing/Taxi Lights	INSPECT Lens & Bulbs
Wing tip, lights and lens	INSPECT
Aileron and attach points	INSPECT
Wing Flap and attach points	INSPECT
Control linkages	INSPECT

10. Baggage Door Area
Baggage Door

	VERIFY SECURED
	(VERIFY inside handle is properly secured)
	(CHECK outside handle operation)

RETURN TO COCKPIT — MASTER/ROCKER SWITCHES OFF

BEFORE STARTING CHECK

Preflight Inspection	COMPLETED
Seats, Seat Belts/Shoulder Harness (1 occupant per restraint)	ADJUST & SECURED
Magneto/Starter Switch	OFF
Master Switch	OFF
Alternator Field Switch	OFF
Radio Master Switch	OFF
Fuel Boost Pump Switches	OFF
Directional Gyro (slave/free switch)	SLAVED (If installed)
Circuit Breakers	CHECK - ALL IN
ELT Switch	ARMED
Rocker Switches	OFF
Alternate Static Source	Push OFF
Throttle	CLOSED
Propeller	FULL FORWARD (HIGH RPM)
Mixture	IDLE CUT-OFF
Parking Brakes	SET
Wing Flap Switch	FLAPS UP
Defrost	PUSH OFF
Cabin Heat	PUSH OFF
Cabin Vent	AS DESIRED
Fuel Selector	FULLEST TANK
All Rocker Switches	OFF
Landing Gear Switch	DOWN POSITION

SECTION IV NORMAL PROCEDURES

MOONEY
M20R

RED Emergency Gear Extension Handle	DOWN AND LATCHED
Internal Lights	OFF
Passenger Briefing	COMPLETED

(Emergency and general information briefing)

Refer to SECTION 9 for Optional Equipment Procedures and Checks.

Obtain local information prior to engine start.

ENGINE START

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

When either battery voltage is low, inspection should be conducted to determine condition of battery and/or reason for battery being low. Replacement or servicing of batteries is essential and charging for at least one hour should be done before engine is started. Batteries must be serviceable and IT IS RECOMMENDED THAT BATTERIES BE FULLY CHARGED TO OPERATE AIRCRAFT. Electrical components may also be damaged if aircraft is operated when batteries are low.

| NOTE |

When starting engine using the approved external power source, no special starting procedure is necessary. Use normal starting procedures below. DO NOT START ENGINE IF BOTH BATTERIES ARE INCAPABLE OF STARTING ENGINE. Recharge dead batteries for at least one hour (at 3-4 amps) before starting engine. Only No. 1 battery (left side of tailcone) is connected to the Auxiliary Power plug.

Before Starting Checklist	COMPLETED
Throttle	FULL OPEN
Propeller	FULL FWD (High RPM)
Mixture	Full Forward (RICH)
Master Switch	ON
Alternator Field Switch	ON
Annunciator Lights	PRESS TO TEST (All lights should illuminate)
Low Fuel Boost Pump Switch	ON during engine starting sequence

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

For engine operation at outside air temperatures below -25° C (-13°F), the engine and engine oil should be preheated to at least -25° C (-13°F) before the engine is started.

Throttle	IDLE POSITION
Propeller Arca	CLEAR
Magneto/Starter Switch	TURN & PUSH to START, release to BOTH when engine starts.
If No. 1 battery will not start engine	SELECT No. 2 battery

| NOTE |

COLD ENGINE START - Low fuel boost pump ON during 'Start' sequence. Turn low fuel boost pump OFF when engine obtains smooth operation.

| NOTE |

"START POWER" warning light should illuminate when Magneto/Starter switch is in "START" position.

| NOTE |

Cranking should be limited to 30 seconds, and several minutes allowed between cranking periods to permit the starter to cool.

Throttle	IDLE 600 - 700 RPM
* Engine Oil Pressure	CHECK in GREEN ARC
	If minimum oil pressure (10 PSI) is not indicated within 30 seconds, accomplish engine shutdown procedures.
Low Fuel Boost Pump Switch	OFF
* Ammeter	CHECK
	Turn LDG LT ON & observe Negative movement of needle.
* Interior/Exterior Lights	AS DESIRED
* Engine Instruments	CHECKED
* Fuel Flow Indicator	TEST/RESET (if desired)
* Throttle	900/1000 RPM
* Mixture	ADJUST FOR SMOOTH OPERATION

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Do not operate engine above 1000 RPM unless oil temperature is 75° F (24°C) minimum. Operation of engine above 1000 RPM at temperatures below 75° F (24°C) may damage engine.

FLOODED ENGINE START

Throttle	1/2 OPEN
Mixture	IDLE CUTOFF
Low Fuel Boost Pump Switch	ON - 8-10 SECONDS THEN OFF
Magneto/Starter Switch	TURN & PUSH to START
	release to BOTH when engine starts.
Mixture	Slowly advance toward RICH until engine starts
Throttle	IDLE 600 - 700 RPM

SEE ENGINE START PROCEDURES ABOVE * FOR REMAINING SEQUENCES.

WARM ENGINE START

Throttle	1/2 to 1 inch OPEN
Mixture	Full Forward (RICH)
Low Fuel Boost Pump Switch	ON - (TO CLEAR FUEL VAPORS)
Low Fuel Boost Pump Switch	OFF
Magneto/Starter Switch	WITHIN 1-2 SECONDS, TURN & PUSH to START
	release to BOTH when engine starts.
Throttle	IDLE 600 - 700 RPM

SEE ENGINE START PROCEDURES ABOVE * FOR REMAINING SEQUENCES.

HOT ENGINE START

Throttle	FULL OPEN
Mixture	IDLE CUT-OFF
Boost Pump	HIGH for 5 sec. or LOW for 15 sec.
Boost Pump	OFF
Throttle	IDLE POSITION
Mixture	Full Forward (RICH)
Magneto/Starter Switch	TURN & PUSH to START
	release to BOTH when engine starts.
Throttle	IDLE 600 - 700 RPM

SEE ENGINE START PROCEDURES ABOVE * FOR REMAINING SEQUENCES.

BEFORE TAXI

Engine Start Checklist	COMPLETED
Radio Master Switch	ON
Elevator Trim Switch	ON
Internal/External Lights	As Desired
Directional Gyro	SET or Slave switch ON
Stand-by Vacuum Pump Operational Check	
Stand-by vacuum operational indicator red button - VISIBLE	
STBY VAC Switch	ON

BEFORE TAXI (con't.)

Stand-by vacuum operational indicator red button - NOT VISIBLE	
STBY VAC Switch	OFF
Instruments	Normal Operation
Radios	CHECKED and SET
Altimeter	SET
Fuel Selector	SWITCH TANKS verify engine runs on other tank
Cabin Heat	AS DESIRED
Defroster	AS DESIRED
Cabin Vent	AS DESIRED
Optional Equipment Checks	Reference SECTION IX.

TAXI

Before Taxi Checklist	COMPLETED
Rudder Trim	AS DESIRED

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

With rudder trim in the full right position, the aircraft will tend to steer to the right during taxi.

Parking brake	RELEASE
Brakes	CHECK during TAXI
Directional Gyro	Proper indication during turns
Turn Coordinator	Proper indication during turns
Artificial Horizon	ERECT during turns
Throttle	Minimum power
Propeller	Full Forward (HIGH RPM)

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

To prevent battery depletion in prolonged taxi or holding position before takeoff, increase RPM until "AMMETER" indicates positive charge.

BEFORE TAKEOFF

Taxi Checklist	COMPLETED
Parking Brake	SET
Fuel Selector	FULLEST TANK
Throttle	1000 RPM
Propeller	HIGH RPM
Mixture	FULL FORWARD
Alternate Air	Verify CLOSED
Alternator Field Switch	Verify ON
Throttle	2000 RPM
Magneto Switch	CHECK - BOTH to L, BOTH to R, BOTH
	Verify engine operates smoothly on each magneto separately. (150 RPM MAX drop on each magneto, 50 RPM MAX difference)

NOTE

An absence of RPM drop may be an indication of faulty magneto grounding or improper timing. If there is doubt concerning ignition system operation, RPM checks at a leaner mixture setting or higher engine speed will usually confirm whether a deficiency exists.

Propeller	CYCLE/Return to high RPM
Ammeter	CHECK Positive Charge Indication
Throttle	RETARD to 1000 RPM
Low Fuel Boost Pump Switch	ON-Verify annunciator light will illuminate BLUE
Low Fuel Boost Pump Switch	OFF

Elevator Trim	TAKEOFF SETTING
Rudder Trim	TAKEOFF SETTING
Wing Flaps	CHECK operation.
SET AT TAKEOFF position (10 Degrees)	
Flight Controls	CHECK free and correct movement
Cabin Door	CHECK SECURED
Seats, Seat Belts and Shoulder Harness	SECURED
Avionics and Auto Pilot	CHECK - (Refer to SECTION IX)
Annunciator Lights	CHECK
Internal/External Lights	AS DESIRED
Strobe Lights/Rotating Beacon	ON
Pilots Window	CLOSED
Emergency Gear Extension (RED) Handle	DOWN & LATCHED
Oil Temperature	75°F(24°C) minimum
CHT	250°F(121°C) minimum
Parking Brake	RELEASE

TAKEOFF

Proper engine operation should be checked early in the takeoff roll. Any significant indication of rough or sluggish engine response is reason to discontinue takeoff.

When takeoff must be made over a gravel surface, it is important that the throttle be applied **SLOWLY**. This will allow the aircraft to start rolling before high RPM is developed, and gravel or loose material will be blown back from the propeller area instead of being pulled into it.

TAKEOFF (NORMAL)

Power	FULL THROTTLE (2500 RPM)
Annunciator	CHECK
Engine Instruments	CHECK for proper indications
Lift Off/Climb Speed	As specified in SECTION 5 (Takeoff Distance)
Landing Gear	RETRACT IN CLIMB after clearing obstacles.
Wing Flaps	UP

| NOTE |

If maximum performance takeoffs are desired obtain full power before brake release. Use lift off and climb speed as specified in SECTION 5.

CLIMB**| NOTE |**

If applicable, use noise abatement procedures as required.

| NOTE |

See SECTION 5, for rate of climb graph.

CLIMB (CRUISE)

Power	2500 RPM
Manifold Pressure	24 Inches
Mixture	FULL RICH or BLUE ARC on EGT
Rudder Trim	As Desired
Airspeed	120 KIAS

CLIMB (BEST RATE)(V_y)

Power	FULL THROTTLE /2500 RPM
Mixture	FULL RICH or BLUE ARC on EGT
Rudder Trim	As Desired
Airspeed	105 KIAS

SECTION IV
NORMAL PROCEDURES
CLIMB (BEST ANGLE)(V_x)

MOONEY
M20R

Power	FULL THROTTLE/2500 RPM
Mixture	FULL RICH
Rudder Trim	As Desired
Airspeed	85 KIAS

Leaning may be required during CLIMB depending on atmospheric conditions.

CRUISE

| NOTE |

Use recommended engine break-in procedures as published by engine manufacturer.

Airspeed	ACCELERATE to cruise airspeed
Throttle	SELECTED SETTING
(Ref. CRUISE PERFORMANCE CHARTS in SECTION 5)	

| NOTE |

Prolonged climbs to high cruise altitudes during hot weather operations may result in some fuel flow fluctuations as throttle is reduced. If fluctuations occur, turn Low Boost Pump Switch ON until cooling has alleviated fluctuations.

Propeller	Set RPM to selected setting
Mixture	LEAN TO 50°F rich of PEAK EGT

| NOTE |

Cruise operation at BEST POWER will result in a substantial increase in fuel flow, greatly decreasing range and endurance; reference charts published in SECTION 5.

Engine instruments	CHECK
------------------------------	-------

| NOTE |

Careful leaning of mixture control will result in best fuel efficiency. This requires operating at proper EGT. Failure to do so will result in excessive fuel burn. After leveling off at cruise altitude, set RPM for desired power setting per Cruise Power Chart in Section V. Slowly lean Mixture until EGT reaches peak value. Enrichen to 50°F rich of peak EGT for best power (50°F lean of peak is best economy); careful adjustments are necessary for accurate setting. Changes in altitude or power MAY REQUIRE readjustment of EGT.

Engine temperatures	STABILIZE at cruise condition.
Rudder Trim	As Desired

When increasing power, always return mixture to full rich, then increase RPM before increasing manifold pressure; when decreasing power, decrease manifold pressure before reducing RPM. Always stay within the established operating limits, and always operate the controls slowly and smoothly.

FUEL TANK SELECTION

Low Fuel Boost Pump Switch	ON
Fuel Selector	OPPOSITE TANK
Low Fuel Boost Pump Switch	OFF

OXYGEN SYSTEM

(OPTIONAL EQUIPMENT)

///////// // WARNING // /////////

Greasy lipsticks and waxed mustaches have been known to ignite spontaneously inside oxygen masks. Passengers should be suitably advised prior to flight.

For safety reasons NO SMOKING should be allowed in the airplane while oxygen is being used.

When ready to use the oxygen system, proceed as follows:

Mask and Hose	Adjust mask to face and adjust metallic nose strap for snug mask fit.	SELECT - either MIC or STD
Delivery Hose	PLUG INTO OUTLET assigned to that seat.	

| NOTE |

When the oxygen system is turned ON, oxygen will flow continuously at the appropriate rate of flow for the altitude without any manual adjustments.

Oxygen Supply Control Knob	ON.	
Face Mask Hose Flow Indicator	CHECK	
Oxygen is flowing if the indicator is being forced toward the mask.		
Delivery Hose	UNPLUG from outlet when discontinuing use of oxygen.	
This automatically stops flow of oxygen from that outlet.		
Oxygen Supply Control Knob	OFF - when oxygen is no longer required.	

///////// // WARNING // /////////

Proper oxygen flow is critical to pilot/passenger safety, especially at altitudes above 20,000 ft. MSL. It is important to closely monitor the face mask hose flow indicator to ensure oxygen is constantly flowing to the mask. A GREEN indication on the flow indicator denotes proper oxygen flow. Always place the flow indicator in a position where it is in the normal scan area of the cockpit.

Refer to duration chart (Fig. 7-13) for safe operational quantities.

DESCENT

| NOTE |

Avoid extended descents at low manifold pressure setting, as engine can cool excessively and may not accelerate satisfactorily when power is re-applied.

NORMAL DESCENT - GEAR UP

Seats, Seat Belts/Shoulder Harness	ADJUST AND SECURE
Wing Flaps	UP
Landing Gear	UP
Throttle	CHT in Green)
Propeller	2400 RPM
Mixture	Peak EGT (Monitor as descent progresses)
Cylinder Head Temperature (CHT)	MONITOR [250° F (121°C) minimum]
Airspeed	AS DESIRED (196 KIAS max.)
Rudder Trim	AS DESIRED

| NOTE |

Plan descents to arrive at pattern altitude on downwind leg for maximum fuel efficiency and minimum aircraft noise.

~ CAUTION ~

DO NOT fly in YELLOW ARC speed range unless the air is smooth.

NORMAL DESCENT - GEAR DOWN

Seats, Seat Belts/Shoulder Harness	ADJUST AND SECURE
Wing Flaps	UP
Airspeed	DECELERATE to 140 KIAS
Landing Gear	DOWN
Throttle	Keep CHT in Green Arc
Propeller	2400 RPM
Mixture	Peak EGT (Monitor as descent progresses)
Cylinder Head Temperature (CHT)	Monitor (250° F (121° C) min)
Airspeed	165 KIAS or LESS.

| NOTE |

Using landing gear as a descent aid will result in a steeper descent rate (greater altitude loss per horizontal distance traveled).

APPROACH FOR LANDING

~ CAUTION ~

The airplane must be within allowable weight and balance envelope for landing (REF. SECTION VI). It will require a minimum of one hour of flight before a permissible landing weight is attained when takeoffs are made at maximum gross weight. If landing at a weight exceeding maximum landing weight (3200 Lbs.)(1452 Kgs.) is required, see OVERWEIGHT LANDING PROCEDURE, SECTION III.

Seats, Seat Belts/Shoulder Harness	ADJUST AND SECURE
Internal/External lights	AS DESIRED
Landing Gear	EXTEND below 140 KIAS
Mixture	(Check Gear Down light ON-Check visual indicator)
Propeller	FULL RICH (on final)
Fuel Boost Pump Switches	HIGH RPM (on final)
Fuel Selector	OFF
Wing Flaps	FULLEST TANK
	T/O POSITION
	(FULL DOWN below 110 KIAS)

~ CAUTION ~

To minimize control wheel forces when entering landing configuration, timely nose-up trimming is recommended to counteract nose down pitching moment caused by reduction of power and/or extension of flaps.

Elevator Trim	AS DESIRED
Rudder Trim	AS DESIRED
Parking Brake	VERIFY OFF

| NOTE |

The parking brake should be rechecked to preclude partially applied brakes during touchdown.

GO AROUND (BALKED LANDING)

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

To minimize control wheel forces during GO-AROUND, timely nose-down trimming is recommended to counteract nose up pitching moment as power is increased and/or flaps are retracted.

Power		FULL FORWARD/2500 RPM)
Mixture		Verify FULL RICH
Fuel Boost Pump Switches		OFF
Wing Flaps		TAKEOFF POSITION (10°)
Trim		(After POSITIVE climb established)
Airspeed		NOSE DOWN to reduce forces
Landing Gear		85 KIAS
Wing Flaps		RETRACT
Airspeed		RETRACT
		105 KIAS

LANDING

LANDING (NORMAL)

Approach for Landing Checklist		COMPLETED
Approach Airspeed		As specified in SECTION V (Landing Distance)
Touchdown		MAIN WHEELS FIRST (aligned w/ runway)
Landing Roll		LOWER nose wheel gently
Brakes		MINIMUM required

NOTE

Landing information for reduced flap settings is not available.
See SECTION V for Landing Distance tables.

NOTE

If maximum performance landings are desired, use above procedures except, reduce approach airspeed to 70 KIAS (flaps full down) and apply maximum braking (without skidding tires) during rollout.

NOTE

Crosswind landings should be accomplished by using above procedures except maintain approach speed appropriate for wind conditions. Allow aircraft to crab until the landing flare. Accomplish touchdown in a slight wing low sideslip (low wing into wind) and aircraft aligned with runway. During landing roll, position flight controls to counteract crosswind.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Landing gear may retract during landing roll if landing gear switch is placed in the UP position.

TAXI AFTER LANDING

Throttle		AS REQUIRED
Fuel Boost Pump Switches		OFF
Wing Flaps		RETRACT
Elevator Trim		TAKEOFF SETTING
Avionics/Radios		AS REQUIRED
Interior/Exterior Lights		AS DESIRED

**MOONEY
M20R**

Parking Brake	.	.	.	.	.	.	.	.	. SET
Throttle	.	.	.	.	.	.	.	. IDLE RPM	
Radio Master Switch	.	.	.	.	.	.	.	. OFF	
Interior/Exterior Lights	.	.	.	.	.	.	.	. OFF	
Pitot Heat	.	.	.	.	.	.	.	. OFF	
Magneto/Starter Switch	.	.	.	.	.	.	.	. GROUNDING CHECK	
Mixture	.	.	.	.	.	.	.	. IDLE CUT-OFF	
Alternator Field Switch	.	.	.	.	.	.	.	. OFF	
Master Switch	.	.	.	.	.	.	.	. OFF	
Magneto/Starter Switch	.	.	.	.	.	.	.	. OFF	

Magneto/Starter Switch	.	.	.	.	.	.	VERIFY OFF/ Key removed
Master Switch	.	.	.	.	.	.	VERIFY OFF
Radio Master Switch	.	.	.	.	.	.	Verify OFF
Electrical Switches	.	.	.	.	.	.	Verify OFF
Interior Light Switches	.	.	.	.	.	.	VERIFY OFF
Parking Brake	.	.	.	.	.	.	RELEASE - INSTALL WHEEL CHOCKS
Extended parking	.	.	.	.	.	.	CONTROL WHEEL SECURED
Cabin Windows and Doors	.	.	.	.	.	.	with seat belts, cabin vents closed; CLOSED AND LOCKED

ISSUED 6 - 94

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	5-3
VARIABLES	5-3
OPERATIONAL PROCEDURES FOR MAXIMUM FUEL EFFICIENCY	5-3
PERFORMANCE CONSIDERATIONS	5-4
MISSION PROFILE CHARTS	5-4

- TABLES AND CHARTS -

TEMPERATURE CONVERSION	5-5
CROSSWIND COMPONENT CHART	5-6
AIRSPED CALIBRATION - PRIMARY STATIC SYSTEM (GEAR UP)	5-7
AIRSPED CALIBRATION - PRIMARY STATIC SYSTEM (GEAR DOWN)	5-8
AIRSPED CALIBRATION - ALTERNATE STATIC SYSTEM	5-9
ALTIMETER CORRECTION - PRIMARY STATIC SYSTEM (GEAR UP, FLAPS UP)	5-10
ALTIMETER CORRECTION - ALTERNATE STATIC SYSTEM (GEAR DN, FLAPS DN)	5-11
STALL SPEED VS ANGLE OF BANK	5-12
TAKEOFF DISTANCE - HARD SURFACE	5-13
TAKEOFF DISTANCE - GRASS SURFACE	5-14
RATE OF CLIMB - MAX CLIMB	5-15
RATE OF CLIMB - CRUISE CLIMB	5-16
TIME-FUEL-DISTANCE TO CLIMB - MAX CLIMB	5-17
TIME-FUEL-DISTANCE TO CLIMB - CRUISE CLIMB	5-18
CRUISE POWER SETTINGS AND FUEL FLOWS	5-19
SPEED POWER VS ALTITUDE	5-20
RANGE	5-21
ENDURANCE	5-22
TIME-FUEL-DISTANCE TO DESCEND	5-23
LANDING DISTANCE - HARD SURFACE	5-24
LANDING DISTANCE - GRASS SURFACE	5-25
MISSION PROFILE - 200	5-26
MISSION PROFILE - 400	5-27
MISSION PROFILE - 600	5-28
MISSION PROFILE - 800	5-29

TABLE OF CONTENTS (con't)

INTRODUCTION

The purpose of this section is to present the owner or operator with information needed to facilitate planning of flights with reasonable accuracy.

The Performance Data and charts presented herein are calculated, based on actual flight tests with the airplane and engine in good condition and the engine power control system properly adjusted.

The flight test data has been corrected to International Standard Atmosphere conditions and then expanded analytically to cover various airplane gross weights, operating altitudes, and outside air temperatures.

VARIABLES

It is not possible to make allowances in the charts for varying levels of pilot technique, proficiency or environmental conditions. Mechanical or aerodynamic changes are not authorized because they can affect the performance or flight characteristics of the airplane. The effect of such things as soft runways, sloped runways, winds aloft or airplane configuration changes must be evaluated by the pilot. However, the performance on the charts can be duplicated by following the stated procedures in a properly maintained, standard MOONEY M20R.

Examples are given to show how each chart is used. The only charts with no example are those where such an example of use would be repetitive.

To obtain effect of altitude and OAT on aircraft performance:

1. Set altimeter to 29.92 and read "pressure altitude".
2. Using the OAT grid for the applicable chart read the corresponding effect of OAT on performance.

~~~~~  
~CAUTION~  
~~~~~

Be sure to return to local altimeter setting in calculating aircraft elevation above sea level.

OPERATIONAL PROCEDURES FOR MAXIMUM FUEL EFFICIENCY

For maximum fuel efficiency on the M20R, proper mixture leaning during cruise flight must be accomplished. The TCM IO-550-G(5) engine in the M20R has been designed to attain maximum fuel efficiency at desired cruise power. Best power mixture (at 2400 RPM) has been determined to be 50°F (10°C) rich of peak EGT. EGT is usually a more accurate indication of engine operation and fuel burn than indicated fuel flow. Therefore, it is recommended that the mixture be set using EGT as the primary reference instead of setting to a particular fuel flow.

The following procedures is recommended for setting cruise power and leaning to best economy at 75% power or less.

1. After leveling off, set manifold pressure and RPM for the desired cruise power settings as shown in this SECTION. At this point, mixture is at full rich from the climb.
2. Slowly move mixture control toward lean while observing EGT indicator. If leaning mixture toward peak EGT causes the original manifold pressure setting to change, adjust throttle to maintain that desired cruise manifold pressure and continue leaning until best economy setting is obtained.

PERFORMANCE CONSIDERATIONS

RANGE and ENDURANCE ASSUMPTIONS

Range and endurance allowance is based on climbing at maximum continuous power to cruise altitude.
Range and endurance reserves of 45 minutes at cruise power have been allowed for. Other conditions used for Range and Endurance are listed on each chart.

OPTIONAL PROPELLER DE-ICE BOOTS

With the optional propeller de-ice boots installed, expect climb performance to be degraded approximately 50 FPM from what is presented in the manual.

LANDING GEAR DOORS

When snow and ice are likely to be present on taxi and runway surfaces, inboard landing gear doors should be removed. Accumulation of ice and snow could prevent landing gear operation.
If inboard landing gear doors are removed, a decrease in cruise speed and range can be expected and should be considered in preflight planning. To be conservative the following figures should be used:

Decrease of true airspeed at normal cruise power setting by approximately 5 KTAS.

An approximate adjustment to range data shown in this manual can be made based on flight time planned **with landing gear doors removed** from aircraft. For example, using the above cruise speed decrease for a 5 hour flight will result in a decrease in range of approximately 25 N.M.:

5 HR X 5 KTS = 25 N.M. reduction in range.

MISSION PROFILE CHARTS

The Mission Profile Charts are presented as a flight planning aid. They can provide information to assist in the selection of altitude and power setting to fly as well as provide the flight time and fuel to fly a given distance.

The charts are based on the following:


- Fuel used to warmup, taxi and takeoff.
- Time and fuel to climb at maximum power.
- Time and fuel to cruise at the specified power setting.
- Cruise with gear and flaps UP.
- Time and fuel to descend at 750 FPM at 150 KIAS.
- Zero wind.
- Gross weight.

~ ~ ~ ~ ~ - CAUTION - ~ ~ ~ ~ ~


Zero wind conditions seldom occur. In addition, varying atmospheric conditions, aircraft weight, mechanical condition of the aircraft and piloting techniques all affect the actual flight time and fuel used during a flight.

It is the pilot's responsibility to determine the actual operating conditions and plan the flight accordingly.

TEMPERATURE CONVERSION




CROSSWIND COMPONENT CHART



**DEMONSTRATED CROSS WIND IS 13 KNOTS
(THIS IS NOT A LIMITATION)**

AIRSPEED CALIBRATION - PRIMARY STATIC SYSTEM (GEAR UP)



AIRSPEED CALIBRATION - PRIMARY STATIC SYSTEM (GEAR DN)

AIRSPEED CALIBRATION
PRIMARY STATIC SYSTEM
GEAR AND FLAPS DOWN

EXAMPLE:


GIVEN: IAS 80 KTS

FLAPS 10

POWER OFF

FIND: CAS 79 KTS

NOTE: INDICATED AIRSPEED ASSUMES
ZERO INSTRUMENT ERROR



AIRSPEED CALIBRATION - ALTERNATE STATIC SYSTEM

KIAS	GEAR & FLAPS UP KIAS	GEAR & FLAPS DN (10°) KIAS	GEAR & FLAPS DN (33°) KIAS
50	3.0	0.0	-1.0
60	1.5	-1.2	-2.0
70	0.0	-2.2	-3.2
80	-1.8	-3.2	-4.5
90	-2.8	-4.0	-6.0
100	-3.0	-4.7	-7.4
110	-3.0	-5.4	-8.8
120	-3.0	-	-
130	-3.6	-	-
140	-4.5	-	-
150	-5.1	-	-
160	-5.6	-	-
170	-6.1	-	-
180	-6.5	-	-
190	-7.2	-	-
200	-7.9	-	-

NOTE: . . The minus sign indicates subtraction of the given numbers from KIAS to obtain the corrected airspeed.

CONDITIONS: Power-ON, Storm Window & Vents - CLOSED,
. . . Heater & Defroster - ON or OFF

SEA LEVEL

12,500 FT.

25,000 FT.

NOTE: The minus sign indicates subtraction of the given numbers from the indicated pressure altitude to obtain correct altitude, assuming zero instrument error.

FLAPS = 10° ALTITUDE CORRECTION: -7 ft.
(Subtract from Indicated Altitude)
INDICATED PRESSURE ALTITUDE: 12,500 ft. **PRESSURE ALTITUDE: = 12,493 ft.**

ALTIMETER CORRECTION - ALTERNATE STATIC SYSTEM

	SEA LEVEL			12,500 FT.			25,000 FT.		
CIAS	GEAR UP FLAPS UP	GEAR & FLAPS DN 10° 33°		GEAR UP FLAPS UP	GEAR & FLAPS DN 10° 33°		GEAR UP FLAPS UP	GEAR & FLAPS DN 10° 33°	
50	13	0 -4		20	0 -7		30	0 -10	
60	8	-6 -11		12	-9 -16		18	-14 -24	
70	0	-14 -20		0	-20 -29		0	-31 -45	
80	-13	-23 -32		-19	-34 -47		-29	-51 -72	
90	-23	-32 -48		-33	-47 -71		-50	-72 -108	
100	-27	-42 -66		-39	-62 -97		-68	-94 -148	
110	-30	-53 -87		-43	-78 -127		-66	-119 -194	
120	-32	- -		-48	- -		-72	- -	
130	-53	- -		-77	- -		-118	- -	
140	-57	- -		-84	- -		-127	- -	
150	-69	- -		-102	- -		-155	- -	
160	-82	- -		-128	- -		-182	- -	
170	-95	- -		-139	- -		-211	- -	
180	-107	- -		-158	- -		-248	- -	
190	-126	- -		-185	- -		-282	- -	
200	-146	- -		-215	- -		-327	- -	

NOTE: The minus sign indicates subtraction of the given number from the indicated altitude to obtain the corrected altitude.

CONDITIONS: Power -ON, Vents & Storm Window - CLOSED,
Heater & Defroster - ON or OFF.

STALL SPEED VS. ANGLE OF BANK

STALL SPEED vs. ANGLE OF BANK

ASSOCIATED CONDITIONS:
FORWARD C.G.
POWER IDLE

EXAMPLE:

WEIGHT 3000 LBS (1361 KGS)
LANDING GEAR DOWN
FLAPS 10°
ANGLE OF BANK 45°
STALL SPEED 72.5 KCAS (73.0 KIAS)

NOTE: UP TO 500 FEET ALTITUDE LOSS MAY
OCCUR DURING STALLS AT MAXIMUM WEIGHT

GROSS WEIGHT	GEAR AND FLAP POSITION	ANGLE OF BANK							
		0°		30°		45°		60°	
		KCAS	KIAS	KCAS	KIAS	KCAS	KIAS	KCAS	KIAS
3368 LBS (1528 KGS)	GEAR UP, FLAPS 0°	66.0	66.0 66.5	71.0	71.5	78.5	79.0	93.5	94.0
	GEAR DOWN, FLAPS 10°	64.5	64.5 65.0	69.5	69.5	76.5	77.5	91.0	92.0
	GEAR DOWN, FLAPS 33°	59.0	59.0	63.5	63.5	70.0	70.0	83.5	84.5
3000 LBS (1361 KGS)	GEAR UP, FLAPS 0°	62.5	62.5 63.0	67.0	67.5	74.5	75.0	88.5	89.5
	GEAR DOWN, FLAPS 10°	61.0	61.0 62.0	65.5	65.5	72.5	73.0	86.5	87.5
	GEAR DOWN, FLAPS 33°	55.5	55.5	59.5	59.5	66.0	66.0	78.5	79.5
2700 LBS (1225 KGS)	GEAR UP, FLAPS 0°	59.0	59.5	63.5	64.0	70.0	70.5	83.5	84.0
	GEAR DOWN, FLAPS 10°	58.0	58.0	62.5	62.5	69.0	69.0	82.0	83.0
	GEAR DOWN, FLAPS 33°	53.0	53.0	57.0	57.0	63.0	63.0	75.0	76.0

TAKEOFF DISTANCE

TAKEOFF WEIGHT-LBS (KGS)	TAKEOFF SPEED KIAS	SPEED AT 50 FT-KIAS
3368 LBS (1528 KGS)	56	80
3100 LBS (1406 KGS)	64	78
2700 LBS (1225 KGS)	59	74

NOTE: 1. MAXIMUM DEMONSTRATED CROSSWIND IS 13 KNOTS.
2. CONDITIONS OF HIGH HUMIDITY CAN RESULT IN AN INCREASE OF UP TO 10% TO THE TAKEOFF DISTANCE.

80% HUMIDITY IS STD.

ASSOCIATED CONDITIONS


POWER FULL THROTTLE/2500 RPM
LDG GEAR DOWN UNTIL OBSTACLE CLEARED
WING FLAPS 10°
RWY SURF. PAVED
LEVEL, DRY

EXAMPLE:

OAT 17 °C
PRESSURE ALTITUDE 5000 FT
WEIGHT 3250 LBS (1474 KGS)
HEADWIND COMPONENT 5 KTS

GROUND ROLL 1550 FT (472 M)

TOTAL TAKEOFF DISTANCE (50 FT OBSTACLE) 2900 FT (884 M)



TAKEOFF DISTANCE - GRASS SURFACE

TAKEOFF DISTANCE - GRASS SURFACE

TAKEOFF WEIGHT-LBS (KGS)	TAKEOFF SPEED KIAS	SPEED AT 50 FT-KIAS
3368 LBS (1528 KGS)	66	80
3100 LBS (1406 KGS)	64	78
2700 LBS (1225 KGS)	59	74


NOTE: 1. MAXIMUM DEMONSTRATED CROSSWIND IS 13 KNOTS.
2. CONDITIONS OF HIGH HUMIDITY CAN RESULT IN AN INCREASE OF UP TO 10% TO THE TAKEOFF DISTANCE.

ASSOCIATED CONDITIONS


POWER FULL THROTTLE/2500 RPM
LDG GEAR DOWN UNTIL OBSTACLE CLEARED
WING FLAPS 10°
RWY SURF. SHORT DRY GRASS, LEVEL

EXAMPLE:

OAT 17 °C
PRESSURE ALTITUDE 5000 FT
WEIGHT 3250 LBS (1474 KGS)
HEADWIND 5 KTS
GROUND ROLL 1745 FT (532 M)
TOTAL TAKEOFF DISTANCE (50 FT OBSTACLE) 3095 FT (943 M)




MAXIMUM RATE of CLIMB




5-16

REV. C 9-94

ISSUED 6-94



TIME-FUEL-DISTANCE TO CLIMB (MAX CLIMB)




ISSUED 6-94

REV. C 9-94

5-17

TIME-FUEL-DISTANCE TO CLIMB (CRUISE CLIMB)

TIME-FUEL-DISTANCE TO CLIMB (CRUISE CLIMB)
FULL THROTTLE, 2500 RPM, 120 KIAS, FULL RICH, GEAR UP, FLAPS UP



CRUISE POWER SETTINGS AND FUEL FLOWS

EXAMPLE: M20R CRUISE POWER SETTINGS AND FUEL FLOWS
 Cruise Alt. 8000 ft.
 OAT 9°C (SEE NOTE)
 Power Setting Desired 75% 1. BEST POWER is 50 °F Rich of Peak. 2. ECONOMY CRUISE is 50 °F Lean of Peak.


RPM/MP 2400/22.9 Fuel Flow 15.6 (Best Power)		Max. Recommended		75% Power 210 HP			65% Power 182 HP			55% Power 154 HP			45% Power 126 HP		
Pressure Altitude (Feet)	RPM	2400	2500	2300	2400	2500	2300	2400	2500	2300	2400	2500	2300	2400	2500
	Fuel Flow	15.2	15.3	13.5	13.6	13.7	11.8	11.9	12.0	10.0	10.1	10.2	8.2	8.3	8.4
	Best ECON. Best POWER	17.5	17.6	15.5	15.6	15.7	13.9	14.0	14.1	11.7	11.8	11.9	9.6	9.7	9.8
Std. Day	Std. Temp.	MANIFOLD PRESSURE — INCHES OF MERCURY													
S. L.	15°C 59°F	27.0	26.2	25.3	24.3	23.0	22.4	21.4	20.3	19.5	18.6	17.7	16.6	15.8	15.0
2,000	11°C 52°F	27.0	25.7	24.8	23.8	22.6	22.0	21.1	20.0	19.1	18.2	17.3	16.2	15.4	14.6
4,000	7°C 45°F		25.2	24.2	23.2	22.3	21.7	20.8	19.7	18.7	17.7	16.8	15.7	14.9	14.3
6,000	3°C 38°F		24.7	23.6	22.8	22.0	21.2	20.3	19.2	18.2	17.2	16.3	15.3	14.6	14.0
8,000	-1°C 31°F				22.5	21.7	20.7	19.8	18.7	17.7	16.8	16.0	14.9	14.2	13.7
10,000	-5°C 23°F						20.2	19.3	18.2	17.2	16.4	15.8	14.6	13.9	13.4
12,000	-9°C 16°F						19.5	18.7	17.9	16.7	16.0	15.6	14.3	13.6	13.1
14,000	-13°C 9°F							18.1	17.7	16.3	15.8	15.4	14.0	13.3	12.9
16,000	-17°C 2°F									16.1	15.6	15.2	13.7	13.0	12.7
18,000	-21°C -5°F											15.0	13.5	12.8	12.5
20,000	-25°C -12°F												13.3	12.6	12.3

NOTE: Add .4" MP for each 10 °C (18 °F) OAT above standard day temperature. Subtract .4" MP for each 10 °C (18 °F) below standard day temperature. If OAT above standard precludes obtaining the desired MP, use the next higher RPM/MP with appropriate temperature correction to MP.


SPEED POWER VS ALTITUDE

SPEED, POWER vs ALTITUDE

GEAR UP, FLAPS UP, 3200 LBS (1452 KGS)



RANGE



ISSUED 6-94


REV. C 9-94

5-21

5-22

REV. C 9-94

ISSUED 6-94



TIME-FUEL-DISTANCE TO DESCEND

TIME-FUEL-DISTANCE TO DESCEND

150 KIAS DESCENT SPEED

ASSOCIATED CONDITIONS:

POWER: 2000 RPM/MAP AS REQ'D TO MAINTAIN

750 FPM RATE OF DESCENT

LANDING GEAR: UP

FLAPS: UP

MIXTURE:

LEAN TO BLUE ARC or ENRICHEN FOR SMOOTHNESS

EXAMPLE:

INITIAL PRESSURE ALT:

18000

FINAL PRESSURE ALT:

4000


TIME TO DESCEND:

24.0-5.0=19 MINUTES

FUEL TO DESCEND:

3.6-0.7=2.9 GALLONS

DISTANCE TO DESCEND: 69.0-13.0=56.0 NAUTICAL MILES



LANDING DISTANCE

LANDING WEIGHT - LBS (KGS)	APPROACH SPEED KIAS
3200 (1452)	75
2900 (1315)	71
2600 (1175)	68

ASSOCIATED CONDITIONS:

POWER IDLE
LANDING GEAR DOWN
WING FLAPS FULL DOWN (33°)
RUNWAY SURFACE PAVED, LEVEL, DRY
BRAKING MAXIMUM


EXAMPLE:

DAT 15 °C
PRESSURE ALTITUDE 6000 FT.
WEIGHT 2800 LBS (1270 KGS)
HEADWIND COMPONENT 5 KTS

GROUND ROLL 1350 FT. (411 M)

TOTAL LANDING DISTANCE 2800 FT. (853 M)
(50 FT. OBSTACLE)

NOTE: 1) MAXIMUM DEMONSTRATED CROSSWIND IS 13 KNOTS.



LANDING DISTANCE - GRASS SURFACE

LANDING DISTANCE - GRASS SURFACE

NOTE: 1) MAXIMUM DEMONSTRATED CROSSWIND IS 13 KNOTS.

LANDING WEIGHT - LBS (KGS)	APPROACH SPEED KIAS
3200 (1452)	75
2900 (1315)	71
2600 (1175)	68

ASSOCIATED CONDITIONS:


POWER IDLE
LANDING GEAR DOWN
WING FLAPS FULL DOWN (33°)
RUNWAY SURFACE SHORT DRY GRASS, LEVEL
BRAKING MAXIMUM

EXAMPLE:

DAT 0 °C
PRESSURE ALTITUDE 6000 FT.
WEIGHT 2800 LBS (1270 KGS)
HEADWIND COMPONENT 5 KTS

GROUND ROLL 1650 FT. (503 M)

TOTAL LANDING DISTANCE 3100 FT. (945 M)
(30 FT. OBSTACLE)




MISSION PROFILE — 200 NM

3,200 LBS (1,452 KGS)
Zero Wind, Standard Day, Cruise Power: Best Power (2400 RPM)
Clean Configuration, 89.0 Gallons (337 Liters) (74 Imp. Gal.) Usable Fuel
Missions Profiles Allow for: Warmup, Taxi, Takeoff, Max Power Climb, and Descent

EXAMPLE:

PRESSURE ALT 11,500 FT
POWER 55%
MISSION TIME 1.26 HRS
FUEL USED 15.4 GAL




MISSION PROFILE - 400

MISSION PROFILE - 400 NM

3,200 LBS (1,452 KGS)
Zero Wind, Standard Day, Cruise Power: Best Power (2400 RPM)
Clean Configuration, 89.0 Gallons (337 Liters) (74 Imp. Gal.) Usable Fuel
Missions Profiles Allow for: Warmup, Taxi, Takeoff, Max Power Climb, and Descent

EXAMPLE:


PRESSURE ALT	11,500 FT
POWER	55%
MISSION TIME	2.47 HRS
FUEL USED	29.6 GAL




5 - 28

REV. C 9-94

ISSUED 6 - 94



MISSION PROFILE - 800



BLANK

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	. 6-2
AIRPLANE WEIGHING PROCEDURE	. 6-2
WEIGHT & BALANCE CHART	. 6-4
OWNERS WEIGHT & BALANCE RECORD	. 6-5
PILOTS LOADING GUIDE	. 6-6
PROBLEM FORM	. 6-7
LOADING COMPUTATION GRAPH	. 6-7
CENTER OF GRAVITY MOMENT ENVELOPE	. 6-8
CENTER OF GRAVITY LIMITS	. 6-9
FIXED BALLAST	. 6-10
EQUIPMENT LIST	. 6-10

NOTE:

The empty weight, center of gravity, and equipment list for the airplane as delivered from Mooney Aircraft Corporation is contained in this section. The use of this section is valid for use with the airplane identified below when approved by Mooney Aircraft Corporation.

MOONEY - M20R

AIRCRAFT SERIAL NO. 29-0045

AIRCRAFT REGISTRATION NO. 0Y-ELW

  03-06-2009

Mooney Aircraft Corporation - Approval Signature & Date

ISSUED 6-94

BenAir A/S
Stauning Airport, DK 6900 Skjern
tlf. +45 9681 4444 - fax +45 9681 4450

6-1

INTRODUCTION

This section describes the procedure for calculating loaded aircraft weight and moment for various flight operations. In addition, procedures are provided for calculating the empty weight and moment of the aircraft when the removal or addition of equipment results in changes to the empty weight and center of gravity. A comprehensive list of all Mooney equipment available for this airplane is included in this section. Only those items checked (X) were installed at Mooney and are included in the empty weight-and-balance data.

The aircraft owner and/or pilot, has the responsibility of properly loading the aircraft for safe flight. Data presented in this section will enable you to carry out this responsibility and insure that your airplane is loaded to operate within the prescribed weight and center-of-gravity limitations.

At the time of delivery, Mooney Aircraft Corporation provides the empty weight and center of gravity data for the computation of individual loadings. (The empty weight and C.G. (gear extended) as delivered from the factory is tabulated on page 6-5 when this manual is supplied with the aircraft from the factory.)

FAA regulations also require that any change in the original equipment affecting the empty weight and center of gravity be recorded in the Aircraft Log Book. A convenient form for maintaining a permanent record of all such changes is provided on page 6-5. This form, if properly maintained, will enable you to determine the current weight-and-balance status of the airplane for load scheduling. The weight-and-balance data entered as your aircraft left the factory, plus the record you maintain on page 6-5, is all of the data needed to compute loading schedules.

The maximum certificated gross weight for the TCM powered M20R is 3368 lbs (1528 Kg) for Takeoff and 3200 pounds (1452 Kgs) for Landing. Maximum useful load is determined by subtracting the corrected aircraft empty weight from its maximum gross weight. The aircraft must be operated strictly within the limits of the Center-of-Gravity Moment Envelope shown on page 6-8.

AIRPLANE WEIGHING PROCEDURE

(A) LEVELING: Place a spirit level on the leveling screws above the tailcone left access door when leveling the aircraft longitudinally. Level the aircraft by increasing or decreasing air pressure in the nose wheel tire.

- (B) WEIGHING: To weigh the aircraft, select a level work area and:
1. Check for installation of all equipment as listed in the Weight & Balance Record Equipment List.
 2. Top off both wing tanks with full fuel. Subtract usable fuel, 89.0 U.S. gals. (337 liters) @ 5.82 lb/gal (100LL) (.69 Kg/l) = 518 lbs. (235 Kgs.), from total weight as weighed.

---*---

OPTIONAL METHOD - Ground aircraft and defuel tanks as follows:

- a. Disconnect fuel line at fuel system union located forward of the firewall on the lower left hand side.
- b. Connect a flexible line to output fitting that will reach fuel receptacle.
- c. Turn fuel selector valve to tank to be drained; remove filler cap from fuel filler port.
- d. Turn on fuel boost pump until tank is empty.
REPEAT STEPS C, AND D, TO DRAIN OTHER TANK.
- e. Replace 3.0 gallons (11.4 liters) fuel into each tank (unusable fuel).
(Use 5.82lb/gal(.69 Kg/liter) for 100LL fuel).
- f. Replace filler caps.

---*---

WEIGHING (con't.)

3. Fill oil tank to capacity (8 qts.).
4. Position front seats in full forward position.
5. Position flaps in full up position.
6. Position a 2000-pound (907.2 Kg.) capacity scale under each of the three wheels.
7. Level aircraft as previously described making certain nose wheel is centered.
8. Weigh the aircraft and deduct any tare from each reading.
9. Find reference point by dropping a plumb bob from center of nose gear trunion (retracting pivot axis) to the floor. Mark the point of intersection.
10. Locate center line of nose wheel axle and main wheel axles in the same manner.
11. Measure the horizontal distance from the reference point to main wheel axle center line. Measure horizontal distance from center line of nose wheel axle to center line of main wheel axles.
12. Record weights and measurements, and compute basic weight and CG as follows on next page:

NOTE:

Wing Jack Points are located at Fus. Sta. 56.658 in. (143.91 cm). Nose Jack Point is located at Fus. Sta. -5.51 in. (-14.0 cm.). Refer to SECTION VIII, Jacking, for procedures.

SECTION VI WEIGHT AND BALANCE

MOONEY
M20R

M20R - WEIGHT & BALANCE CHART

MEASUREMENTS	
L _{M/R}	INCHES/CM/MM
L _{M/N}	INCHES/CM/MM

SCALE POSITION AND SYMBOL	SCALE READING	TARE	NET WEIGHT
NOSE WHEEL (W _N)			
RIGHT MAIN WHEEL (W _R)			
LEFT MAIN WHEEL (W _L)			
BASIC EMPTY WEIGHT (W _T)			OF fuel has been drained
AS WEIGHED (W _T)			OF fuel has not been drained

a. CG Forward of Main Wheels:

$$\frac{\text{Lbs/Kg Weight of Nose (W}_N\text{)}}{\text{Distance Between Main and Nose Wheel Axle Centers (L}_{M/N}\text{)}} \times \frac{\text{In/cm/mm}}{\text{Distance From Nose Gear Trunion to Datum (L}_N\text{)}} = \frac{\text{Lbs/Kg Total weight of Aircraft (W}_T\text{)}}{\text{CG Forward of Main Wheels (L}_N\text{)}}$$

b. CG Aft of Datum (Station 0):

$$\frac{\text{In/cm/mm Distance From Center Nose Gear Trunion to Center of Main Wheel Axles (Horizontal) (L}_{M/R}\text{)}}{\text{Distance From Nose Gear Trunion to Datum (CONSTANT) (13 in/33.0 cm/330 mm)}} = \frac{\text{In/cm/mm Result of Computation Above (L}_N\text{)}}{\text{CG (FUS. STA) Distance Aft of Datum (Empty Weight CG) (L}_{END}\text{)}}$$

If fuel has not been drained, the usable fuel must be analytically subtracted to determine the Basic Empty Wt. and CG. Use loading calculation procedure shown on page 6-6.

WEIGHT	LBS. (Kg)	C.G. IN/CM/MM	MOMENT Lb-In (Kg-cm) (Kg-mm)/1000
As Weighed (W _T)			
Usable Fuel	—	49.23 in/125 cm/1250 mm	—
Basic Empty Wt.			

DAO

We keep our customers flying

EASA Part 145 Approval DK.145.0020

A/C reg.:	A/C Type:	A/C S/N:	WO:
OY-ELW	M20R	29-0045	A1010
Date:	Item:	Of:	AC TT:
02-04-2012			728
			AC TC:
			0

Additional Equipment List / Revised Weight and Balance

	WEIGHT	ARM	MOMENT
Choose between LBS. and KG.	LBS.	INCH	LBS./INCH

Previous Aircraft Empty weight at date:

9. maj 1995

DATA:

WEIGHT

2317,00

ARM

43,36

MOMENT

100465,00

DESCRIPTION	TYPE	SERIAL No.	WEIGHT LBS.	ARM INCH	MOMENT LBS./INCH
REMOVED ITEMS:			<i>REMEMBER - minus in front of weight!</i>		
• Com/Nav	KX165	55179	-5,70	X 14,40	-82,08
• GPS	KLN90B	20518	-6,30	X 14,40	-90,72
Transponder	KT76A	133066	-3,10	X 14,40	-44,64
• GPS Ann.	810435-501	0006	-1,10	X 16,50	-18,15
• GPS Ant.	KA92	01727	-0,60	X 117,96	-70,78
TXP. Ant.	CI105	N/A	-0,40	X 41,50	-16,60
Encoder	AT3000	0018195	-0,50	X 4,00	-2,00
				X	
				X	
				X	
				X	
				X	
INSTALLED ITEMS:					
• Com/Nav/GPS	GTN750	1ZA010052	7,80	X 14,40	112,32
Transponder	GTX33	89121556	3,60	X 128,00	460,80
• GPS Ant.	GA35	80693	0,60	X 117,96	70,78
TXP. Ant.	CI105-16	25947	0,40	X 170,00	68,00
Encoder	SSD120	13035	0,30	X 18,00	5,40
				X	
				X	
				X	
				X	
				X	
				X	
				X	

NEW AIRCRAFT EMPTY 2312,00 X 43,62 100857,33

NEW AIRCRAFT EMPTY WEIGHT 2312,00 LBS.

NEW AIRCRAFT CENTER OF GRAVITY 43,62 INCH

PS. ARM. Has only to decimals.

Support Staff signature & stamp.:

P. Koff 

Date: 10/4-12

(CENTER BELOW ALL WEIGHT CHANGE DATA FROM AIRCRAFT LOG BOOK)

FAA REG. NO.

[illegible]

OWNERS WEIGHT & BALANCE RECORD

SECTION VI WEIGHT AND BALANCE

PILOT'S LOADING GUIDE

LOADING CALCULATION PROCEDURE

Proper loading of the aircraft is essential for maximum flight performance and safety. This section will assist you in determining whether the aircraft loading schedule is within the approved weight and center-of-gravity limits.

To figure an actual loading problem for your aircraft, proceed as follows:

Step 1. Refer to the latest entry on page 6-5 for the current empty weight and moment.

[NOTE]

Since the engine oil is normally kept at the full level, the oil weight and moment is included in basic empty weight and is constant in calculating all loading problems.

Step 2: Note the pilot's weight and the position his seat will occupy in flight. Find this weight on the left scale of the Loading Computation Graph (page 6-6) and cross the graph horizontally to the graph for #1 and #2 seats. When this point is located, drop down to the bottom scale to find the value of the moment/1000 due to the pilot's weight and seat position.

Repeat procedure for co-pilot and enter these weights and moment/1000 values in the proper sub-columns in the Problem Form on page 6-7.

Step 3: Proceed as in Step 2 to account for the passengers in seats 3 and 4. Enter the weight and value of moment/1000 in the proper columns.

Step 4: Again proceed as in Step 2 to account for the amount of fuel carried, and enter the weight and moment/1000 values in the proper columns.

Step 5: Once more proceed as in Step 2 to account for the baggage to be carried and enter the figures in the proper columns.

Step 6: Total the weight columns. This total must be 3368 Pounds(1528 Kg) or less. Total the Moment/1000 column.

DO NOT FORGET TO SUBTRACT NEGATIVE NUMBERS.


Step 7: Refer to the Center-of-Gravity Moment Envelope (page 6-8). Locate the loaded weight of your airplane on the left scale of the graph and trace a line horizontally to the right. Locate the total moment/1000 value for your airplane on the bottom scale of the graph and trace a line vertically above this point until the horizontal line for weight is intersected. If the point of intersection is within the shaded area, your aircraft loading is acceptable. If the point of intersection falls outside the shaded area, you must rearrange the load before takeoff.

PROBLEM FORM							
STEP	ITEM	SAMPLE PROBLEM			YOUR PROBLEM		
		WEIGHT (Kg) Lbs	MOMENT (Kg-cm) /1000 lb-in /1000		WEIGHT (Kg) Lbs	MOMENT (Kg-cm) /1000 lb-in /1000	
1.	A/C Basic Empty Wt.(W) (from page 6-5) (Includes Full Oil) 8 Ols.(7.57 Li) @1.875lbs /Ol.(.80 Kg/Li)(Sta. -20.19)(-51.3 cm) (Oil sump assumed FULL for all flights)	(1009) 2225	(114.6) 99.46				
2.	Pilot Seat (#1) *	(77.1) 170	(7.64)(olt pos)6.63				
	Co-Pilot Seat (#2) *	(77.1) 170	(7.25)(2nd pos)6.29				
3.	Left Rear Seat (#3) or Cargo Area	(77.1) 170	(14.3) 12.41				
	Right Rear Seat (#4) or Cargo Area	(77.1) 170	(14.3) 12.41				
4.	Fuel (Max. Usable - 89.0 Gal/534 Lbs) (337 Li/242Kg) @ Sta 49.23(125 cm)	(164.7) 363	(20.59) 17.87				
5.	Baggage (Max. 120 Lbs(54.4 cm)@Sta.101.5 (257.8 cm)	(45.4) 100	(11.70) 10.15				
	Hat Rack (Max. 10 Lbs(4.54 Kg)@Sta. 126.0 (320 cm)						
6.	Loaded A/C Weight(Takeoff at Max. Weight) A/C will have to burn off 168 lbs. fuel before normal landing is accomplished.	(1528) 3368	(190.2) 165.0				
7.	Required Fuel Burn-Off 28 Gals (105.9 Li) @ 6 Lbs./Gal.	(76.2) 168	(-9.53) -8.27				
8.	MAXIMUM LANDING WEIGHT of A/C	(1452) 3200	(180.5) 156.7				
9.	Refer to Center of Gravity Moment Envelope, to determine whether your A/C loading is acceptable. CAUTION-DO NOT LAND A/C WHEN OVER 3200 LBS EXCEPT IN AN EMERGENCY SITUATION.						
* Obtain the moment/1000 value for each seat position (FWD, MID or AFT) from loading computation graph.							

R-PREFRM


CAUTION

Pilot is responsible for cargo loaded in rear seat area, with seat backs folded down. Cargo Center of Gravity location varies with total weight loaded.
Compute CG value when cargo is loaded.



SECTION VI
WEIGHT AND BALANCE


MOONEY
M20R



MOONEY
M20R

SECTION VI
WEIGHT AND BALANCE

M20R - CENTER OF GRAVITY LIMITS ENVELOPE



**SECTION VI
WEIGHT AND BALANCE**

**MOONEY
M20R**

FIXED BALLAST

The M20R has provisions for a fixed ballast located in the tailcone at Fuselage Station 209.5. Some aircraft with EFIS, TKS & other systems, may require all or a portion of the fixed ballast to be removed in order to stay within the weight and balance center of gravity envelope.

EQUIPMENT LIST

The following equipment list is a listing of items approved at the time of publication of this manual for the Mooney M20R.

Only those items having an X in the "Mark If Installed" column and dated were installed at Mooney Aircraft Corporation at the time of manufacture.

If additional equipment is to be installed it must be done in accordance with the reference drawing or a separate FAA approval.

| NOTE |

Positive arms are distances aft of the airplane datum. Negative arms are distances forward of the airplane datum.

Asterisks (*) after the item weight and arm indicate complete assembly installations. Some major components of the assembly are listed and indented on the lines following. The summation of the major components will not necessarily equal the complete assembly installation.

6-11

MOONEY
M20R

M-EQ-A

MO.	5
DAY	9
YEAR	95

SECTION VI WEIGHT AND BALANCE

6-12

REV. F 9-96

ISSUED 6-94

EQUIPMENT LIST						MO.		
R-EQ-B1						DAY		
						YEAR	95	
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF	
			(Kg)	Lbs.	(Cm)	In.	INSTLD	
	B. POWERPLANT & ACCESSORIES							
1B	ENGINE-TCM 10550-G (*) INCLUDES: STARTER, ALT'NR, VAC. PUMP, EXH., INDUCT. SYST., ALT. AIR, ENG. MT., FULL OIL, PROP.GOV.	600270	(249.3)	549.5	(159.16)	-23.29	X	
2B	PROPELLER - CONSTANT SPEED; McCAULEY - HUB- 3A32C418 BLADES (*) -82NRC-9 W/ SPINNER	680030	(34.7)	76.6	(-125.7)	-49.5	X	
3B								
	* Refer to Section I & II for engine/propeller configuration.							

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

6-13

MOONEY
M20R

M-EQ-B2

MO.	5
DAY	9
YEAR	95

[illegible]

SECTION VI WEIGHT AND BALANCE

6-14

EQUIPMENT LIST						MO.	5		
						DAY	9		
						YEAR	95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF INSTALLED		
			(Kg)	(POUNDS)	(cm)	(INCHES)			
	C. ELECTRICAL SYSTEM								
1C	BATTERIES 24 VOLTS (2)	800311	(13.4)	29.55	(370.8)	146.0	X		
2C	REGULATOR, VOLTAGE (2)	800311	(.27)	.6 EA	(41.28)	16.25	X		
3C	PITOT, HEATED	820252	(.52)	1.15	(106.3)	41.85	X		
4C	CIGAR LIGHTER	800311	(.08)	.17	(49.53)	19.5	X		
5C	FUEL PUMP, ELECTRIC	610293	(.86)	1.9	(38.1)	15.0	X		
6C	STALL WARNING INDICATOR	800311	(.45)	1.0	(127.0)	50.0	X		
7C	GEAR WARNING INDICATOR	800311	(.45)	1.0	(49.53)	19.5	X		
8C	WING TIP STROBE LIGHT INSTL.	800311	(2.27)	5.0	(134.62)	53.0	X		
9C	TAIL STROBE LIGHT INSTL.	800311	(.68)	1.5	(578.7)	227.82	X		
10C	LANDING/TAXI LIGHTS (2 SETS)	210417	(2.7)	5.88	(105.6)	41.6	X		
11C	ACTUATOR, FLAPS	750110	(2.3)	5.1	(277.1)	109.1	X		
12C	ACTUATOR, LANDING GEAR	560260	(5.08)	11.2	(99.06)	39.0	X		

M-EQ-C1

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 6-94

ISSUED 8-94

REV. G

8-15

EQUIPMENT LIST

M-EQ-C2

MO. 5
DAY 9
YEAR 95MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF		
			(Kg)	(POUNDS)	(cm)	(INCHES)	INSTALLED		
	C. ELECTRICAL SYSTEM (CON'T)								
13C	E.L.T. (D & M) ELT-8	810152	(1.63)	3.59	(337.8)	133.0			
14C									
15C	E.L.T. (ARTEX) ELT110-4	810150	(2.26)	4.98	(436.8)	172.0	X		
16C	E.L.T. (ARTEX) ELS-10	810150	(2.95)	6.5	(407.7)	160.5			
17C	E.L.T. (AMERI-KING)	810436	(1.41)	3.1	(429.0)	168.9			
18C									
19C									
20C									
21C									

EQUIPMENT LIST						MO.		
M-EQ-D1						DAY		
						YEAR	95	
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF	
			(Kg)	(POUNDS)	(cm)	(INCHES)	INSTALLED	
	D. WHEELS, TIRES & BRAKES							
1D	MAIN WHEEL & BRAKE ASSYS (2)	520029	(6.22)*	13.72*	(163.57)	64.4	X	
	WHEEL ASSEMBLY (2)	520029	(4.99)	11.0	(162.51)	63.98	X	
	BRAKE ASSEMBLY (2)	520029	(.816)	1.8	(153.74)	60.53	X	
2D	TIRES, MAIN (2) (6 PLY RATING) 6.00 X 6 TYPE III W/ TUBES	520029	(7.71)	17.0	(162.51)	63.98	X	
3D	NOSE WHEEL ASSEMBLY (1)	540000	(1.18)	2.6	(-33.8)	-13.3	X	
4D	TIRE, NOSE (1) (6 PLY RATING) 5.00 X 5 TYPE III W/ TUBE	540000	(3.18)	7.0	(-33.8)	-13.3	X	
5D	MASTER CYLINDER, BRAKE (2)	850109	(1.36)	3.0	(21.08)	8.3	X	
6D	VALVE, PARKING BRAKE	850109	(.27)	.5	(-3.68)	-1.45	X	
7D	DUAL PUCK BRAKE ASSEMBLY (2)	520029	(1.35)	2.98	(168.48)	66.53	X	
8D								
9D								

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

[illegible]

SECTION VI WEIGHT AND BALANCE

B-17

EQUIPMENT LIST							MO.		
							DAY		
							YEAR		
M-EQ-E1							5		
							9		
							95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF		
			(Kg)	(POUNDS)	(cm)	(INCHES)	INSTALLED		
	E. INSTRUMENTS								
1E	GYRO HORIZON	820336	(1.33)	2.93	(44.3)	17.46			
2E	DIRECTIONAL GYRO		(1.33)	2.93	(42.7)	16.8			
3E	CLOCK, PANEL MOUNTED		(.11)	.25	(49.78)	19.6	X		
4E	DAT GAUGE		(.25)	.55	(46.99)	18.5	X		
5E	INDICATOR, VERTICAL SPEED		(.23)	.5	(44.9)	17.67	X		
6E	INDICATOR, TURN & SLIP/TURN COORD		(.83)	1.84	(41.91)	16.5	X		
7E	ALTIMETER (2)		(.49)	1.07	(36.0)	14.17	X		
8E	INDICATOR, AIRSPEED		(.32)	.70	(47.75)	18.8	X		
9E	TACHOMETER		(.36)	.8	(48.13)	18.95	X		
10E	FUEL FLOW		(.63)	1.39	(46.99)	18.48	X		
11E									
12E	ENGINE GAUGES (DUAL CLUSTERS)	820336	(1.6)	3.5	(46.99)	18.5	X		

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 8-84

EQUIPMENT LIST							MO.		
							DAY		
							YEAR		
M-EQ-E2							5		
							9		
							95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF		
			(KG)	(POUNDS)	(CM)	(INCHES)	INSTALLED		
	E. INSTRUMENTS (CON'T)								
13E	ANNUNCIATOR PANEL	820336	(.58)	1.3	(44.45)	17.5	X		
14E	MAGNETIC COMPASS	130323	(.23)	.5	(60.6)	23.87	X		
15E	MANIFOLD PRESSURE	820336	(.45)	1.0	(46.94)	18.48	X		
16E	ALTERNATE STATIC AIR SOURCE	820336	(.14)	.31	(44.69)	18.5	X		
17E									
18E									
19E									
20E									

6-18

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

6-20

REV. G

ISSUED 6-94

EQUIPMENT LIST							MO.		
							DAY		
							YEAR		
MR-EQ-F1							5		
							9		
							95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED				
	F. MISCELLANEOUS SYSTEMS								
1F	VACUUM SYSTEM INSTALLATION	860015	(2.58) 5.68	(-2.54) -1.0	X				
2F	VACUUM PUMP	860015	(1.54) 3.4	(-7.6) -3.0	X				
3F	STAND-BY VACUUM PUMP (CLUTCH)	860015	(2.45) 5.41	(-6.4) -2.5	X				
4F	STAND-BY VACUUM PUMP (TAIL CONE)	860063	(5.44) 12.0	(280.42) 110.4					
5F	OXYGEN SYSTEM (115.7 cu. ft.)	870029	(20.2) 44.55	(347.9) 137.0					
6F	DESCENT RATE CONTROL (VACUUM)	950155	(5.59) 12.32	(177.8) 70.0					
7F	DESCENT RATE CONTROL (ELECTRIC)	950271	(5.8) 12.8	(177.8) 70.0	X				
8F	PROPELLER DE-ICE (ELECTRIC)	690003	(2.69) 5.93	(-115.6) -45.5	X				
9F									
10F									
11F									

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 6-94

REV. 9

6-21

EQUIPMENT LIST							MO.		
							DAY		
							YEAR		
M-EQ-G1							5		
							9		
							95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED				
	G. CABIN ACCOMMODATIONS								
1G	SUN VISORS (2)	130303	(.32) 1.0	(83.8) 33.0	X				
2G	RESTRAINT ASSY, REAR (2)	140318	(2.27) 5.0	(194.3) 76.48	X				
3G	RESTRAINT ASSY, FWD (2)	140318	(2.27) 5.0	(106.7) 42.0	X				
4G	SEAT BELT ASSY - REAR (2)	140262	(1.36) 3.0	(180.3) 71.0	X				
5G									
6G									
7G									
8G									
9G									
10G									
11G									

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

6-22

REV. G

ISSUED 8-94

EQUIPMENT LIST

MR-EQ-H1

MO. 5
DAY 9
YEAR 95

ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF INSTALLED		
			(KG)	(POUNDS)	(CM)	(INCHES)			
	H. AVIONICS & AUTOPILOTS								
1H	NAT AA80 INTERVOX	810150	(.32)	.7	(43.2)	17.0	X		
2H	KING KLN90A GPS	810427	(3.13)	6.9	(59.44)	23.4			
3H	KING KCS-55A	810150	(5.14)	11.34	(168.81)	66.46	X		
4H	KING KMA-24	810150	(.77)	1.7	(48.26)	19.0	X		
5H	TERRA ENCODER	810150	(.23)	.50	(30.48)	12.0	X		
6H	KING KLN-90B GPS	810434	(3.13)	6.9	(59.44)	23.4	X		
7H	DAVID CLARK ISDCOM	810150	(.32)	.70	(43.18)	17.0			
8H	KING KX 155	810150	(2.3)	5.1	(36.65)	14.43	X		
9H	KING KX 165	810150	(2.6)	5.7	(36.53)	14.38	X		
10H	KING KI 203	810150	(.73)	1.6	(38.1)	15.0	X		
11H	KING KR 87 w/KI 229	810150	(3.61)	8.0	(112.4)	44.25			
12H	KING KR 87	810150	(2.41)	5.2	(148.3)	58.4			

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 8-84

REV. F 9-88

6-23

EQUIPMENT LIST						MO.	DAY	YEAR			
MR-EQ-H2						5	9	95			
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF INSTALLED				
			(KG)	(POUNDS)	(CM)	(INCHES)					
	H. AVIONICS & AUTOPILOTS										
13H	KING KN 62A	810150	(1.20)	2.6	(38.1)	15.0	X				
14H	KING KT 76A	810150	(1.4)	3.1	(37.1)	14.6	X				
15H	KING KFC 150	810150	(13.4)	29.5	(204.0)	80.3	X				
16H	KING KR87 w/KI227	810150	(2.67)	5.9	(136.1)	53.6					
17H	KING KLN89B	810434	(1.43)	3.15	(86.7)	34.13					
18H	INSIGHT STRIKEFINDER	810430	(2.0)	4.35	(220.0)	86.6					
19H	INSIGHT GEM MODEL 602	950248	(1.20)	2.6	(-7.6)	-3.0					
20H	GARMIN 155 GPS	810433	(1.0)	2.2	(36.5)	14.38					
21H	DRE SYMPHONY INTERCOM	810202	(.55)	1.22	(81.28)	32.0					
22H	INTERCOM (QUITE FLITE)	810150	(.23)	.5	(48.3)	19.0					
23H											
24H											

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

EQUIPMENT LIST					MO.		
					DAY		
					YEAR		
M-EQ-H3					5		
					9		
					95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED		
	H. AVIONICS & AUTOPILOTS (CON'T)						
25H	KT71-00 TRANSPONDER	810150	(1.8) 3.9	(39.6) 15.6			
26H	KI229 RMI	810150	(1.3) 2.8	(45.7) 18.0			
27H	AA80 INTER-VOX	810202	(.32) .7	(43.2) 17.0	X		
28H	AA83 INTER-VOX (MUSIC)	810202	(.32) .7	(43.2) 17.0			
29H	WX10/10A	810413	(5.6) 12.3	(245.1) 96.5			
30H	WX1000/1000+ SERIES III	810197	(5.0) 10.9	(283.3) 111.5			
31H	KAP 150 PA (KFC-150)	830081	(13.2) 29.1	(206.5) 82.6			
32H	KAS297B ALT. PRESELECT	830081	(1.4) 3.1	(29.7) 11.7			
33H	EHIS 40	810247	(15.8) 34.9	(226.1) 81.3			
34H	KRA 10 RADAR ALT.	810150	(1.7) 3.8	(149.4) 58.8			
35H	FUEL FLOW (SHADIN)	820336	(.63) 1.4	(46.9) 18.5			
36H	GPS 155 (GARMIN)	810433	(1.5) 3.3	(58.4) 23.0			

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 6-94

REV. G

6-25

EQUIPMENT LIST					MO.	5		
					DAY	9		
MR-EQ-H4					YEAR	95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED			
	H. AVIONICS & AUTOPILOT'S (CON'T)							
37H	KING KX155A-w/GLIDE SLOPE	810150	(1.81) 4.0	(36.9) 14.54				
38H	KING KX155A-	810150	(1.59) 3.5	(36.9) 14.54				
39H	KING KI 204	810150	(.77) 1.7	(38.1) 15.0				
40H	KING KT 76C	810150	(1.09) 2.4	(38.1) 15.0				
41H	BOSE HEADSET (w/INTERFACE)	810150		*			X	
42H	PMA 7000MS	810150	(1.0) 2.2	(73.7) 29.0				
43H								
44H								
45H								
46H								
47H								
	* LOCATION WILL VARY							

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

6-28

REV. G

ISSUED 6-94

EQUIPMENT LIST							MO.		
							DAY		
							YEAR		
M-EQ-11							5		
							9		
							95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT		ARM		MARK IF		
			(Kg)	(POUNDS)	(cm)	(INCHES)	INSTALLED		
	I. AUXILIARY EQUIPMENT (FLY AWAY)								
1I	TOW BAR, FOLDING (STOWED)	010036	(1.03)	2.6	(273.1)	107.5	X		
2I	JACK POINTS (2) (STOWED)		(.07)	.1	(332.7)	131.0	X		
3I	EYE BOLT, WING TIE DOWN (2) (STOWED)		(.09)	.1	(332.7)	131.0	X		
4I	FUEL SAMPLER CLP (STOWED)		(.04)	.05	(332.7)	131.0	X		
5I	BAGGAGE TIE DOWNS (2) (STOWED)		(.04)	.16	(332.7)	131.0	X		
6I	CARGO RESTRAINT BELTS (2) (STOWED)		(.27)	1.0	(332.7)	131.0	X		
7I	PITOT COVER (STOWED)		(.03)	.3	(332.7)	131.0	X		
8I	POH/AFM No. - MOONEY		(.84)	1.5	(332.7)	131.0	X		
9I	ENGINE OPERATOR'S MANUAL-LYCOMING		(.35)	.5	(332.7)	131.0	X		
10I	ENGINE LOG BOOK		(.07)	.2	(332.7)	131.0	X		
11I	AIRFRAME LOG BOOK	010036	(.063)	.2	(332.7)	131.0	X		
12I									

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 8-94

REV. G

6-27

EQUIPMENT LIST

M-EQ-J1

MO.
DAY
YEAR

5

9

95

ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)		ARM (cm) (INCHES)		MARK IF INSTALLED		
	J. OPTIONAL EQUIPMENT								
1J	ARM REST INSTL, PILOT'S SEAT	140295	(.95)	2.1	(87.6)	34.5	X		
2J	LUMBAR SUPPORT INSTL (2)	140300	(.99)	2.18	(88.9)	35.0			
3J	ACCESS PANEL, FUEL GAUGE (2)	210099	NEGLIGIBLE DIFFERENCE				X		
4J	RECOGNITION LIGHT INSTL (2)	210413	(.60)	1.32	(134.6)	53.0	X		
5J	RUDDER PEDAL EXTENSION INSTL ¹ or ₂	720115	(.059)	.13	(38.1)	15.0			
6J	AUX. POWER RECPT. INSTL	800166	(1.48)	3.27	(332.7)	131.0	X		
7J	AUX. POWER CABLE ADAPTER	880042	(3.43)	7.57					
8J	DUAL BRAKE INSTL	950112	(1.38)	3.05	(38.1)	15.0			
9J	STATIC DISCHARGE INSTL	950253	NEGLIGIBLE DIFFERENCE				X		
10J	STEP ASSY & INSTL	950256	(1.25)	2.75	(274.3)	108.0	X		
11J	FIRE EXTINGUISHER INSTL	130328	(1.20)	2.65	(153.7)	60.5	X		
12J									

NORMALLY STOWED IN BAGGAGE COMPARTMENT BETWEEN STA. 110 & 130.

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

6-28

REV. G

ISSUED 8-94

EQUIPMENT LIST						MO.	5		
						DAY	9		
M-EQ-J2						YEAR	95		
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED				
	J. OPTIONAL EQUIPMENT (CON'T)								
13J	ANTI-COLLISION BEACON, FLASHING (RED)	950272	(.48) 1.06	(457.2) 180.0					
14J	ANTI-COLLISION BEACON, ROTATING (RED)	950252	(.68) 1.5	(457.2) 180.0					
15J	TANIS HEATER	950209	(.78) 1.71	(-62.87) -24.75					
16J	HEADREST INSTL., REAR	140313/140323	(1.57) 3.47	(203.20) 80.0	X				
17J	HEADREST INSTL., FRONT	140313/140323	(1.57) 3.47	(114.3) 45.0	X				
18J	SKYMAP	810218	(8.71) 19.2	(159.25) 62.7					
19J	DEFROSTER BLOWER	640314	(.39) .87	(24.1) 9.5	X				
20J	3 PASSENGER, REAR, BENCH SEAT	140305	NO CHANGE	NO CHANGE					
21J	TKS AIRFRAME/WINGS	690007	(16.8) 36.5	(202.3) 79.6	(NO FLUID)				
22J	TKS PROPELLER (KNOWN ICING)	690007	(18.1) 39.8	(203.5) 80.1	(NO FLUID)				
23J	TKS - FLUID (6 GAL.)	690007	(25.0) 55.2	(179.6) 70.7					
24J	WX-950 STORMSCOPE	810437	(2.7) 5.9	(175.4) 69.1					

SECTION VI
WEIGHT AND BALANCEMOONEY
M20R

ISSUED 6-94

REV. G

6-28

EQUIPMENT LIST					MO. DAY YEAR			
ITEM NO.	ITEM DESCRIPTION	REF. DRAWING	WEIGHT (Kg) (POUNDS)	ARM (cm) (INCHES)	MARK IF INSTALLED			
MR-EQ-J3								
	J. OPTIONAL EQUIPMENT (CON'T)							
25J								
26J								
27J								
28J								
29J								
30J								
31J								
32J								
33J								
34J								

MOONEY
M20RSECTION VI
WEIGHT AND BALANCE

MO.
DAY
YEAR

M-EQ-J3

[illegible]

SECTION VI WEIGHT AND BALANCE

MOONEY
M20R

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	7-3
AIRFRAME	7-3
FLIGHT CONTROLS DESCRIPTION	7-3
AILERON SYSTEM	7-3
ELEVATOR SYSTEM	7-3
RUDDER SYSTEM	7-4
STABILIZER TRIM SYSTEM	7-4
RUDDER TRIM SYSTEM	7-4
WING FLAPS.	7-4
INSTRUMENT PANEL	7-4
FLIGHT PANEL & INSTRUMENTS.	7-4
SWITCHES & CONTROLS.	7-8
ANNUNCIATOR & SWITCH PANEL	7-13
GROUND CONTROL	7-15
NOSE GEAR STEERING	7-15
TAXIING AND GROUND HANDLING	7-15
LANDING GEAR	7-15
CONSTRUCTION	7-15
RETRACTION SYSTEM	7-15
WHEEL BRAKES	7-16
EMERGENCY EXTENSION SYSTEM.	7-16
WARNING SYSTEM	7-16
STEERING	7-16
CABIN	7-16
BAGGAGE COMPARTMENT	7-16
CARGO RESTRAINT	7-17
SEATS	7-17
SEAT BELTS/SAFETY HARNESS.	7-17
DOORS, WINDOWS & EXITS.	7-18
CABIN DOOR	7-18
PILOT'S WINDOW	7-18
EMERGENCY EXITS	7-18
ENGINE.	7-18
GENERAL	7-18
ENGINE CONTROLS	7-19
ENGINE INSTRUMENTS	7-19
ENGINE OPERATION AND CARE.	7-19
OIL SYSTEM	7-19

TABLE OF CONTENTS (con't)

TITLE	PAGE
ENGINE (con't.)	
IGNITION SYSTEM	7-20
AIR INDUCTION SYSTEM	7-20
ICING PROTECTION	7-20
EXHAUST SYSTEM.	7-20
FUEL INJECTION	7-21
ENGINE COOLING AIR.	7-21
ENGINE STARTING SYSTEM	7-21
ACCESSORIES	7-21
PROPELLER	7-22
FUEL SYSTEM.	7-22
ELECTRICAL SYSTEM	7-23
ALTERNATOR & BATTERY	7-23
SCHEMATIC.	7-24
ANNUNCIATOR PANEL	7-25
CIRCUIT BREAKER PANEL	7-25
ELT PANEL	7-25
LIGHTING SYSTEM.	7-25
CABIN ENVIRONMENT	7-26
PITOT PRESSURE & STATIC SYSTEM.	7-26
STALL WARNING SYSTEM	7-27
OXYGEN SYSTEM.	7-27
VACUUM SYSTEM	7-28
EMERGENCY LOCATOR TRANSMITTER	7-30
E.L.T. REMOTE SWITCH OPERATION	7-30

INTRODUCTION

Acquiring a working knowledge of the aircraft's controls and equipment is one of your important first steps in developing a fully efficient operating technique. This Airplane and Systems Section describes location, function, and operation of systems' controls and equipment. It is recommended that you, the pilot, familiarize yourself with all controls and systems while sitting in the pilot's seat and rehearsing the systems operations and flight procedures portions of this manual.

AIRFRAME

The M20R is an all metal, low wing, high performance airplane. The fuselage has a welded, tubular-steel cabin frame covered with non-structural aluminum skins. Access to the cabin is provided by a door located on the right side of the fuselage. A door is provided aft of the rear seat for access to the baggage compartment. The aft fuselage, tailcone, is of semi-monocoque construction.

Seating in the cabin is provided for the pilot and three passengers.

The M20R has a tapered, full-cantilever, laminar-flow type wing. The airfoil varies from a NACA 63₂-215 at the wing root to a NACA 64₁-412 at the wing tip, modified by an inboard leading edge cuff.

An aerodynamically designed cover is attached to the wing tip and contains the wing navigation, anti-collision and optional recognition lights. Wrap-around stretched formed skins cover the wing; flush riveting is used on the forward, top and bottom two thirds of the wing chord to provide benefit of laminar flow aerodynamics.

The empennage consists of the vertical and horizontal stabilizer assembly and the rudder and elevator surfaces. The entire empennage pivots around attaching points on the aft fuselage to provide pitch attitude trim.

The tricycle landing gear allows maximum vision and ground maneuvering. Hydraulic disc brakes and a steerable nose wheel aid in directional control during taxiing and ground operations. The landing gear is electrically retracted and extended. A warning horn, a gear position indicator on the floorboard and a green "GEAR DOWN" light help prevent inadvertent gear-up landings. A manual emergency gear extension system is provided in the event of electrical failure.

FLIGHT CONTROLS DESCRIPTION

The aircraft has dual flight controls and can be flown from either the pilot or co-pilot seat. Dual pairs of foot pedals control rudder and nose wheel steering mechanisms. Push-pull tubes, rather than conventional cable/pulley systems, actuate all-metal flight control surfaces. Rod-end bearings are used throughout the flight control systems. These bearings are simple and require little maintenance other than occasional lubrication. Specially designed aluminum-alloy extrusions, that permit flush skin attachment, form the leading edges of the rudder and elevators. A spring-loaded interconnect device indirectly joins aileron and rudder control systems to assist in lateral stability during flight maneuvers. Longitudinal pitch trim is achieved through a trim control system that pivots the entire empennage around tailcone attachment points. A variable down-spring located in the tailcone and a bobweight located forward of the control column help create desirable stability characteristics.

Aileron System

The ailerons are of all-metal construction with beveled trailing edges. Three hinges of machined, extruded aluminum attach each aileron to aft wing spar outboard of wing flaps. The ailerons link to the control wheel through push-pull tubes and bellcranks. Counterweights balance the system.

Elevator System

Elevator construction is essentially the same as that of the ailerons. Both elevators attach to the horizontal stabilizer at four hinge points. Push-pull tubes and bellcranks link the elevators to the control wheel. Counterweights balance the elevators.

Rudder System

The rudder attaches to the aft, vertical fin spar at four hinge points. Push-pull tubes and bellcranks link rudder to the rudder pedals.

Stabilizer Trim System

To provide pitch trim control, the entire empennage pivots around its main hinge points. The system consists of a manually operated (electrical operation optional) actuator that operates a series of torque tubes and universal joints connected to a jack screw on the aft tailcone bulkhead. A trim control wheel, located between pilot and co-pilot seats, allows pilot to set stabilizer trim angle. Trim position is indicated by an electrical gauge (LED) located in the lower, center instrument panel. The indicator is controlled by a potentiometer. This indicates stabilizer position relative to the aircraft thrust line.

Rudder Trim System

The M20R is equipped with an electric rudder trim system which allows the pilot to trim out much of the rudder force required for takeoff, climb, cruise and descent. The system is a "bungee" type spring assembly, attached to the rudder control system and driven by an electric motor. The trim system is operated by a split, toggle switch located above the throttle on the pilot's panel. The split switch is a safety measure that greatly reduces the possibility of a runaway trim situation. The electric trim indicator (LED) is located adjacent to the toggle switch. A potentiometer controls the rudder trim position indicator. Takeoff position is within the last 3 lighted segments on the right end of the indicator. Rudder force varies from negligible (with trim to the far right) to mild (with trim set to the third segment from the right). Cruise setting will result in the trim indicator being slightly left of neutral. A high speed descent will result in an even more left of neutral position.

Wing Flaps

The wing flaps are electrically operated and interconnected through a torque tube and bellcranks. Total flap area is 17.98 square feet. Nominal travel is 0 to 33°. Limit switches prevent travel beyond these limits. Wing flap position is controlled by a pre-select switch located on the lower center console. Also located on the center console is a flap position indicator showing which pre-select position has been selected: full up, takeoff (10°) or full down positions. A potentiometer controls the flap position indicator (LED). Generally, aircraft trim requirements will change with use of the flaps. Lowering of the flaps will cause a nose down pitching condition which can be easily corrected by application of nose up trim. Conversely, retraction of the flaps, from a trimmed flight condition, will cause a nose up pitching condition. Use of flaps should always be within the operational limits established in SECTION II. The flaps are very effective in lowering landing speed and can be used to slow the aircraft to approach speeds.

INSTRUMENT PANEL

The instrument panel is designed to provide functional grouping of all flight, radio, engine instruments, switches and controls required to operate various systems. All flight instruments are grouped on the shock-mounted panel directly in front of the pilot. Power plant instruments are grouped into two clusters and located to the right of the flight instruments. The radio panel is in two sections, slightly left and forward of co-pilot's seat. The annunciator panel and optional radio console are on the left section of the radio panels. The circuit breaker panel is located on the far right, in front of the co-pilot's seat.

FLIGHT PANEL & INSTRUMENTS

Flight instruments operate: (1) by barometric pressure or barometric-impact air pressure differences, (2) by variations in electric current due to mechanically varied resistance, (3) by air drawn into an evacuated case or (4) by reference to the earth's magnetic field.




FIGURE 7 - 1 FLIGHT PANEL (29-0001 THRU 29-0169)

1. CLOCK - (S/N 29-0001 thru 29-0169) (Refer to Figure 7-1)

The electric, digital, panel mounted clock, may be used and set by the following procedures:
Three buttons are located below digital face of clock and identified as START/STOP, CLEAR & MODE.

Normal or Elapsed time.

MODE - Push to switch from normal time to elapsed time.

START/STOP - Push to start or stop seconds when in elapsed time mode.

CLEAR - Push to reset elapsed time to Zero.

Set Hours, Minutes or 24 vs 12 hour time.

- Push and Hold CLEAR button for 4 - 5 seconds to enter clock set mode; 12 H or 24 H will flash.
- Push START/STOP button to select either 12 or 24 hour mode.
- Push CLEAR to select hours (hours flashing/minutes steady) or minutes (hour steady/minutes flashing) for setting.
- Push START/STOP to increase either hours or minutes until desired time is set.
- Push MODE to return to normal time.

1. CLOCK (S/N 29-0170 thru 29-0199) (Refer to Figure 7-1A)

The electric, digital, panel mounted DAVTRON Model 800 clock, may be used and set by the following procedures:

The SEL button selects what is to be displayed on the four digit window and the CTL button controls what is being displayed. Pressing select sequentially selects GMT, Local Time, Elapsed Time and back to GMT. The control button starts and resets Elapsed Time when momentarily pushed. Normal operation of the M800 cannot accidentally reset time.

SETTING GMT

Select GMT for display in the four digit window with the SEL button. Simultaneously press both the select and control buttons to enter the set mode. The tens of hours digit will start flashing. The control button has full control of the flashing digit and each button push increments the digit. Once the tens of hours is set, the select button selects the next digit to be set. After the last digit has been selected and set with the control button, a final push of the select button exits the mode. The lighted annunciator will resume its normal flashing, indicating the GMT clock is running.




FIGURE 7 - 1A FLIGHT PANEL (29-0170 thru 29-0182, 29-0184 thru 29-0199)

SETTING LOCAL TIME

Select Local Time, (LT) using the SEL button. Simultaneously push the SEL and CTL buttons to enter set mode. The tens of hours digit will start flashing. The set operation is the same as GMT, except that minutes are already synchronized with the GMT clock and cannot be set in Local Time.

TEST MODE

Hold SEL button down for three seconds and the display will indicate 88:88 and activate all four annunciators.

ELAPSED TIME COUNT "UP"

Select ET for display. Press CTL button, ET count will start. Elapsed Time counts up to 59 minute, 59 seconds, and then switches to hours and minutes. It continues counting up to 99 hours and 59 minutes. Press CTL button again to reset to zero.

ELAPSED TIME COUNT "DOWN"

Select ET display and enter set mode by pressing both buttons. The countdown time can now be set. Entering the time is identical to GMT time setting. When the time is entered and the last digit is no longer flashing, the clock is ready to start the countdown. Momentarily pressing the CTL button starts the countdown. When the count reaches zero, the displays flash and the external alarm is activated. Pressing either SEL or CTL will deactivate the alarm. ET continues counting UP.

2. AIRSPEED INDICATOR

The airspeed indicator registers airspeed in knots. The air pressure difference between the pitot tube and static ports on each side of the tailcone operates the airspeed indicator.

3. ARTIFICIAL HORIZON

Varies with installed equipment.

4. ALTIMETER

The altimeter operates by absolute pressure and converts barometric pressure to altitude reading in feet above mean sea level. The altimeter has a fixed dial with three pointers to indicate hundreds, thousands and tens-of-thousands of feet. Barometric pressure is sensed

through the static ports. A knob adjusts a movable dial, a small window on the face of the main dial, to indicate local barometric pressure and to correct the altimeter reading for prevailing conditions.

5. TURN COORDINATOR

The turn coordinator operates from an electric power source. The turn coordinator is independent of the flight reference gyros. The turn coordinator displays variation in roll and yaw to the pilot by means of a damped miniature aircraft silhouette display - this provides the pilot with essential information to execute a "proper turn".

6. GYROSCOPIC HEADING INDICATOR (DG)

The vacuum operated directional gyro displays airplane heading on a compass card in relation to a fixed simulated airplane image and index. The directional indicator may precess slightly over a period of time. Therefore, the compass card should be set in accordance with the magnetic compass just prior to takeoff and occasionally checked and readjusted on extended flights. A knob on the lower left edge of the instrument is used to adjust the compass card to correct for any precession. A slaved flux gate compass is optional; if installed and ON will keep the DG corrected during the flight. Optional equipment may be installed as desired.

7. VERTICAL SPEED INDICATOR

The vertical speed indicator converts barometric pressure changes in the static lines to aircraft ascent or descent rate readings in feet per minute. This indicator has a single needle and two adjoining scales that read from 0 to 2000 feet per minute.

8. AUTOMATIC DIRECTION FINDER (INDICATOR) (ADF)

9. NAVIGATION INSTRUMENT NO. 2.

10. (OPTIONAL) Stormscope, Second Altimeter, etc.

11. MANIFOLD PRESSURE

The manifold pressure gauge is of the direct reading type. The gauge is calibrated in inches of mercury (Hg) and indicates the pressure in the induction air manifold.

12. TACHOMETER

The tachometer is an electronic meter which counts ignition pulses. The instrument is calibrated in engine revolutions per minute (RPM).

13. FUEL FLOW

Fuel flow gauge - an electric instrument operating from information provided by a fuel flow transducer. The gauge indicates fuel flow being used by the engine. The FT-101A system will depict the quantity of fuel used when the "USED" button is pushed.

14. AMMETER

Ammeter indicates battery charge or discharge. A PUSH for VOLTS button is available to show buss voltage if desired. Voltage is read on a separate scale using the same needle.

15 & 16. FUEL QUANTITY INDICATORS

Fuel quantity indicators are used in conjunction with float-operated variable-resistance transmitters in each fuel tank. Tank-full position of transmitter floats produces maximum resistance through the transmitters, permitting minimum current flow through fuel quantity indicator and maximum pointer deflection. Instruments are calibrated in portions of tank volume.

17. VACUUM INDICATOR Indicates operating vacuum pump pressure. Location varies on panel.

18. OIL PRESSURE

Electrical instrument - uses a transducer as a reference. Calibrated in pounds per square inch (PSI).

19. OAT (Outside Air Temperature)

Outside air temperature gauge provides pilot with free stream outside air temperature in ° C. Location may vary on panel.

20. EXHAUST GAS TEMPERATURE (EGT)

A thermocouple probe, located at junction of #1, 3 & 5 exhaust pipes, transmits temperature variations to the indicator which serves as a visual aid during leaning. EGT varies with fuel-air ratio, power and RPM. Engine operation within BLUE ARC, during climbs, provides sufficient fuel to keep engine power within proper temperature range. Location varies on panel.

21. OIL TEMPERATURE

Oil temperature gauge - an electric instrument connected to an electrical resistance bulb on engine. Temperature changes of engine oil changes electrical resistance, thereby allowing more or less current to flow through indicating gauge. Instrument is calibrated in °F.

22. CYLINDER HEAD TEMPERATURE

Cylinder head temperature indication is controlled by an electrical resistance type temperature probe installed in cylinder number 2. The indicator receives power from aircraft electrical system. Instrument is calibrated in °F.

A 6 position switch, with probes installed in all cylinders, is optional.

23. ANNUNCIATOR PANEL

See description elsewhere in this SECTION.

24. MAGNETIC COMPASS

Magnetic compass dial is graduated in five-degree increments and is encased in liquid-filled glass and metal case. It is equipped with compensating magnets, adjustable from front of case. Access to compass light and compensating magnets is provided by pivoted covers. No maintenance is required on magnetic compass except an occasional check on a compass rose, adjustment of the compensation screws (if necessary) and replacement of the lamp.

25. HOUR METER

Hour meter - located on baggage compartment bulkhead and indicates elapsed time while engine is running. Location may vary depending on installed systems.

26. RADIO INSTRUMENTS

Refer to SECTION IX for the description of the radio/navigation configuration installed in this aircraft.

27. ALTITUDE PRE-SELECT - OPTIONAL

28. MASTER WARNING LIGHT - When any RED warning light on the panel shows that a system or component is malfunctioning, this MASTER WARN light illuminates in approximately 15-20 seconds after any annunciator light begins to show a malfunction. Pilot should identify the source system warning light on the annunciator, then PUSH the MASTER WARN light (it contains a PUSH switch under the light). MASTER WARN light will extinguish for approximately 2 minutes or until the next system malfunction warning light on the annunciator illuminates. Repair inoperable system prior to next flight.

SWITCHES & CONTROLS

1. MAGNETO/STARTER SWITCH

Magneto/Starter switch combines both ignition and starting functions. Turning ignition key clockwise through R, L, and BOTH to START position and then pushing forward on key and receptacle, engages starter. Releasing key when engine starts allows switch to return, by spring action, to BOTH position.

2. RADIO MASTER SWITCH

Switch operates a relay supplying power to the avionics buss. Since relay is energized to turn avionics buss OFF, failure of relay coil will still allow electrical power to avionics buss. Energizing starter automatically energizes relay and disconnects all avionics from buss. Electric trim switch, on control wheel, is tied to avionics buss and will not operate unless RADIO MASTER and TRIM switch on pilot's panel are - ON.

3. ALTERNATOR FIELD SWITCH

This switch cuts alternator field power from main buss to alternator.

4. MASTER SWITCH

Master switch operates battery relay which controls battery power (selected battery) to main buss. This switch cuts ALL ship power OFF, except cabin overhead lights, baggage compartment light and electric clock.

5. OPTIONAL - Rotating/Flashing Beacon, etc.

6. STROBE LIGHT (STROBE LITE) SWITCH/CIRCUIT BREAKER

Strobe light combination switch/circuit breaker turns wing tip and tail strobe lights ON. Should short occur, the combination switch/circuit breaker will automatically trip to the OFF position.

7. NAVIGATION LIGHT (NAV LITE) SWITCH/CIRCUIT BREAKER

Navigation light combination switch/circuit breaker turns wing tip and tail navigation lights ON. Should a short occur, the combination switch/circuit breaker will automatically trip to the OFF position.




FIGURE 7 - 2 SWITCHES/CONTROLS (S/N 29-0001 thru 29-0169)

position. The glareshield and panel lights are also turned on when this switch is ON. Control dimming of either glareshield or panel lights with rotating switches on lower console.

8. RECOGNITION LIGHT (RECOG LITE) (If installed)

Recognition light combination switch/circuit breaker turns recognition light ON. Should a short occur, combination switch/circuit breaker will automatically trip to OFF position.

9. TAXI LIGHT (TAXI LITE) SWITCHES (L & R)

10. LANDING LIGHT (LDG LITE) SWITCHES (L & R)

Select and push split switches to turn desired set of lights ON. Push switches OFF to turn desired set of lights off. Lights should be operated only for short time periods while not in flight to preclude overheating of lamps. Over load protection is achieved by circuit breakers in panel.

11. GEAR SAFETY BY PASS SWITCH (Gear Retraction Override)

Gear safety override switch is a manual means of electrically by-passing the Airspeed Safety Switch. In the event the landing gear switch is placed in gear-up position, a properly operating Airspeed Safety Switch prevents gear from being retracted before takeoff speed of approximately 60 +/- 5 KTS is reached. To retract landing gear at a lower airspeed, the GR SAFETY BY PASS switch may be held de-pressed until landing gear is completely retracted.

~ CAUTION ~


Activation of landing gear safety override switch overrides the safety features of airspeed safety switch and CAN cause landing gear to start retracting while aircraft is on ground.

12. LANDING GEAR SWITCH

Electric gear switch, identified by its wheel shaped knob, is a two-position switch. Pulling aft and lowering knob lowers landing gear while pulling aft and raising knob raises landing gear.

| NOTE |

Failure to "Pull" knob out prior to movement may result in a broken switch.



**FIGURE 7 - 2A SWITCHES/CONTROLS (S/N 29-0170 thru 29-0182,
29-0184 thru 29-0199)**

13. STABILIZER TRIM POSITION INDICATOR

Stabilizer trim position indicator (LED) is electrically activated by a potentiometer attached to trim wheel mechanism. The position signal is transmitted to indicator by resistance readings.

14. FLAP POSITION INDICATOR

Wing flap position is electrically indicated by the (LED) flap indicator, located on flight panel. The intermediate mark on lens is the flap TAKEOFF setting. Signal is transmitted to indicator thru a potentiometer attached to flap mechanism. Position signal is transmitted to indicator by resistance readings.

15. RUDDER TRIM SWITCH

Push split toggle switch to position rudder into trimmed condition to reduce rudder pedal forces during takeoff, climbs or descents. Right - takeoff and climbs; Left - descents. Pushing left side of spring loaded switch trims rudder left, pushing right side of switch trims rudder right.

16. RUDDER TRIM POSITION INDICATOR

Rudder trim position is electrically indicated on an (LED) indicator located adjacent to switch. Signal is transmitted to indicator thru a potentiometer attached to trim mechanism. Position signal is transmitted to indicator by resistance readings.

17. " HIGH BOOST " FUEL BOOST PUMP SWITCH

An electric fuel boost pump, capable of operating engine at reduced power in case of engine driven fuel pump failure, is provided. The guarded switch (lift guard) can be pushed ON to operate engine (at reduced power) if required.

~ CAUTION ~

Pushing HIGH BOOST pump switch ON when engine driven pump is operating properly will cause engine to quit due to excessive rich fuel mixture.

17A. BOOST PUMP SWITCH (LOW BOOST)

The Low Fuel boost pump switch connects the fuel boost pump through a voltage regulator to provide engine priming capability prior to engine start and to provide a means of purging fuel

vapor from fuel system during extreme temperature situations, either environmental sources or from engine heat soak situations.

18. STAND-BY VACUUM (STBY VAC) SWITCH.

When HI/LO VAC annunciator light illuminates (steady or flashing), the vacuum operated gyro instruments are considered to be unreliable. STBY VAC switch should be turned ON. Refer to Airborne Service Letter, No. 31, located in Section X.

19. PITOT HEAT SWITCH/CIRCUIT BREAKER

Pitot heat combination switch/circuit breaker turns heating elements within pitot tube on. Should a short occur, the combination switch/circuit breaker will automatically trip to OFF position. "PITOT HEAT" annunciator light will illuminate "BLUE" when switch is ON and current is flowing through pitot heater. On some export aircraft, annunciator will illuminate "AMBER" when switch is OFF and will not be illuminated when ON and drawing current.

20. PROPELLER DE-ICE (PROP DE-ICE) SWITCH (If installed).

See SECTION IX for operating procedures. (29-0001 thru 29-0169)
NOT USED ON FIGURE 2A.

21. ELEVATOR TRIM (ELEC TRIM) SWITCH

Switch is normally left in ON position and serves as both a circuit protector and a master disconnect for the electric trim system in the event of a malfunction. The Radio Master Switch must be ON before power is available to elevator trim system.

22. THROTTLE CONTROL

Push throttle control forward to increase engine power. Pull throttle aft to decrease engine power. Full throttle automatically activates fuel boost pump. Vernier control is optional.

23. PROPELLER CONTROL

Push propeller control forward to increase engine RPM; pull control aft to decrease engine RPM. Control is a vernier type and fine adjustments of RPM can be obtained by turning knob clockwise to increase RPM and counter clockwise to decrease RPM. Knob should not be turned IN any closer than .030" to .060" to panel nut face.

24. MIXTURE CONTROL

Mixture control allows pilot to adjust the fuel-air ratio (mixture) of the engine. Push control forward to enrichen mixture. Pull control full aft to close idle cutoff, shutting down engine. Control is a vernier type and fine adjustments of mixture can be obtained by turning knob clockwise to enrichen mixture and counterclockwise to lean. Knob should not be turned IN any closer than .030" to .060" to panel nut face.

25. WING FLAP SWITCH

Flap switch, on console, operates the electrically-actuated wide span wing flaps. The flap switch incorporates a pre-select feature for TAKEOFF and FULL DOWN positions. Move switch down to first detent position to obtain TAKEOFF flaps (10°). Move switch to full down position to select FULL DOWN flaps (33°). When flap switch is moved UP to either TAKEOFF position or FULL UP position the flaps will retract to the selected position.

~CAUTION~

Positioning Flap Switch to the UP position retracts the flaps completely.

26. ALTERNATE STATIC SOURCE VALVE

Pull alternate static source valve full aft to change source of static air for the altimeter, airspeed and vertical speed indicator from outside of aircraft to cabin interior. Airspeed and altimeter readings are affected slightly when alternate static source is used (See Charts in SECTION V).

27. PARKING BRAKE CONTROL

Depress brake pedals and pull parking brake control to set parking brake. Push parking brake control in to release parking brake.

28. CABIN VENT CONTROL (Fresh Air)

Pull cabin vent control aft to open valve in mixing box connected to cabin air inlet NACA vent located on the right side of the airplane. Optimum use of cabin vent control is described in the Cabin Environment Section.

29. CABIN HEAT CONTROL

Pull cabin heat control to turn cabin heat on. To lower cabin temperature, cabin heat control is pushed forward toward the OFF position. Optimum use of cabin heat control is described in the Cabin Environment Section.

30. DEFROST CONTROL

Pull defrost control to decrease air flow to lower cabin area and increase air flow to windshield ducts in the front of glareshield area. Optimum use of the defrost control is described in the Cabin Environment Section.

31. MIKE JACK (Hand Held Microphone) (EMERGENCY MIC. AND PHONE JACK)

Plug hand held microphone jack into this plug and place microphone in holder located on front of lower console.

32. TRIM CONTROL WHEEL

Rotating trim control wheel forward lowers nose during flight; rearward rotation raises nose of aircraft during flight. If optional electric trim system is installed, pushing both sides of split trim switch, located on left hand portion of pilots control wheel, will electrically trim aircraft.

33. FUEL SELECTOR VALVE

Fuel selector valve, located on floorboard, is a three position valve which allows pilot to select either left or right fuel tank. Turning valve OFF, shuts off ALL fuel to engine. At full throttle engine will stop from fuel starvation in 2 to 3 seconds.

34. GEAR DOWN POSITION INDICATOR (Floorboard)

The gear-down position indicator, near back of fuel selector valve pan, aft of center console, has two marks that align when landing gear is down and illuminates when GREEN GEAR DOWN light is ON. A red-white striped decal shows when landing gear is NOT in the down position.

35. RADIO LIGHT SWITCH AND DIMMER

Turning radio light switch knob clockwise turns radio and indicator lights ON. Continued turning clockwise increases light intensity. This control also operates internal instrument lights.

36. PANEL LIGHT SWITCH AND DIMMER

Turning panel light switch knob clockwise turns instrument lights located in glareshield ON. Continued turning clockwise increases light intensity.

37. CIRCUIT BREAKER PANEL

See details elsewhere in this Section.

38 & 39. CO-PILOT'S HEADSET JACKS.

40 & 41. PILOT'S HEADSET JACKS.

42. FUEL FLOW TOTALIZER INDICATOR & FUEL MEMORY SWITCH.

"Fuel Totalizer" memory is connected to the aircraft battery through a "FUEL MEM"ory switch. Indicates fuel flow being used at given power setting, fuel used, fuel remaining and/or time remaining since last fuel filling, if memory switch has been left ON and system has not been RESET. Optional systems depict different data. (Some optional "Fuel Totalizer" systems do not contain a memory switch.).

43. ANNUNCIATOR PANEL

See description elsewhere in this section.

44. OPTIONAL DIRECTIONAL GYROSCOPIC INDICATOR REMOTE SLAVE and/or COMPENSATION SWITCH.

45. EMERGENCY LOCATOR TRANSMITTER (ELT) SWITCH (ARM/ON)

Place in ARM position for routine operation. Refer to ELT description elsewhere in this section on proper and lawful usage.

46. ALTERNATE AIR (ALT AIR)

Automatically opens when Induction air system becomes blocked for any reason. May be opened manually by pulling knob aft. AMBER annunciator light will illuminate when alternate air door is open.

47. BATTERY SELECT SWITCH - BAT 1/BAT 2

This switch allows pilot to select either battery as primary for any flight. Battery #1 is normally used for operations. The battery not being used is recharged through a trickle charge system. It is recommended to switch batteries occasionally.

48. FUEL FLOW MEMORY SWITCH (OPTIONAL FOR S/N 29-0001 thru 29-0169)

Normally left in "ON" position at all times so that "Fuel Used" information is retained from one flight to the next, until reset. Memory switch may be turned OFF to prevent battery drain if aircraft is to be stored for extended periods of time. (Some OPTIONAL "Fuel Flow" systems do not contain a memory switch.)

48. EMERGENCY BUS SWITCH (29-0170 thru 29-0199)

(Optional when Stand-by Alternator is installed)

When Low Voltage annunciator light illuminates, steady or flashing, pull 70A BAT circuit breaker and PUSH EMERG BUS switch ON to bring Stand-by Alternator on line.

49. CIGAR LIGHTER (CAUTION 28 volts)**50. STAND-BY VACUUM OPERATIONAL INDICATOR**

RED button is visible when STBY VAC switch is OFF. RED button is pulled back (not visible) when stand-by vacuum pump is operating. This indicator is for pre-flight check only.

51. OPTIONAL - INTER-COM CONTROL PANEL**52. OPTIONAL EQUIPMENT SWITCH(ES)****MAP LIGHT SWITCH/RHEOSTAT, MIC SWITCH, ELECTRIC TRIM SWITCH** (if installed) & **OPTIONAL AUTO-PILOT SWITCHES** are located in the pilot's control wheel.**ANNUNCIATOR & SWITCH PANEL****ANNUNCIATOR****A. PRESS-TO-TEST SWITCH**


Press RED press-to-test switch (3-5 sec.) with Master Switch ON to illuminate light bulbs (some annunciator legends may not be active, see descriptions below). Defective bulbs must be replaced prior to flight. Includes MASTER WARN light on S/N 29-0170 thru 29-0199

B. DIM SWITCH

The DIM switch may be activated after the low fuel lights come on bright. The switch will dim both low fuel lights but will not turn them off. To restore display to bright, press TEST switch.

**1. GEAR SAFETY INDICATOR (GEAR DOWN)
2. GEAR SAFETY INDICATOR (GEAR UNSAFE)**

A GEAR DOWN light (GREEN), a GEAR UNSAFE light (RED), and a warning horn provide visual and audible gear position signals. The green (GEAR DOWN) light shows continuously when gear is fully extended. With navigation lights ON, the GEAR DOWN light is dimmed for night operation. All gear lights are OUT when landing gear is fully retracted. Additional verification is accomplished by checking floorboard indicator window.

**FIGURE 7 - 3 ANNUNCIATOR & SWITCH PANEL
S/N 29-0001 THRU 29-0169****3. LEFT FUEL****4. RIGHT FUEL**

Left and/or right, fuel annunciator light (RED) comes on when there is 2-1/2 to 3 gallons (9.5 to 11.4 liters) for S/N 29-0001 thru 29-0169; 6 to 8 gallons (23 to 30.3 liters) for S/N 29-0170 thru 29-0199, of usable fuel remaining in the respective tank.

5. SPEED BRAKE

Illuminates AMBER when speed brakes are extended.

6. ALT AIR

Illuminates AMBER when the alternate air door is opened, either manually or automatically. In this situation, induction air for the engine is drawn from inside cowling rather than through the NACA induction air intake. The normal induction air system **MUST** be checked, for proper operation, prior to next flight.




FIGURE 7 - 3A ANNUNCIATOR & SWITCH PANEL
S/N 29-0170 THRU 29-0199

[NOTE]
Induction of
alternate air
(warm air) will
result in loss of
power.

7. PROP DE-ICE
Illuminates BLUE when Propeller De-Ice has been selected ON.

8. PITOT HEAT
Illuminates BLUE when pilot has selected PITOT HEAT rocker switch ON. Some exported aircraft will illuminate AMBER when switch is OFF or when there is any type of electrical failure in pitot heat system and **WILL NOT BE** illuminated when the switch is ON.

9. HI/LO VAC

A RED light indicates a malfunction or improper adjustment of vacuum system. Vacuum is available for operation of attitude gyro and directional gyro. Designated vacuum range is 4.25 +/- .25 to 5.5 +/- .2/-0.0 inches of mercury (Hg). The HI/LO VAC light will BLINK WHEN VACUUM IS BELOW 4.25 in. Hg. and illuminate STEADY WHEN VACUUM IS ABOVE 5.5 in. Hg. In either case, gyros should not be considered reliable during this warning time. Refer to Airborne Service Letter No. 31, located in Section X.

10. ALT VOLTS

A RED light indicates improper voltage supply. A FLASHING RED light indicates alternator voltage output is below load requirements or no voltage from alternator; a STEADY RED light indicates overvoltage or tripped voltage relay.

11. SPARE

12. START POWER

Illuminates RED when the starter switch or relay has malfunctioned and the starter is engaged while the engine is running. Shut the engine off as soon as practicable.

13. STBY VAC

Illuminates AMBER when Stand by Vacuum Switch has been selected to ON.

14. REMOTE RNAV (Optional)

Illuminates when DME 2 is selected and optional RNAV system is not functioning.

15. SPARE (S/N 29-0001 THRU 29-0169)

15. EMERGENCY BUS (S/N 29-0170 THRU 29-0199) (OPTIONAL)

Illuminates when the EMERG BUS switch is selected ON to bring Standby Alternator on line.

16. BOOST PUMP

Illuminates BLUE when the Electric Fuel Boost Pump is selected ON. Light comes on high; intensity when HI BOOST switch is ON and low intensity when LOW BOOST switch is ON.

SWITCH PANELS & ANNUNCIATOR PANELS WILL VARY WITH AIRCRAFT**C., D., E.. NAVIGATION MODE SELECTION SWITCHES (Figure 7-3A)****17. ELT SWITCH (29-0001 THRU 29-0169)****17. MARKER BEACONS (29-0170 thru 29-0199)**

Illuminates applicable colors as aircraft passes over marker beacons on approach.

18. OPTIONAL SWITCHES (29-0001 thru 29-0169)**18. NAVIGATION SELECTION LIGHTS (29-0170 thru 29-0199)**

Illuminates as the pilot selects the navigation system desired. Varies with installed equipment.

19. ELT SWITCH (29-0170 thru 29-0199)**20. OPTIONAL SWITCHES (29-0170 thru 29-0199)****GROUND CONTROL****NOSE GEAR STEERING**

Nose gear steering system consists of a steering horn on nose gear leg linked to the rudder pedals by push-pull tubes and bellcranks. Gear retraction automatically disengages steering mechanism from nose wheel and centers nose wheel for entry into wheelwell.

TAXIING AND GROUND HANDLING

The aircraft can be easily taxied with minimum use of brakes. Minimum turning radius is 40 ft. (12.0 m) right & 48 ft. (14.4 m) left, without use of brakes. A MANUAL tow bar is provided to ground handle aircraft. Care must be used to not swivel nose wheel beyond 13° right or 11° left from center. Adjustable steering stops are incorporated on nose gear leg assembly.

~ CAUTION ~

Exceeding steering swivel angle limits may cause structural damage.

LANDING GEAR**CONSTRUCTION**

Landing gear legs are constructed of chrome-molybdenum tubular steel, heat-treated for greater strength and wear resistance. Main gear leg attaching points pivot in bearing surfaces on forward and stub spars. The nose gear mounts on cabin tubular steel frame and engine mount. Rubber discs in all gear leg assemblies absorb shock of taxiing and landing.

RETRACTION SYSTEM

Landing gear is electrically retracted and extended. The landing gear switch operates a landing gear actuator relay. Pull wheel-shaped knob out and move it to upper detent to raise landing gear. However, an Airspeed Safety Switch, located on left fuselage side adjacent to the pilot's left knee and connected to the airspeed indicator, is incorporated into the electrical system to prevent landing gear retraction while on the ground and until a safe takeoff speed (approximately 60 +/- 5 KTS) is reached. A properly rigged up-limit switch will stop landing gear in its retracted position. Move control knob to its lower detent to lower landing gear. A properly rigged down-limit switch will stop landing gear actuating motor when proper force has been exerted to hold landing gear in the down-and-locked position. Bungee springs preload retraction mechanism in an overcenter position to assist in holding landing gear down. A landing gear safety by-pass switch override is provided, next to the gear switch, should landing gear fail to retract. Depress and hold this switch to manually bypass airspeed safety switch and allow landing gear to retract.

~ CAUTION ~

Never rely on airspeed safety switch to keep landing gear down during taxi, takeoff or landing. Always make certain that landing gear switch is in down position during these operations.

WHEEL BRAKES

Main gear wheels incorporate self-adjusting, disc-type, dual puck, hydraulic brakes. The pilot's rudder pedals have individual toe-actuated brake cylinders linked to the rudder pedals. Depressing both toe pedals and pulling parking brake control, on console, sets the brakes. Push parking brake control forward to release brakes.

It is not advisable to set parking brake when brakes are overheated, after heavy braking or when outside temperatures are unusually high. Trapped hydraulic fluid may expand with heat and damage the system. Wheel chocks and tie-downs should be used for long-term parking.

EMERGENCY EXTENSION SYSTEM

A manual, emergency gear extension mechanism is provided to allow emergency lowering of landing gear. The control mechanism is located between and aft of pilot and co-pilot seats. The RED lever must be released and pulled up (rotated aft) to engage the manual emergency extension mechanism. The mechanism has a spring retracted pull cable which manually drives the gear actuator to extend landing gear. 12-20 pulls are required to fully extend and lock landing gear down. The electrical extension or retraction system will not operate if the manual extension lever is not properly positioned down.

WARNING SYSTEM

The landing gear warning system consists of: 1) landing gear condition lights, GREEN for "GEAR DOWN" and RED for "GEAR UNSAFE", and 2) a warning horn, activated when landing gear is not down-and-locked and throttle is approximately 1/4 inch from idle position. The green light shows continuously when landing gear is fully extended. The red light shows whenever landing gear is in transit or not locked down but is OFF when landing gear is fully retracted. A visual gear-position indicator, located on floorboard, aft of the fuel selector, shows that landing gear is down when indicator marks align. The gear down light is dimmed when navigation lights are turned on.

STEERING

Rudder pedal action steers the nose wheel. Gear retraction relieves the rudder control system of its nose wheel steering and centers wheel to permit retraction into the nose wheel well. Minimum turning radius on the ground is 40 feet (12.0 m) to the right and 48 feet (14.4 m) to the left. Adjustable steering stops have been incorporated on nose gear leg assembly.

~ CAUTION ~

The nose wheel must not be swiveled beyond 11° left or 13° right of center. To exceed these limits may cause structural damage.

CABIN

BAGGAGE COMPARTMENT

The baggage compartment is located aft of rear passenger seats. The standard compartment has 20.9 cubic feet (.59 cu.m.) of baggage or cargo space. A maximum of 120 pounds (54 Kg) may be loaded in this area. There are floor tie-down straps provided. Passengers should not be allowed to occupy this space.

Additional cargo space is available by removing rear seat, bottom cushion and seat back cushion/cover (fold seat back forward and slide seat cover UP and OFF frame. Store cushions as desired).

To fold rear seat back down, pull lock pin (left side frame). Pull seat frame from pivot rods. Place pivot rods into portion of seat frame that carpet is attached to. Slide frame down until approximately bottomed out. Pull seat back release handle UP to move catch down. Pivot seat back forward & down into seat cushion cavity.

Both rear seats can be folded down together or independent of each other.

The storage area located aft of the top of the aft baggage compartment bulkhead (hat rack) is restricted to 10 pounds (4.5 Kg).

CARGO RESTRAINT

Cargo tiedown rings/clevis pins are to be inserted into holes provided in web of front seat rails. The cargo belts attach to these rings and to standard seat belt harness to retain cargo. Refer to Figure 7-4 for typical restraint.

~ CAUTION ~

Proper loading and retention of cargo is mandatory. See Loading Computation Graph, SECTION VI.

SEATS

The front seats are individually mounted and may be adjusted fore and aft to fit individual comfort preferences. The front seat back may be adjusted by turning left side hand crank (knob) until seat back is in desired position.

Both optional front seat configurations allow vertical seat height adjustment by turning right side hand crank to raise or lower the entire seat assembly.

The rear seat backs have four (4) adjustment positions. Each seat can be adjusted independent of the other by pulling up on respective release handle located on left or right of aircraft center line on forward spar. This allows adjustments from approximately 10° to 40° recline position.




FIGURE 7 - 4 CARGO RETENTION (TYPICAL)

SEAT BELTS/SAFETY HARNESS

Safety restraints, if worn properly, (1 occupant per restraint) keep occupants firmly in their seats during T/O, landing, turbulent air and during maneuvers. The belts/harnesses are mechanically simple and comfortable to wear. The front seat inertia belts/harnesses are attached to hardpoints on side structure and seats. The rear seat belts are attached to brackets firmly mounted to structural hardpoints. Shoulder harnesses are provided for rear seat occupants. Safety belts/harnesses MUST be fastened for take-off and landing operations. It is recommended that all infants and small children below 40 lbs. weight and/or under 40 in. height be restrained in an approved child restraint system appropriate to their height and weight.

The single diagonal type safety harness is designed so the chest strap crosses diagonally from the outboard shoulder to an attachment point as low on the inboard hip as possible. Rear seat occupants should take care to conform with this procedure in adjusting chest strap and inboard belt length. This diagonal configuration places body center-of-gravity inside the triangle formed by chest strap and lap belt. The lap belt should be adjusted comfortably tight. As a result, the body is restricted from rolling out to-




FIGURE 7 - 5 INERTIAL
REEL/HARNESS RETENTION

DOORS, WINDOWS & EXITS

Access into cabin is provided by a door located on right side of fuselage. This door has inside and outside operating handles. Outside door handle can be locked with a key specifically provided for it. The door has two latching mechanisms, one located at the top of door and one at the aft, center of door. Should the door come open in flight, flying qualities of the aircraft will not be affected. Procedures for closing door in flight are contained in SECTION III.

A pilot's storm window is located in the left main cabin window. This window is generally used for fresh air for prolonged ground operations or as required during adverse weather conditions. The window should not be opened in flight above 132 KIAS.

The CABIN DOOR is the primary emergency exit from the cabin. If a situation exists where a probable off airport landing will occur, the door should be unlatched to prevent jamming during landing.

The BAGGAGE compartment access DOOR can be used as an auxiliary exit. The door can be opened from the inside even though locked. To open, pull off small ABS cover, pull out latch pin and pull Red Handle.
To verify re-engagement of latching mechanism; open outside handle fully, close inside handle to engage pin into cam slide of latch mechanism; insert latch pin into shaft hole to hold Red Handle down. Replace ABS cover. Operate outside handle in normal method.

ENGINE

The engine installed is a Teledyne Continental Motors IO 550-G(*), normally aspirated fuel injected engine. The following designation describes engine :

* Refer to TCDS for engine configuration required.

The engine operates with three, standard engine controls. The propeller turns clockwise as viewed from the cockpit.

The engine controls are centrally located between the pilot and co-pilot on the engine control console. The **BLACK** throttle knob regulates manifold pressure; push the knob forward to increase the setting; pull the knob aft to decrease the setting. A vernier throttle control is optional.

The propeller control, with its crowned BLUE knob, controls engine RPM through the propeller governor. Push the knob forward to increase engine RPM; pull the knob aft to decrease RPM.

The mixture control, with its RED fluted knob, establishes the fuel-air ratio (mixture). Push the knob full forward to set the mixture to full-rich, pull the knob gradually aft to lean the mixture. Pull the knob to its maximum aft travel position to close the idle cut-off valve to completely shut down the engine. Precise mixture settings can be established by observing the EGT gauge on the pilot's instrument panel while adjusting the mixture control.

The optional throttle, propeller and mixture controls are vernier type and fine adjustment can be made by turning knobs clockwise or counter-clockwise. The vernier controls should be rigged within .030 to .060 in. from panel nut face. Rapid movement or large adjustments can be made by pushing button on end of control and positioning control where desired. The non-vernier throttle has an integral friction device.

be made by pushing button on end of control and positioning control where desired. The non-vernier throttle has an integral friction device.

ENGINE INSTRUMENTS

Engine instruments operate electrically, except manifold pressure, through variations in resistance caused by pressure or temperature changes or by variations in current output caused by varying engine RPM or alternator output. The tachometer receives its signal from the Hall effect sensor in magneto.

Engine operating instruments are located in the center of the instrument panel. Colored arcs on instrument faces mark operating ranges. Proper interpretation of engine instrument readings is essential for selecting optimum control settings and for maintaining maximum cruise fuel economy. (Refer to SECTION II for Limitations).

ENGINE OPERATION AND CARE

Life of an engine is determined by the care it receives. Maximum efficiency and engine service life can be expected when a good maintenance program is followed. Poor maintenance results in faulty engine performance and reduced service life. Efficient engine operation demands careful attention to cleanliness of air, fuel, oil and maintaining operating temperatures within required limits. Servicing of the engine should be accomplished only by qualified personnel. The minimum grade of fuel for this engine is 100 LL or 100 octane aviation gasoline. If the grade required is not available, use a higher rated fuel; never use a lower rated fuel. Operational procedures for adverse environmental conditions can be found in engine maintenance and operator's manual.

OIL SYSTEM

The engine has a full-pressure, wet sump oil system with an 8 quart (7.57 liters) capacity. A conventional dip stick is provided for determining oil quantity. The oil system is depicted in Figure 7-6. The propeller governor boosts engine oil pressure for operation of the propeller. It controls oil pressure going to the propeller hub to maintain or change propeller blade angles. This oil flows through propeller shaft to reach the propeller.

LUBRICATION SYSTEM




FIGURE 7 - 6 OIL SYSTEM SCHEMATIC

BREATHER FOR CRANKCASE

The crankcase is vented overboard to a near static location.

IGNITION SYSTEM

Power from the engine crankshaft is transmitted through camshaft gear to the magneto drive gears, which in turn drives the magneto drive couplings. The left magneto incorporates an impulse coupling. As the rubber bushings in the drive gear turns the coupling drive lugs, counter-weighted latch pawls inside the coupling cover, engage pins on the magneto case and hold back the latch plate until forced inward by the coupling cover. When the latch plate is released, the coupling spring spins the magneto shaft through its neutral position and the breaker opens to produce a high voltage surge in the secondary coil. The spring action permits the latch plate, magnet and breaker to be delayed through a lag angle of 30 degrees of drive gear rotation during the engine cranking period. Two lobes on the breaker cam produce two sparks per revolution of the drive shaft. After engine is running, counter-weights hold the latch pawls away from the stop pins and the magneto shaft is driven at full advance.

The engine firing order is 1-6-3-2-5-4. Ignition harnesses are connected to the magnetos so right magneto fires the upper plugs on the right side and lower plugs on the left. The left magneto fires the upper plugs on the left and lower plugs on the right. The magneto cases, spark plugs, harnesses and connections are shielded to prevent radio interference.

AIR INDUCTION SYSTEM

The engine air induction system consists of a NACA, flush-type air inlet duct located on front of lower cowl. The air inlet duct incorporates the air filter housing. This housing contains a throw-away, paper canister type air filter element.

A secondary or alternate air source for combustion air is provided. This air inlet has a spring loaded door which normally remains closed. If the air filter or induction air inlet should become restricted, the alternate air door will automatically open. Warmer air will then be drawn from the engine compartment. There will be a reduction of engine power when the alternate air door is open due to lower inlet air pressure and higher air temperature. Whenever the alternate air door is open, a switch will activate the "ALT AIR" annunciator light on the panel to alert the pilot.

ICING PROTECTION

Continued operation of the induction system in the event of intake air being obstructed is provided by activation of the alternate air system. The alternate air is automatically or manually controlled. When the door is opened, unfiltered, relatively warm air, from engine compartment, is admitted into the induction system.

EXHAUST SYSTEM

The exhaust system consists of tubes from each cylinder mating




FIGURE 7 - 7 AIR INDUCTION SYSTEM
SCHEMATIC

out an exhaust pipe on the left side of aircraft. The left collector pipe crosses through muffler and out an exhaust pipe on the right side of aircraft. A short tailpipe attaches to the end of each exhaust pipe.

The muffler has a heat shroud around it which serves as a cabin air heater. Outside ambient air is forced into the cabin heater by forward velocity. Air flows around the muffler, picking up heat and is then carried to a cabin heat J-box mounted on the firewall. When cabin heat is not required, the air continues to flow around the muffler for cooling and is dumped overboard through the cabin heat J-box outlet duct.

FUEL INJECTION

The fuel injection system is of the multi-nozzle, continuous flow type which controls fuel flow to match engine requirements. Any change in air throttle position, engine speed or a combination of these causes changes in fuel pressure in direct relation to engine requirements. A manual mixture control is provided for precise leaning at any altitude and power setting. A fuel flow system is installed for digital readout of fuel flow in gallons per hour. However, fuel flow is NOT to be used as reference for manual leaning. Use the EGT gauge for this purpose.

The continuous-flow system permits the use of a typical rotary vane pump with integral relief valve. With this system there is no need for an intricate mechanism for timing fuel injection to the engine. The fuel injector pump is equipped with a separator where vapor is separated by a swirling augmentor system from the liquid fuel and returned to the tank selected. The fuel injector pump forces liquid fuel into the metering unit assembly.

The fuel metering unit/air throttle controls the amount of intake air admitted into the intake manifold and meters the proportionate amount of fuel to the fuel manifold valve. The assembly has three control units, one for air, in the air throttle assembly, and two for the fuel control unit.

The manifold valve receives fuel from the metering unit. When fuel pressure reaches approximately 3.5 PSI, a check valve opens and admits fuel to six ports in the manifold valve (one port for each fuel nozzle line). The manifold valve also serves to provide a clean cutoff of fuel to the cylinder when engine is shut down.

The injector nozzle lines connect the manifold valve to the six fuel injector nozzles.

The injector nozzles (one per cylinder) are "air bleed" type fuel nozzles which spray fuel directly into the intake port of the cylinder. When engine is running, flow through the nozzle is continuous and will enter the cylinder combustion chamber when the intake valve opens.

Since the size of the fuel nozzles are fixed, the amount of fuel flowing through them is determined by the pressure applied. For this reason, fuel flow may be accurately determined by measuring fuel pressure at the manifold valve.

ENGINE COOLING AIR

Ram air is drawn into the forward part of upper cowl and flows down, around the cylinders using several baffles to control air direction. Hot air, off the cylinders, exits cowl thru lower cowl openings, located on either side of engine lower cowl, immediately forward of the firewall.

ENGINE STARTING SYSTEM

Engine starting is provided by a 24 volt starter. A starter engaged warning light (START POWER) is incorporated as standard equipment in annunciator panel. Ignition is provided by an impulse coupled magneto.

The engine firing order is 1-6-3-2-5-4. The ignition harnesses are connected to the magnetos so the right magneto fires the upper plugs on the right side and lower plugs on the left. The left magneto fires the upper plugs on the left and the lower plugs on the right.

ACCESSORIES

ALTERNATOR

Standard electrical power is supplied by a gear driven, 28 Volt, 100 ampere alternator.

An optional gear driven, 24 Volt, 20 ampere stand-by alternator is available.

VACUUM PUMP

A full time, engine driven vacuum pump supplies suction for the vacuum-operated gyroscopic flight instruments. Air entering vacuum-powered instruments is filtered; hence, sluggish or erratic operation of vacuum driven instruments may indicate that a clogged vacuum filter is preventing adequate air intake. A vacuum annunciator light is provided to monitor system operation. Refer to Airborne Service Letter No. 31, located in Section X.

One Stand-by Vacuum pump is also driven from the engine accessory case, but is coupled through an electrically actuated clutch. Another Stand-by Vacuum pump system (electric) is installed in the tailcone. The pilot must PUSH a panel mounted rocker switch ON for either Stand-by Vacuum system to be operable.

EXHAUST GAS TEMPERATURE PROBE

The exhaust gas temperature (EGT) probe measures exhaust gas temperature as it exits the exhaust valves into the exhaust manifold. The EGT probe varies electrical current (milliamps), based on exhaust gas temperature, and supplies this to an EGT gauge located on instrument panel. The EGT gauge is used as the primary source to lean fuel mixture.

PROPELLER

The propeller is a three blade, metal, constant speed unit. Propeller rotational speed (RPM) is maintained by a balance of air load, oil pressure and engine rotational forces. The propeller governor regulates a flow of high pressure engine oil to a piston in the propeller dome. The piston is linked by a sliding rod and fork arrangement to propeller blades. Governor oil pressure, acting on a piston and spring, increase propeller blade pitch, thus decreasing propeller and engine RPM. As oil pressure is reduced, centrifugal twisting moments on the propeller blades decrease propeller blade pitch and increase RPM.

In cruise, always use the power setting charts provided in SECTION V.

FUEL SYSTEM

Fuel is carried in two integrally sealed sections of the forward, inboard area of wing. Total usable fuel capacity is 89 U.S. gallons (337 liters). There are sump drains at the lowest point in each tank for taking fuel samples to check for sediment contamination or condensed water accumulation.

The recessed three position fuel selector valve, aft of console, on the floor, allows pilot to set selector valve to LEFT tank, RIGHT tank or OFF position.

The gascolator, located at right of selector valve, in the floorboard, is for draining condensed water and sediment from lowest point in fuel system before first flight of the day and after each refueling. The gascolator sump can be used to drain the selected fuel tank.




FIGURE 7 - 8 FUEL SYSTEM SCHEMATIC

Fuel is delivered, by the engine driven pump, to a throttle body fuel injector where pressure is regulated and the correct volume of fuel is metered to each cylinder of the engine. Fuel not needed by the engine is returned to the tank from which it is drawn.

An electric Fuel Boost Pump is provided which has the capability of operating engine at partial power in case of engine driven fuel pump failure. The pump is controlled by two switches. The "BOOST PUMP" switch is to be used for priming engine during normal starting procedures (See SECTION IV) or purging fuel vapor from system when environmental conditions or a heat soaked engine may require it. (See SECTION III). The BOOST PUMP switch connects the pump through a voltage regulator for correct pump output. A guard on the "HIGH BOOST" switch prevents inadvertent operation and must be lifted for switch operation. (See SECTION III). "HIGH BOOST" is to be used when engine driven fuel pump has malfunctioned and will provide sufficient fuel for partial power operation until a precautionary landing can be made to correct malfunction.

Two electric fuel-level transmitters, working in series, in each wing tank operate the appropriate, left or right, fuel quantity gauges. The master switch actuates the fuel quantity indicator system to depict an indication of fuel remaining in each tank. Vents in each fuel tank allow for overflow and pressure equalization.

The optional, visual fuel quantity indicators, in each wing, are to be used for PARTIAL FUEL LOADING only and NOT for preflight inspection purpose.

Fuel Flow Indicating system (if installed) indicates the volume of fuel being used, total fuel used or fuel remaining or time remaining. Optional fuel flow systems are available and each do not indicate the same type data. The fuel flow memory switch can be shut off if aircraft is to be stored for long periods of time.

ELECTRICAL SYSTEM

ALTERNATOR & BATTERY

Two 24-volt, 10-ampere-hour storage batteries (in the tailcone) and one 100 ampere self-rectifying alternator (produces 99 amps) supplies electrical power for equipment operation. The No. 1 battery, left side of tailcone, is normally used as the primary to sustain the electrical system and to start the aircraft. The No. 2 battery, right side of tailcone, is normally considered as backup and is kept in a fully charged condition by trickle charge, through a diode system.

Should the No. 1 battery be depleted to the point of being unable to supply adequate power for system needs, it may be de-selected from the system and No. 2 battery selected on line by pushing the rocker switch marked BAT-1/BAT-2, on the circuit breaker panel, from the BAT-1 to BAT-2 position. The MASTER switch still controls battery power to the buss from either position. With the BAT-1/BAT-2 switch in the No. 2 position the No. 1 battery will be recharged (trickle charged) through the diode system. Alternate between #1 & #2 batteries, as desired, to keep both active.

A standard Ammeter which has a "PUSH for Volts" button depicts battery charge or discharge.

SCHEMATIC (See FIGURE 7-9)

The voltage regulator adjusts alternator output to current load while maintaining a constant voltage level. A voltage warning light illuminates steadily when voltage limits are exceeded (ie. voltage spikes) and flashes when the voltage is low.

CIRCUIT BREAKER PANEL (See FIGURE 7-10)

(Illustration depicts typical C/B panel; may vary from your aircraft)

Push-pull or rocker switch-circuit breakers automatically break the electrical current flow if the system or unit receives an overload to prevent damage to electrical wiring. The main circuit breaker panel is in the extreme right panel. Figure 7-10 illustrates a typical main circuit breaker panel with its push-pull circuit breakers. Rocker switch-circuit breakers are at the bottom and left of the pilot's flight panel.

The alternator's push-pull circuit breaker, on the main breaker panel, furnish an emergency overload break between the alternators and the power buss. Since the alternator is incapable of output in excess of circuit breaker capacity, a tripped breaker normally indicates a fault within the alternator.

The alternator field has a push-pull circuit breaker to furnish an emergency break in the alternator field excitation circuit in the event of alternator or voltage regulator malfunction. If regulator





FIGURE 7 - 9 ELECTRICAL SCHEMATIC

output voltage exceeds limits, the overvoltage warning light illuminates steadily and the alternator field circuit breaker trips.

Resetting the alternator field circuit breaker should reset alternator. If the circuit breaker will not reset, continue flight with minimum electrical load. The flight will be continued using only battery power, caution is advised to not drain both batteries if electrical power will be required before you are able to land. Land when practical to correct the malfunction.

FIGURE 7 - 10 CIRCUIT BREAKER PANEL
(TYPICAL)**[NOTE]**

The circuit breakers installed in the panel may vary depending on installed equipment.

ANNUNCIATOR PANEL

The landing gear, low fuel, speed brakes, alternate air, propeller de-ice and pitot heat lights are grouped in the upper annunciator panel. The vacuum malfunction, alternator fail, start power, stand-by vacuum, remote RNAV are grouped in the lower annunciator panel.

A test and dim switch are also found in the panel; each of the lights and switches are discussed elsewhere in this Section.

ELT PANEL

The ELT Panel houses the remote ELT Switch and provides room for other switches as required for optional avionics installations. (See SECTION IX for Avionics Systems installed in this aircraft).

**LIGHTING
SYSTEM****INSTRUMENT & PLACARD LIGHTS**

All placards are floodlighted by lights from the glareshield. There are two rheostat knobs on the right hand radio panel. The left control regulates intensity of the placard lighting. The right control provides avionics and instrument lighting. Rotating the knobs clockwise turns ON and increases light intensity.

MAP LIGHT

The map light switch is located on the center of the pilot's and co-pilot's control wheel.

CABIN LIGHTING

Two sets of overhead lights illuminate the cabin.

~ CAUTION ~

The Cabin Light rocker switches are connected directly to battery.

All passenger overhead lights are controlled by a Master Light switch located on the pilot's arm rest. With Master Light Switch ON, individual overhead cabin lights are controlled by rocker switches located on each passenger's arm rest (excluding front seat passenger). Front seat passenger's light switch is located forward of cabin door hinge on side panel.

EXTERIOR LIGHTING

Conventional navigation and high intensity strobe lights are installed on the wing tips and on the rudder trailing edge (strobe light only). Landing and Taxi lights are installed in the right and left wing leading edge. Split switches are used to control either the left or right taxi or landing lights. All exterior light switches are located on overhead panel just behind top of windshield.

The high intensity wing tip and tail strobe lights are required for night operation but should be turned OFF when taxiing near other aircraft or flying in fog or clouds. The conventional position lights must be used for all night operations.

CABIN ENVIRONMENT

HEATING & VENTILATION SYSTEMS

Four ventilating systems provide cabin environmental conditions which can be controlled to pilot and passenger individual preferences:

FRESH AIR - One source of outside air enters cabin through air ducts on both sides of fuselage. This outside air is always available through adjustable outlets (Wemacs) near pilot's and co-pilot's knees.

CABIN VENT - When the CABIN VENT control is pulled, fresh air from air duct on fuselage right side is supplied to the cabin (through mixer box and lower console duct) and/or to the defrost system.

CABIN HEAT - Fresh air, heated by engine exhaust muff, and cool air from air duct on co-pilot side can be individually controlled and mixed to desired temperature by use of the Cabin Vent and Cabin Heat controls. Pulling cabin heat control supplies heat to cabin and defroster system. Hot and cold air may be mixed by adjusting both heat and vent controls. These controls may be adjusted anywhere between full open and full closed.

OVERHEAD VENTILATION - Cabin overhead ventilating system works independently of cabin heating and ventilating system. Fresh air enters a NACA duct on dorsal fin and is controlled by individual outlets above and between each seat. A master air vent control regulates flow of air through the individual overhead outlets. This control is located between the pilots & co-pilots seat on the overhead panel.




FIGURE 7 - 11 CABIN AIR FLOW

WINDSHIELD DEFROSTING SYSTEM

The windshield defrost system takes air from the cabin air distribution system and distributes this over the windshield interior surface any time the heat and/or fresh air valves are opened. Pulling the defrost control Full AFT decreases flow to the cabin, turns defroster blower ON and forces maximum air to flow through the defrost ducts.

PITOT PRESSURE & STATIC SYSTEM

A pitot tube, mounted on lower surface of the left wing, picks up ram air for airspeed indicator. A pitot heater prevents pitot tube icing when flying in moisture-laden air. A pitot system drain valve is located on the forward bottom skin of the left wing to fuselage fillet. Static ports on each side of the tailcone supply static air pressure for the altimeter, the airspeed indicator, and vertical speed indicator. A static system drain valve is located on fuselage bottom skin below the left

side, tailcone access door and is used to drain moisture that might collect in static system lines. An alternate static pressure source valve handle is installed in the instrument panel below the pilot's control wheel shaft. Alternate static air is taken from within the cockpit and will affect flight instrument readings. Performance variation charts in SECTION V depict the difference between primary and alternate static indications.

STALL WARNING SYSTEM

The electrical stall warning system uses a vane-actuated switch, installed in left wing leading edge, to energize stall warning horn located in the cabin. The stall warning switch is adjusted to provide aural warning at 5 to 10 KIAS before actual stall is reached and will remain on until aircraft flight attitude is changed toward a non-stalled condition.

NOTE

Do not attempt to adjust prestall warning speed by bending the vane. This part has been heat treated and cannot be bent without damaging or breaking the vane.

OXYGEN SYSTEM

An optional four-place oxygen system provides supplementary oxygen necessary for continuous flight at high altitude. An oxygen cylinder is located in the equipment bay, accessible through a removable panel on the aft wall of the baggage compartment, or through the standard external, right side, panel in the tailcone. A combined pressure regulator/shutoff valve, attached to the cylinder, automatically reduces cylinder pressure to the delivery pressure required for operating altitude. The oxygen cylinder filler valve is located under a springloaded door aft of the baggage door.

A pilot's oxygen panel contains a cylinder pressure gauge, on the pilot's arm rest, effectively a quantity gauge, and a control knob, below arm rest, which is mechanically connected to the shutoff valve at the cylinder. The supply of oxygen can thus be shut off from the cockpit when not required. When the control is in the "ON" position, sufficient oxygen flow is available at the maximum airplane operating altitude (see Section II Limitations) while at lower altitudes the reducing valve automatically economizes the flow to conserve oxygen for longer duration or for future availability, without requiring any action by the pilot. (See Fig. 7-13)

Four oxygen outlets are provided in the overhead panel between the pilot's and co-pilot's seat for the convenience of all occupants. Oxygen flows from the outlets only when a mask hose is connected. Four partial re-breathing type masks are provided, each with vinyl plastic hoses and flow indicators. The three passenger masks are of the disposable type. The pilot's mask is a permanent type with a built-in microphone for ease of radio communication while using oxygen. To use the mask-microphone, connect its lead to the microphone jack located left of the instrument panel, in place of the aircraft or headset microphone lead, and key the switch on the control yoke.

The oxygen cylinder, (composite) when fully charged, contains 115.7 ft.³ of aviator's breathing oxygen (Spec No. MIL-O-27210) under a pressure of 1850 PSI at 21° C (70° F). Filling pressures will vary, however, due to ambient temperature in filling area, and the rise of temperature resulting from compression of the oxygen. Because of this, merely filling to 1850 PSI will not necessarily result in a properly filled cylinder. Fill to pressures indicated on Fig. 7-12 for ambient temperatures.

WARNING

Oil, grease or other lubricants in contact with oxygen create a serious fire hazard, and such contact must be avoided when handling oxygen equipment.

Ambient Temperature ° F	Filling Pressure PSIG	Ambient Temperature ° F	Filling Pressure PSIG
0	1650	50	1875
10	1700	60	1925
20	1725	70	1975
30	1775	80	2000
40	1825	90	2050

FIGURE 7-12 - OXYGEN FILLING PRESSURES

[NOTE]

The oxygen cylinder should not be run down to less than 100 PSI. Below this pressure, atmospheric contamination of the cylinder may occur, requiring valve removal and cylinder cleaning and inspection at an FAA approved repair station.


For FAA requirements concerning supplemental oxygen, refer to FAR 91.32. Supplemental oxygen should be used by all occupants when cruising above 12,500 feet. It is often advisable to use oxygen at altitudes lower than 12,500 feet under conditions of night flying, fatigue, or periods of physiological or emotional disturbances. Also the habitual and excessive use of tobacco or alcohol will usually necessitate the use of oxygen at less than 10,000 feet.

The oxygen duration chart (Fig. 7-13) should be used in determining the usable duration (in hours) of the oxygen supply in the airplane for the chosen cruising altitude. The following procedure outlines the method of finding the duration from the chart:

1. Note the available oxygen pressure shown on the pressure gage.
2. Locate this pressure on the scale on the left side of the chart. Then go across the chart horizontally to the right until intersecting the diagonal line which represents the number of persons on board. From that intersection drop vertically down to the heavy line, marked 30,000 ft..
3. From this point on the heavy line, follow the trend of the curved lines, down to the horizontal line representing cruise altitude. Then drop vertically down to the bottom of the chart and read the duration in hours given on the scale.
4. As an example of the above procedure, 1400 PSI of pressure will safely sustain the pilot and one passenger for 4 hours and 55 minutes (Fig. 7-13) at 28,000 ft.; however, cruising at 20,000 ft. would permit an oxygen duration of 7 hours and 55 minutes (Fig. 7-13). Light crew loads and relatively low altitudes will permit oxygen durations off the chart. Such durations can be calculated by determining the duration at 30,000 feet (by steps 1 and 2 above) and multiplying by the "duration multiplier" shown on the right of the appropriate cruising altitude. Example, Pilot only, at 1600 PSI has 11.25 hours duration at 30,000 ft. Duration Multiplier of 2.4 for 20,000 ft., gives 26 hours and 54 minutes duration. Oxygen durations off the chart obviously exceed the airplanes duration. However, judicious choices of altitude for the number of persons on board can permit flight planning for several fuel stops, without need for recharging oxygen system at each stop.

CAUTION

Facial hair, beards & mustaches may prevent a proper seal between face and mask, causing 16 - 67% leakage. Duration chart may be invalid.

**VACUUM SYSTEM**

The standard vacuum system on the M20R consists of a main vacuum pump, regulator, filters and a clutch activated, engine driven, stand-by vacuum pump. The main vacuum pump operates when the engine is running. The standard stand-by vacuum pump is coupled to the engine accessory drive but the electrically activated clutch must be turned ON, by pushing the STBY VAC switch, before the pump is on line. An optional Stand-by Vacuum Pump System is located in the tailcone when the optional, No. 2 alternator is installed.

A vacuum system malfunction is shown to the pilot by a RED, HI/LO VAC, annunciator light. A FLASHING annunciator light indicates LOW VACUUM and a STEADY light indicates HIGH VACUUM. In either case, vacuum operated instruments are to be considered UNRELIABLE and use of stand-by vacuum pump is recommended. The STBY VAC legend on the annunciator will be illuminated when the STBY VAC switch is ON.

EMERGENCY LOCATOR TRANSMITTER

The Emergency Locator Transmitter (ELT) is located in the tailcone and is accessible from the battery access door on the right side of the tailcone. The emergency locator transmitter meets the requirements of FAR 91.52 and is automatically activated by a longitudinal force of 5 to 7 g's. The ELT transmits a distress signal on both 121.5 MHz and 243.0 MHz for a period of from 48 hours in low temperature areas and up to 100 hours in high temperature areas. The unit operates on a self-contained battery. The battery should be checked at each annual inspection. The battery has a useful life of four years. However, to comply with FAA regulations it must be replaced after two years of shelf life. The battery should also be replaced if the transmitter has been used in an emergency situation or if accumulated test time exceeds one hour. The battery replacement date is marked on the transmitter label.

On the unit itself is a three position selector switch placarded "ARM", "OFF", "ON". The "ARM" position is provided to set the unit to the automatic position so that it will transmit only after impact and will continue to transmit until battery is drained to depletion or until the switch is manually moved to "OFF". "ARM" position is selected when the transmitter is installed at the factory and switch should remain in that position whenever unit is installed in the airplane. The "ON" position is provided so unit can be used as a portable transmitter or in the event the automatic feature was not triggered by impact or to periodically test the function of the transmitter.

Select the "OFF" position when changing battery, when rearming the unit if it has been activated for any reason, or to discontinue transmission.

| NOTE |

If the switch has been placed in the "ON" position for any reason, the "OFF" position has to be selected before selecting "ARM". If "ARM" is selected directly from the "ON" position the unit will continue to transmit in the "ARM" position.

E.L.T. REMOTE SWITCH OPERATION

A pilot's remote ELT switch, located at the top of right hand radio panel, is provided to allow transmitter to be controlled from inside cabin. The pilot's remote switch is placarded "ON", & "ARM". The unit will start transmitting with switch in "ON" position and will stop when remote switch is returned to "ARM" position during cockpit checkout.

| NOTE |

If for any reason a test transmission is necessary, the operator must first obtain permission from a local FAA or FCC representative (or other applicable Authority) or in accordance with current regulations. Test transmission should be kept to a minimal duration. Testing of ELT should be conducted only during the first five (5) minutes after any hour and no longer than three (3) audible sweeps.

The ELT should be checked during the ground check to make certain the unit has not been accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating/warbling sound, the locator may have been activated and should be turned off immediately. Reset to "ARM" position and check again to insure against outside interference.

TABLE OF CONTENTS

TITLE.	PAGE
INTRODUCTION	8-2
GROUND HANDLING	8-3
TOWING	8-3
TIEDOWN	8-3
JACKING	8-3
SERVICING	8-4
REFUELING	8-4
ENGINE LUBRICATION	8-4
INDUCTION AIR FILTER	8-5
GEAR AND TIRES.	8-6
BATTERIES	8-6
HYDRAULIC BRAKE RESERVOIR SYSTEM.	8-7
MAINTENANCE	8-7
ENGINE PERFORMANCE CHECKS	8-7
PROPELLER CARE	8-7
EXTERIOR CARE	8-7
INTERIOR CARE	8-8
AIRPLANE FILE	8-8

INTRODUCTION

This section contains factory recommended procedures for proper ground handling, routine care and servicing of your Mooney.

It is recommended that all aircraft undergo a complete inspection (ANNUAL) each twelve calendar months. In addition to the recommended ANNUAL inspection aircraft operated commercially (for hire) should have a complete inspection every 100 hours of operation. All inspections must be performed by a designated representative of the FAA or the Aviation Authority of the country in which the aircraft is licensed.

The FAA may require other inspections by the issuance of airworthiness directives applicable to the airplane, engine, propeller and other components. It is the responsibility of the owner/operator to ensure compliance with all applicable Airworthiness Directives and recommended "MANDATORY" Mooney Aircraft Service Bulletins/Instructions. When inspections are repetitive the owner/operator should take appropriate steps to prevent inadvertent non-compliance.

Scheduling of ALL maintenance is the responsibility of the aircraft operator. A general knowledge of the aircraft is necessary to perform day-to-day service procedures and to determine when non-routine or unusual service or shop maintenance is needed.

Service information in this section of the manual is limited to service procedures which the operator will normally perform or supervise. Reference should be made to FAR Part 43 for information regarding preventive maintenance which may be performed by a U.S. licensed pilot.

It is wise to follow a planned schedule of lubrication and preventive maintenance based on climatic and flying conditions encountered in your locality.

Keep in touch with your Mooney Service Center and take advantage of his knowledge and experience. He knows your airplane and how to maintain it. Should an extraordinary or difficult problem arise concerning the repair or upkeep of your Mooney, consult the Product Support Department, Mooney Aircraft Corporation, Louis Schreiner Field, Kerrville, TX. 78028. Telephone: Area Code (830)-896-6000 (ext. 2092) or (830) 792-2092.

All correspondence regarding your airplane should include the aircraft MODEL and SERIAL NUMBER. These numbers can be found on an identification plate located on the lower aft portion of the left side of the tailcone. The aircraft Model and Serial Number must also be used when consulting either the Service & Maintenance Manual or Illustrated Parts Catalog.

Service & Maintenance, Illustrated Parts and Service Bulletin/Service Instruction Manuals for your airframe and systems (excluding Avionics & Navigation) may be obtained from your Mooney Service Center.

Avionics and Navigation Systems information should be obtained from the applicable manufacturers.

Engine information should be obtained from Teledyne Continental Motors, P.O. Box 90, Mobile, AL 36601, USA, Telephone, (205) 438-3411.

GROUND HANDLING

TOWING

For maneuvering the aircraft in close quarters, in the hangar, or on the ramp, use the manual tow bar furnished with the aircraft loose equipment. The towbar attaches to the nose gear crossbar. One man can move the aircraft providing the ground surface is relatively smooth and the tires are properly inflated.

When no towbar is available, or when assistance in moving the aircraft is required, push by hand:

- (1) on wing leading edges
and
- (2) on inboard portion of propeller blades adjacent to propeller hub.

Towing by tractor or other powered equipment is NOT RECOMMENDED.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Exercise care not to turn the nose wheel past its normal swivel angle of 11°
Left or 13° Right of center. Exceeding the turn limits shown on the turn
indicator may cause structural damage.

TIEDOWN

As a precaution against wind damage, always tie down the aircraft when parked outside. Removable wing tiedown eye-bolts, supplied with the loose equipment, screw into wing receptacles marked HOIST POINT just outboard of each main gear. Replace these eyebolts with jack point fixtures when it is necessary to lift the aircraft with jacks. The tail tiedown point is part of the tail skid.

TO TIE DOWN AIRCRAFT:

- a. Park the airplane facing the wind.
- b. Fasten the co-pilot seat belt through the flight control wheel. Pull seat belt snug so flight controls are immobilized.
- c. Fasten strong ground-anchored chain or rope to the installed wing tiedown eyebolts, and place wheel chocks fore and aft of each wheel.
- d. Fasten a strong ground-anchored chain or rope through the tail skid.

JACKING

When it is necessary to raise the aircraft off the ground:

- a. Install jack points in tiedown mounting holes outboard of each main gear.
- b. Use standard aircraft jacks at both wing hoist points (wing tiedown eyebolt receptacles) outboard of the main gears. While holding jack point in place, raise jack to firmly contact jack point.
- c. Place a jack under front jack point (Sta. — 5.51) to lift nose wheel.
- d. Raise aircraft, keeping wings as nearly level as possible.
- e. Secure safety locks on each jack.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Do not raise the aircraft on jacks out of doors when wind velocity is over 8
KTS. When lowering aircraft on jacks, bleed off pressure on all jacks
simultaneously and evenly to keep aircraft level as it is lowered.

[NOTE]

Individual wheels may be raised without raising entire aircraft. Wheels not
being raised should be chocked fore and aft.

SERVICING

REFUELING

Integrally sealed tanks, in forward, inboard sections of wing (LH & RH), carry the standard fuel quantity. With aircraft positioned on level ground, service each fuel tank after flight with 100 octane or 100LL aviation grade gasoline. The fuel tank is considered full when fuel completely covers bottom of standpipe.

The optional, visual fuel quantity indicators on top of each wing tank should be used as a reference for partial refueling only. These gauges will not indicate the tank's total capacity above 30 gallons of fuel.

Before filling fuel tanks, when planning a maximum weight flight configuration, consult the Weight & Balance Record (SECTION VI) for loading data.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Never use aviation fuel of a lower grade than 100 octane or 100 LL avgas.

Fuel samples from the sump drain of each tank should always be taken before the first flight of the day to check for water, sediment or other contamination. It is recommended that fuel samples be taken prior to each flight. Fuel samples taken immediately after refueling may not show water or sediment due to mixing action of refueling process.

//////
//WARNING//
//////

Allow five minutes after refueling for water and sediment to settle in tank and fuel drain valve before taking fuel samples or draining gascolator.

Tank sump drains are near each wing root, forward of the wheel wells. A small plastic cup is supplied as loose equipment for obtaining fuel samples. To collect a fuel sample, insert cup actuator prong into sump drain receptacle; push upward to open valve momentarily and drain fuel into cup. If water is in fuel, a distinct line separating water from gasoline will be seen through transparent cup wall. Water, being heavier, will settle to bottom of cup, while colored fuel will remain on top. Continue taking fuel samples until all water is purged from tank. Aircraft should be in a level position to prevent the possibility of any contamination not being at sump drain area.

The fuel system gascolator is on the cabin floor, forward of co-pilot's seat. To flush system and lines leading from wing tanks to selector valve, turn selector handle to the left tank position and pull fuel drain valve for about five seconds. Repeat procedure for right tank. Be sure fuel drain valve is returned to closed position and drain valve is not leaking.

--
NOTE

Use recommended engine break-in procedures as published by engine manufacturer.

ENGINE LUBRICATION

Operate and service new engine within limitations given in SECTION II and per TCM Maintenance and Operators Manual.

Before every flight, check engine oil level and replenish as necessary.

The oil filler cap access door is located in top cowl. Any lubricating oil must conform with TCM Specification MHS24 or MHS25 to be acceptable for use in engine. See TCM Maintenance and Operators Manual for specifically approved products.

New or newly overhauled engines should be operated on aviation grade mineral oil during the first 25 HOURS of operation or until oil consumption has stabilized. The aircraft is delivered from Mooney with multi-viscosity mineral oil. Single viscosity mineral oil may be added to multi-viscosity mineral oil if necessary.

The engine is equipped with an external, full flow, oil filter. Engine oil change intervals are recommended at each 50-HOUR INTERVALS if small capacity oil filter is installed. If large capacity oil filter is installed, the oil change interval may be increased to 100-HOUR INTERVALS provided the oil filter is replaced every 50 hours. The external oil filter element is recommended to be replaced at 50-HOUR INTERVALS in all cases.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

If an engine has been operating on mineral oil for several hundred hours, a change to additive oil should be undertaken with caution.

If the engine is in an extremely dirty condition, the switch to additive oil should be deferred until after engine has been overhauled. When changing from mineral oil to additive or compounded oil, after several hundred hours of operation on mineral oil, take the following precautionary steps:

- a. DO NOT MIX additive oil and mineral oil. Drain mineral oil from engine, change filter and fill with additive oil.
- b. DO NOT operate engine longer than FIVE HOURS before again changing oil.
- c. Check oil filter for evidence of sludge or plugging. CHANGE oil and REPLACE oil filter element every 10 HOURS if sludge is evident. Resume normal oil drain periods after sludge conditions improve.

Your Mooney Service Center will change engine oil in addition to performing all other service and inspection procedures needed when you bring your airplane in for its 50-hour, 100-hour, or annual inspections.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Excessive oil sludge buildup indicates that the oil system needs servicing at less than 50-hour intervals.

When changing or adding oil, the following grades of oil are recommended:

Multi-Viscosity 15W-50 or 20W-50 *

* Refer to the latest edition of TCM Maintenance and Operators Manual for approved brands of oil.

Mooney Service Center's stock approved brands of lubricating oil and all consumable materials necessary to service your airplane.

INDUCTION AIR FILTER

The importance of keeping the induction air filter clean cannot be over-emphasized. A clean filter promotes fuel economy and longer engine life. The dry-type filter can usually be washed six to eight times before replacement is necessary. Replace the paper induction air filter every 500 HOURS or at ONE YEAR intervals, whichever occurs first.

1. To clean the dry-type induction air filter:

- a. Remove engine cowling.
- b. Remove filter element.
- c. Direct a jet of air from inside of filter out (opposite normal airflow). Cover entire filter area with air jet.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Do not use a compressor unit with a nozzle pressure greater than 100 PSI.

- d. After cleaning, inspect filter for damage. Discard if filter or gasket is damaged.

[NOTE]

If filter shows an accumulation of carbon, soot, or oil, continue with cleaning steps e through h.

e. Soak filter in nonsudsing detergent for 15 minutes; then agitate filter back and forth for two to five minutes to free filter element of deposits.

[NOTE]

A Donaldson D-1400 Filter Cleaner is also recommended. Do not use solvents.

f. Rinse filter element with a stream of clear water until rinse water is clear.

g. Dry filter thoroughly. Do not use a light bulb or air heated above 180° F. for filter drying.

h. Inspect for damage and ruptures by holding light bulb inside filter. If damage is evident, replace filter with a new one.

GEAR & TIRES

The aircraft is equipped with 6-ply, Type III, standard-brand tires and tubes. Keep main gear tires inflated at 42 PSI and the nose tire at 49 PSI for maximum service life. Proper inflation will minimize tire wear and impact damage. Visually inspect tires during preflight for cracks, ruptures and worn spots. Avoid taxi speeds that require heavy braking or fast turns. Keep the gear and exposed gear retraction system components free of mud and ice to prevent retraction interference and binding. It is recommended that retraction/extension cycles (5 minimum) be done any time any tire is replaced to assure that no interference exists during the cycle.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

After any landing, other than a smooth touchdown and rollout, when aircraft is above 3200 Lbs (1,452 Kg), the aircraft should undergo the Gear System Operational Inspection as outlined in M20R Service and Maintenance Manual, No. 160, Chapter 32-30-01.

The gear warning horn may be checked in flight by retarding throttle with the gear up. The gear horn should sound with an intermittent note when throttle is positioned 1/4 to 3/8 inch from idle (while gear is up).

BATTERIES

The two 24-volt, 10 ampere-hour electrical storage batteries are located in the tailcone, aft of baggage compartment bulkhead, accessible through left and right side tailcone access panels. Check battery fluid level every 25 FLIGHT HOURS or each 30 DAYS whichever comes first.

To service batteries, remove tailcone access cover(s) to gain access to battery(ies). Check terminals and connectors for corrosion. Add distilled water to each battery cell as necessary. Keep the fluid at one-quarter inch over the separator tops.

Check fluid specific gravity for a reading of 1.265 to 1.275. A recharge is necessary when the specific gravity is 1.240 or lower. Start charging at four amperes and finish at two amperes; do not allow battery temperature to rise above 120° F. during recharging. Keep battery at full charge to prevent freezing in cold weather and to prolong service life.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Alternator and voltage regulator operate only as a one-polarity system. Be sure the polarity is correct when connecting a charger or booster battery.

If corrosion is present, flush battery, shelf and mounting area with a solution of baking soda and water. Do not allow soda to enter battery cells. Keep cable connections clean and tightly fastened and keep overflow line free of obstruction.

HYDRAULIC BRAKE RESERVOIR SYSTEM

The brake system hydraulic reservoir is located on the tailcone bulkhead, forward of the avionics components. To service, remove the left side tailcone access panel and check fluid level every 50 HOURS of operation. Fluid level should be no higher than two (2) inches (5 cm) below filler cap. Use only hydraulic fluid (Red) conforming to specification MIL-H-5606. DO NOT FILL reservoir while parking brake is set.

MAINTENANCE

ENGINE PERFORMANCE CHECKS

When the aircraft leaves the factory the IO-550-G(5) engine has been properly tuned and will perform at optimum efficiency. To insure that the engine is continuing to perform properly certain maintenance action should be performed during the 100 HOUR or ANNUAL inspection or whenever it is suspected that engine performance is not correct.

Refer to M20R SERVICE AND MAINTENANCE MANUAL or TCM maintenance manuals for specific maintenance actions to adjust engine, if necessary.

PROPELLER CARE

The high stresses to which propeller blades are subjected makes their careful inspection and maintenance vitally important. Check blades for nicks, cracks or indications of other damage before each flight. Nicks tend to cause high stress concentrations in the blades which, if ignored, may result in cracks. It is very important that all nicks and scratches be repaired prior to flight. It is not unusual for propeller blades to have some end play or fore and aft movement as a result of manufacturing tolerances in the parts. This has no adverse effect on propeller performance or operation. With the first turn, centrifugal force firmly seats the blades, rigidly and positively against the retention bearing in the propeller hub.

Preflight inspection of the propeller blades should include, in addition to the foregoing, an occasional wiping with a cloth soaked in kerosene. NEVER USE AN ALKALINE CLEANER ON THE BLADES.

Your Mooney Service Center will answer any questions you may have concerning blade repair and inspection.

EXTERIOR CARE

As with any paint applied to a metal surface, an initial curing period is necessary for developing the desired qualities of durability and appearance. Therefore, DO NOT APPLY WAX TO THE NEW AIRCRAFT EXTERIOR UNTIL TWO OR THREE MONTHS AFTER DELIVERY. Wax substances will seal paint from the air and prevent curing. Wash the exterior to prevent dirt from working into the curing paint. Hold buffing to a minimum until curing is complete and there is no danger of disturbing the undercoat.

~ ~ ~ ~ ~
~ CAUTION ~
~ ~ ~ ~ ~

Before washing the exterior, be certain the brake discs are covered, a pitot cover is in place, and all static-air buttons are masked off.

Remove grease or oil from the exterior by wiping with a cotton cloth saturated in kerosene. Flush away loose dirt and mud deposits before washing the exterior with an aircraft-type washing compound mixed in warm water. Use soft cleaning cloths or a chamols, and USE ONLY MILD LIQUID TYPE DETERGENTS, avoid harsh or abrasive detergents that might scratch or corrode the surface. It is essential that ALL CLEANING COMPOUNDS AND APPLICATION CLOTHS BE FREE OF ABRASIVES, GRIT, OR OTHER FOREIGN MATTER. Use a prewax cleaner to remove a heavy oxidation film. For nonoxidized or precleaned surfaces, apply a good exterior finish wax recommended for protection of urethane enamel finishes. Carefully follow the manufacturer's instructions. A heavier coating of wax on the

If fuel, hydraulic fluid or any other dye-containing substance is found on the exterior paint, wash the area at once to prevent staining. Immediately flush away spilled battery acid and treat the area with a baking soda-and-water solution, followed by a thorough washing with a mild aircraft detergent and warm water.

Before wiping windows or windshield, flush exterior with clear water to remove particles of dirt. Household window cleaning compounds should NOT be used; some contain abrasives or solvents which could harm plexiglas. Any commercial anti-static plexiglass cleaner is recommended for cleaning and polishing the windshield and windows.

INTERIOR CARE

Normal household cleaning practices are recommended for routine interior care. Frequently vacuum clean seats, carpets, fabric, side panels and headliner to remove as much surface dust and dirt as possible. For cleaning Izit Leather side panels and wool upper cabin panels, use Woolite, mixed 1 part Woolite to 3 parts water. Other type cleaners are not recommended at this time.

~ CAUTION ~

Never use benzene, carbon tetrachloride, acetone, or gasoline for cleaning plexiglas or interior panels. Carefully follow the manufacturer's instructions when using commercial cleaning and finishing compounds.

Foam type shampoos may be used for routine cleaning of carpets. To minimize carpet wetting, keep foam type cleaners as dry as possible and gently rub in circles. Use vacuum cleaner to remove foam and dry the materials. Grease spots, on carpet, should be removed with jelly-type spot lifter. Do not saturate carpet with a solution which could damage backing materials.

Use a damp cloth to clean metal surfaces.

AIRPLANE FILE

Certain miscellaneous data, information and licenses are a part of the airplane file. The following is a checklist of documents that must either be carried in the airplane or available on request of the proper authority.

1. To be displayed in the airplane at all times:
 - a. Aircraft Airworthiness Certificate (FAA Form 8100-2).
 - b. Aircraft Registration Certificate (FAA Form 8050-3).
 - c. Aircraft Radio Station License, if transmitter installed (FCC Form 556).
2. To be carried in the airplane during all flight operations:
 - a. Pilot's Operating Handbook (including FAA Approved Flight Manual).
 - b. Weight and Balance, and associated papers (latest copy of the Repair and Alteration Form, FAA Form 337, if applicable).
 - c. Equipment List.

| NOTE |

The original weight and balance data and Equipment List are contained in SECTION VI of this manual. This manual is supplied with each new airplane purchased from Mooney Aircraft Corporation. It is recommended that copies of SECTION VI be made and stored in a safe place.

3. To be made available upon request:
- a. Airplane Log Book.
 - b. Engine Log Book.

Since the Regulations of other nations may require other documents and data, owners of airplanes not registered in the United States should check with their own aviation officials to determine their individual requirements.

BLANK

SECTION IX SUPPLEMENTAL DATA

TITLE	PAGE
INTRODUCTION	9-3

SUPPLEMENT INSERTED DATE

9 - 1

**MOONEY
MODEL M20R**

.DATE

[illegible]

**MOONEY
MODEL M20R**

**SECTION IX
SUPPLEMENTAL DATA**

INTRODUCTION

FAA approved data pertaining to Limitations, Normal Procedures, Emergency Procedures, and effects on performance for certain optional equipment installed in the airplane are contained in this section. Commonly installed items of optional equipment whose function and operation do not require detailed instructions are described by SECTION VII.

The Supplements are Approved by the FAA prior to incorporation into the Airplane Flight Manual.

SECTION IX
SUPPLEMENTAL DATA

MOONEY
MODEL M20R

BLANK

MOONEY AIRCRAFT CORPORATION
PO Box 72
KERRVILLE, TX 78029-0072

FAA APPROVED

AIRPLANE FLIGHT MANUAL SUPPLEMENT

FOR

MOONEY M20J, M20K, M20M, M20R

WITH

PRECISE FLIGHT, INC.

ELECTRIC PRECISE SPEEDBRAKE SYSTEM (SBS)
(WITH CONTROL WHEEL SWITCH OPERATION)

REG. NO. ~~C-BVZY~~ 0Y-ELW

SERIAL NO. 29-0045



This Supplement must be attached to the applicable FAA Approved Airplane Flight Manual when the Precise Flight, Inc. Electric Precise Speedbrake System (SBS), with control wheel switch operation, is installed in accordance with Mooney Aircraft Corporation Drawing number 950271. The information contained herein supplements or supersedes the basic manual only in those areas listed. For limitation, procedures and performance information not contained in this Supplement, consult the Basic Airplane Flight Manual.

FAA APPROVED: Henry A. Armstrong

Henry A. Armstrong, Manager
Aircraft Certification Office
FEDERAL AVIATION ADMINISTRATION
Fort Worth, TX.
76193-0150

Date: 12 - 8 - 89
Rev. A 7-94

P. O. BOX 72

Kerrville, Texas 78029-0072

LOG OF REVISIONS

Revision Number	Revision Pages	Description of Revisions	FAA Approved	Date
A	ALL PAGES	Added M20R to Heading of all pages.	<i>[Signature]</i>	7/29/99

The revised portions of affected pages are indicated by vertical black lines in the margin.

SECTION I - GENERAL

The electric Precise Speedbrake System (SBS) may be installed to provide expedited descents at low cruise power, glidepath control on final approach, "lift-dumping" in the landing roll and measure of protection against excessive speed build-up in an inadvertent spiral dive.

The speedbrake system consists of wing mounted Speedbrakes, left and right wing, with internal gear motor actuators. Each Speedbrake unit is connected by a wire conduit to a central logic control unit and the Speedbrake Actuator Switch located on the Pilot's control wheel. Both receive electrical power from the aircraft electrical buss through a panel mounted circuit breaker.

The SPEEDBRAKE SYSTEM push button switch located on the left horn of the pilot's control wheel features a push/ON, retained position, switch to deploy the speedbrakes. To retract, push one additional time and release to OFF position.

SECTION II - OPERATING LIMITATIONS

AIRSPEEDS		Same limitations as basic airplane.
DESCENT IN ICING CONDITIONS		SPEEDBRAKES RETRACTED
PLACARDS		

SPEEDBRAKE

Located on the circuit breaker panel (included on the aircraft C/B panel placard when speedbrake system is installed).

SPEEDBRAKE

Located in front of and in full view of the pilot near the panel mounted, individual annunciator light on aircraft that do not incorporate the "SPEEDBRAKE" legend in the standard annunciator panel. These aircraft will have no individual annunciator light and therefore no separate placard.

SPEEDBRAKE EQUIPPED: FOR OPERATING INSTRUCTION AND LIMITATIONS SEE SUPPLEMENT IN AIRPLANE FLIGHT MANUAL.

Located in front of and in full view of the pilot.

SECTION III - EMERGENCY PROCEDURES

FORCED LANDING		
AFTER ENGINE FAILURE		SPEEDBRAKES RETRACTED
	 or as required to modulate glidepath with use of speedbrakes.	

SPINS		SPEEDBRAKES RETRACTED
-------	-----------	-----------------------

DITCHING		SPEEDBRAKES RETRACTED
----------	-----------	-----------------------

DISABLED ELEVATOR SYSTEM		SPEEDBRAKES RETRACTED
--------------------------	-----------	-----------------------

ELECTRICAL FAILURE		SPEEDBRAKES RETRACTED
--------------------	-----------	-----------------------

SECTION IV - NORMAL PROCEDURES

BEFORE TAKEOFF

SPEEDBRAKE system Switch Push once "ON"
to deploy speedbrakes. Verify deployed (AMBER light illuminated)
SPEEDBRAKE system Switch Push again "OFF"
to retract speedbrakes. Verify retracted (AMBER light extinguished)

WARNING

If speedbrakes do not fully deploy or do not operate simultaneously (deploy or retract) DO NOT OPERATE SPEEDBRAKES IN FLIGHT.

DURING TAKEOFF

SPEEDBRAKE SYSTEM RETRACTED during takeoff roll.

ENROUTE

SPEEDBRAKE SYSTEM NORMALLY RETRACTED

EXPEDITED DESCENTS

Select 2200 RPM and approximately 22 inches manifold pressure to keep engine within recommended operating ranges.

Speedbrake switch ON to deploy speedbrakes (below V_{NE}).

Speedbrake switch OFF to retract speedbrakes (as needed during descent).

FINAL APPROACH

Fly a high base leg and final approach. Extend wing flaps as desired and place the SPEEDBRAKE SYSTEM switch ON to deploy speedbrakes.

NOTE

The SPEEDBRAKE SYSTEM switch may be operated intermittently, as required, to modulate the glidepath.

Maintain an 85 KIAS approach speed by establishing a moderately steep, nose down attitude.

NOTE

Increase the aircraft nose down attitude in anticipation of increased drag as the SPEEDBRAKE SYSTEM is actuated.

LANDING

Initiate landing flare at a slightly higher altitude above runway and rotate aircraft more rapidly than usual to perform a tail-low touchdown.

CAUTION

If the landing rate of descent is excessive, place SPEEDBRAKE SYSTEM switch OFF to retract the speedbrakes; add power as required to reduce the rate of descent.

BALKED LANDING (Go Around)

Advance throttle, SPEEDBRAKE SYSTEM - RETRACTED, retract wing flaps.

SECTION V thru X

No Change with Speedbrakes retracted.

MOONEY AIRCRAFT CORPORATION
P. O. BOX 72
KERRVILLE, TX. 78029-0072

FAA APPROVED

AIRPLANE FLIGHT MANUAL SUPPLEMENT

FOR

MOONEY MODEL M20M, M20R

WITH

KING 150 SERIES FLIGHT CONTROL SYSTEM

Reg. No. ~~C-BVZY~~

Ser. No. 29-0045

The supplement must be attached to the FAA Approved Airplane Flight Manual when the King 150 Series Automatic Flight Control System is installed in accordance with Mooney drawing number 830081. The information contained herein supplements or supersedes the basic manual only in those areas listed herein. For limitations, procedures and performance information not contained in this supplement, consult the basic Airplane Flight Manual.

FAA APPROVED: *BR Parker*

Henry A. Armstrong, Mgr.
Aircraft Certification Office
FEDERAL AVIATION ADMINISTRATION
Fort Worth, TX
76193-0150

DATE: 7 - 21 - 89
Revision A 7 - 94

Page 1 of 16

MOONEY AIRCRAFT CORPORATION

P. O. BOX 72

Kerrville, Texas 78029-0072

LOG OF REVISIONS

Revision Number	Revision Pages	Description of Revisions	FAA Approved	Date
A	Title Page, LOEP, Log of Revisions All Pages	Added M20R application Added M20R to Heading of all pages.	<i>[Signature]</i>	<i>7/27/94</i>

The revised portions of affected pages are indicated by vertical black lines in the margin.

SECTION I - GENERAL

This manual is provided to acquaint the pilot with the limitations as well as normal and emergency operating procedures of the King 150 Series Automatic Flight Control Systems. The limitations presented are pertinent to the operation of the 150 System as installed in the Mooney Model M20M & M20R airplane; the Flight Control Systems must be operated within the limitations herein specified.

The 150 Series AFCS is certified in this airplane with 2 axis control, pitch and roll as described in Figures 1 thru 8.

The 150 Series AFCS has an electric pitch trim system which provides autotrim during autopilot operation and manual electric trim for the pilot. The trim system is designed to withstand any single inflight malfunction. Trim faults are visually and aurally annunciated.

A lockout device prevents autopilot engagement until the system has been successfully preflight tested.

The following conditions will cause the Autopilot to automatically disengage:

A. Power failure.

B. Internal Flight Control System failure.

C. With the KCS 55A Compass System, a loss of compass valid (displaying HDG flag) disengages the Autopilot when a mode using heading information is engaged. With the HDG flag present, the Autopilot may be re-engaged in the basic wings level mode along with any vertical mode.

D. Roll rates in excess of 14° per second will cause the autopilot to disengage except when the CWS switch is held depressed.

E. Pitch rates in excess of 5° per second will cause the autopilot to disengage except when the CWS switch is held depressed.




FIGURE 1 - KC 192 AUTOPILOT & FLIGHT DIRECTOR COMPUTER




FIGURE 2 - KC 191 AUTOPILOT COMPUTER

1. KFC 150 SYSTEM KC 192 AUTOPILOT COMPUTER - Complete Flight Director and Autopilot computer, including system mode annunciators and system controls.
2. (Not used)
3. MODE ANNUNCIATORS - Illuminate when a mode is selected by the corresponding mode selector button (PUSH ON - PUSH OFF).
4. GLIDESLOPE (GS) ANNUNCIATOR - Illuminates continuously whenever the autopilot is coupled to the glideslope signal. The GS annunciator will flash if the glideslope signal is lost. (GS flag in CDI or absence of glideslope pointers in KI 525A). The autopilot reverts to pitch attitude hold operation. If a valid glideslope signal returns within six seconds, the autopilot will automatically recouple in the GS mode. If the valid signal does not return within six seconds, the autopilot will remain in pitch attitude hold mode until such time that a valid glideslope returns and the aircraft passes thru the glideslope. At that point GS couple will re-occur.
5. TRIM WARNING LIGHT (TRIM) - Illuminates continuously whenever trim power is not on or the system has not been preflight tested. The TRIM warning light illuminates and is accompanied by an audible warning whenever a manual trim fault is detected. The Manual Trim System is monitored for the Trim Servo running without a command. The TRIM warning light will illuminate and be accompanied by an audible warning whenever an autotrim failure occurs. The autotrim system is monitored for the following failures: trim servo running without a command; trim servo not running when commanded to run; trim servo running in the wrong direction.
6. AUTOPILOT (AP) ANNUNCIATOR - Illuminates continuously whenever the autopilot is engaged. Flashes approximately 12 times whenever the autopilot is disengaged (an aural alert will also sound for 2 seconds).
7. AUTOPILOT ENGAGE (AP ENG) BUTTON - When pushed, engages autopilot if all logic conditions are met. When pushed again, disengages autopilot.
8. PREFLIGHT TEST (TEST) BUTTON - When momentarily pushed, initiates preflight test sequence which automatically turns on all annunciator lights, tests the roll and pitch rate monitors, tests the autotrim fault monitor, checks the manual trim drive voltage and tests all autopilot valid and dump logic. If the preflight is successfully passed, the AP annunciator light will flash for approximately 6 seconds (an aural tone will also sound simultaneously with the annunciator flashes). The autopilot cannot be engaged until the autopilot preflight tests are successfully passed.
9. BACK COURSE APPROACH (BC) MODE SELECTOR BUTTON - When pushed will select the Back Course Approach mode. This mode functions identically to the approach mode except that response to LOC signals is reversed. Glideslope coupling is inhibited in the Back Course Approach mode.
10. APPROACH (APR) MODE SELECTOR BUTTON - When pushed, will select the Approach mode. This mode provides all angle intercept (with HSI) or a fixed angle intercept of 45° (with DG); automatic beam capture and tracking of VOR, RNAV or LOC signals plus Glideslope coupling in the case of an ILS. The tracking gain of the APR mode is greater than the gain in the NAV mode. The APR annunciator on the Autopilot Computer will flash until the automatic capture sequence is initiated. At beam capture, APR will annunciate without flashing.
11. NAVIGATION (NAV) MODE SELECTOR BUTTON - When pushed will select the Navigation mode. The mode provides all angle intercept (with HSI) or a fixed angle intercept of 45° (with DG), automatic beam capture and tracking of VOR, RNAV or LOC signals. The NAV annunciator on the Autopilot Computer will flash until the automatic capture sequence is initiated. At beam capture, NAV will annunciate without flashing.
12. HEADING (HDG) MODE SELECTOR BUTTON - When pushed will select the Heading mode, which commands the airplane to turn to and maintain the heading selected by the heading bug on the DG or HSI. A new heading may be selected at any time and will result in the airplane turning to the new heading with a maximum bank angle of about 22°. Selecting HDG mode will cancel NAV, APR or BC track modes.

13. ALTITUDE HOLD (ALT) MODE SELECTOR BUTTON - When pushed will select the Altitude Hold mode, which commands the airplane to maintain the pressure altitude existing at the moment of selection. Engagement may be accomplished in climb, descent, or level flight. In the APR mode, altitude hold will automatically disengage when the glideslope is captured.

14. FLIGHT DIRECTOR (FD) MODE SELECTOR BUTTON - When pushed will select the Flight Director mode (with KC 192 Autopilot Computer only), bringing the Command Bar in view on the KI 256 and will command wings level and pitch attitude hold. The FD mode must be selected prior to Autopilot engagement.

15. VERTICAL TRIM CONTROL - A spring loaded to center rocker switch which will provide up or down pitch command changes: while in ALT will adjust altitude at rate of about 500 fpm; when not in ALT will adjust pitch attitude at a rate of .7 deg/sec. Will cancel GS couple. The aircraft must pass through the glideslope again to allow GS recouple.

16. KAP 150 SYSTEM KC 191 AUTOPILOT COMPUTER - Complete Autopilot computer, including system mode annunciators and system controls.

17. thru 21. (Not used)




FIGURE 3 - AUTOPILOT CONTROL WHEEL SWITCH CAP

22. AUTOPILOT CONTROL WHEEL SWITCH CAP - Switch assembly mounted on the pilot's control wheel associated with the autopilot and manual electric trim systems.

23. AUTOPILOT DISCONNECT/TRIM INTERRUPT (A/P DISC/TRIM INTER) Switch - When depressed will disengage the autopilot and cancel all operating Flight Director modes. When depressed and held will interrupt all electric trim power (stop trim motion), disengage the autopilot and cancel all operating Flight Director modes.

24. CONTROL WHEEL STEERING (CWS) BUTTON - When depressed, allows pilot to manually control the aircraft (disengages the pitch and roll servos) without cancellation of any of the selected modes. Will engage the Flight Director mode if not previously engaged. Automatically synchronizes the Flight Director/Autopilot to the pitch attitude present when the CWS switch is released, or to the present pressure altitude when operating in the ALT hold mode. Will cancel GS couple. The aircraft must pass through the glideslope again to allow GS recouple.

25. **MANUAL ELECTRIC TRIM CONTROL SWITCHES** - A split switch unit in which the left half provides power to engage the trim servo clutch and the right half to control the direction of motion of the trim servo motor. Both halves of the split trim switch must be actuated in order for the manual trim to operate in the desired direction. When the autopilot is engaged, operation of the manual electric trim will automatically disconnect the autopilot.

26. **KI 256 FLIGHT COMMAND INDICATOR (FCI)** - Displays airplane attitude as a conventional attitude gyro and displays commands for flight director operation. The gyro is air driven.




FIGURE 4 - KI 256 FLIGHT COMMAND INDICATOR

27. **DECISION HEIGHT (DH) ANNUNCIATOR LIGHT** - Optional light for use with the aircraft's optional radar altimeter.

28. **ROLL ATTITUDE INDEX** - Displays airplane roll attitude with respect to the roll attitude scale.

29. **ROLL ATTITUDE SCALE** - Scale marked at 0, +/-10, 20, 30, 60, and 90°.

30. **PITCH ATTITUDE SCALE** - Moves with respect to the symbolic airplane to present pitch attitude. Scale graduated at 0, +/-5, 10, 15, 20 and 25°.

31. **COMMAND BAR** - Displays computed steering commands referenced to the symbolic airplane. The command bar is visible only when FD mode is selected. The command bar will be biased out of view whenever the system is invalid or a Flight Director mode is not engaged.

32. **FCI SYMBOLIC AIRPLANE** - Airplane pitch and roll attitude is displayed by the relationship between the fixed symbolic airplane and the movable background. During flight director operation, the symbolic airplane is flown to align it with the command bar to satisfy the flight director commands.

33. **KG 258 VERTICAL GYRO** - Displays airplane attitude as a conventional attitude gyro. The gyro is air driven.




FIGURE 5 - KG 258 VERTICAL GYRO

34. SYMBOLIC AIRPLANE - Serves as a stationary symbol of the aircraft. Aircraft pitch and roll attitudes are displayed by the relationship between the fixed symbolic aircraft and the movable background.

35. SYMBOLIC AIRCRAFT ALIGNMENT KNOB - Provides manual positioning of the symbolic aircraft for level flight under various load conditions.

36. KI 525A HORIZONTAL SITUATION INDICATOR (HSI) - Provides a pictorial presentation of aircraft deviation relative to VOR radials or localizer beams. It also displays glideslope deviations and gives heading reference with respect to magnetic north.

37. NAV FLAG - Flag is in view when the NAV receiver signal is inadequate. When a NAV flag is present in the navigation indicator (CDI or KI 525A) the autopilot operation is not affected. The pilot must monitor the navigation indicators for NAV flags to insure that the Autopilot and/or Flight Director and tracking valid navigation information.

38. LUBBER LINE - Indicates aircraft magnetic heading on compass card (45).

39. HEADING WARNING FLAG (HDG) - When flag is in view the heading display is invalid. If a HDG flag appears and a lateral mode (HDG, NAV, APR or APR BC) is selected, the Autopilot will be disengaged. The Autopilot may be re-engaged in the basic wings level mode along with any vertical mode. The CWS switch would be used to manually maneuver the aircraft laterally.

40. COURSE BEARING POINTER - Indicates selected VOR course or localizer course on compass card (45). The selected VOR radial or localizer heading remains set on the compass card when the compass card (45) rotates.

41. TO/FROM INDICATOR FLAG - Indicates direction of VOR station relative to selected course.

42. DUAL GLIDESLOPE POINTERS - Indicate on glideslope scale (43) aircraft displacement from glideslope beam center. Glideslope pointers in view indicate a usable glideslope signal is being received.

43. GLIDESLOPE SCALES - Indicate displacement from glideslope beam center. A glideslope deviation bar displacement of 2 dots, represents full scale (0.7°) deviation above or below glideslope beam centerline.





FIGURE 6 - KI 525A HSI

44. HEADING SELECTOR KNOB  - Positions heading bug (49) on compass card (45) by rotating the heading selector knob. The Bug rotates with the compass card.

45. COMPASS CARD - Rotates to display heading of airplane with reference to lubber line (38) on HSI or DG.




FIGURE 7 - KG 107 DG

46. **COURSE SELECTOR KNOB** - Positions course bearing pointer (40) on the compass card (45) by rotating the course selector knob.

47. **COURSE DEVIATION BAR (D-BAR)** - The center portion of omni bearing pointer moves laterally to pictorially indicate the relationship of aircraft to the selected course. It indicates degrees of angular displacement from VOR radials and localizer beams, or displacement in nautical miles from RNAV courses.

48. **COURSE DEVIATION SCALE** - A course deviation bar displacement of 5 dots represents full scale (VOR = ± 10 , LOC = $\pm 2 \frac{1}{2}$, RNAV = 5NM, RNAV APR = $1 \frac{1}{4}$ NM) deviation from beam centerline.

49. **HEADING BUG** - Moved by  knob (44) to select desired heading.

50. **KG 107 NON-SLAVED DIRECTIONAL GYRO (DG)** - Provides a stable visual indication of aircraft heading to the pilot. The gyro is air driven.

51. **GYRO ADJUSTMENT KNOB (PUSH)** - When pushed in, allows the pilot to manually rotate the gyro compass card (45) to correspond with the magnetic heading indicated by the magnetic compass. The unslaved compass card must be manually reset periodically to compensate for precessional errors in the gyro.




FIGURE 8 - KI 204/206 VOR/LOC/GS INDICATOR

52. **KI 204/206 VOR/LOC/GLIDESLOPE INDICATOR** - Provides rectilinear display of VOR/LOC and Glideslope deviation.

53. **COURSE INDEX** - Indicates selected VOR course.

54. **COURSE CARD** - Indicates selected VOR course under course index.

55. **GLIDESLOPE DEVIATION NEEDLE** - Indicates deviation from ILS glideslope.

56. **GLIDESLOPE SCALE** - Indicates displacement from glideslope beam center. A glideslope deviation needle displacement of 5 dots, represents full scale (0.7°) deviation above or below glideslope beam centerline.

- 57. RECIPROCAL COURSE INDEX - Indicates reciprocal of selected VOR course.
- 58. OMNI BEARING SELECTOR (OBS) KNOB - Rotates course card to selected course.
- 59. COURSE DEVIATION NEEDLE - Indicates course deviation from selected omni course or localizer centerline.
- 60. GLIDESLOPE (GS) FLAG -Flag is in view when the GS receiver signal is inadequate.

The airplane MASTER SWITCH function is unchanged and can be used in an emergency to shut off electrical power to all flight control systems while the problem is being isolated.

The RADIO MASTER switch supplies power to the avionics bus bar of the radio circuit breakers and the autopilot circuit breaker.

The following circuit breakers are used to protect the following elements of the King 150 Series Autopilot:

LABEL	FUNCTION
AUTOPILOT/TRIM	Supplies power to the KC 192 or the KC 191 Computer, the autopilot pitch and roll servos, and the Elev Trim Switch/Circuit Breaker.
RADIO MASTER	Switch /circuit breaker supplies power to the avionics bus.
ELEV TRIM	Switch/circuit breaker supplies power to the autotrim and manual electric pitch trim systems.
HSI	Supplies power to the optional KCS 55A Compass System.
AUTOPILOT/ALERT	Supplies power to the KAA 15 Aural Alert Box.

SECTION II - LIMITATIONS

- A. During autopilot operation, a pilot with seat belt fastened must be seated at the left pilot position.
- B. The autopilot must be OFF during takeoff and landing.
- C. The system is approved for Category I operation only (Approach mode selected).
- D. Do not operate autopilot with flaps extended beyond the take-off position.
- E. Autopilot airspeed limitations: Maximum 180 KIAS; minimum 80 KIAS.

NOTE

IN ACCORDANCE WITH FAA RECOMMENDATION, USE OF " ALTITUDE HOLD" MODE IS NOT RECOMMENDED DURING OPERATION IN SEVERE TURBULENCE.

Placards:

NONE

SECTION III - EMERGENCY PROCEDURES

- A. In case of Autopilot malfunction: (Accomplish Items 1 and 2 simultaneously).
 - 1. Airplane Control Wheel - GRASP FIRMLY and regain aircraft control.
 - 2. A/P DISC/TRIM INTER switch - PRESS and HOLD.
 - 3. A/P DISC/TRIM INTER switch - RELEASE while observing pitch trim wheel. If pitch trim wheel is in motion, follow the Electric Trim Malfunction Procedure.

B. In case of Electric Trim Malfunction (either manual electric or autotrim):

1. A/P DISC/TRIM INTER switch - PRESS and HOLD throughout recovery.
2. ELEV TRIM switch - OFF.
3. Aircraft - RETRIM manually.

CAUTION

WHEN DISCONNECTING THE AUTOPILOT AFTER A TRIM MALFUNCTION, HOLD THE CONTROL WHEEL FIRMLY; UP TO 45 POUNDS OF FORCE ON THE CONTROL WHEEL MAY BE NECESSARY TO HOLD THE AIRCRAFT LEVEL.

Maximum Altitude losses due to autopilot malfunction:

<u>Configuration</u>	<u>Alt. Loss</u>
Cruise, Climb, Descent	190 FT
Maneuvering	90 FT
APPR	70 FT

SECTION IV - NORMAL PROCEDURES

A. PREFLIGHT (Perform prior to each flight)

1. GYROS - Allow 3-4 minutes for gyros to come up to speed.
2. RADIO MASTER - ON
3. ELEV TRIM - ON
4. PREFLIGHT TEST Button - PRESS momentarily and NOTE:
 - a. All annunciator lights on (TRIM annunciator flashing).
 - b. After approximately 5 seconds, all annunciator lights off, except AP, which will flash approximately 12 times and then remain off.
 - c. Note Aural Alert tone sounds with the flashing AP light.

NOTE

IF TRIM WARNING LIGHT STAYS ON THEN THE AUTOTRIM DID NOT PASS PREFLIGHT TEST. THE AUTOPILOT CIRCUIT BREAKER SHOULD BE PULLED.

(THE AUTOPILOT AND MANUAL ELECTRIC TRIM WILL BE INOPERATIVE).

5. MANUAL ELECTRIC TRIM - TEST as follows:

- a. Actuate left side of split switch unit to the fore and aft positions. The trim wheel should not move on its own. Rotate the trim wheel manually against the engaged clutch to check the pilot's trim overpower capability.
- b. Actuate right side of split switch unit to the fore and aft positions. Trim wheel should not move on its own and normal trim wheel force is required to move it manually.
- c. Press the A/P DISC/TRIM INTER switch down and hold. Manual Electric Trim should not operate either nose up or nose down.

6. FLIGHT DIRECTOR (KFC 150 Only) - ENGAGE by pressing FD or CWS button.

7. AP ENG Button - PRESS to engage autopilot.

8. Flight Controls - MOVE fore, aft, left and right to verify that the autopilot can be overpowered.
9. A/P DISC/TRIM INTER switch - PRESS. Verify that the autopilot disconnects and all flight director modes are canceled.
10. TRIM - SET to take off position.

B. AUTOPILOT OPERATION

1. Before takeoff

A/P DISC/TRIM INTER switch - PRESS.

2. Inflight Autopilot Engagement

a. FD Mode Selector Button (KFC 150 Only) - PRESS.

b. AP ENG Button - PRESS. Note AP annunciator on. If no other modes are selected the autopilot will operate in wings level and pitch attitude hold.

CAUTION

DO NOT HELP THE AUTOPILOT AS THE AUTOPILOT WILL RUN THE PITCH TRIM TO OPPOSE YOUR HELP.

3. Climb or Descent

a. Using CWS

1) CWS Button - PRESS and Move aircraft nose to the desired attitude.

2) CWS Button - RELEASE. Autopilot will maintain aircraft pitch attitude up to the pitch limits of +15 or -10.

b. Using Vertical Trim.

1) VERTICAL TRIM Control - PRESS either up or down to modify aircraft attitude at a rate of .7 deg/sec. up to the pitch limits of +15° or -10°.

2) VERTICAL TRIM Control - RELEASE when desired aircraft attitude is reached. The autopilot will maintain the desired pitch attitude.

4. Altitude Hold

a. ALT Mode Selector Button - PRESS. Note ALT mode annunciator ON. Autopilot will maintain the selected pressure altitude.

b. Change selected altitudes

1) Using CWS (recommended for altitude changes greater than 100 ft.).

a) CWS Button - PRESS and fly aircraft to desired pressure altitude.

b) CWS Button - RELEASE when desired pressure altitude is reached. The autopilot will maintain the desired pressure altitude.

2) Using Vertical Trim (Recommended for altitude changes less than 100 ft.)

a) VERTICAL TRIM Control - PRESS either up or down. Vertical Trim will seek an altitude rate of change of about 500 fpm.

b) VERTICAL TRIM Control - RELEASE when desired pressure altitude is reached. The autopilot will maintain the desired pressure altitude.

5. Heading Changes

a. Manual Heading Changes.

- 1) CWS Button - PRESS and MANEUVER aircraft to the desired heading.
- 2) CWS Button - RELEASE. Autopilot will maintain aircraft in wings level attitude.

NOTE

AIRCRAFT HEADING MAY CHANGE IN THE WINGS LEVEL MODE DUE TO AN AIRCRAFT OUT OF TRIM CONDITION.

b. Heading Hold

- 1) HEADING Selector Knob - SET BUG to desired heading.
- 2) HDG Mode Selector Button - PRESS. Note HDG mode annunciator ON. Autopilot will automatically turn the aircraft to the selected heading.

c. Command Turns (Heading Hold mode ON)

- 1) HEADING Selector Knob - MOVE BUG to the desired heading. Autopilot will automatically turn the aircraft to the new selected heading.

6. NAV Coupling

a. When equipped with HSI.

- 1) Course Bearing Pointer - SET to desired course.

NOTE

WHEN EQUIPPED WITH NAV 1/NAV 2 SWITCHING AND NAV 2 IS SELECTED, SET OBS TO THE DESIRED COURSE.

- 2) HEADING Selector Knob - SET BUG to provide desired Intercept angle.
- 3) NAV Mode Selector Button - PRESS.

a) If the Course Deviation Bar is greater than 2 to 3 dots: the aircraft will continue in HDG mode (or wings level if HDG not selected) with the NAV annunciator flashing; when the computed capture point is reached the HDG will disengage, the NAV annunciator will illuminate steady and the selected course will be automatically captured and tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting NAV mode; the NAV annunciator will illuminate steady and the capture/track sequence will automatically begin.

b. When equipped with DG.

- 1) OBS Knob - SELECT desired course.
- 2) NAV Mode Selector Button - PRESS.
- 3) HEADING Selector Knob - ROTATE BUG to agree with OBS course.

NOTE

WHEN NAV IS SELECTED, THE LATERAL OPERATING MODE WILL CHANGE FROM HDG (IF SELECTED) TO WINGS LEVEL FOR 5 SECONDS. A 45° INTERCEPT ANGLE WILL THEN BE AUTOMATICALLY ESTABLISHED BASED ON THE POSITION OF THE BUG.

a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate HDG mode (unless HDG not selected) and NAV flashing; when the computed capture point is reached the HDG annunciator will go out, the NAV annunciator will illuminate steady and the selected course will be automatically captured and tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting NAV mode; the NAV annunciator will illuminate steady and the capture/track sequence will automatically begin.

7. Approach (APR) Coupling.

a. When equipped with HSI.

1) COURSE Bearing Pointer - SET to desired course.

NOTE

**WHEN EQUIPPED WITH NAV 1/NAV 2 SWITCHING AND NAV 2 IS SELECTED,
SET OBS TO THE DESIRED COURSE.**

2) HEADING Selector Knob - SET BUG to provide desired intercept angle.

3) APR Mode Selector Button - PRESS.

a) If the Course Deviation Bar is greater than 2 to 3 dots: the aircraft will continue in HDG mode (or wings level if HDG not selected) with the APR annunciator flashing; when the computed capture point is reached the HDG will disengage, the APR annunciator will illuminate steady and the selected course will be automatically captured and tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting APR mode; the APR annunciator will illuminate steady and the capture/track sequence will automatically begin.

c) When equipped with DG.

1) OBS Knob - SELECT desired approach course.

2) APR Mode Selector Button - PRESS.

3) HEADING Selector Knob - ROTATE Bug to agree with OBS course.

NOTE

**WHEN APR IS SELECTED, THE LATERAL OPERATING MODE WILL CHANGE
FROM HDG (IF SELECTED) TO WINGS LEVEL FOR 5 SECONDS. A 45°
INTERCEPT ANGLE WILL THEN BE AUTOMATICALLY ESTABLISHED BASED
ON THE POSITION OF THE BUG.**

a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate HDG mode (unless HDG not selected) and APR flashing; when the computed capture point is reached the HDG annunciator will go out, the APR annunciator will illuminate steady and the selected course will be automatically captured and tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting APR mode; the APR annunciator will illuminate steady and the capture/track sequence will automatically begin.

8. BC Approach Coupling.

a. When equipped with HSI.

1) COURSE Bearing Pointer - SET to the ILS front course Inbound heading.

NOTE

**WHEN EQUIPPED WITH NAV 1/NAV 2 SWITCHING AND NAV 2 IS SELECTED,
SET OBS TO THE ILS FRONT COURSE INBOUND HEADING.**

2) HEADING Selector Knob - SET BUG to provide desired intercept angle.

3) BC Mode Selector Button - PRESS.

a) If the Course Deviation Bar is greater than 2 to 3 dots: the aircraft will continue in HDG mode (or wings level if HDG not selected) with BC annunciated steady and APR annunciator flashing; when the computed capture point is reached the HDG will disengage, and the BC and APR annunciators will illuminate steady and the selected course will be automatically captured and tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting BC mode; the APR BC annunciator will illuminate steady and the capture/track sequence will automatically begin.

b. When equipped with DG.

1) OBS Knob - SELECT the ILS front course inbound heading.

2) BC Mode Selector button - PRESS.

3) HEADING Selector Knob - ROTATE Bug to the ILS front course inbound heading.

NOTE

**WHEN BC IS SELECTED, THE LATERAL OPERATING MODE WILL CHANGE
FROM HDG (IF SELECTED) TO WINGS LEVEL FOR 5 SECONDS. A 45°
INTERCEPT ANGLE WILL THEN BE ESTABLISHED BASED ON THE
POSITION OF THE BUG.**

a) If the D-Bar is greater than 2 to 3 dots: the autopilot will annunciate HDG (unless HDG not selected) and BC modes with APR flashing; when the computed capture point is reached the HDG annunciator will go out, the BC and APR annunciators will illuminate steady and the selected course will be automatically captured tracked.

b) If the D-Bar is less than 2 to 3 dots: the HDG mode will disengage upon selecting BC mode; the BC and APR annunciators will illuminate steady and the capture/track sequence will automatically begin.

9. Glideslope Coupling.

NOTE

**GLIDESLOPE COUPLING IS INHIBITED WHEN OPERATING IN NAV OR APR
BC MODES. GLIDESLOPE COUPLING OCCURS AUTOMATICALLY IN THE
APR MODE.**

a. APR Mode - ENGAGED.

b. At glideslope centering - NOTE GS annunciator ON.

NOTE

**AUTOPILOT CAN CAPTURE GLIDESLOPE FROM ABOVE OR BELOW THE
BEAM WHILE OPERATING IN EITHER PITCH ATTITUDE HOLD OR ALT HOLD
MODES.**

10. Missed Approach.

a. A/P DISC/TRIM INTER switch - PRESS to disengage AP.

b. MISSED APPROACH - EXECUTE.

c. CWS Button - PRESS (KFC 150 ONLY) as desired to activate FD mode during Go-Around maneuver.

d. AP ENG Button - PRESS (if AP operation is desired). Note AP annunciator ON.

NOTE

IF IT IS DESIRED TO TRACK THE ILS COURSE OUTBOUND AS PART OF THE MISSED APPROACH PROCEDURE, USE THE NAV MODE TO PREVENT INADVERTENT GS COUPLING.

11. Before Landing.

A/P DISC/TRIM INTER switch - PRESS to disengage AP.

C. FLIGHT DIRECTOR OPERATION (KFC 150 Systems Only).

NOTE

THE FLIGHT DIRECTOR MODES OF OPERATION ARE THE SAME AS THOSE USED FOR AUTOPILOT OPERATIONS EXCEPT THE AUTOPILOT IS NOT ENGAGED AND THE PILOT MUST MANEUVER THE AIRCRAFT TO SATISFY THE FLIGHT DIRECTOR COMMANDS.

SECTION V thru X

No Change.

MOONEY AIRCRAFT CORPORATION
P.O. BOX 72
KERRVILLE, TEXAS 78029-0072

FAA APPROVED

AIRPLANE FLIGHT MANUAL SUPPLEMENT

FOR

Mooney Aircraft Models

M20J, M20K, M20L, M20M, M20R

WITH

AA80 "InterVOX" Intercom System

REG. NO. ~~C-BVZY~~ 0Y-ELW



SERIAL NO. 29-0045

This Supplement must be attached to the applicable FAA Approved Pilot's Operating Handbook and Airplane Flight Manual (POH/AFM) when the AA80 InterVOX Intercom System, is installed in accordance with Mooney Drawing number 810417 (M20J, M20K), 810202 (M20L, M20M, M20R). The information contained herein supplements or supersedes the basic manual only in those areas listed. For limitations, procedures and performance information not contained in this supplement, consult the basic Airplane Flight Manual.

FAA APPROVED: Henry A. Armstrong

Henry A. Armstrong, Manager
Aircraft Certification Service
FEDERAL AVIATION ADMINISTRATION
Fort Worth, Texas.
76193-0150

Issue Date: 1 - 8 - 90
REV A. 7 - 94

P. O. BOX 72

Kerrville, Texas 78029-0072

LOG OF REVISIONS

The revised portions of affected pages are indicated by vertical black lines in the margin.

SECTION I - GENERAL

The AA80 intercom system provides one central control for all aircraft audio, allowing existing radio and entertainment audio to be mixed with live or voice activated intercom audio. Boom microphone control is also provided for two places (pilot & co-pilot), with pilot's control having priority. Muting of the entertainment audio is provided during ICS or TX operation. An emergency/isolation mode is also provided for the pilot.

Control over radio receive level (internal), transmit sidetone level (internal), music level (internal), intercom level (front panel), and VOX threshold (front panel) is provided. The vox threshold or squelch also allow for a "live" mode, by defeating the squelch, and allowing continuous ICS operation.

Operation of the ICS is transparent, allowing transmit during any ICS mode simply by use of the TX PTT switch.

SECTION II - LIMITATIONS

The AA80 intercom system imposes no limitations on the original airframe or other systems.

SECTION III - EMERGENCY PROCEDURES

The AA80 intercom system does not affect the emergency procedures of the aircraft.

Refer to the following for emergency procedures for the AA80 intercom system.

EMERGENCY OPERATION

If power is lost to the AA80 for any reason, it will drop into the power-fail mode and the pilot will be connected directly to the radios for emergency operation. The external PTT switch will still function. This mode is similar to the "PILOT ISOLATE" mode, except that all co-pilot & passenger functions are lost since they depend on external power. A power failure has occurred when the panel indicator fails to light under any condition.

If a catastrophic relay failure of the AA80 should occur or the rear connector becomes loose or disengaged, the designated emergency hand microphone and headset jacks will allow operation to continue, as they have no connection directly through the AA80.

The "PILOT ISOLATION" mode requires no power and will operate even if other circuitry should fail in the AA80.

NOTE

During this mode the co-pilot's microphone IS NOT locked out and he could transmit if necessary; however he will NOT BE ABLE TO RECEIVE the incoming audio.

All aspects of emergency operation should be confirmed to be working by the pilot before accepting the aircraft into service. This can be accomplished by pulling the intercom circuit breaker during the pre-takeoff ground check to turn all power OFF from the AA80 and checking operation per procedures above.

SECTION IV - NORMAL PROCEDURES**SELECTION OF TRANSMIT FUNCTIONS**

Keying the external TX PTT switch activates the AA80 for transmit with the pilot's switch having priority in normal or "INTERVOX" mode. Proper TX operation is annunciated by a green light on the front of the AA80.

Sidetone is normally heard from the radio(s) connected to the AA80, but if not available, an internal potentiometer will adjust the level of artificial sidetone generated within the AA80 system for the pilot's convenience.

NOTE

This artificial sidetone is only available through the amplifier in the AA80 and will be lost to the pilot in the "PILOT ISOLATION" mode, but will be heard by the passenger(s).

SELECTION OF RECEIVE FUNCTIONS

Receive audio is always enabled through the AA80 and has a separate internal adjustment to allow balancing of this level to suit the pilot's preference and equalize iso/normal operation.

An additional input is provided for entertainment audio (tapes, etc.) with a separate level adjustment. This line is muted during transmit functions and when the intercom is active.

If the "ISO" function is selected, the pilot will be connected directly to the radios, while the co-pilot and rear seat passenger(s) remain on the ICS bus with the entertainment audio. In the "INTERVOX" mode all stations hear the same audio.

ICS FUNCTION

Intercom audio may be generated in two modes between users, "live" (on constantly) or "VOX" (voice activated). This is selected, along with the squelch threshold of the VOX circuit, by the "VOX SQUELCH" control on the front of the AA80. When the VOX trigger is activated, the front panel indicator will light up amber, indicating that the ICS system is ON.

Intercom level or volume is set by the "ICS VOLUME" control on the front of the AA80. It does not affect the level of other audio within the system.

ICS functions are available to all users when the system switch is in the "INTERVOX" mode. When switch is in the "PILOT ISOLATION" mode, only the co-pilot and the passenger(s) have ICS capability.

SECTION V thru X

No change to these Sections when the AA80 intercom system is installed except that the weight and balance information will require updating.

MOONEY AIRCRAFT CORPORATION
P.O. BOX 72
KERRVILLE, TEXAS 78029-0072

FAA APPROVED

AIRPLANE FLIGHT MANUAL SUPPLEMENT

FOR

Mooney Aircraft Model

M20M, M20R

WITH

PROPELLER DE-ICE SYSTEM

REG. NO. ~~G-BVZY~~ OY-EZU
SERIAL NO. 29-0045



This Supplement must be attached to the applicable FAA Approved Pilot's Operating Handbook and Airplane Flight Manual (POH/AFM) when the Propeller De-Ice System is installed in accordance with Mooney Drawing 690003. The information contained herein supplements or supersedes the basic manual only in those areas listed. For limitations, procedures and performance information not contained in this supplement, consult the basic Airplane Flight Manual.

FAA APPROVED: Henry A. Armstrong

Henry A. Armstrong, Manager
Aircraft Certification Service
FEDERAL AVIATION ADMINISTRATION
Fort Worth, Texas.
76193-0150

Issue Date: 6 - 29 - 89
REV. A: 6 - 5 - 90
REV. B: 12 - 93
REV. C: 8 - 94

MOONEY
M20M, M20R

P. O. BOX 72

LOG OF REVISIONS

[illegible]

FAA APPROVED

DATE: 6 - 29 -89
PAGE 2 of 3

SECTION I - GENERAL

The propeller de-ice system is intended for use if unexpected icing conditions are encountered. The system is operated by a rocker switch/circuit breaker located in the pilot's panel.

When the switch is placed in the "ON" position, current flows to a timing device which supplies power to the heating elements in the propeller boots. Each propeller blade boot contains heating elements which are cycled ON and OFF every 90 seconds by the timer. An annunciator light is illuminated whenever the de-ice rocker switch is turned on and will cycle ON & OFF with timer, indicating when current is being applied to heating elements.

SECTION II - LIMITATIONS

There is no change to the airplane limitations when the propeller de-ice system is installed.

Flight into known icing conditions is prohibited.

SECTION III - EMERGENCY PROCEDURES

No change

SECTION IV - NORMAL PROCEDURES

If unexpected icing conditions are encountered, the following procedure is recommended:

1. "PROP DE-ICE" switch - ON.
2. Verify "PROP DE-ICE" light (BLUE) is illuminated on the annunciator panel.

NOTE

The airplane ammeter should fluctuate slightly as the timer cycles ON and OFF every 90 seconds.

SECTION V - PERFORMANCE

Sea level rate of climb will be reduced approximately 50 FPM, with no reduction in cruise true airspeed.

SECTION VI THROUGH X

No Change

AIRCRAFT MAKE: Mooney Airplane Corp
AIRCRAFT MODEL: M20 Series
(DAO DOH Rev: 00)

GARMIN GTX 33 Mode S Transponder
DOCUMENT NO. DAO-DD-0475-AFMS-00 REV. 02

**EASA APPROVED FLIGHT MANUAL SUPPLEMENT
FOR AIRCRAFT EQUIPED WITH
GARMIN GTX 33 Mode S Transponder**

AIRCRAFT MAKE: Mooney Aircraft
AIRCRAFT MODEL: M20R
S/N: 29-0045

This document must be carried in the aircraft at all times. It provides limitations and other information for operation of aircraft equipped with the GARMIN GTX 33 Mode S Transponder, installed in accordance with DAO Aviation Minor Change DAO-DO-0475 rev.02

This document serves as the EASA Approved Supplemental Flight Manual for the Garmin GTX 33 Mode S transponder.

The Information contained herein supplements or supersedes the basic Flight Manual only in those areas listed herein. For limitations, procedures, and performance information not contained in this document, consult the basic Flight Manual.

ISSUED DATE: 10/4-12

PAGE 1 OF 5

AIRCRAFT MAKE: Mooney Airplane Com
AIRCRAFT MODEL: M20 Series
(DAO DOH Rev: 00)

GARMIN GTX 33 Mode S Transponder
DOCUMENT NO. DAO-DD-0475-AFMS-00 REV. 02

RECORD OF REVISIONS

This "Record of Revisions" identifies all revisions to this document. When changes to this document are needed, revisions will be issued by the Applicant for this AFMS and if necessary approved by the EASA.

Applicant:

EASA DOA: EASA.21J.275

Name: DAO Aviation A/S
Address: Hangarvej H 1
4000 Roskilde

This "Record of Revisions" shall remain in this document at all times. Upon receipt of revisions, insert page(s) into this document and enter the revision number, revision date, insertion date and signature of the person incorporating the revision into the document in the appropriate spaces below.

Revision Number	Pages affected	Revision date	EASA Approved by
02	01-05		

ISSUED DATE:

10/4-12

PAGE 2 OF 5

AIRCRAFT MAKE: Mooney Airplane Corp
AIRCRAFT MODEL: M20 Series
(DAO DOH Rev: 00)

GARMIN GTX 33 Mode S Transponder
DOCUMENT NO. DAO-DD-0475-AFMS-00 REV. 02

Table of Contents

<u>SECTION</u>	<u>PAGE</u>
SECTION I: GENERAL	3
SECTION II: LIMITATIONS	3
SECTION III: EMERGENCY PROCEDURES	4
SECTION IV: NORMAL PROCEDURES	4
SECTION V: PERFORMANCE	5
SECTION VI: WEIGHT AND BALANCE	5
SECTION VII: AIRPLANE & SYSTEM DESCRIPTIONS	5

SECTION I: GENERAL

1. The aircraft is equipped with single Garmin GTX 33 ATC Mode A/C/S transponder with IDENT capability. Control of the transponder is done via the installed GTN series navigator system.
2. The installed Mode S system satisfies the data requirements of ICAO Doc 7030/4, Regional Supplementary Procedures for Secondary Surveillance Radar (SSR) Mode S Elementary Surveillance in designated European airspace. The capability to transmit data parameters complies with JAA TGL 13 rev.1.
- ~~3. This transponder installation does not transmit any Enhanced (EHS) surveillance parameters.~~

SECTION II: LIMITATIONS

1. Software version 6.0 or later must be installed in the GTX33 to avoid transmission of EHS parameters.

ISSUED DATE: 10/4-12

PAGE 3 OF 5

AIRCRAFT MAKE: Mooney Airplane Corp
AIRCRAFT MODEL: M20 Series
(DAO DOH Rev: 00)

GARMIN GTX 33 Mode S Transponder
DOCUMENT NO. DAO-DD-0475-AFMS-00 REV. 02

SECTION III: EMERGENCY PROCEDURES

ABNORMAL PROCEDURES

No change

SECTION IV: NORMAL PROCEDURES

I. DETAILED OPERATING PROCEDURES

• Note •

Expected coverage from the GTX 33 is limited to "line of sight." Low altitude or aircraft antenna shielding by the aircraft itself may result in reduced range. Range can be improved by climbing to a higher altitude.

The GTX 33 will power up together with the GTN series navigator system. The GTX 33 air/ground configuration is controlled from the GTN. The air/ground threshold is the groundspeed at which the GTN transitions from a ground state to an airborne state, and vice versa, it is set to 30 knots. The GTX 33 will automatically switch to Ground

Manual operation:

After Engine Start

1. Radio Master SwitchON

The transponder will turn on together with the GTN series navigator system in the same mode of operation selected at the last power down and will display the last entered identification code.

Before Takeoff

1. Touch Altitude reporting key (GTN series touch screen).....ALT displays in the squawk code field.

The transponder will be on and respond to Air Traffic Control (ATC) Mode C (altitude and identification) interrogations.

• Note •

Touch On to turn the transponder On for Mode A operation (On displays in the squawk code field).
The transponder will transmit the squawk code when interrogated.
Touch VFR to set the squawk code to 7000.

ISSUED DATE: 10/4-12

PAGE 4 OF 5

AIRCRAFT MAKE: Mooney Airplane Com)
AIRCRAFT MODEL: M20 Series
(DAO DOH Rev: 00)

GARMIN GTX 33 Mode S Transponder
DOCUMENT NO. DAO-DD-0475-AFMS-00 REV. 02

After Landing

1. Touch Ground reporting key (GTN series touch screen).....GND displays in the squawk code field.

• Note •

Touch Ground to place transponder in Ground mode.
Mode S interrogations will be allowed. (GDN displays in the squawk code field).

SECTION V: PERFORMANCE

No change.

SECTION VI: WEIGHT AND BALANCE

See current weight and balance data.

SECTION VII: AIRPLANE & SYSTEM DESCRIPTIONS

See GTX33 Pilot's Guide for a complete description of the GTX33 system.

ISSUED DATE: 10/4-12

PAGE 5 OF 5

TABLE OF CONTENTS

TITLE	PAGE
INTRODUCTION	.10-2
GENERAL	.10-3
GENERAL SOURCES OF INFORMATION	.10-3
RULES AND REGULATIONS	.10-4
FAR, PART 39, AIRWORTHINESS DIRECTIVES	.10-4
AIRMAN INFORMATION, ADVISORIES, AND NOTICES, FAA AIRMAN'S INFORMATION MANUAL	.10-4
ADVISORY INFORMATION	.10-4
GENERAL INFORMATION ON SPECIFIC TOPICS	.10-5
FLIGHT PLANNING	.10-5
INSPECTIONS-MAINTENANCE	.10-5
SPECIAL CONDITIONS CAUTIONARY NOTICE	.10-5
WALK AROUND INSPECTIONS	10-6
COCKPIT CHECKS	.10-6
FLIGHT OPERATIONS	.10-6
GENERAL	.10-6
TURBULENT WEATHER	.10-6
FLIGHT IN TURBULENT AIR	.10-6
MOUNTAIN FLYING	.10-7
VFR-LOW CEILINGS	.10-7
VFR AT NIGHT	.10-7
VERTIGO-DISORIENTATION	.10-7
STALLS, SPINS AND SLOW FLIGHT	.10-8
STANDARD PROCEDURE - SPIN RECOVERY	.10-8
VORTICES-WAKE TURBULENCE	.10-8
TAKE-OFF AND LANDING CONDITIONS	.10-9
MEDICAL FACTS FOR PILOTS	.10-9
GENERAL	.10-9
FATIGUE	.10-9
HYPOXIA	.10-9
HYPERVENTILATION	10-10
ALCOHOL	10-10
DRUGS	10-10
SCUBA DIVING	10-10
ADDITIONAL INFORMATION	10-11
MANUFACTURER'S INFORMATION	10-11

INTRODUCTION

The best of engineering know-how and manufacturing craftsmanship have gone into the design and building of your Mooney aircraft. Like any high performance airplane, it operates most efficiently and safely in the hands of a skilled pilot.

We urge you to be thoroughly familiar with the contents of your operating manuals, placards, and check list to insure maximum utilization of your airplane. When the airplane has changed ownership, some of these may have been misplaced. If any are missing, replacements should be obtained from any Mooney Service Center as soon as possible.

For your added protection and safety, we have added this special section to the Pilot's Operating Handbook to refresh your knowledge of a number of safety subjects. You should review these subjects periodically.

Topics in this section are mostly excerpts from FAA Documents and other articles pertaining to the subject of safe flying. They are not limited to any particular make or model airplane and do not replace instructions for particular types of airplanes.

Your Mooney aircraft was designed and built to provide you with many years of safe and efficient transportation. By maintaining it properly and flying it prudently, you should realize its full potential.

MOONEY AIRCRAFT CORPORATION

GENERAL

Flying is one of the safest modes of travel. Remarkable safety records are being established each year. As a pilot you are responsible to yourself, your relatives, to those who travel with you, to other pilots and to ground personnel to fly wisely and safely.

The following materials in this Safety section covers several subjects in limited detail. Here are some condensed DO's and DON'Ts.

----- DO'S -----

1. Be thoroughly familiar with your airplane and be current in it, or get a check ride.
2. Pre-plan all aspects of your flight-including weather.
----- FLY YOUR PLAN -----
3. Use services available-FSS, Weather Bureau, etc.
4. Pre-flight you airplane thoroughly.
5. Use your check lists.
6. Have more than enough fuel for takeoff, the planned trip, and adequate reserve.
7. Be sure your weight loading and C.G. are within limits.
8. Be sure articles and baggage are secured.
9. Check freedom of all controls.
10. Maintain appropriate airspeed in takeoff, climb, descent and landing.
11. Avoid other aircraft wake turbulence.
12. Switch fuel tanks before engine starvation occurs.
13. Practice engine out, emergency landing gear extension and other emergency procedures at safe altitude; preferably with a check pilot.
14. Use caution in mountainous terrain.
15. Keep your airplane in good mechanical condition.
16. Stay informed and alert, fly in a sensible manner.

----- DON'TS -----

1. Don't take off with frost, ice or snow on the aircraft surfaces.
2. Don't take off with less than minimum recommended fuel, plus reserves.
3. Don't fly in a reckless, show off, careless manner.
4. Don't fly in thunderstorms or severe weather.
5. Don't fly in possible icing conditions. If you encounter icing conditions, alter altitude or course to minimize exposure.
6. Don't apply controls abruptly or with high forces that could exceed design loads of the airplane.
7. Don't fly when physically or mentally exhausted.
8. **DON'T TRUST TO LUCK.**

GENERAL SOURCES OF INFORMATION

There is a wealth of information available to the pilot created for the sole purpose of making your flying easier, faster, and safer. Take advantage of this knowledge and be prepared for an emergency in the remote event that one should occur. You as a pilot also have certain responsibilities under government regulations. These are designed for your own protection. Compliance is not only beneficial but mandatory.

RULES AND REGULATIONS

Federal Aviation regulations, Part 91, General Operating and Flight Rules, is a document of law governing operation of aircraft and the owner's and pilot's responsibilities.

This document covers such subjects as:

- Responsibilities and authority of the pilot in command
- Certificates required
- Liquor and drugs
- Flight plans
- Pre-flight action
- Fuel requirements
- Flight rules
- Maintenance, preventative maintenance, alterations, inspections and maintenance records

These are only some of the topics covered. It is the owner's and pilot's responsibility to be thoroughly familiar with all items in FAR Part 91 and to follow them.

FEDERAL AVIATION REGULATIONS, PART 39 -AIRWORTHINESS DIRECTIVES

This document specifies that no person may operate a product to which an airworthiness directive issued by the FAA applies, except in accordance with the requirements of that airworthiness directive.

AIRMAN INFORMATION, ADVISORIES, AND NOTICES, FAA AIRMAN'S INFORMATION MANUAL

This document contains a wealth of pilot information for nearly all realms of flight, navigation, ground procedures and medical information. Among the subjects are:

- Controlled Air Space
- Services Available to Pilots
- Radio Phraseology and Technique
- Airport Operations
- Clearances and Separations
- Pre-flight
- Departures - IFR
- Enroute - IFR
- Arrival - IFR
- Emergency Procedures
- Weather
- Wake Turbulence
- Medical Facts for Pilots
- Bird Hazards
- Good Operating Practices
- Airport Location Directory

We urge all pilots to be thoroughly familiar with and use the information in this manual.

ADVISORY INFORMATION

Airmen can subscribe to services to obtain FAA NOTAMS and Airman Advisories, and these are also available at FAA Flight Service Stations. NOTAMS are documents that have information of a time-critical nature that would affect a pilot's decision to make a flight; for example, an airport closed, terminal radar out of service, enroute navigational aids out of service, etc.

GENERAL INFORMATION ON SPECIFIC TOPICS

FLIGHT PLANNING

FAR Part 91 requires that each pilot in command, before beginning a flight, familiarize himself with all available information concerning that flight.

All pilots are urged to obtain a complete preflight briefing. This would consist of weather; local, enroute and destination, plus alternates, enroute navaid information. Also airport runways active, length of runways, take off and landing distances for the airplane for conditions expected should be known.

The prudent pilot will review his planned enroute track and stations and make a list for quick reference. It is strongly recommended a flight plan be filed with Flight Service Stations even though the flight may be VFR. Also, advise Flight Service Stations of changes or delays of one hour or more and remember to close the flight plan at destination.

The pilot must be completely familiar with the performance of the airplane and performance data in the airplane manuals and placards. The resultant effect of temperature and pressure altitude must be taken into account in determining performance if not accounted for on the charts. Applicable FAA manuals must be aboard the airplane at all times including the weight and balance forms and equipment lists.

The airplane must be loaded so as not to exceed the weight and the weight and balance loading center of gravity (c.g.) limitations. Also, that at least minimum fuel for takeoff is aboard and sufficient for the trip, plus reserves. Oil in the engines should be checked and filled as required.

INSPECTIONS - MAINTENANCE

In addition to maintenance inspections and preflight information required by FAR Part 91, a complete pre-flight inspection is imperative. It is the responsibility of the owner and operator to assure that the airplane is maintained in an airworthy condition and proper maintenance records are kept.

While the following items cannot substitute for the pre-flight specified for each type of airplane, they will serve as reminders of general items that should be checked.

SPECIAL CONDITIONS CAUTIONARY NOTICE

Airplanes operated for Air Taxi or other than normal operation and airplanes operated in humid tropics or cold and damp climates, etc., may need more frequent inspections for wear, corrosion and or lack of lubrication. In these areas periodic inspections should be performed until the operator can set his own inspection periods based on experience.

| NOTE |

The required periods do not constitute a guarantee that the item will reach the period without malfunction, as the aforementioned factors cannot be controlled by the manufacturer.

Corrosion, and its effects, must be treated at the earliest possible opportunity. A clean dry surface is virtually immune to corrosion. Make sure that all drain holes remain unobstructed. Protective films and sealants help to keep corrosive agents from contacting metallic surfaces. Corrosion inspections should be made most frequently under high-corrosion-risk operating conditions, such as in regions of heavy airborne salt concentrations (e.g., near the sea) and high-humidity areas (e.g., tropical regions).

WALK AROUND INSPECTIONS

All airplane surfaces free of ice, frost or snow.
Tires properly inflated.
All external locks, covers and tie downs removed.
Fuel sumps drained.
Fuel quantity, adequate for trip, plus reserve, (visually checked) and access doors secured.
Oil quantity checked and access doors secured.
Check general condition of airplane, engine, propeller, exhaust stacks, etc.
All external doors secured.

COCKPIT CHECKS

Flashlight available.
Required documents on board.
Use the check list.
All internal control locks removed (if installed).
Check freedom of controls.
Cabin and baggage door properly closed.
Seat belts and shoulder harnesses fastened.
Passengers briefed.
Engine and propeller operating satisfactorily.
All engine gauges checked for proper readings.
Fuel selector in proper position.
Fuel quantity checked by gauges.
Altimeter setting checked.

FLIGHT OPERATIONS

GENERAL

The pilot should be thoroughly familiar with all information published by the manufacturer concerning the airplane. The pilot is required by FAA to operate in accordance with the FAR's and the FAA Approved Airplane Flight Manual and/or placards installed.

TURBULENT WEATHER

A complete weather briefing prior to beginning a flight is the start of assurance of a safe trip. Updating of weather information enroute is another assurance. However, the wise pilot also knows weather conditions change quickly at times and treats weather forecasting as professional advice rather than as absolute fact. He obtains all the advice he can, but still stays alert through knowledge of weather changes, observations, and conditions.

Plan the flight to avoid areas of severe turbulence and thunderstorms. It is not always possible to detect individual storm areas or find the in between clear areas.

Thunderstorms, squall lines and violent turbulence should be regarded as extremely dangerous and **MUST** be avoided. Hall and tornadic wind velocities can be encountered in thunderstorms that can destroy any airplane, just as tornados destroy nearly everything in their path on the ground.

A roll cloud ahead of a squall line or thunderstorm is visible evidence of violent turbulence, however, the absence of a roll cloud should not be interpreted as denoting the lack of turbulence.

FLIGHT IN TURBULENT AIR

Even though flight in severe turbulence is to be avoided, flight in turbulent air may be encountered under certain conditions. Flying through turbulent air presents two basic problems, to both of which the answer is **PROPER AIRSPEED**. On the one hand, if you maintain an excessive airspeed, you run the risk of structural damage or failure; on the other hand, if your airspeed is too low, you may stall. If turbulence encountered in cruise or descent becomes uncomfortable to the pilot or passengers, the best procedure is to reduce speed to the maneuvering speed, which is listed in the Limitations Section of the FAA Approved Airplane Flight Manual and Pilots Operating Handbook. This speed gives the best

assurance of avoiding excessive stress loads, and at the same time providing margin against inadvertent stalls due to gusts.

Beware of overcontrolling in attempting to correct for changes in altitude; applying control pressure abruptly will build up G-forces rapidly and could cause damaging structural stress loads. You should watch particularly your angle of bank, making turns as wide and shallow as possible, and be equally cautious in applying forward or back pressure to keep the nose level. Maintain straight and level attitude in either up or down drafts. Use trim sparingly to avoid being grossly mistrimmed as the vertical air columns change velocity and direction.

MOUNTAIN FLYING

Avoid flight at low altitudes over mountainous terrain, particularly near the lee slopes. -OBSERVE PUBLISHED MINIMUM ENROUTE ALTITUDES (MEA)-. If the wind velocity near the level of the ridge is in excess of 25 knots and approximately perpendicular to the ridge, mountain wave conditions are likely over and near the lee slopes. If the wind velocity at the level of the ridge exceeds 50 knots, a strong mountain wave is probable with strong up and down drafts and severe or extreme turbulence. The worst turbulence will be encountered in and below the rotor zone which is usually 8 to 10 miles downwind from the ridge. This zone is characterized by the presence of "roll clouds" if sufficient moisture is present; alto cumulus standing lenticular clouds are also visible signs that a mountain wave exists, but their presence is likewise dependent on moisture. Mountain wave turbulence can, of course, occur in dry air and the absence of such clouds should not be taken as any assurance that mountain wave turbulence will not be encountered. A mountain wave downdraft may exceed the climb capability of your airplane.

-- AVOID MOUNTAIN WAVE DOWNDRAFTS --

VFR - LOW CEILINGS

If you are not Instrument rated, avoid "VFR On Top" and "Special VFR". Being caught above an undercast when an emergency descent is required (or at destination) is an extremely hazardous position for the VFR pilot.

Accepting a clearance out of certain airport control zones with no minimum ceiling and one-mile visibility as permitted with "Special VFR" is not a recommended practice for VFR pilots.

Avoid areas of low ceilings and restricted visibility unless you are instrument proficient and have an instrument equipped airplane. Then proceed with caution and have planned alternates.

VFR - AT NIGHT

When flying VFR at night, in addition to the altitude appropriate for the direction of flight, pilots should maintain a safe minimum altitude as dictated by terrain, obstacles such as TV towers, or communities in the area flown. This is especially true in mountainous terrain, where there is usually very little ground reference and absolute minimum clearance is 2,000 feet. Don't depend on your being able to see obstacles in time to miss them. Flight on dark nights over sparsely populated country can be almost the same as IFR and should be avoided by untrained pilots.

VERTIGO -DISORIENTATION

Disorientation can occur in a variety of ways. During flight, inner ear balancing mechanisms are subjected to varied forces not normally experienced on the ground. This combined with loss of outside visual reference can cause vertigo. False interpretations (illusions) result and may confuse the pilot's conception of the attitude and position of his airplane.

Under VFR conditions the visual sense, using the horizon as a reference, can override the illusions. Under low visibility conditions (night, fog, clouds, haze, etc.) the illusions predominate. Only through awareness of these illusions, and proficiency in instrument flight procedures, can an airplane be operated safely in a low visibility environment.

Flying in fog, dense haze or dust, cloud banks, or very low visibility, with strobe lights, and particularly rotating beacons turned on frequently causes vertigo. They should be turned off in these conditions, particularly at night.

All pilots should check the weather and use good judgment in planning flights. The VFR pilot should use extra caution in avoiding low visibility conditions.

Motion sickness often precedes or accompanies disorientation and may further jeopardize the flight.

STALLS, SPINS AND SLOW FLIGHT

Stalls, and slow flight should be practiced at safe altitudes to allow for recovery. Any of these maneuvers should be performed at an altitude in excess of 6,000 feet above ground level. Spins may be dangerous and should be avoided. In fact, most airplanes are placarded against intentional spins. Spins are preceded by stalls. A prompt and decisive stall recovery protects against inadvertent spins. All airplanes are required to have flight characteristics that give adequate advance warning of an impending stall or they must be equipped with an artificial stall warning device. Keep the artificial system in good working order. Do not operate the airplane with the device made inoperative by the use of circuit breakers or other means.

Stalls should be practiced at safe altitudes for ample recovery. Should a spin be encountered inadvertently, spin recovery should be initiated immediately.

As stall attitude is approached, be alert. Take prompt corrective action to avoid the stall or if you are practicing stalls, react the moment the stall occurs. The following is suggested:

1. Do not carry passengers. Be certain that the airplane's center of gravity is as far forward as possible. Forward CG aids spin recovery.
2. Be certain that both student pilot and instructor pilot have a full set of operable controls.
3. Conduct such practice at altitudes in excess of 6,000 ft. above ground level.

Remember that an airplane at or near traffic pattern altitude probably will not recover from a spin before impact with the ground. When descending to traffic pattern altitude and during operation in the traffic pattern and approach, maintain a safe margin above stall speed. During takeoff or go-around, be especially careful to avoid departure stalls associated with turns at low speed. Maintain speeds recommended in this handbook (Section II & V).

STANDARD PROCEDURE FOR SPIN RECOVERY

In the event of an inadvertent spin, the following recovery procedure should be used:

Throttle	RETARD to IDLE
Ailerons	NEUTRAL
Rudder	Apply FULL RUDDER opposite the direction of spin.
Control Wheel	FORWARD of neutral in a brisk motion to break stall. Additional FORWARD elevator control may be required if rotation does not stop.
Flaps (If extended)	RETRACT as soon as possible
Rudder	NEUTRALIZE when spin stops.
Control Wheel	Smoothly MOVE AFT to bring the nose up to a level flight attitude after spin has stopped.

VORTICES - WAKE TURBULENCE

Every airplane generates wakes of turbulence while in flight. Part of this is from the propeller or jet engine and part from the wing tip vortices. The larger and heavier the airplane the more pronounced wake turbulence will be. Wing tip vortices from large heavy airplanes are very severe at close range, degenerating with time, wind and space. These are rolling in nature from each wing tip. In test, vortex velocities of 133 knots have been recorded. Exhaust velocities from large airplanes at takeoff have been measured at 25 mph, 2100 feet behind medium, large airplanes.

Encountering the rolling effect of wing tip vortices within two minutes or less after passage of large airplanes is hazardous to light airplanes. This roll effect can exceed the maximum counter roll obtainable in an airplane.

The turbulent areas may remain for as long as three minutes or more, depending on wind conditions, and may extend several miles behind the airplane. Plan to fly slightly above or to the upwind side of the other airplane's flight path.

Because of the wide variety of conditions that can be encountered, there is no set rule to follow to avoid wake turbulence in all situations. However, the Airman's Information Manual goes into considerable detail for a number of wake turbulence avoidance procedures. Use prudent judgment and allow ample clearance time and space following or crossing the wake turbulence of other airplanes in all takeoff, climb out, approach and landing operations. Be observant of wake turbulence from all aircraft, regardless of size.

The Airman's Information Manual contains a section on wake turbulence. FAA Advisory Circular AC 90-230 is also recommended reading.

TAKE - OFF AND LANDING CONDITIONS

When taking off on runways covered with water or freezing slush, the landing gear should remain extended for approximately ten seconds longer than normal, allowing the wheels to spin and dissipate the freezing moisture. The landing gear should then be cycled up, then down, wait approximately five seconds and then retract again. Caution must be exercised to insure that the entire operation is performed below Maximum Landing Gear Operating Airspeed.

Use caution when landing on runways that are covered by water or slush which cause hydroplaning (aquaplaning), a phenomenon that renders braking and steering ineffective because of the lack of sufficient surface friction. Snow and ice covered runways are also hazardous. The pilot should be alert to the possibility of the brakes freezing.

Use caution when taking off or landing in gusty winds. Be aware of special wind conditions caused by buildings or other obstructions located near runway in a crosswind pattern.

MEDICAL FACTS FOR PILOTS

GENERAL

Modern industry's record in providing reliable equipment is very good. When the pilot enters the airplane, he becomes an integral part of the man-machine system. He is just as essential to a successful flight as the control surfaces. To ignore the pilot in pre-flight planning would be as senseless as failing to inspect the integrity of the control surfaces or any other vital part of the machine. The pilot himself has the responsibility for determining his reliability prior to entering the airplane for flight.

While piloting an airplane, an individual should be free of conditions which are harmful to alertness, ability to make correct decisions, and rapid reaction time.

FATIGUE

Fatigue generally slows reaction times and causes foolish errors due to inattention. In addition to the most common cause of fatigue, insufficient rest and loss of sleep, the pressure of business, financial worries and family problems, can be contributing factors. If your fatigue is a factor prior to a given flight, don't fly. To prevent fatigue effects during long flights, keep mentally active by making ground checks and radio-navigation position plots.

HYPOXIA

Hypoxia in simple terms is a lack of sufficient oxygen to keep the brain and other body tissues functioning properly. There is wide individual variation in susceptibility to hypoxia. In addition to progressively insufficient oxygen at higher altitudes, anything interfering with the blood's ability to carry oxygen can contribute to hypoxia (anemias, carbon monoxide, and certain drugs). Also, alcohol and various drugs decrease the brain's tolerance to hypoxia. Your body has no built in alarm system to let you know when you are not getting enough oxygen. It is impossible to predict when or where hypoxia will occur during a flight, or how it will manifest itself. A major early symptom of hypoxia is an increased sense of well-being (referred to as euphoria). This progresses to slow reactions, impaired thinking ability, unusual fatigue, and dull headache feeling.

Symptoms are slow but progressive, insidious in onset, and are most marked at altitudes starting above 10,000 feet. Night vision, however, can be impaired starting at altitudes lower than 10,000 feet. Heavy smokers may experience early symptoms of hypoxia at altitudes lower than non-smokers. Use oxygen on flights above 10,000 feet and at any time when symptoms appear.

HYPERVENTILATION

Hyperventilation or over-breathing, is a disturbance of respiration that may occur in individuals as a result of emotional tension or anxiety. Under conditions of emotional stress, fright, or pain, breathing rate may increase, causing increased lung ventilation, although the carbon dioxide output of the body cells does not increase. As a result, carbon dioxide is "washed out" of the blood. The most common symptoms of hyperventilation are: dizziness; hot and cold sensations; tingling of the hands, legs and feet; tetany; nausea; sleepiness; and finally unconsciousness.

Should symptoms occur that cannot definitely be identified as either hypoxia or hyperventilation try three or four deep breaths of oxygen. The symptoms should improve markedly if the condition was hypoxia (recovery from hypoxia is rapid). If the symptoms persist, discontinue use of oxygen; consciously slow your breathing rate until symptoms clear; then resume normal breathing rate. Normal breathing can be aided by talking aloud.

ALCOHOL

Common sense and scientific evidence dictate that you not fly as a crew member while under the influence of alcohol. Even small amounts of alcohol in the human system can adversely affect judgment and decision making abilities. FAR 91.11 states "(a) No person may act as a crew member-(1) within 8 hours after the consumption of any alcoholic beverage."

Tests indicate that as a general rule, 2 ounces(.06 liters) of alcohol at 15,000 feet produce the same adverse effects as 6 ounces(.18 liters) at sea level. In other words, the higher you get, "the higher you get".

DRUGS

Self-medication or taking medicine in any form when you are flying can be extremely hazardous. Even simple home or over-the-counter remedies drugs such as aspirin, antihistamines, cold tablets, cough mixtures, laxatives, tranquilizers, and appetite suppressors, may seriously impair the judgment and coordination needed while flying. The safest rule is to TAKE NO MEDICINE before or while flying, except on the advice of your Aviation Medical Examiner.

SCUBA DIVING

Flying shortly after any prolonged scuba diving could be dangerous. Under the increased pressure of the water, excess nitrogen is absorbed into your system. If sufficient time has not elapsed prior to takeoff for your system to rid itself of this excess gas, you may experience the bends at altitudes even under 10,000 feet, where most light planes fly.

ADDITIONAL INFORMATION

In addition to the coverage of subjects in this section, the National Transportation Safety Board and the F.A.A. periodically issue general aviation pamphlets concerning aviation safety, and in greater detail. These can be obtained at FAA Offices, Weather Stations, Flight Service Stations, or Airport Facilities. These are very good sources of information and are highly recommended for study. Some of these are titled:

Airman's Information Manual
12 Golden Rules for Pilots
Weather or Not
Disorientation
Plane Sense
Weather Info Guide for Pilots
Wake Turbulence
Don't Trust to Luck, Trust to Safety
Thunderstorm - TRW
IFR-VFR , Either Way **Disorientation Can be Fatal**

MANUFACTURER'S INFORMATION

See following applicable pages of information that may have been inserted.

BLANK